



VAXstation 4000 Model 60
Service Information

EK-V466B-SV.001

Digital Equipment Corporation
Maynard, Massachusetts

First Edition, February 1992

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

The software described in this document is furnished under a license and may be used or copied only in accordance with the terms of such license.

No responsibility is assumed for the use or reliability of software on equipment that is not supplied by Digital Equipment Corporation or its affiliated companies.

Restricted Rights: Use, duplication, or disclosure by the U. S. Government is subject to restrictions as set forth in subparagraph (c) (1) (ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

Copyright © by Digital Equipment Corporation 1992

All Rights Reserved.
Printed in U.S.A.

The following are trademarks of Digital Equipment Corporation:

DEC, DIGITAL, MicroVAX, MicroVMS, ULTRIX, VAX, VMS, and the DIGITAL logo.

This document was prepared using VAX DOCUMENT, Version 2.0.

Contents

Preface

xv

1 VAXstation 4000 Model 60 System Module

| | | |
|-------|--|------|
| 1.1 | System Overview | 1-2 |
| 1.2 | Central Processor Unit | 1-6 |
| 1.2.1 | Addressing | 1-8 |
| 1.2.2 | Processor State | 1-8 |
| 1.2.3 | Internal Processor Registers | 1-8 |
| 1.2.4 | Data Types | 1-13 |
| 1.2.5 | Instruction Set | 1-13 |
| 1.3 | Interrupt Controller | 1-14 |
| 1.3.1 | Interrupt Sources and Ranking | 1-15 |
| 1.3.2 | Interrupt Vector Generation | 1-15 |
| 1.4 | Secondary Cache | 1-17 |
| 1.4.1 | Diagnostic Mode | 1-17 |
| 1.5 | Main Memory | 1-18 |
| 1.5.1 | Main Memory Requests | 1-19 |
| 1.5.2 | DMA Mapping | 1-19 |
| 1.5.3 | Translation | 1-19 |
| 1.6 | ROM Memory | 1-20 |
| 1.6.1 | System ROM | 1-20 |
| 1.6.2 | Network Address ROM | 1-21 |
| 1.7 | Graphics Controller | 1-21 |
| 1.7.1 | Graphics Controller Screen Formats | 1-22 |
| 1.7.2 | Graphics Controller Communication | 1-22 |
| 1.8 | Serial Line Controller | 1-23 |
| 1.8.1 | Serial Line Controller Registers | 1-23 |
| 1.9 | Time-of-Year Clock | 1-24 |
| 1.9.1 | Battery Backup | 1-24 |
| 1.9.2 | TOY Clock Chip Registers | 1-24 |
| 1.10 | Network Controller | 1-26 |

| | | |
|--------|-----------------------------|------|
| 1.10.1 | Packet Format | 1-26 |
| 1.10.2 | Network Addresses | 1-27 |
| 1.11 | SCSI Controller | 1-28 |
| 1.11.1 | SCSI Bus Signals | 1-29 |

2 Model 60 Firmware

| | | |
|--------|---|------|
| 2.1 | Power-Up Initialization Code | 2-2 |
| 2.2 | Console Overview | 2-3 |
| 2.3 | Extended Self-Test Overview | 2-4 |
| 2.4 | Utilities Test Overview | 2-5 |
| 2.5 | System Test Overview | 2-6 |
| 2.6 | System ROM Overview | 2-7 |
| 2.6.1 | System ROM Part Format | 2-7 |
| 2.6.2 | System ROM Set Format | 2-8 |
| 2.7 | Option ROM Overview | 2-9 |
| 2.7.1 | Option ROM Part Format | 2-9 |
| 2.7.2 | Option ROM Set Format | 2-11 |
| 2.8 | Configuration Table Overview | 2-12 |
| 2.8.1 | Main Configuration Table | 2-13 |
| 2.8.2 | Device Configuration Table | 2-14 |
| 2.9 | Driver Descriptor Overview | 2-19 |
| 2.10 | Interfacing to Diagnostic Drivers | 2-20 |
| 2.11 | Console Driver Interface | 2-22 |
| 2.11.1 | Shared Console Interface Area | 2-23 |
| 2.11.2 | Console Port Driver | 2-25 |

3 System Configuration

| | | |
|---------|---------------------------------------|------|
| 3.1 | Model 60 System Box | 3-2 |
| 3.1.1 | Mass Storage Device Areas | 3-2 |
| 3.1.2 | Power Supply | 3-3 |
| 3.1.2.1 | Power Supply Specifications | 3-4 |
| 3.1.3 | System Box Internal Cabling | 3-6 |
| 3.1.4 | System Box Control Panel | 3-8 |
| 3.1.5 | I/O Panel | 3-10 |
| 3.1.6 | System Box Specifications | 3-13 |

4 Using the Console

| | | |
|----------|-----------------------------------|------|
| 4.1 | System Console | 4-1 |
| 4.1.1 | Additional console commands | 4-2 |
| 4.1.1.1 | HELP or ? | 4-2 |
| 4.1.1.2 | LOGIN | 4-2 |
| 4.1.1.3 | REPEAT | 4-2 |
| 4.1.2 | SET and SHOW Commands | 4-3 |
| 4.1.2.1 | SET and SHOW Command Syntax | 4-4 |
| 4.1.2.2 | BFLG | 4-4 |
| 4.1.2.3 | BOOT | 4-4 |
| 4.1.2.4 | CONFIG | 4-5 |
| 4.1.2.5 | DEVICE | 4-6 |
| 4.1.2.6 | DIAGENV | 4-7 |
| 4.1.2.7 | ERROR | 4-8 |
| 4.1.2.8 | ESTAT | 4-8 |
| 4.1.2.9 | ETHER | 4-9 |
| 4.1.2.10 | FBOOT | 4-9 |
| 4.1.2.11 | HALT | 4-9 |
| 4.1.2.12 | KBD | 4-10 |
| 4.1.2.13 | MEM | 4-10 |
| 4.1.2.14 | MOP | 4-11 |
| 4.1.2.15 | PSE and PSWD | 4-11 |
| 4.1.2.16 | SCSI | 4-12 |
| 4.1.2.17 | TRIGGER | 4-12 |
| 4.1.3 | Memory Commands | 4-13 |
| 4.1.3.1 | DEPOSIT Commands | 4-13 |
| 4.1.3.2 | EXAMINE Commands | 4-14 |
| 4.1.4 | Processor Control Commands | 4-15 |
| 4.1.4.1 | BOOT | 4-16 |
| 4.1.4.2 | CONTINUE | 4-17 |
| 4.1.4.3 | INITIALIZE and UNJAM | 4-17 |
| 4.1.4.4 | START | 4-17 |
| 4.2 | Alternate Consoles | 4-18 |
| 4.2.1 | Printer Port Console | 4-18 |
| 4.2.2 | Network Console | 4-18 |

5 Diagnostic Testing

| | | |
|----------|--|------|
| 5.1 | Diagnostic Functions | 5-2 |
| 5.2 | System Power-up Test | 5-2 |
| 5.2.1 | Power-up Sequence | 5-3 |
| 5.3 | Displaying System Configuration | 5-6 |
| 5.3.1 | SHOW DEVICE | 5-6 |
| 5.3.2 | SHOW CONFIG | 5-7 |
| 5.4 | Displaying Additional Error Information | 5-8 |
| 5.5 | Setup Required for Self-Tests | 5-9 |
| 5.5.1 | Selecting a Diagnostic Environment | 5-9 |
| 5.6 | Device Tests | 5-11 |
| 5.7 | Running Self-Tests | 5-12 |
| 5.7.1 | Running a Single Device Self-Test | 5-13 |
| 5.7.2 | Running Multiple Device Self-Tests | 5-13 |
| 5.7.3 | Running a self-test Continuously | 5-14 |
| 5.8 | Descriptions of Self-Tests | 5-15 |
| 5.8.1 | TOY/NVR Self-Test (1) | 5-15 |
| 5.8.2 | LCG Self-Test (2) | 5-15 |
| 5.8.3 | DZ Self-Test (3) | 5-16 |
| 5.8.4 | CACHE Self-Test (4) | 5-17 |
| 5.8.5 | Memory Self-Test (5) | 5-18 |
| 5.8.6 | Floating Point Unit Self-Test (6) | 5-18 |
| 5.8.7 | Interval Timer Self-Test (7) | 5-19 |
| 5.8.8 | System Self-Test (8) | 5-19 |
| 5.8.9 | Network Interconnect Self-Test (9) | 5-19 |
| 5.8.10 | SCSI Self-Test (10) | 5-20 |
| 5.8.11 | Audio Self-Test (11) | 5-21 |
| 5.8.12 | Synchronous Communication Self-Test (12) | 5-22 |
| 5.9 | System Test | 5-22 |
| 5.10 | System Test Monitor | 5-23 |
| 5.10.1 | Display from the System Test | 5-24 |
| 5.10.2 | System Test Summary Screens | 5-26 |
| 5.10.2.1 | DZ System Test | 5-27 |
| 5.10.2.2 | Network Interconnect System Test | 5-28 |
| 5.10.2.3 | SCSI System Test | 5-28 |
| 5.10.2.4 | DSW21 Communication System Test | 5-30 |

| | | |
|--------|-------------------------------|------|
| 5.11 | Utilities | 5-31 |
| 5.11.1 | LCG Utilities | 5-33 |
| 5.11.2 | LCG Utility Menu | 5-34 |
| 5.11.3 | NI Utilities | 5-34 |
| 5.11.4 | NI Listener | 5-34 |
| 5.11.5 | EMB | 5-35 |
| 5.11.6 | SCSI Utilities | 5-36 |
| 5.11.7 | Invoking SCSI Utilities | 5-36 |
| 5.11.8 | SCSI Utility Menu | 5-37 |
| 5.11.9 | SCSI Utility Notes | 5-39 |

6 FRUs Removal and Replacement

| | | |
|---------|---|------|
| 6.1 | Precautions | 6-2 |
| 6.1.1 | System FRU Removal | 6-2 |
| 6.2 | System Preparation | 6-4 |
| 6.3 | Mass Storage Drive Removal | 6-6 |
| 6.3.1 | Hard Disk Drive Removal | 6-6 |
| 6.3.1.1 | Hard Disk Drive Replacement | 6-7 |
| 6.3.2 | RRD42 CDROM Drive Removal | 6-10 |
| 6.3.2.1 | RRD42 CDROM Drive Replacement | 6-10 |
| 6.3.3 | RX26 (Diskette) Drive Removal | 6-12 |
| 6.3.3.1 | RX26 (Diskette) Drive Replacement | 6-12 |
| 6.3.4 | TLZ04 Cassette Tape Drive Removal | 6-14 |
| 6.3.4.1 | TLZ04 Cassette Tape Drive Replacement | 6-14 |
| 6.3.5 | TZK10 QIC Tape Drive Removal | 6-16 |
| 6.3.5.1 | TZK10 (Tape) Drive Replacement | 6-16 |
| 6.4 | Power Supply Removal | 6-18 |
| 6.4.1 | Power Supply Replacement | 6-18 |
| 6.5 | Module Removal | 6-19 |
| 6.5.1 | Light and Switches Module Removal | 6-19 |
| 6.5.1.1 | Light and Switches Module Replacement | 6-19 |
| 6.5.2 | Memory Module Identification | 6-20 |
| 6.5.3 | MS44 Memory Module Removal | 6-21 |
| 6.5.3.1 | MS44 Memory Module Replacement | 6-22 |
| 6.5.4 | Graphics Module Removal | 6-22 |
| 6.5.5 | Replacing the LCG Graphics Module | 6-23 |

| | | |
|---------|---|------|
| 6.5.6 | System Module (CPU) Removal | 6-25 |
| 6.5.6.1 | System Module (CPU) Replacement | 6-25 |
| 6.6 | DSW21 Communications Device Removal | 6-26 |
| 6.6.1 | DSW21 Communications Device Replacement | 6-26 |
| 6.7 | Bezel Removal | 6-26 |
| 6.7.1 | Bezel Replacement | 6-27 |
| 6.8 | Clearing System Password | 6-27 |
| 6.9 | Testing the VAXstation 4000 Model 60 System | 6-27 |
| 6.9.1 | Restore the System | 6-27 |
| 6.9.2 | Testing the System | 6-28 |

A Interpreting Error Codes

| | | |
|----------|---|------|
| A.1 | Error Messages | A-2 |
| A.1.1 | Extended Error Message | A-3 |
| A.1.2 | FRU Codes | A-4 |
| A.2 | Self-Test Error Codes | A-5 |
| A.2.1 | TOY/NVR Self-Test Error Messages | A-6 |
| A.2.2 | DZ Self-Test Error Codes | A-7 |
| A.2.3 | Memory Test Error Codes | A-11 |
| A.2.4 | Interval Timer Test Error Codes | A-12 |
| A.2.5 | System Device Self-Test Error Codes | A-13 |
| A.2.6 | SCSI Self-Test Error Codes | A-14 |
| A.2.7 | SCSI Utilities Messages | A-26 |
| A.2.8 | SCSI System Test Error Codes | A-28 |
| A.2.9 | SCSI System Test Summary Screen | A-30 |
| A.2.10 | Audio Test Error Codes | A-30 |
| A.2.11 | DSW21 Communications Device Test Error Codes | A-33 |
| A.2.12 | DSW21 Communications Device Test Numbers | A-40 |
| A.2.13 | DSW21 Communications Utilities Error Codes | A-50 |
| A.2.14 | DSW21 Communications Device System Test Error Codes | A-50 |
| A.2.15 | Floating Point Unit (FPU) Test Error Codes | A-51 |
| A.2.16 | CACHE Test Error Codes | A-54 |
| A.2.17 | LCG Self-Test Error Codes | A-55 |
| A.2.18 | LCG Utilities | A-63 |
| A.2.18.1 | LCG Utility Commands | A-63 |
| A.2.19 | LCG System Test Overview | A-64 |

| | | |
|--------|--|------|
| A.2.20 | LCG System Test Error Codes | A-64 |
| A.2.21 | LCG System Test Summary Screen | A-65 |
| A.2.22 | NI Self-Test Error Codes | A-66 |
| A.2.23 | NI System Test Error Codes | A-74 |

B Reading the Diagnostic LED Codes

| | | |
|--------|---|------|
| B.1 | Diagnostic LED Codes | B-2 |
| B.1.1 | LED Error Codes | B-2 |
| B.1.2 | Power-up/Initialization LED Codes | B-3 |
| B.1.3 | TOY/NVR LED Codes | B-4 |
| B.1.4 | LCG LED Codes | B-5 |
| B.1.5 | DZ LED Codes | B-6 |
| B.1.6 | CACHE LED Codes | B-7 |
| B.1.7 | Memory LED Codes | B-8 |
| B.1.8 | System Device LED Codes | B-9 |
| B.1.9 | NI Device LED Codes | B-10 |
| B.1.10 | SCSI Device FRU LED Codes | B-11 |
| B.1.11 | Audio Device LED Codes | B-12 |
| B.1.12 | DSW21 Communications Device LED Codes | B-13 |

C Troubleshooting

| | | |
|-----|------------------------------------|-----|
| C.1 | Troubleshooting Overview | C-1 |
|-----|------------------------------------|-----|

D FRU Part Numbers

| | | |
|-----|------------------------------------|-----|
| D.1 | Precautions | D-2 |
| D.2 | Model 60 System Box FRUs | D-2 |

Index

Examples

| | | |
|------|--------------------------------------|------|
| 4-1 | SHOW CONFIG Command | 4-5 |
| 4-2 | SHOW DEVICE Command | 4-6 |
| 4-3 | Network Console Session | 4-20 |
| 5-1 | Displaying System Configuration | 5-6 |
| 5-2 | Configuration Table | 5-7 |
| 5-3 | SHOW ERROR | 5-8 |
| 5-4 | SET DIAGENV | 5-10 |
| 5-5 | TEST - Single | 5-13 |
| 5-6 | Running a Single Device Test | 5-13 |
| 5-7 | Running a Self-Test Continuously | 5-14 |
| 5-8 | System Test Commands | 5-24 |
| 5-9 | System Test Error - Network | 5-28 |
| 5-10 | System Test Summary Screen - Display | 5-29 |
| 5-11 | Communication System Test - Display | 5-30 |
| 5-12 | LCG Utilities Menu | 5-34 |
| 5-13 | Enabling Listener | 5-35 |
| 5-14 | Disabling Listener | 5-35 |
| 5-15 | Enabling MOP | 5-35 |
| 5-16 | Disable MOP | 5-35 |
| 5-17 | SCSI Utilities Sample Session | 5-37 |

Figures

| | | |
|-----|---|------|
| 1-1 | KA46 System Module Layout | 1-3 |
| 1-2 | KA46 System Module Internal Connectors | 1-5 |
| 1-3 | KA46 System Module Block Diagram (Model 60) | 1-7 |
| 1-4 | Tag Store Diagnostic Access | 1-17 |
| 1-5 | General Format of a Command Packet | 1-22 |
| 1-6 | Ethernet Packet Format | 1-26 |
| 2-1 | System ROM Format | 2-7 |
| 2-2 | Option ROM Byte Data | 2-10 |
| 2-3 | Option ROM Set Data | 2-11 |
| 2-4 | Model 60 Configuration Tables | 2-12 |
| 2-5 | Main Configuration Tables | 2-13 |
| 2-6 | Device Configuration Table | 2-15 |

| | | |
|------|--|------|
| 2-7 | Driver Descriptor Data Structure | 2-19 |
| 2-8 | Diagnostic Driver Console Support | 2-20 |
| 2-9 | Model 60 Console Structure | 2-22 |
| 2-10 | SCIA Data Structure | 2-24 |
| 2-11 | Console Port Driver Function Block | 2-25 |
| 3-1 | Model 60 System Box | 3-2 |
| 3-2 | Internal Cabling | 3-7 |
| 3-3 | System Box Control Panel | 3-8 |
| 3-4 | Model 60 I/O Panel | 3-11 |
| 5-1 | Successful Power-Up Self-Test | 5-4 |
| 5-2 | Unsuccessful Power-Up | 5-5 |
| 5-3 | Successful and Unsuccessful Self-Test | 5-12 |
| 5-4 | Successful System Test | 5-24 |
| 5-5 | Unsuccessful System Test | 5-25 |
| 5-6 | Summary Screen | 5-26 |
| 5-7 | Utilities List | 5-32 |
| 5-8 | SCSI Utilities Display | 5-38 |
| 6-1 | System FRU Locations | 6-3 |
| 6-2 | Halt Button | 6-4 |
| 6-3 | RZ23L Disk Drive SCSI ID Jumper Location | 6-7 |
| 6-4 | RZ24 Disk Drive SCSI ID Jumper Location | 6-8 |
| 6-5 | RRD42 (CDROM) Jumper Settings | 6-11 |
| 6-6 | Setting the RX26 (Diskette) Drive ID Number | 6-13 |
| 6-7 | RX26 (Diskette) Drive SCSI ID Switch Location | 6-14 |
| 6-8 | TLZ04 Tape Drive SCSI ID Jumper Location | 6-15 |
| 6-9 | TZK10 (QIC) Tape Drive SCSI ID Jumper Location | 6-17 |
| 6-10 | Memory Module Identification | 6-20 |
| 6-11 | Removing the LCG Graphics Module | 6-23 |
| 6-12 | Replacing the LCG Graphics Module | 6-24 |

Tables

| | | |
|-----|---|------|
| 1-1 | KA46 Internal Processor Registers | 1-8 |
| 1-2 | Interrupt Signal Sources and Interrupt Vectors - IPL15h ... | 1-16 |
| 1-3 | Graphics Controller Screen Formats | 1-22 |
| 1-4 | Serial Line Usage | 1-23 |
| 1-5 | Serial Line Controller Register Addresses | 1-24 |
| 1-6 | TOY Chip Register Addresses | 1-25 |
| 2-1 | Directory Type Definitions | 2-17 |
| 2-2 | Data Path Size Definitions | 2-17 |
| 2-3 | Flag Definitions | 2-18 |
| 3-1 | Internal System Devices and Their Cables | 3-6 |
| 3-2 | External System Devices and Their Cables | 3-12 |
| 3-3 | System Box Operating Conditions | 3-13 |
| 3-4 | System Box Electrical Specifications | 3-13 |
| 4-1 | SET/SHOW Parameters | 4-3 |
| 4-2 | Diagnostic Environments | 4-7 |
| 4-3 | SET DIAGENV Command | 4-7 |
| 4-4 | DEPOSIT Command Qualifiers | 4-13 |
| 4-5 | EXAMINE Command Qualifiers | 4-14 |
| 4-6 | BOOT Command Syntax | 4-16 |
| 5-1 | Diagnostic Functions | 5-2 |
| 5-2 | SET DIAGENV Command | 5-10 |
| 5-3 | Device Test IDs and Mnemonics | 5-11 |
| 5-4 | Running the Self-Test | 5-12 |
| 5-5 | Multiple Test - Syntax Rules | 5-13 |
| 5-6 | Formats for Running Multiple Tests | 5-14 |
| 5-7 | Running the System Test Using the Test Command | 5-23 |
| 6-1 | Hard Disk Drive SCSI Jumper Settings | 6-9 |
| 6-2 | Standard IDs for SCSI Devices | 6-9 |
| A-1 | FRU Codes | A-4 |
| A-2 | TOY/NVR Test Error Messages | A-6 |
| A-3 | DZ Self-Test error codes | A-7 |
| A-4 | DZ suberror codes | A-9 |
| A-5 | Memory Test Error Codes | A-11 |
| A-6 | MEM Memory Module FRU Values | A-12 |
| A-7 | Interval Timer Test Error Codes | A-12 |

| | | |
|------|---|------|
| A-8 | System Device Self-Test Error Codes | A-13 |
| A-9 | SCSI Self-Test Error Codes | A-14 |
| A-10 | SCSI Information Values | A-22 |
| A-11 | SCSI Mode Values | A-26 |
| A-12 | Text Messages for SCSI Utilities | A-26 |
| A-13 | Additional SCSI Information Values for Utilities | A-27 |
| A-14 | SCSI System Test Error Codes | A-28 |
| A-15 | Audio Self-Test Error Codes | A-31 |
| A-16 | DSW21 Device Test Error Codes | A-33 |
| A-17 | DSW21 Communications Self-Test Sequence Numbers | A-40 |
| A-18 | DSW21 Communications Utilities Error Codes | A-50 |
| A-19 | FPU Test Error Codes | A-51 |
| A-20 | FP Exception Vectors | A-53 |
| A-21 | CACHE Test Error Codes | A-54 |
| A-22 | LCG Self-Test Error Codes | A-55 |
| A-23 | Color Compare Failures - One Head | A-61 |
| A-24 | Color Compare Failures - Two Heads | A-61 |
| A-25 | LCG Utilities | A-63 |
| A-26 | LCG Utility Commands | A-63 |
| A-27 | LCG System Test Error Codes | A-64 |
| A-28 | NI Self-Test Error Codes | A-66 |
| A-29 | NI System Test Error Codes | A-74 |
| B-1 | Power-up and Initialization LED Codes (1111 XXXX) | B-3 |
| B-2 | TOY and NVR LED Codes (0001 XXXX) | B-4 |
| B-3 | LCG LED Codes (0010 XXXX) | B-5 |
| B-4 | DZ LED Codes (0011 XXXX) | B-6 |
| B-5 | Cache LED Codes (0100 XXXX) | B-7 |
| B-6 | Memory FRU LED Codes (0101 XXXX) | B-8 |
| B-7 | System Device LED Codes (1000 XXXX) | B-9 |
| B-8 | NI LED Codes (1001 XXXX) | B-10 |
| B-9 | SCSI Device LED Codes (1010 XXXX) | B-11 |
| B-10 | Audio Device LED Codes (1011 XXXX) | B-12 |
| B-11 | DSW21 Communication Device LED Codes (1100 XXXX) | B-13 |
| C-1 | Symptoms, Causes, and Action | C-2 |
| D-1 | Model 60 System Box FRUs | D-2 |
| D-2 | Model 60 System Box Miscellaneous Hardware | D-4 |

| | | |
|-----|---|-----|
| D-3 | System and Expansion Box Cables and Terminators | D-4 |
| D-4 | Internal System Devices and Their Cables | D-5 |
| D-5 | External System Devices and Their Cables | D-5 |
| D-6 | Expansion Box FRUs | D-5 |
| D-7 | Monitor and Graphic Module Cross Reference | D-6 |

Preface

This manual is a support and reference document for Digital Services personnel who perform maintenance work on the VAXstation 4000 Model 60 workstation. It is also intended for Digital customers who have a self-maintenance agreement with Digital.

Manual Organization

This manual is organized in the following way:

- Chapter 1 provides an overview of the Model 60 features, main memory, network interface, and SCSI controller.
- Chapter 2 provides information on diagnostic firmware.
- Chapter 3 provides configuration information on the system box.
- Chapter 4 describes system console commands and using alternate consoles.
- Chapter 5 provides information on diagnostic testing.
- Chapter 6 provides information on how to remove and replace system FRUs.
- Appendix A contains tables listing error codes and error messages.
- Appendix B describes how to read the diagnostic LED codes.
- Appendix C contains troubleshooting information.
- Appendix D contains tables that provide part numbers for Field Replaceable Units (FRUs).

Associated Documentation

The following documents provide additional information about the VAXstation 4000 Model 60 workstation:

| | |
|---|-------------|
| <i>VAXstation 4000 Model 60 Quick Installation Guide</i> | EK-PMARI-IN |
| <i>VAXstation 4000 Model 60 Options Installation Guide</i> | EK-PMARI-IG |
| <i>VAXstation 4000 Model 60 Owner's and System Installation Guide</i> | EK-PMARI-OM |
| <i>VAXstation 4000 Model 60 Service Information Kit Guide</i> | EK-V466H-SV |

Conventions

This guide uses the following conventions:

| Convention | Description |
|-------------------|---|
| WARNINGS | Contain important information that relate to personal safety. |
| CAUTIONS | Contain information to prevent damage to the equipment. |
| NOTES | Contain general information. |
| PN | Part number |

1

VAXstation 4000 Model 60 System Module

This chapter describes the features of the VAXstation 4000 Model 60 system module. The topics covered include:

| | |
|--------------|------------------------------|
| Section 1.1 | System Overview |
| Section 1.2 | Central Processor Unit (CPU) |
| Section 1.3 | Interrupt Controller |
| Section 1.4 | Secondary Cache |
| Section 1.5 | Main Memory |
| Section 1.6 | ROM Memory |
| Section 1.7 | Graphics Controller |
| Section 1.8 | Serial Line Controller |
| Section 1.9 | Time-of-Year Clock (TOY) |
| Section 1.10 | Network Controller |
| Section 1.11 | SCSI Controller |

1.1 System Overview

The VAXstation 4000 Model 60 system is a single-user engineering workstation, based on the KA46 system module. The Model 60 includes:


- An LK401 keyboard
- A VSXXX-AA mouse or VSXXX-AB tablet
- A monochrome or color video monitor
- One or more storage devices
- SCSI and Ethernet controllers

Each Model 60 system is housed in a desktop enclosure that contains a KA46 system module and an H7819-AA power supply. Figure 1-1 shows the module layout and other major components that comprise the system module. Figure 1-3 shows a block diagram of the module.

The KA46 system module contains the following list of components. The numbers in this list correspond to the numbers in Figure 1-1.

- | | |
|-----------------------|----------------------------------|
| ① CPU chip | ② Floating point unit (FPU) chip |
| ③ Clock chip | ④ Secondary cache |
| ⑤ MARR chip | ⑥ Base system ROMs |
| ⑦ On-board memory | ⑧ S-chip |
| ⑨ SCSI Controller | ⑩ Ethernet Controller |
| ⑪ Network address ROM | ⑫ Sound chip |
| ⑬ Time-of-Year clock | |

Figure 1-1 KA46 System Module Layout




LJ-00643-T10

The KA46 system module includes the following internal connectors, shown in Figure 1-2.

- ① Power supply connector
- ② Memory module connectors (6)
- ③ Graphics module connector
- ④ Mass storage power connector
- ⑤ Lights and switches module connector
- ⑥ SCSI Connector
- ⑦ Communications option connector
- ⑧ Channel adapter connector
- ⑨ NVR reset etch pad

Figure 1-2 KA46 System Module Internal Connectors




LJ-00644-T10

1.2 Central Processor Unit

The Central Processor Unit (CPU) of the KA46 system module supports the MicroVAX computer chip subset (plus six additional string instructions) of the VAX computer instruction set and data types, and full VAX computer memory management. The CPU is implemented as a single VLSI chip. The CPU supports both 30-bit and 32-bit physical addressing. Physical addressing mode is selected by a mode bit in the internal processor register (ACCS).

The CPU chip connects to the floating point accelerator (FPA) chip, the clock chip, the MARR gate array chip, and the secondary cache RAMs only. All other connections to the system are using the MARR gate array. See Figure 1-3.

Figure 1-3 KA46 System Module Block Diagram (Model 60)



LJ-00645-T10

1.2.1 Addressing

In the 30-bit mode, 0.5 Gbytes of program space and 0.5 Gbytes of I/O space are addressable. The actual physical address output by the CPU has address bits <31:29>=000 for program space references and address bits <31:29>=111 for I/O references.

1.2.2 Processor State

The processor state is composed of 16 general purpose registers (GPR), the processor status longword (PSL), and the internal processor registers (IPR).

Non-privileged software can access the GPR and the processor status word (and bits <15:00> of the PSL). The IPR and bits <31:16> of the PSL can be accessed only by privileged software. The IPR is accessible only by the move to processor register (MTPR) and the move from processor register (MFPR) instructions, which can be executed only while running in kernel mode.

1.2.3 Internal Processor Registers

The CPU Internal Processor Registers (IPRs) can be accessed by using the MFPR and MTPR privileged instructions. Table 1-1 lists each of the IPRs with its mnemonic, access type (read or write), scope (CPU-wide or per-process), the chip it is implemented in, whether it is initialized by hardware reset, and its category number.

Table 1-1 KA46 Internal Processor Registers

| Register Name | Mnem | Dec | Hex | Type | Scope | Impl | Init | Cat |
|--------------------------|------|-----|-----|------|-------|-------|------|-----|
| Kernel stack pointer | KSP | 0 | 0 | RW | PROC | DC595 | | 1 |
| Executive stack pointer | ESP | 1 | 1 | RW | PROC | DC595 | | 1 |
| Supervisor stack pointer | SSP | 2 | 2 | RW | PROC | DC595 | | 1 |
| User stack pointer | USP | 3 | 3 | RW | PROC | DC595 | | 1 |

Table 1-1 (Cont.) KA46 Internal Processor Registers

| Register Name | Mnem | Dec | Hex | Type | Scope | Impl | Init | Cat |
|-------------------------------------|-------------|------------|------------|-------------|--------------|-------------|-------------|------------|
| Interrupt stack pointer | ISP | 4 | 4 | RW | CPU | DC595 | | 1 |
| Reserved | | 5-7 | 5-7 | | | | | 3 |
| P0 base register | P0BR | 8 | 8 | RW | PROC | DC595 | | 1 |
| P0 length register | P0LR | 9 | 9 | RW | PROC | DC595 | | 1 |
| P1 base register | P1BR | 10 | A | RW | PROC | DC595 | | 1 |
| P1 length register | P1LR | 11 | B | RW | PROC | DC595 | | 1 |
| System base register | SBR | 12 | C | RW | CPU | DC595 | | 1 |
| System length register | SLR | 13 | D | RW | CPU | DC595 | | 1 |
| Reserved | | 14-15 | E-F | | | | | 3 |
| Process control block base | PCBB | 16 | 10 | RW | PROC | DC595 | | 1 |
| System control block base | SCBB | 17 | 11 | RW | CPU | DC595 | | 1 |
| Interrupt priority level | IPL | 18 | 12 | RW | CPU | DC595 | Yes | 1 |
| AST level | ASTLVL | 19 | 13 | RW | PROC | DC595 | Yes | 1 |
| Software interrupt request register | SIRR | 20 | 14 | W | CPU | DC595 | | 1 |
| Software interrupt summary register | SISR | 21 | 15 | RW | CPU | DC595 | Yes | 1 |

Table 1-1 (Cont.) KA46 Internal Processor Registers

| Register Name | Mnem | Dec | Hex | Type | Scope | Impl | Init | Cat |
|---|-------------|------------|------------|-------------|--------------|-------------|-------------|------------|
| Reserved | | 22- 23 | 16- 17 | | | | | 3 |
| Internal counter control status | ICCS | 24 | 18 | RW | CPU | DC595 | | 2 |
| Reserved | | 25- 26 | 19- 1A | | | | | 3 |
| Time-of-year register | TODR | 27 | 1B | RW | CPU | | | 1 |
| Console storage receiver status | CSRS | 28 | 1C | RW | CPU | | | 5 |
| Console storage receiver data | CSRD | 29 | 1D | R | CPU | | | 5 |
| Console storage transmitter status | CSTS | 30 | 1E | RW | CPU | | | 5 |
| Console storage transmitter data | CSTD | 31 | 1F | W | CPU | | | 5 |
| Console receiver control/status | RXCS | 32 | 20 | RW | CPU | | | 2 |
| Console receiver data buffer | RXDB | 33 | 21 | R | CPU | | | 2 |
| Console transmitter control/status | TXCS | 34 | 22 | RW | CPU | | | 2 |
| Console transmitter data buffer | TXDB | 35 | 23 | W | | | | 2 |
| Reserved | | 36- 37 | 24- 25 | | | | | 3 |

Table 1-1 (Cont.) KA46 Internal Processor Registers

| Register Name | Mnem | Dec | Hex | Type | Scope | Impl | Init | Cat |
|---------------------------------------|-------------|------------|------------|-------------|--------------|-------------|-------------|------------|
| Machine check error register | MCESR | 38 | 26 | W | CPU | DC595 | | 2 |
| Reserved | | 39 | 27 | | | | | 3 |
| Accelerator control & status register | ACCS | 40 | 28 | RW | CPU | DC595 | Yes | 2 |
| Reserved | | 41 | 29 | | | | | 3 |
| Console saved PC | SAVPC | 42 | 2A | R | CPU | DC595 | | 2 |
| Console saved PSL | SAVPSL | 43 | 2B | R | CPU | DC595 | | 2 |
| Reserved | | 44-46 | 2C-2E | | | | | 3 |
| Translation buffer tag | TBTAG | 47 | 2F | W | CPU | DC595 | | 2 |
| Reserved | | 48-54 | 30-36 | | | | | 3 |
| I/O system reset register | IORESET | 55 | 37 | W | CPU | | | 2 |
| Memory management enable | MAPEN | 56 | 38 | RW | CPU | DC595 | Yes | 1 |
| Translation buffer invalidate all | TBIA | 57 | 39 | W | CPU | DC595 | | 1 |
| Translation buffer invalidate single | TBIS | 58 | 3A | W | CPU | DC595 | | 1 |
| Translation buffer data | TBDATA | 59 | 3B | W | CPU | DC595 | | 2 |
| Reserved | | 60-61 | 3C-3D | | | | | 3 |

Table 1-1 (Cont.) KA46 Internal Processor Registers

| Register Name | Mnem | Dec | Hex | Type | Scope | Impl | Init | Cat |
|--|-------------|------------|------------|-------------|--------------|-------------|-------------|------------|
| System identification | SID | 62 | 3E | R | CPU | DC595 | | 1 |
| Translation buffer check | TBCHK | 63 | 3F | W | CPU | DC595 | | 1 |
| Reserved | | 64-122 | 40-7A | | | | | 3 |
| Vector interface error status register | VINTSER | 123 | 7B | RW | CPU | | | 2 |
| Primary cache tag store | PCTAG | 124 | 7C | RW | CPU | DC595 | | 2 |
| Primary cache index register | PCIDX | 125 | 7D | RW | CPU | DC595 | | 2 |
| Primary cache error address register | PCERR | 126 | 7E | RW | CPU | DC595 | | 2 |
| Primary cache status register | PCSTS | 127 | 7F | RW | CPU | DC595 | Yes | 2 |
| Reserved | | 128-255 | 80-FF | | | | | 3 |
| Reserved | | >255 | >FF | | | | | 4 |

1.2.4 Data Types

The KA46 CPU supports the following subset of the VAX computer data types:

- Byte
- Word
- Longword
- Quadword
- Character string
- Variable length bit field
- Absolute queues
- Self-relative queues
- F-floating
- G-floating
- D-floating

Support for the remaining VAX computer data types is provided by way of macrocode emulation.

1.2.5 Instruction Set

The CPU implements the following subset of the VAX computer instruction set types in microcode:

- Integer arithmetic and logical
- Address
- Variable length bit field
- Control
- Procedure call
- Miscellaneous
- Queue
- Character string (MOVC3, MOVC5, CMPC3, CMPC5, LOCC, SCANC, SKPC, SPANC)
- Operating system support

- F-floating
- G-floating
- D-floating

The CPU chip provides special microcode assistance to aid the macrocode emulation of the following instruction groups:

- Character string (except MOVC3, MOVC5, CMPC3, CMPC5, LOCC, SCANC, SKPC, SPANC)
- Decimal
- CRC
- EDITPC

The following instruction groups are not implemented, but can be emulated by macrocode:

- Octaword
- Compatibility mode instructions

1.3 Interrupt Controller

The interrupt controller section of the S-chip performs two separate functions.

- Receives eight interrupt request signals from the system I/O devices, synchronizes and latches them. The eight latched requests are then masked by individual enable bits and the eight results are read to form a single interrupt. The interrupt is presented to the CPU on IRQ1_L, interrupt priority level 15H.
- Recognizes the CPU interrupt acknowledge cycles for both IPL 14H and IPL 15H.

For IPL 15H, the controller generates a three bit number from the eight possible interrupt requests. Using a fixed priority encoding, it presents that number to the system ROM as an address from which it retrieves the interrupt vector specific to the highest priority interrupt currently active.

For IPL 14H, the controller generates a fixed address to the system ROM from which a single interrupt vector is retrieved.

The controller contains three 8-bit registers.

- INT_REQ - Holds the latched interrupt requests received from I/O devices (read-only).
- INT_MSK - Contains a mask that determines which interrupt requests generate a processor interrupt (read/write).
- INT_CLR - Enables a program to selectively reset interrupt request bits in the \INT_REQ register (write-only).

1.3.1 Interrupt Sources and Ranking

There are eight interrupt sources. These sources are listed in Table 1-2. The interrupt numbers 7:0 indicate their bit positions in the registers and their relative priority when more than one request is pending; 7 is the highest priority.

Interrupts 0, 1, 2, 3, 4, and 5 are dedicated to devices on the KA46 system module. Interrupt 7 comes from an optional device.

1.3.2 Interrupt Vector Generation

When the CPU acknowledges an interrupt from the interrupt controller, the interrupt controller causes a vector number to be placed on the CDAL bus that corresponds to the highest priority pending interrupt. The interrupt controller obtains this vector number from a reserved location in the KA46 system module on the board ROM. The conventional vector values established by the ROM firmware for the eight devices are listed in Table 1-2.

Table 1-2 Interrupt Signal Sources and Interrupt Vectors - IPL15h

| No | Name | Vector | P | Source |
|----|------|--------|---|--|
| 7 | SY | 02C0 | 0 | VSSYNC controller request for service |
| 6 | SO | 02C4 | 0 | 79C30 request for service |
| 5 | AR | 0250 | 0 | Asynchronous serial line controller receiver done or silo full |
| 4 | AT | 0254 | 0 | Asynchronous serial line controller transmit done |
| 3 | G1 | 0244 | 0 | Graphics interrupt 1 |
| 2 | G0 | 0248 | 0 | Graphics interrupt 0 |
| 1 | N1 | 03F8 | 0 | Network controller |
| 0 | SC | 03FC | 0 | Storage controller |

1.4 Secondary Cache


The CPU and floating point accelerator connect to the secondary cache, which is used to reduce the load on main memory. This cache supports a maximum main memory size of 128 Mbytes and has a capacity of 256 Kbytes. The tag store is 32K x 9, plus valid and (odd) parity bits. The data store is 32K x 64 plus eight parity bits, one per byte. The CPU generates and checks the data store parity, and the MARR gate array generates and checks the tag store parity. The cache is organized as single set, quadword line size, direct mapped, write-through.

1.4.1 Diagnostic Mode

The secondary cache tag and data stores can be accessed by way of two ranges of fixed addresses for diagnostic purposes.

Tag Store Diagnostic Access - The address range allocated for diagnostic access to the secondary cache tag store is 2D00.0000 - 2D01.FFFF. The tag store entries are accessed at sequential quadword addresses (address bits <02:00> = 000) using the format shown in Figure 1-4.

Figure 1-4 Tag Store Diagnostic Access



- V Tag Valid Bit - read/write. When accessed via this address range, the Valid bit is directly accessible. Reads of the Tag Store do not cause a Tag comparison as does a normal access.
- P Tag Parity Bit - read/write. When accessed via this address range, the Parity bit is directly accessible. Writing wrong parity will not cause a parity error if the subsequent read also occurs via the diagnostic address range.
- TAG Cache Tag - read/write.

LJ-00126-T10

Data Store Diagnostic Access - The address range allocated for diagnostic access to the secondary cache data store is 0800.0000 - 0803.FFFF. Use of this address range performs no tag loop, so the entire data store is accessible as 32,768 sequential quadwords. Parity checking is performed by the CPU.

1.5 Main Memory

Main memory consists of 8 Mbytes of DRAM installed on the KA46 system module. Additional memory is added as pairs of memory modules, using 4 Mbyte or 16 Mbyte modules. A maximum of six memory modules may be installed. Memory addressing is adjusted automatically according to the type of memory module installed in each socket to always present a contiguous address range to the CPU, starting at physical address 0 and extending upwards to 67FFFFFF.

Each memory module is 32-bits wide, so it has just one DRAM per bit for either the 4 Mbytes or 16 Mbytes variations. Four parity bits are added to each module, one per byte.

The S-chip arbitrates and services requests for main memory cycles from several sources; the Ethernet Controller (NI), Mass Storage Controller (SCSI), Invalidate Filter, CPU, and Graphics Controller (GC) section of the S-chip. To minimize interaction between the requesters, the S-chip has three buses: the CDAL, which connects to the CPU; the EDAL, which connects to the Ethernet controller, storage controller, and the invalidate filter; and the MDAL, which connects to the memory system, including video RAMs.

The S-chip is capable of performing several types of RAM cycles: longword, quadword and octaword. Buffering between the requesters and the memory allows these cycles to make the best use of the available memory bandwidth.

The Ethernet controller and SCSI controller are DMA devices. The graphics controller can generate addresses independently. All three of these devices may attempt to write to memory locations that are currently cached. To maintain cache coherency, the CPU cache is checked and, if necessary, the entry invalidated for writes requested by any of these devices. This could impose a significant load on the CPU to check the potential invalidated entries. For this reason the S-chip controls a separate invalidate filter that maintains a copy of the CPU's cache tags. In this way only those entries that do require a cache invalidate disturb the CPU.

1.5.1 Main Memory Requests

Main memory requests have a fixed priority, as follows (highest to lowest):

- GC - Shift register load
- GC - Cursor buffer load
- Refresh
- NI Controller
- DCXXXX
- Bus adapter controller
- SCSI Controller
- GC Address generator

1.5.2 DMA Mapping

The Ethernet and SCSI controllers access memory by way of a translation table which is stored in main memory. A Map Base Address Register (MAP_BASE) within the S-chip points to this reserved section of memory. The 32,768 longwords extending upwards from MAP_BASE provide translations for the page address supplied by either DMA device.

Each DMA device has a two entry cache of current translations kept in the S-chip. It is the responsibility of the operating system to allocate entries for each DMA device in the translation table.

1.5.3 Translation

Each DMA controller has its own 24-bit address counter for DMA transfers, which has a page field (15 bits) and an address-within-page field (9 bits). When a DMA controller presents an address to the S-chip to perform a DMA cycle to/from main memory, the S-chip translates the address supplied, using MAP_BASE and the translation table contained in main memory as follows:

The bits <23:09> of the address supplied by the DMA controller (the page field) are compared to the address value held in either the read or write translation cache for that DMA device.

If the addresses match and if the entry is marked valid, the associated page address held in a field of the cache entry is connected with the address-within-page field of the supplied address to form the actual address to be used and the DMA cycle proceeds.

If the address match fails, indicating that the DMA transfer is to an address on a different page than the last DMA transfer the device initiated, bits <23:09> of the DMA address supplied are connected with bits <24:17> of MAP_BASE to form a new 23-bit longword aligned map register address. This address is used to retrieve data from the translation table in main memory.

Bits <15:00> of the data that returned from memory are connected with the original address-within-page bits supplied by the controller to form a 25-bit address that is the actual address to be accessed. Bits <15:00> that were retrieved from the translation table are stored as a new value in the appropriate translation cache associated with the DMA device and the valid bit set for the entry.

1.6 ROM Memory

The KA46 system module ROM contains the processor restart, diagnostic, console code, and bootstrap programs. Another small NI ROM is programmed for the system network address.

1.6.1 System ROM

The system ROM data is stored in two 64K by 16 EPROM chips that hold a total of 256 Kbytes of data. The data appears at physical addresses 2004.0000 through 2007.FFFF. The ROM data path is 32 bits wide. Some physical addresses in the ROM have fixed use. These are:

| | |
|-----------|---|
| 2004.0000 | Processor restart address. The processor begins execution at this address in non-mapped mode when a processor restart occurs. |
| 2004.0004 | System type register SYS_TYPE. The contents of this longword supplement the internal processor SID register to identify the processor and system type. |
| 2004.0020 | Interrupt vector numbers. Eight consecutive longwords starting at this address are automatically referenced by the hardware to supply the interrupt vector numbers for the eight interrupt sources connected to the interrupt controller. |

1.6.2 Network Address ROM

A 32-byte ROM on the KA46 system module contains the network address for the system. Information from this ROM is read in the low-order bytes of 32 consecutive longwords at physical addresses 2009.0000 through 2009.007C. The network address occupies the first six bytes (addresses 2009.0000 through 2009.0014). The byte at 2009.0000 is the first byte to be transmitted or received in an address field of an Ethernet packet; its low-order bit is transmitted or received first in the serial bit stream.

1.7 Graphics Controller

The graphics controller is a part of the memory control section of the S-chip. The graphics controller competes for memory cycles as do other devices. However, graphics operations have the lowest priority of all devices requesting memory cycles.

The graphics controller supports both 8 plane and single plane 2D graphics and can execute the most commonly used primitives of DECwindows. The controller draws by way of linear addressing. The types of operations supported are:

- Lines
- One, two, and three operand rasterops
- Text

Rasterops can be:

- Solid colored
- Tiled
- Stippled
- Color expanded
- Plane compacted

All operations can be performed to both the frame buffer and non-displayable main system memory using virtual addressing with multiple clipping rectangles for overlapping window hardware support.

The Model 60 system has no video frame buffer; one of several video option modules can be added to the KA46 system module to provide the frame buffer from which pixels are output to the monitor. The video option modules carry video RAMS, pixel timing, and output digital-to-analog conversion/level shifters. The interface to the KA46 system module is at the "nibble" level, that is one quarter of the pixel rate.

1.7.1 Graphics Controller Screen Formats

The graphics controller supports several formats, which may not be supported by individual video frame buffer modules. The graphics ROM is located on the graphics module. Table 1-3 lists the screen formats supported by the graphics controller.


Table 1-3 Graphics Controller Screen Formats

| Format | Color | Mono | Refresh Rate |
|-------------|-----------|---------------|--------------|
| 1280 x 1024 | Supported | Supported | 66 Hz |
| 1024 x 768 | Supported | Supported | 60 Hz |
| 800 x 600 | Supported | Not Supported | 60 Hz |
| 1024 x 864 | Supported | Supported | 60 Hz |

1.7.2 Graphics Controller Communication

Commands are passed from the CPU to the graphics controller in the form of variable length packets. The controller accepts the command packet data and, if it is not busy and if the Clip List feature is not enabled, loads the command directly into its registers for execution. If the graphics controller is busy, or the Clip List feature is enabled, the command packet data is written by the controller into a circular buffer area in main memory - the LCG Common FIFO. The size and location of the FIFO are two of the setup parameters required by the graphics controller. Figure 1-5 shows a command packet.

Figure 1-5 General Format of a Command Packet



1.8 Serial Line Controller

The KA46 system module serial line controller handles four asynchronous serial lines. The controller and a 64 entry silo shared by all four receive lines are parts of the S-chip. The four serial lines are numbered 0 through 3, and each has a particular primary use, as listed in Table 1-4:

Table 1-4 Serial Line Usage

| Line | Device |
|------|---|
| 0 | Keyboard - connected to a 15-pin D-sub connector and to a 4-pin modular jack mounted on KA46 system module. Data leads only. Supports the LK401 Keyboard |
| 1 | Pointer - connected to a 15-pin D-sub connector and to a miniature DIN connector mounted KA46 system module. Data leads only. Supports VSXXX-AA mouse or VSXXX-AB Tablet. |
| 2 | Communications - connected to a 25-pin D-sub connector mounted on the KA46 system module, RS423 compatible. Data leads plus modem control signals. |
| 3 | Printer - connected to a 6-pin MMJ mounted on the KA46 system module. DEC423 data leads only. |

Line 3 is normally connected to a printer through a BC16E cable. (If a special jumper is installed in the MMJ on the KA46 system module, a break condition sensed on this line triggers the CPU halt signal, which restarts the system with code 2.)

1.8.1 Serial Line Controller Registers

The serial line controller has eight addressable registers. These registers are listed in Table 1-5, along with their addresses and names.

Table 1-5 Serial Line Controller Register Addresses

| Address | Name | Access | Description |
|----------------|-------------|---------------|---------------------------------------|
| 200A.0000 | SER_CSR | R/W | Control and status register |
| 200A.0004 | SER_RBUF | R | Receiver buffer - oldest data in silo |
| 200A.0004 | SER_LPR | W | Line parameter register |
| 200A.0008 | SER_TCR | R/W | Transmitter control register |
| 200A.000C | SER_MSR | R | Modem status register |
| 200A.000C | SER_TDR | W | Transmitter data register |
| 200A.0010 | DZ_LPR0 | R | Line parameter register, line 0 |
| 200A.0014 | DZ_LPR1 | R | Line parameter register, line 1 |
| 200A.0018 | DZ_LPR2 | R | Line parameter register, line 2 |
| 200A.001C | DZ_LPR3 | R | Line parameter register, line 3 |

1.9 Time-of-Year Clock

The time-of-year (TOY) clock is a chip that keeps the date and time of day. The clock contains 50 bytes of general purpose RAM storage, and a 32.768 KHz time base oscillator.

1.9.1 Battery Backup

A rechargeable battery powers the clock's chip and oscillator while the system is off. When fully charged, the battery maintains the clock for a minimum of 100 hours. The battery automatically recharges while the system power is on.

1.9.2 TOY Clock Chip Registers

The TOY clock chip contains 64 8-bit registers. Ten of these contain date and time data, four are control and status registers, and the remaining 50 provide general purpose RAM storage. The registers occupy 64 consecutive longwords of address space as shown in Table 1-6.

Each register is accessed using bit <9:> of the longword; bits <31:10> and <1:0> are ignored on writing and undefined on reading.

Table 1-6 TOY Chip Register Addresses

| Address | Name | Description |
|----------------|-------------|---------------------------|
| 200B.0000 | WAT_SEC | Time seconds, 0...59 |
| 200B.0004 | WAT_ALMS | Alarm seconds (not used) |
| 200B.0008 | WAT_MIN | Time minutes, 0...59 |
| 200B.000C | WAT_ALMM | Alarm minutes (not used) |
| 200B.0010 | WAT_HOUR | Time hours, 0...23 |
| 200B.0014 | WAT_ALMH | Alarm hours (not used) |
| 200B.0018 | WAT_DOW | Day of week, 1...7 |
| 200B.001C | WAT_DAY | Day of month, 1...31 |
| 200B.0020 | WAT_MON | Month of year, 1...12 |
| 200B.0024 | WAT_YEAR | Year of century, 0...99 |
| 200B.0028 | WAT_CSRA | Time base divisor |
| 200B.002C | WAT_CSRB | Date mode and format |
| 200B.0030 | WAT_CSRC | Interrupt flag (not used) |
| 200B.0034 | WAT_CSRD | Valid RAM and time flag |
| 2008.0038 | | First byte of RAM data |
| . | | |
| . | | |
| . | | |
| 200B.00FC | | Last byte of RAM data |

NOTE

Because each register spans two bytes on the system bus, only *word* or *longword* instructions can be used to manipulate these registers. Instructions for modifying bits such as BBSS, BBSC, BBCC, and BBCS cannot be used; they generate byte instructions for read-modify-write cycles that corrupt the portion of the register not being accessed.


1.10 Network Controller

The network controller enables the Model 60 workstation to be connected to an Ethernet network by way of a ThinWire connection using RG-58 coax cable or a transceiver cable. Either of these connections can be selected by setting a two-position switch at the rear of the Model 60 workstation. The network controller is a part of the KA46 system module and consists of a LANCE Ethernet controller chip, a serial interface adapter, an Ethernet transceiver chip, a BNC connector for the RG-58 cable to the Ethernet, and a 15-pin D-sub connector for the transceiver cable.

1.10.1 Packet Format

Data is passed over the Ethernet at a serial data rate of 10 million bits per second in variable-length packets. Each packet has the format shown in Figure 1-6.

Figure 1-6 Ethernet Packet Format



LJ-00091-T10

The minimum size of a packet is 64 bytes. Packets shorter than this are called *runt packets* and are treated as erroneous when received by the network controller.

1.10.2 Network Addresses

Ethernet network addresses are 48 bits (6 bytes) long and are of two types:

- **Physical Address:** The unique address associated with a particular workstation on the Ethernet network, which should be different from the physical address of any other workstation on any other Ethernet network.
- **Multicast Address:** A multi-destination address associated with one or more workstations on a given Ethernet network (also called a logical address). There are two kinds of multicast addresses:
 - Multicast-Group address: An address associated by higher-level convention with a group of logically related workstations.
 - Broadcast address: A predefined multicast address which denotes the set of all the workstations on the Ethernet network.

Bit 0 (the least significant bit of the first byte) of an address denotes the type:

- 0 = Physical addresses
- 1 = Multicast addresses

In either case the remaining 47 bits form the address value. A value of 48 ones is always treated as the broadcast address.

The physical address of each Model 60 workstation is determined before the system ships from the factory. The physical address is stored in the Ethernet Address ROM on the KA46 system module.

1.11 SCSI Controller

The controller conforms to the ANSI small computer system interface (SCSI) specification. It has a single port, connecting to devices within the Model 60 workstation system enclosure and allowing for external expansion.

The SCSI controller interface is a single-ended, bi-directional, 8-bit wide bus. When the KA46 system module is connected to the SCSI bus, as many as seven additional devices can be attached to the bus. Devices can be either an initiator or a target. An initiator originates an operation by sending a command to a specific target. A target performs an operation which was requested by an initiator. The Model 60 workstation is always the initiator and all other SCSI devices attached to it are targets.

Each device attached to the SCSI bus is identified by a unique device ID. The device IDs of the initiator and targets are both placed on the data bus by asserting the data bits corresponding to the device ID number. This number is controlled by programs that drive the SCSI interface, and is fixed in the Model 60 firmware to ID 6.

The interface consists of 18 signal lines, of which some are driven by initiators and some by targets. The SCSI bus always should be terminated internally and externally. The bus is permanently terminated internally at the SCSI controller end. External termination can take place in one of two locations:

- At the expansion connector on the rear of the system enclosure.
- At the second connector on the last storage expansion unit.

1.11.1 SCSI Bus Signals

SCSI bus signals are described next.

| | |
|------------------|---|
| DB7..0 and DBP | Comprise an 8-bit parallel data bus with an associated odd parity bit. The use of the parity bit is optional but strongly encouraged. These lines may be driven by either an initiator or a terminator, depending upon the direction of data transfer. |
| RST | Signals all devices on the SCSI bus to reset to their initial power-on states. Thereafter, it should be asserted only as a last resort during error recovery since it indiscriminately affects all devices on the bus. An RST signal generated by some other device on the bus causes an internal reset of the 53C94 chip used in this controller and sets the interrupt request bit (INT in register SCS_STATUS) |
| BSY and SEL | Are used by initiators and targets during the arbitration, selection, and reselection bus phases to establish or resume a logical connection between an initiator and a target. Once the connection is established, the target asserts BSY and the SEL signal is not driven by anyone. |
| C/D, I/O and MSG | Collectively indicate one of six possible information transfer phases according to the following table. These signals are always driven by the target device. |

| MSG | C/D | I/O | Phase name | Transfer direction |
|------------|------------|------------|-----------------------|-------------------------------|
| 0 | 0 | 0 | Data out | To target |
| 0 | 0 | 1 | Data in | To initiator |
| 0 | 1 | 0 | Command | To target |
| 0 | 1 | 1 | Status | To initiator |
| 1 | 0 | 0 | | (reserved) |
| 1 | 0 | 1 | | (reserved) |
| 1 | 1 | 0 | Message out | To target |
| 1 | 1 | 1 | Message in | To initiator |

ATN

Is used by an initiator to signal a target that it has a message ready. The target can receive the message by entering the "message out" phase. ATN is always driven by an initiator.

REQ and ACK

Are used to synchronize information transfers over the data bus during any of the six information transfer phases. REQ is always driven by the target, ACK is always driven by the initiator.

2

Model 60 Firmware

This chapter is an overview of the system firmware. The firmware is located in two EPROMs, which hold a total of 256 Kbytes of data. The system firmware is grouped into the following areas of operation:

| | |
|-------------|------------------------------|
| Section 2.1 | Power-Up Initialization Code |
| Section 2.2 | Console |
| Section 2.3 | Extended Self-Test Code |
| Section 2.4 | Utilities |
| Section 2.5 | System Test |

Additional topics in this chapter include:

| | |
|--------------|-----------------------------------|
| Section 2.6 | System ROM |
| Section 2.7 | Option ROM |
| Section 2.8 | Configuration Table |
| Section 2.9 | Driver Descriptor |
| Section 2.10 | Interfacing to Diagnostic Drivers |
| Section 2.11 | Console Driver Interface |

2.1 Power-Up Initialization Code

The initialization code executes when power to system is turned on. The initialization code sequence is as follows:

- The system tests enough memory to allow it to bring up the console for building console and device structures.
- The system checks its configuration for optional devices.
- The system tests the TOY clock and the non-volatile RAM. If this test fails, the test stops.
- The system constructs the Master Configuration Table (MCT), Device Configuration Table (DCT), Driver Descriptor, Shared Console Interface Area, and a blank Page Frame Map.
- The system tests the serial lines. If this test fails, the console terminal is not enabled.

NOTE

If the alternate console switch is set to alternate console, the terminal connected to line three of the serial port is used as the console. If a video option is plugged into the video slot, the system tests that option. If the test passes, the video option becomes the console device. If the test fails or no video option is present, the system defaults to line three of the serial port.

- The system calls up the console device initialization routine.
The system type and ROM ID are printed out at the console device, followed by the amount of memory, and the Ethernet address.
- The system Test Dispatcher tests the functional blocks of the system. The dispatcher runs the tests in the following order:
 1. Non-Volatile RAM (NVR)
 2. Color graphics (LCG)
 3. Serial line controller (DZ)
 4. CACHE Memory (CACHE)
 5. Memory configuration (MEM)
 6. Floating point unit (FPU)
 7. Interval timer (IT)

8. Miscellaneous system board (checksums, interrupt controller, Ethernet ID ROM) (SYS)
9. Network controller (NI)
10. SCSI Controller (SCSI)
11. Sound chip (AUD)
12. Option board (COMM)

If any device fails during testing, the dispatcher continues to test the remaining devices until all tests are completed.

NOTE

If halts are enabled, the console prompt >>> displays. If not, the system is autobooted using the default device stored in the NVR or the Ethernet if no device is specified.

2.2 Console Overview

The Model 60 system console mode allows operation of a console device, which can be one of the following:

- A workstation video device and LK401 keyboard and mouse
- A terminal connected to line three of the serial port
- A remote system connected using the Ethernet

The console mode can be entered if:

- The HALT parameter is set to halt when power is turned on.
- A severe processor condition occurs (such as an invalid interrupt stack).
- An external HALT is detected (pressing the halt button on the front panel)

In console mode input and output (I/O) routines are used by:

- Self-test
- Extended self-test
- Utilities
- System test
- Virtual memory boot (VMB)

2.3 Extended Self-Test Overview

The extended self-tests are started by entering the TEST command at the console prompt, followed by the test number or numbers you wish to run. The test dispatcher runs the self-test requested until an error occurs or until all tests are completed.

The dispatcher uses the Main Configuration Table (MCT), Device Configuration Table (DCT), and Drive Descriptor data structures when running a self-test. The dispatcher performs the following steps when running self-tests:

- Uses the device number to index into the MCT
- Gets a pointer to the device's DCT from the MCT
- Finds a pointer to the device's directory entries in the DCT
- Scans all the directories for a directory type of the self-test directory (=1)
- Reads the flags field in the DCT to determine if the self-test diagnostic needs to be loaded into RAM

If the diagnostic needs to be loaded into RAM, the dispatcher allocates memory for loading the diagnostic (moving it from ROM to RAM).

- Reads the flags field in the DCT to determine if the diagnostic uses a shared diagnostic driver.

If the self-test diagnostic uses a shared diagnostic driver, the dispatcher gets the directory entry and the pointer to the Driver Descriptor from the DCT.

If the shared driver is not already in RAM, the dispatcher allocates temporary RAM for the shared driver (loading the driver from ROM to RAM) and fills in the driver descriptor data structure to point to the RAM based shared driver.

- Calls the device's self-test interface

2.4 Utilities Test Overview

To start a utility test, at the console prompt enter the command:

```
TEST/UTIL dev_nbr util_nbr op1...opn
```

Where:

- /UTIL - instructs the test dispatcher to run a utility.
- dev_nbr - is the device on which the utility operates.
- util_nbr - is the utility number.
- op1...opn - is one to n optional parameters.

The console mode passes a list of parameters to the test dispatcher. The test then uses the Main Configuration Table (MCT), Device Configuration Table (DCT), and Driver Descriptor data structures when running a utility. The dispatcher performs the following to run a utility:

- Uses the device number to index into the MCT
- Gets a pointer to the device's DCT from the MCT
- Finds a pointer to the device's directory entries in the DCT
- Scans all the directories for a directory type of the utility directory (=3)
- Reads the flags field in the DCT to determine if the utility needs to be loaded into RAM

If the utility needs to be loaded into RAM, the dispatcher allocates memory for loading the utility (moving it from ROM to RAM).

- Reads the flags field in the DCT to determine if the utility uses a shared diagnostic driver

If the utility uses a shared diagnostic driver, the dispatcher gets the directory entry and the pointer to the Driver Descriptor from the DCT.

If the shared driver is not already in RAM, the dispatcher allocates temporary RAM for the shared driver (loading the driver from ROM to RAM) and fills in the driver descriptor data structure in the Driver Descriptor for the shared driver.

- Calls the utility entry point

- Checks the parameters passed. If the parameters are out of range or too many passed, the dispatcher sends out an illegal parameter message
- Prompts the user if more parameters are needed
- Prompts the user if the utility is going to destroy any of the user's data
- Starts the utility

2.5 System Test Overview

The system test tests the device interaction in the system by creating maximum DMA and interrupt activity. The test consists of:

- Modified VAXELN kernel
- System test monitor
- System diagnostics
- Shared drivers (if present)

The system test can be run in three environments, selected by the SET DIAGENV command:

- Customer
- Digital Services
- Manufacturing

CAUTION


**Do not use the manufacturing mode in the field.
Manufacturing mode erases customer data on hard disks,
excluding the system disk.**

Refer to Table 5-7 for more detailed information on running the system test.

2.6 System ROM Overview

The firmware contains 256 Kbytes of ROM split into two 64 Kbytes by sixteen-bit wide ROMs. This provides the 32-bit wide memory data path shown in Figure 2-1.

Figure 2-1 System ROM Format



LJ-00092 T10

The system firmware ROMs supply some information on a per byte basis for ease of manufacture and development; other information (software and tables) is supplied by the set of ROM parts.

2.6.1 System ROM Part Format

- Version (word 02h) - contains the low eight bits of the version number of the console code for the Model 60 system firmware.
- ROM byte number (byte 03h) - indicates the position of the byte among the set of ROMs used to implement the firmware. This value is equal to the low two bits of the physical address of the first byte in the ROM part. The value ranges from 0 to 3.

- Manufacturing check data (bytes 04h - 06h) - used for a quick check of the ROM. The data are 55h, AAh, and 33h.
- ROM part length (byte 07h) - indicates the length of the ROM part divided by the data path width in bytes.
- Checksum (last byte) - each ROM byte contains a simple eight-bit add and rotate checksum. In a 16-bit ROM the last two bytes contain a checksum, one checksum for each byte address in the device.

2.6.2 System ROM Set Format

The physical addresses in the system ROM set are fixed.

- 2004.0000 processor restart address - The hardware begins execution at this address when:
 - Power is turned on
 - Kernel mode halt instruction executes.
 - A break signal is received from the console device
 - The HALT button is depressed
 - The CPU detects a severe corruption of its operating environment
- 2004.0004 SYS_TYPE - This longword is the System Type Register. The system type value is 0401.0001.
- 2004.0008 reserved for ROM part data - These 24 bytes are reserved for information contained in each ROM byte.
- 2004.0020 interrupt vector numbers - These eight longwords are used by the hardware as part of the interrupt process.
- 2004.0040 console I/O routines - There are eight I/O routines provided in the system ROM. Entry points for these routines are located at longword intervals in the area.
- 2004.0070 reserved - Reserved so all ROM set data that follows it will be in the same relative position.
- 2004.0078 system console firmware revision number - This word contains the system console firmware revision number.
- 2004.007A system diagnostic firmware revision number - This word contains the system diagnostic firmware revision number.

- **2004.007C diagnostic descriptor** - This longword contains the physical address of the beginning of the system level diagnostic boot block. A value of zero indicates that there is no system level diagnostic present in the Model 60 system firmware ROM.
- **2004.0080 pointers to keyboard map** - These two longwords point to the tables used to translate the LK401 main array keycodes to character codes. The first longword contains the physical address of the beginning of the keyboard tables. The second longword contains the physical address of the beginning of the keyboard mapping tables.

2.7 Option ROM Overview

Each option in the Model 60 system has its own ROM firmware. The ROM memory on the option board may be implemented as discussed in the following sections.

2.7.1 Option ROM Part Format

The option ROM part format is provided for each byte in the ROM set. This format is compatible with the system ROM format, with the addition of the data path indicator. Figure 2-2 shows the ROM byte data.

- **Data Path Indicator (byte 00h)** - indicates the size of the ROM data path. The data path must be one of the following:
 - 1: one byte per longword - Bytes in ROM occupy the low byte of each longword.
 - 2: two bytes per longword - Words in ROM occupy the low two bytes of each longword.
 - 4: four bytes per longword - Longwords in ROM correspond to longwords in the address space.
- **Version (byte 02h)** - contains the low eight bits of the version number for the option's firmware.
- **ROM Byte number (byte 03h)** - indicates the position of the byte among the set of ROMs used to implement the firmware. This value is equal to the low two bits of the physical address of the first byte in the ROM set. Note that this value is always less than the data path indicator.

Figure 2-2 Option ROM Byte Data

| | |
|--------------------------------|-----------|
| Data Path Indicator | Byte 0 |
| Reserved | Byte 1 |
| Version | Byte 2 |
| ROM Index Number | Byte 3 |
| Manufacturing Check Data (55h) | Byte 4 |
| Manufacturing Check Data (AAh) | Byte 5 |
| Manufacturing Check Data (33h) | Byte 6 |
| ROM Part Length | Byte 7 |
| Reserved for ROM set Data | Byte 8 |
| Checksum | Last Byte |

LJ-00101-T10

- Manufacturing check data (bytes 04h through 06h) - these three bytes may be used for a quick verify check of the ROM contents. The data are 55h, AAh, and 33h.
- ROM Part length (byte 07h) - indicates the length of each byte address in the set. It is the number of bytes associated with each byte in the ROM in Kbytes.

NOTE

The number of bytes in the ROM set equals the sum of the number of bytes in each of the ROM parts divided by the data path of each device. Each of the ROM parts on the option board must have the same number of bytes.


- Reserved for ROM set data - byte 8.
- Checksum (last byte) - each byte in the ROM set has a simple add and rotate checksum in its last byte.

2.7.2 Option ROM Set Format

For options that have a one-byte or two-byte data path, the data from the ROM set must be moved into RAM. Note that a device cannot have both an 8-bit data path and a 16-bit data path. An option with a full 32-bit data path may not have to be moved. Devices with a 16-bit data path are treated as though each byte of the device is a device in itself.

Figure 2-3 shows option ROM set data.

Figure 2-3 Option ROM Set Data




LJ 00102 T10

- Option revision - this number controls changes in both the option hardware and firmware.
- Option index value - index value of the last DCT entry. A zero in this field indicates a single DCB for the device, a one indicates two device control blocks for this device. An option that occupies the storage option slot can have the values of zero or one. An option that occupies the video option slot can have the values of zero, one, or two.
- Reserved for expansion - these 32 bytes are reserved.
- Device Configuration Table template - the device implemented by the option must have an associated Device Configuration Table template. The DCT contains static and dynamic data and pointers to code required for the device.

2.8 Configuration Table Overview

Information on the Model 60 devices is saved in the system configuration tables by the power-up initialization code. The code sizes the system by reading the ROM-based Device Configuration Tables (DCT) and builds a memory resident configuration data structure. Figure 2-4 shows how the data structures are linked together.

Figure 2-4 Model 60 Configuration Tables



LJ-00097-T10

The initialization code saves a pointer to the scratch RAM in the Model 60 NVR in four consecutive bytes. The scratch RAM contains a pointer to the Main Configuration Table (MCT) at its base address. The MCT contains pointers to the DCT.

2.8.1 Main Configuration Table

The Main Configuration Table (MCT) contains a list of the devices in the system and a pointer to the Device Configuration Table for each device. The MCT is built when power is turned on and resides in the diagnostic area in memory. The MCT gives the test dispatcher a single interface into the various components of the system. The MCT is shown in Figure 2-5.

Figure 2-5 Main Configuration Tables

| | |
|---------------------------------------|------------------|
| Minor Version ID | Major Version ID |
| Number of Devices | Edit Version ID |
| 0 | Device ID |
| Pointer to Device Configuration Table | |
| 0 | Device ID |
| Pointer to Device Configuration Table | |
| ⋮ | ⋮ |
| ⋮ | ⋮ |
| ⋮ | ⋮ |
| 0 | Device ID |
| Pointer to Device Configuration Table | |

Number of Devices *8
 (Number of Devices *8)+4

LJ-00104-T10

The components of the Main Configuration Table are:

- Major version ID - version number is used to track major changes in the diagnostic interface.
- Minor version ID - version number is used to track minor changes in the diagnostic interface.

- Edit version ID - reserved for use by diagnostic developers.
- Number of devices - the number of entries in the MCT table.

The next three fields are replicated for each device in the system.

- Device ID - the device ID number
- Must be zero - reserved for future use.
- Pointer to Device Configuration Table - points to the DCT for this particular device.

2.8.2 Device Configuration Table

There is a Device Configuration Table (DCT) entry for each device in the Model 60 system. The DCT contains extended information about the device, such as:

- Device name
- Diagnostic code location
- Header information

The test dispatcher and the system test monitor use this data to fetch the appropriate diagnostic code to execute from the ROM or to load into RAM. The DCT is shown in Figure 2-6.

Figure 2-6 Device Configuration Table

| | | | |
|--|------------------|--------|----|
| Minor Version ID | Major Version ID | 0 | |
| Number of Devices | Edit Version ID | 4 | |
| Device Name | | 8 | |
| Pointer to Driver Descriptors | | 10 | |
| Device Status | | 14 | |
| Pointer to Extended Status | | 18 | |
| Size of Extended Status | | 1C | |
| Pointer to Extended Config | | 20 | |
| Pointer to Permanent Memory | | 24 | |
| Size of Permanent Memory | | 28 | |
| System Test Status | | 2C | |
| Pointer to Extended System Test Status | | 30 | |
| Size of Extended System Test Status | | 34 | |
| Flags | DPSIZE | DIRTYP | 38 |
| Physical Address of Module | | | 3C |
| Code Length | | | 40 |
| Entry Point Offset | | | 44 |

| | | | |
|----------------------------|--------|--------|-------------------------|
| Flags | DPSIZE | DIRTYP | ((NBR OF DIRS 1)*10)+2C |
| Physical Address of Module | | | |
| Code Length | | | |
| Entry Point Offset | | | |

The components of the Device Configuration Table are:

- Major version ID - version number is used to track major changes in the device's diagnostic routines.
- Minor version ID - version number is used to track minor changes in the device's diagnostic routines.
- Device ID - device ID number
- Number of directories - the number of directory entries for the device. A directory entry tells the user where to find a particular component of code for the device.
- Device name - the name of the device is ASCII. This is used by the show configuration utility and the system test to display information about the device.
- Pointer to the driver descriptors - points to the drive descriptor area associated with the device.
- Device status - saved from the last time that self-test was run on the device. The show configuration utility uses this field to display information about the device. The device status is split into two words, the lower word is the error field and the upper word is the Field Replaceable Unit (FRU) thought to be bad.
- Size of extended device status - the length of the extended device status in bytes. The extended device status can be up to 16 longwords of information. The extended status is displayed when the user enters the "SHOW ERRORS" command at the console prompt.
- Pointer to extended device status - points to any extended information that is saved by the device self-test.
- Pointer to extended configuration data - points to extended configuration information about the device. For example, the SCSI self-test code uses this field to save a pointer to information about the devices connected to the SCSI bus. The information is displayed when the user enters the "SHOW CONFIG" command at the console prompt.
- Pointer to permanent memory allocated - points to the permanent memory that has been allocated. The field is filled in by the diagnostic, the first time that it allocates memory.
- Size of permanent memory allocated - the amount of permanent memory (in pages) that has been allocated. This field is filled in by the diagnostic the first time that it allocates memory.

- System test status - the status saved the last time that System Test was ran on this device without doing intervening test commands.
- Pointer to extended system test status - points to any extended information that is saved by the device's self-test. The "SHOW ESTAT" utility uses the extended status to display information about the device.
- Size of extended system test status - the length in bytes of the extended System Test status.
- Directory type - contains the type of directory entry that the previous elements refer to. Table 2-1 lists the directory type.

Table 2-1 Directory Type Definitions

| Definition | Meaning |
|------------|-----------------------------------|
| 1 | Self-test directory entry |
| 2 | System test directory entry |
| 3 | Utility directory entry |
| 4 | Console routine directory entry |
| 5 | Unjam routine directory entry |
| 6 | Diagnostic driver directory entry |

- Data path size - contains the data path size of the ROM in which the piece of code resides. The path size is listed in Table 2-2.

Table 2-2 Data Path Size Definitions

| Definition | Meaning |
|------------|------------------------------|
| 1 | ROM Width is one byte wide |
| 2 | ROM Width is two bytes wide |
| 4 | ROM Width is four bytes wide |

- Flags - contains flag data associated with the particular device routine. Table 2-3 lists the flag definitions.

Table 2-3 Flag Definitions

| Definition | Meaning |
|-------------------|---|
| Bit 15=1 | Code must be loaded into RAM at power-up and memory marked as unavailable to the operating system. |
| Bit 14=1 | Code must be loaded into RAM to execute. The memory is released after execution is complete. |
| Bit 13=1 | Code has been loaded into RAM at power-up and memory marked as unavailable to the operating system. |
| Bit 0=1 | Code uses shared diagnostic driver. |

- Length of code - contains the length of code in bytes.
- Physical address of the module - contains the physical address for this particular component of the code.
- Entry point offset - contains the offset from the beginning of the code to where the entry point is.

2.9 Driver Descriptor Overview

Any device that provides a shared port driver or shared class driver must provide a descriptor that supplies the Model 60 base system firmware, system test monitor, and any other piece of software specific information about the drive. The format for a driver descriptor is shown in Figure 2-7.

Figure 2-7 Driver Descriptor Data Structure

| | |
|-----------------------------|----|
| Device ID | 0 |
| Address of Driver | 4 |
| Length of Driver | 8 |
| Entry Point of Driver | C |
| Size of Driver Data Area | 10 |
| Address of Driver Data Area | 14 |
| Address of IO Segment Table | 18 |

LJ-00106-T10

The fields of the driver descriptor are:


- **Device ID** - ensures that the driver descriptor ID matches the function block ID. This allows a function the ability to determine if it is being used correctly.
- **Address of the driver** - contains the address of the Device Driver. This address may be ROM or memory address.
- **Length of the driver** - contains the length of the Device Driver in bytes. This field is used by both the base system ROM and the system test monitor to determine the amount of code that needs to be loaded into RAM.
- **Entry point offset of the driver** - contains the number of bytes from the beginning of the device driver to the INIT_DRIVER function.
- **Size of driver data area** - contains the length in bytes of the amount of memory that a driver needs for its parameters and local data.

- Address of the driver data area - contains the address of the Device Driver data area that is used by the driver to store local data.
- Address of the I/O segment table - contains the address of the I/O segment table.

2.10 Interfacing to Diagnostic Drivers

The network device contains routines to UNJAM the device and to run self-test routines, system test routines, console routines, and a shared diagnostic driver routine. Figure 2-8 shows how these pieces of code relate to each other.

Figure 2-8 Diagnostic Driver Console Support




User application performs console input/output to the network by calling the console code, which calls the network diagnostic driver. The console, self test, system test, and UNJAM routines interface to the diagnostic driver in similar ways. All diagnostic routines, utilities, and console routines do the following:

- Allocate memory for the driver data area
- Allocate memory for the diagnostic function block or console function block
- Call the INIT_DRIVER routine with the following parameters:
 - Pointer to the I/O Segment Table
 - Pointer to the Driver Data Area
 - Pointer to the Driver Function Block or Console Function Block
 - Pointer to the Shared Console Interface Area or display zero if this is not a console driver
 - As many as two additional device-specific parameters

2.11 Console Driver Interface

The Model 60 console code is split into a class/port driver scheme. The class driver contains the main console functions, such as `PUT_CHARACTER` and `GET_CHARACTER`. The port drivers contain the device specific code required to support these functions. Figure 2-9 shows the division of the console function.

Figure 2-9 Model 60 Console Structure



LJ-00108-T10

The console device can require either one channel or two channels to perform I/O to the console device. If the console device is a graphics terminal with a LK401 keyboard, the console program must interface with the serial line device driver for console input and interface with the graphics device driver for output from the console. If the console device is a terminal connected to a serial line, the console responds to the serial line driver for both input and output.

The console class driver contains the generic routines that interface to the console and user application to perform terminal input and output transactions. The console class driver interfaces with the port driver depending on the current console device.

If the console port driver does not support `PUT_CHARACTER` or `GET_CHARACTER` functions, it must interface with the appropriate port driver to perform the needed function.

2.11.1 Shared Console Interface Area

The shared console interface area (SCIA) consists of a console class driver descriptor and three port driver descriptors. The port driver descriptors can be associated with a DZ port driver, a graphics output driver, and a network driver.

The SCIA provides an interface to the console terminal that isolates the implementation specifics of accessing the console terminal. It is designed so the console drivers can run in both virtual and physical mode.

The SCIA is set up by the initialization code. After the SCIA is set up, the software can use this area to interface with the console class driver routine. The shared console performs the following:

- Raw character I/O to console terminal
- Higher level of I/O functions that handle XON/XOFF flow (ASCII bell character and LK401 keyboard translation are handled by the DZ driver)
- Data structures to allow system software to map all console code and I/O space references into virtual memory as needed

SCIA data structure is shown in Figure 2-10.

Figure 2-10 SCIA Data Structure

| |
|--|
| Console Type |
| LK401 Keyboard Type |
| Address of US Font Table |
| Address of MCS Font Table |
| Address of Keyboard Translation Table |
| Address of Keyboard Map Table |
| Console Class Device ID |
| Console Class Driver Driver Descriptor |
| DZ Device ID |
| DZ Port Driver Driver Descriptor |
| Graphics Device ID |
| Graphics Port Driver Driver Descriptor |
| NI Device ID |
| NI Port Driver Driver Descriptor |
| VMS Debug Device ID |
| VMS Debug Port Device Driver |

| |
|------------------------|
| XXX Device ID |
| XXX Port Device Driver |

2.11.2 Console Port Driver

The fields of the console port driver's driver descriptor are the same as the console class driver's driver descriptor, except the port driver contains pointers to the console port level routines. The port driver supports all functions whether or not the device supports console output only or console input/output. Figure 2-11 shows the function block of the port driver.

Figure 2-11 Console Port Driver Function Block

| |
|----------------------|
| Device Id |
| INIT DRIVER Pointer |
| GETCHAR Pointer |
| PUTCHAR Pointer |
| RESET_INPUT Pointer |
| INIT INPUT Pointer |
| RESET OUTPUT Pointer |
| INIT OUTPUT Pointer |

LJ-00110-T10

3

System Configuration


This chapter describes the system box used with the VAXstation 4000 Model 60 workstation, and its the components, cabling, and specifications. The topics covered in this chapter are:

| | |
|---------------|---------------------------|
| Section 3.1 | System Box |
| Section 3.1.1 | Mass Storage Device Areas |
| Section 3.1.2 | Power Supply |
| Section 3.1.3 | Internal Cabling |
| Section 3.1.4 | System Box Control Panel |
| Section 3.1.5 | I/O Panel |
| Section 3.1.6 | System Box Specifications |

3.1 Model 60 System Box

The Model 60 System box is used for desktop and floorstand installation of the VAXstation 4000 Model 60 system. Figure 3-1 shows the system box and its components.

Figure 3-1 Model 60 System Box



LJ-01481-SCAN

3.1.1 Mass Storage Device Areas

The system box can hold two half-height drives, 8.9 cm (3.5 in), in the H bracket (front left, Figure 3-1), and one half-height drive, 13.3 cm (5.25 in), in another bracket (front right, Figure 3-1). The bottom drive in the H bracket is mounted upside down. The H bracket releases by a single latch and the other bracket uses two release points.

3.1.2 Power Supply

The system box has space for one power supply, the H7819-AA. The power supply provides protection against excess voltage, current, and temperature.

The power supply voltage connectors are located at the rear of the unit. The input connector is used to connect to a wall outlet and the output connector connects to the system monitor. The power switch and power OK LED are located on the front of the unit. Inside the power supply is a -9.0 V LED, visible from the outside. The supply also has two 12 V fans for cooling the system.

The power supply has an automatic voltage select (AVS) circuit to automatically select the AC input for 100 to 120 Vac or 220 to 240 Vac mode of operation. The supply is a 163 watt (W) unit. It supplies the following voltages:

| Voltage (dc) | Ampere |
|--------------|--------|
| +5.1 | 19.52 |
| +3.3 | 6.39 |
| +12.1 | 3.82 |
| -12.0 | 0.69 |
| -9.0 | 0.17 |

Power is supplied to the following components:

- System module (which supplies power for option modules installed in the system)
- Mass storage devices
- Cooling fans
- AC power for system monitor

3.1.2.1 Power Supply Specifications**Input Characteristics**

| Parameter | Specifications | |
|--------------------------|---|---|
| Line voltage | 120 V | 240 V |
| Voltage tolerance | 88 V to 132 V | 176 V to 264 V |
| Frequency | 60 Hz | 50 Hz |
| Frequency tolerance | 47 Hz to 63 Hz | 47 Hz to 63 Hz |
| Input current | 2.9 A (max.) PS only 4.0 A (max.) AUX only | 1.4 A (max.) PS only 2.0 A (max.) AUX only |
| Inrush current | 45.0 A (max) cold PS only | 45.0 A (max) cold PS only |
| Power consumption (max.) | 251 W | 251 W |

Output Characteristics

| Parameter | Specifications | | |
|----------------------------|-----------------------|----------------|----------------|
| | Minimum | Typical | Maximum |
| +5.1 V reg. Short term | 4.90 V | 5.05 V | 5.20 V |
| +5.1 V reg. Long term | +4.85 V | +5.10 V | +5.25 V |
| +12.1 V reg. Short term | +11.70 V | +12.10 V | +12.50 V |
| +12.1 V reg. Long term | +11.50 V | +12.10 V | +12.70 V |
| -12.0 V reg. Long term | -11.40 V | -12.00 V | -12.60 V |

| Parameter | Specifications | | |
|--|----------------|---------|----------|
| | Minimum | Typical | Maximum |
| -9.0 V (isolated) Long term | -8.55 V | -9.00 V | -9.45 V |
| +3.3 V Long term | +3.13 V | +3.3 V | +3.46 V |
| Load range | | | |
| +3.3 V | 3.20 A | | 6.39 A |
| +5.1 V | 2.8 A | | 19.52 A |
| +12.1 V | 0.18 A | | 3.82 A |
| -12.0 V | 0.26 A | | 0.69 A |
| -9.0 V | 0.12 A | | 0.17 A |
| Ripple and noise 1Hz to 10Hz | | | |
| +3.3 V | | 20.0 mV | 30.0 mV |
| +5.1 V | | 30.0 mV | 50.0 mV |
| +12.1 V | | 50.0 mV | 70.0 mV |
| -12.0 V | | | 120.0 mV |
| -9.0 V | | | 50.0 mV |
| Ripple and noise (except +5.1 V and +3.3 V) 10 MHz to 50 MHz | | 1.0% | 2.0% |
| Ripple and noise 10 MHz to 50 MHz | | | |
| +5.1 V | | 30 mV | 50 mV |
| +3.3 V | | 20 mV | 30 mV |

Physical Dimensions

| Weight | Height | Width | Depth |
|-------------------|----------------------|----------------------|-----------------------|
| 14.9kg (33 lb) | 6.99 cm (2.75 in) | 11.18 cm (4.4 in) | 38.10 cm (15.0 in) |

3.1.3 System Box Internal Cabling

The system box internal cabling is shown in Figure 3-2. Note that there is one SCSI cable and one dc power harness connecting to the drives.

NOTE


The power cable for half-height drives must be routed above the SCSI cable, as shown in Figure 3-2.

Table 3-1 lists internal system devices and their cable part numbers.

Table 3-1 Internal System Devices and Their Cables

| System Device | Cable PN | Description |
|------------------------------|-----------------|---|
| 3 SCSI devices | 17-02875-01 | Three 50-pin IDC to 50-pin champ (external) |
| SCSI device dc power harness | 17-02876-01 | Four 4-pin Mat-N-Loks to 4-pin mini |

Figure 3-2 Internal Cabling




LJ-00628-T10

3.1.4 System Box Control Panel

The controls and indicators for the system box are located behind the flip-down door on the front bezel (Figure 3-3) of the box.

Figure 3-3 System Box Control Panel



MLO 005090

AC Power Switch - This switch, located on the upper left side of the front bezel, controls ac power to the H7819-AA power supply. The switch does not affect the ac power outlet provided for add-on peripherals at the rear of the system box.

Power OK LED - This small green indicator is visible on the upper left side of the front bezel. The LED is lit when ac power is applied and the proper output voltage levels are present.

Audio In/Out - This jack is a four-pin MJ-type connector.

Speaker/Headset Switch - This switch selects between speaker output and headset output.

Alternate Console Switch - This switch selects either the graphics terminal or printer/console port to be the system's console.

Halt Console Switch - When actuated, this momentary switch sends a halt signal to the CPU module.

Diagnostic LEDs - These LEDs are located on the right side of the control panel. These LEDs display two binary fields, which represent a two-digit hexadecimal diagnostic code.


3.1.5 I/O Panel

The I/O panel provides connectors to devices external to the system. The system configuration determines which external devices are connected to the panel. The external devices shown in Figure 3-4 are as follows:

- ❶ Ethernet interface (from left to right: standard Ethernet port, network switch, and ThinWire port)
- ❷ RS423 communications port
- ❸ Printer/console port with a DEC423 connector (MMJ)
- ❹ Keyboard port
- ❺ Mouse port
- ❻ Remote keyboard/mouse port
- ❼ SCSI port
- ❽ Option port (for the DSW21 communications device)
- ❾ Monitor video port
- ❿ Monitor power socket
- ⓫ AC power socket

Table 3-2 lists external system devices and their cables.

Figure 3-4 Model 60 I/O Panel



LJ-00639-T10

Table 3-2 External System Devices and Their Cables

| System Devices | Cable P/N | Description |
|--|------------------|---|
| System to monitor | BC27R-03 | 3 coax Dsub. to 3 BNC 39 in (99.1 cm) |
| System to VRT13 | | 3 row 15-pin Dsub. to 9-pin Dsub. 3 ft (.91 m) |
| Remote video | BC27R-10 | 3 coax Dsub. to 3 BNC 10 ft (3.0 m) |
| Remote LK/VSXXX (mouse/keyboard) | 17-02640-01 | 15-pin Dsub. to LK/VSXXX 10 ft (3.0 m) |
| DSW21 communications device option | DSW21-AX | 50-pin Dsub. to x-pin ¹ 2 ft (.61 m) |
| External SCSI | BC19J-03 | 50-pin champ to 50-pin champ 3 ft (.91 m) |
| AC power input (to power supply) | 17-00606-10 | IEC to 3 prong AC 6 ft (1.83 m) |
| AC power output (system to monitor) | 17-00442-25 | IEC to IEC, 39 in (99.1 cm) |

¹x=6, 12, 16, 22, 24, or 26.

3.1.6 System Box Specifications

The system box specifications are listed next. Table 3-3 lists the system box operating conditions and Table 3-4 lists the electrical specifications.

NOTE

The operating clearance is 8.9 cm (3.5 in) minimum on the sides and back of the system box. The service clearance is 15.2 cm (6 in) minimum on all sides of the box.

Table 3-3 System Box Operating Conditions

| | |
|------------------------------------|--------------------------------------|
| Temperature range | 15° C to 32° C (59° F to 90° F) |
| Maximum rate of temperature change | 11° C (20° F) per hour |
| Relative humidity | 20% to 80% (with disk or tape drive) |
| Altitude | 2400 m at 36° C (8000 ft at 96° F) |
| Maximum wet bulb temperature | 28° C (82° F) |
| Minimum dew point | 2° C (36° F) |

Table 3-4 System Box Electrical Specifications

| | |
|-----------------|--|
| Input voltage | 100 VAC to 120 VAC 220 VAC to 240 VAC |
| Frequency range | 47 to 63 Hz |

4

Using the Console

This chapter describes the system console commands and using alternate consoles. Diagnostic commands, used to troubleshoot a system, are described in Chapter 5. The following topics are covered in this chapter:

| | |
|-------------|-------------------------|
| Section 4.1 | System Console Commands |
| Section 4.2 | Alternate Consoles |

4.1 System Console

Standard console commands for the VAXstation 4000 Model 60 are listed by functional groups as follows:

- Additional commands - HELP or ?, LOGIN, and REPEAT
- SET/SHOW Commands - used to set or examine system parameters and configuration.
- Memory commands - include the DEPOSIT and EXAMINE commands.
- Processor control commands - BOOT, CONTINUE, INITIALIZE, START, and UNJAM commands.

4.1.1 Additional console commands

| Command | Function |
|-----------|--|
| HELP or ? | Lists console commands and syntax. |
| LOGIN | Enables restricted console commands when PSE and PSWD are set. |
| REPEAT | Continuously repeats a console command. |

4.1.1.1 HELP or ?

The HELP command or question mark (?) lists the console commands and the syntax allowed with each command.

4.1.1.2 LOGIN

The LOGIN command enables restricted console commands when the PSE bit is set. Enter the console password on the line following the LOGIN command.

4.1.1.3 REPEAT

The REPEAT command repeats a console command entered on the same line following REPEAT.

- BOOT, INIT, and UNJAM cannot be repeated.
- The command is terminated by entering the **Ctrl C** key sequence.

Example:

```
>>> REPEAT TEST MEM ! Repeats the memory test.
      .
      .
      .
CTRL C ! Terminates the test.
>>>
```

4.1.2 SET and SHOW Commands

The SET and SHOW commands are used to set and examine system parameters. Table 4-1 lists the SET/SHOW parameters and their meanings:

Table 4-1 SET/SHOW Parameters

| Parameter | Meaning |
|-----------|--|
| BFLG | Default bootflag |
| BOOT | Default boot device |
| CONFIG | System configuration |
| DEVICE | Ethernet and SCSI devices information |
| DIAGENV | Diagnostic environment (mode) |
| ETHER | Ethernet hardware address |
| ERROR | Errors from the last system or self-test |
| ESTAT | Status from the last system test |
| FBOOT | Power-up memory test flag |
| HALT | Halt recovery action |
| KBD | Keyboard language |
| MEM | Memory address range |
| MOP | MOP listener |
| PSE | Password enable |
| PSWD | Password |
| SCSI | System SCSI ID |
| TRIGGER | Enable network console |

4.1.2.1 SET and SHOW Command Syntax

The following are the syntax and examples of the SET and SHOW parameters:

Syntax:

```
>>> SHOW parameter
>>> SET parameter value
```

Example:

```
>>> SHOW BOOT
>>> SET BOOT DKA200:
```

4.1.2.2 BFLG

The BFLG parameter is the default bootflag. It is equivalent to R5:xxxxxxxx in the boot command.

- BFLG is normally set to 0.

Example:

```
>>> SET BFLG 00000001    ! Set BLFG to
                           conversational boot
BFLG = 00000001

>>> SHOW BFLG
BLFG = 00000001
```

4.1.2.3 BOOT

The BOOT parameter is the default boot device.

- The boot device can be set to a bootable SCSI drive or the network device.
- To see the valid device boot names, type >>> SHOW DEVICE. The first column of the table (VMS/VMB) lists the boot names.

Example:

```
>>> SET BOOT DKA200
BOOT = DKA200

>>> SHOW BOOT
BOOT = DKA200
```

4.1.2.4 CONFIG

The CONFIG parameter is used to display the system configuration and device status.

- The SET command does not apply to this parameter.
- Use SHOW DEVICE for more information on SCSI devices.

Example 4-1 shows the information displayed by the SHOW CONFIG command.

Example 4-1 SHOW CONFIG Command

```
>>> SHOW CONFIG
```

```
KA46-A BL3-186-B3.1      ! System type and firmware revision
08-00-2B-F3-31-03      ! Ethernet hardware address
16 MB                   ! Total memory
```

| DEVNBR | DEVNAM | INFO |
|--------|--------|--|
| 1 | NVR | OK |
| 2 | LCG | OK |
| | | HR - 8 PLN FB - 2.7 |
| 3 | DZ | OK |
| 4 | CACHE | OK |
| 5 | MEM | OK |
| | | 16MB = SY=8MB, S0/S1=8MB, S2/S3=0MB, S4/S5=0MB |
| 6 | FPU | OK |
| 7 | IT | OK |
| 8 | SYS | OK |
| 9 | NI | OK |
| 10 | SCSI | OK |
| | | 1-RZ23L 6-INITR |
| 11 | AUD | OK |
| 12 | COMM | OK |

```
! Non-volatile RAM
! 2D high res. color graphics rev 2.7
! Serial line controller
! Cache memory
! Memory configuration
! Floating point accelerator
! Interval timer
! Other system functions
! Ethernet
! SCSI and drives
! One RZ23L at ID 1, system at ID 6.
! Sound
! DSW21 communications device
```

4.1.2.5 DEVICE

The **DEVICE** parameter is used to display SCSI and Ethernet device information.

The **SET** command does not apply to this parameter.

Example 4-2 shows the information displayed by the the **SHOW DEVICE** command.

Example 4-2 SHOW DEVICE Command

```
>>> SHOW DEVICE
```

| VMS/VMB | ADDR | DEVTYPE | NUMBYTES | RM/FX | WP | DEVNAM | REV |
|-------------|-------------------|---------|----------|-------|----|--------|------|
| ----- | ---- | ----- | ----- | ----- | -- | ----- | --- |
| ESA0 | 08-00-2B-17-EA-FD | | | | | | |
| DKA100 | A/1/0 | DISK | 121 MB | FX | | RZ23L | 1F25 |
| DKA300 | A/3/0 | RODISK | 594 MB | RM | WP | RRD42 | 1.1A |
| MKA500 | A/5/0 | TAPE | | RM | | TZK10 | 00AD |
| ..Host ID.. | | INITR | | | | | |
| DKA700 | A/7/0 | DISK | 332 MB | FX | | RZ55 | 0900 |

!Column Meanings:

VMS/VMB - The VMS device name, and console boot name for the device.
 ADDR - Ethernet hardware address or SCSI device ID.
 The SCSI device ID has the format:

A/DEVICE_ID/LOGICAL_ID

The LOGICAL ID is always 0.

DEVTYPE - Device type, RODISK is a read-only disk (CDROM).
 NUMBYTES - Drive capacity. Capacity is not be displayed for empty removable media drives
 RM/FX - Indicates whether the drive has removable or fixed media.
 WP - Indicates whether the drive is write protected.
 DEVNAM - Device name for the drive.
 REV - Firmware revision level for the drive.

4.1.2.6 DIAGENV

The DIAGENV parameter determines the diagnostic environment that the diagnostics run under. Table 4-2 lists the diagnostic environments and their use.

Table 4-2 Diagnostic Environments

| Mode | Usage |
|-----------------------------------|---|
| Customer | No setup is required. Default mode on power-up. |
| Digital Services | Provides a more thorough test than in customer mode. Some tests require loopback connectors for successful completion. |
| Manufacturing | Some tests require loopback connectors for successful completion. Do not use this mode in the field. It can erase customer data. |
| Loop on error Digital Services | The system loops on a test when an error occurs. Do not use this mode in the field. It can erase customer data. |
| Loop on error Manufacturing | The system loops on a test when an error occurs. |

To set the diagnostic environment, enter a console command from Table 4-3.

Table 4-3 SET DIAGENV Command

| Command | Result |
|----------------------|---|
| SET DIAGENV 1 | Resets environment to Customer mode. |
| SET DIAGENV 2 | Sets environment to Digital Services mode. |
| SET DIAGENV 3 | Sets environment to Manufacturing mode. |
| SET DIAGENV 80000001 | Sets environment to loop on error in Digital Services mode. |
| SET DIAGENV 80000002 | Sets environment to loop on error in manufacturing mode. |

4-8 Using the Console

Example:

```
>>> SET DIAGENV 2
      DIAGENV = 2
>>> SHOW DIAGENV
      DIAGENV = 2
```

4.1.2.7 ERROR

The **ERROR** parameter displays extended error information about any errors that occur during the last execution of:

- Initialization (power-up) test
- Extended test
- System test

The **SET** command does not apply.

Example:

```
>>> SHOW ERROR
?? 150 10 SCSI 0032
150 000E 00000005 001D001D 03200000 00000024
(cont.) 00000002 00000000 00000004
```

4.1.2.8 ESTAT

The **ESTAT** parameter displays status information about the system test.

The **SET** command does not apply.

The following example shows the information displayed by the **SHOW ESTAT** command:

```
>>> SHOW ESTAT
```

4.1.2.9 ETHER

The ETHER parameter displays the Ethernet hardware address.

- The SET command does not apply.

Example:

```
>>> SHOW ETHER
ETHERNET = 08-00-2B-1B-48-E3
```

4.1.2.10 FBOOT

The FBOOT (fast boot) parameter determines whether the memory is tested when power is turned on. The test time is reduced when main memory is not tested.

- When FBOOT = 0 the memory is tested on power-up.
- When FBOOT = 1 the memory test is skipped on power-up.
- The setting only affects the power-up test.
- FBOOT should only be set to 1 when troubleshooting requires a number of power cycles, and memory is not the suspected fault.

Example:

```
>>> SET FBOOT 1    ! Enables fast power-up test.
FBOOT = 1
>>> SHOW FBOOT
FBOOT = 1
```

4.1.2.11 HALT

The HALT parameter determines the recovery action. The recovery action is the action the system takes after power-up, system crash, or halt. The following table lists the HALT parameter values and their meanings:

| Value | Meaning |
|-------|--|
| 1 | System tries to restart operating system. If restart fails, then the system tries to reboot. |
| 2 | System tries to reboot. |
| 3 | System halts and enters console mode. |

4-10 Using the Console

Examples:

```
>>> SET HALT 2          >>> SHOW HALT
                        HALT = 2          HALT = 2
```

4.1.2.12 KBD

The KBD parameter determines the keyboard language.

- The SHOW KBD command only displays a numeric keyboard code.
- The SET KBD command displays the language choices and the corresponding numeric code.

Example:

```
>>> SHOW KBD
KBD = 4
>>> SET KBD
0) Dansk                      8) Francais (Suisse Romande)
1) Deutsch                   9) Italiano
2) Deutsch (Schweiz)        10) Nederlands
3) English                  11) Norsk
4) English (British/Irish) 12) Portugues
5) Espanol                 13) Suomi
6) Francais                14) Svenska
7) Francais (Canadian)    15) Vlaams
3 >>> 4                      ! Enter numeric code
```

4.1.2.13 MEM

The MEM parameter displays the memory address range and the unavailable memory address range.

- The unavailable range is memory that is used by the console, and memory that is marked unavailable by the diagnostics.
- The SET command does not apply.

Example:

```
>>> SHOW MEM
MEM_TOP = 01000000
MEM_BOT = 00000000
MEM_NOT_AVAIL
-----
00FC0800:00FFFFFF
```

4.1.2.14 MOP

The MOP bit enables the NI (Ethernet) listener while the system is in console mode. The listener can send and receive messages on the network.

- The default mode is listener enabled (MOP = 1).

Examples:

```
>>> SET MOP 1                                >>> SHOW MOP
MOP = 1                                       MOP = 1
```

4.1.2.15 PSE and PSWD

The PSE parameter is the enable console password bit. This enables the console password to restrict access to the console.

The PSWD parameter is used to set the console password.

The following are key points to remember about passwords:

- The password must be exactly 16 characters.
- Valid password characters are 0 through 9 and A through F only.
- The password feature is enabled when PSE = 1.
- The password feature is disabled when PSE = 0.
- SHOW PSWD does not apply.

Example:

```
>>> SET PSWD
PSWD0>>> xxxxxxxxxxxxxxxxxxxx ! Old password (only if a
                                password has been
                                previously set)
PSWD1>>> 1234567890ABCDEF      ! New password
PSWD2>>> 1234567890ABCDEF      ! Verify new password

>>> SET PSE 1
PSE = 1
```

NOTE

After PSE is set to 1, type LOGIN at the >>> prompt, and type the password at the PSWD0>>> prompt.

4.1.2.16 SCSI

This parameter is the SCSI ID for the system.

- The system SCSI ID should be set to 6.
- The system SCSI ID should never be changed.

Example:

```
>>> SHOW SCSI
SCSI = 6
```

4.1.2.17 TRIGGER

The TRIGGER bit enables the Entity-Based Module (EMB).

- With EMB and the NI listener enabled (TRIGGER = 1, MOP = 1) you can access the console or boot the system from a remote system.
- Refer to Section 4.2.2 for more information about remote console access.

Example:

```
>>> SHOW TRIGGER
TRIGGER = 0
>>> SET TRIGGER 1
TRIGGER = 1
```

4.1.3 Memory Commands

The following table lists console commands that manipulate memory and registers.

| Command | Function |
|---------|---|
| DEPOSIT | Enters a value(s) into memory location(s) or register(s). |
| EXAMINE | Displays the contents of memory location(s) or register(s). |

4.1.3.1 DEPOSIT Commands

The DEPOSIT command is used to write to memory locations from the console.

Syntax:

```
DEPOSIT /QUALIFIERS ADDRESS DATA
```

Table 4-4 lists the qualifiers and what each one specifies.

Table 4-4 DEPOSIT Command Qualifiers

| | |
|--------------------|---|
| Data size | /B - byte (8 bits) /W - word (16 bits) /L - longword (32 bits) /Q - quadword (64 bits) |
| Address type | /V - virtual address /P - physical address /I - internal processor register /G - general purpose register /M - machine register |
| Range of addresses | /N:X specifies that the X+1 locations be written with the value specified by DATA. |
| Protection | /U unprotects a protected memory location. An example of a protected area is the area of memory that the console uses. |

The ADDRESS specifies the address (or first address) to be written.

DATA values must be given in hexadecimal.

Example:

```
!This example writes the value 01234567 into 6 longword
!locations starting at address 00100000.
```

```
>>> DEPOSIT/P/N:5 00100000 01234567
```

```
P 00100000 01234567
P 00100004 01234567
P 00100008 01234567
P 0010000C 01234567
P 00100010 01234567
P 00100014 01234567
```

4.1.3.2 EXAMINE Commands

The EXAMINE command is used to display specific memory locations from the console.

Syntax:

```
EXAMINE /QUALIFIERS ADDRESS
```

Table 4-5 lists the qualifiers and what each one specifies.

Table 4-5 EXAMINE Command Qualifiers

| | |
|--------------------|---|
| Data size | /B - byte (8 bits) /W - word (16 bits) /L - longword (32 bits) /Q - quadword (64 bits) |
| Address type | /V - virtual address /P - physical address /I - internal processor register /G - general purpose register /M - machine register |
| Range of addresses | /N:X specifies that the X+1 locations be written. |
| Protection | /U unprotects a protected memory location. An example of a protected area is the area of memory that the console uses. |

The ADDRESS specifies the address (or first address) to be read.

Example:

!This example reads the Ethernet hardware address.

```
>>> EXAMINE/P/N:5 20090000
```

```
P 20090000 0000FF08
P 20090004 0000FF00
P 20090008 0000FF2B
P 2009000C 0000FF1B
P 20090010 0000FF48
P 20090014 0000FFE3
```

4.1.4 Processor Control Commands

The following table lists the processor control commands.

| Command | Function |
|------------|---|
| BOOT | Bootstraps the operating system. |
| CONTINUE | Starts the CPU running at the current program counter (PC). |
| INITIALIZE | Initializes processor registers. |
| START | Starts the CPU at a given address. |
| UNJAM | Sets devices to an initial state. |

4.1.4.1 BOOT

The boot command starts the bootloader, which loads the operating system and starts it. The boot command causes the system to exit console mode and enter program mode. The boot command has the following syntax:

Syntax:

```
>>> boot /qualifier device, second_device
```

Table 4-6 BOOT Command Syntax

| Term | Meaning |
|---------------|---|
| /qualifier | <p>This optional qualifier sets the value for R5 for the bootloader. It is used to select a boot on the disk, or a conversational boot.</p> <p>The qualifier can be specified in either of the following formats:</p> <ul style="list-style-type: none"> • /R5:XXXXXXXX • /XXXXXXXX |
| device, | <p>This optional term is the primary boot device. If no device is specified, the system attempts to boot the default device. You can set the default boot device with the SET BOOT command.</p> |
| second_device | <p>This optional term is the device the bootloader tries to boot if the primary boot device fails.</p> |

Example:

```
>>> BOOT /R5:00000001 DKA200, DKA400
```

The preceding example shows the system performing a conversational boot from DKA200. If the system cannot boot from DKA200, it tries a conversational boot from DKA400.

4.1.4.2 CONTINUE

The CONTINUE command switches the system from console mode to program mode. The CPU starts running at the current Program Counter (PC).

Example:

```
>>> CONTINUE
```

4.1.4.3 INITIALIZE and UNJAM

The INITIALIZE command resets the processor registers. UNJAM resets the system devices. These commands together reset the system. UNJAM should be entered first.

Example:

```
>>>INITIALIZE  
>>>UNJAM
```

4.1.4.4 START

The START command is used to set the program counter (PC) and start the CPU. The command causes the system to exit console mode and enter program mode. The syntax for the START command is:

```
>>> START ADDRESS  
! ADDRESS is the value loaded into the PC.
```

Example:

```
!This example starts the bootloader.  
>>> START 200
```

4.2 Alternate Consoles

The Model 60 provides two ways to use alternate consoles if the graphics subsystem fails. Console commands may be entered on a terminal connected to the printer port of the workstation or from a network connection. The two alternate consoles are described in the following sections.

4.2.1 Printer Port Console

To access the printer port console verify that:

- The baud rate of the terminal connected to the printer port is set at 9600 baud.
- The alternate console switch (S3) located on the front panel is up.

NOTE

The state of the alternate console switch is only read at power up. Changing the switch setting when the system is powering up has no effect until the system box is powered down and then up.

4.2.2 Network Console

The system console can also be accessed from the network. The network console allows you to remotely troubleshoot the system or provide a console when the other consoles are not available.

Some console tests and commands cause the network connection to be terminated because the commands use the network device, or they cause a connection timeout at the remote node.

To access the console you need:

- The hardware Ethernet address of the VAXstation computer.
- Access to a VMS operating system on the same Ethernet segment as the VAXstation 4000 computer (the systems cannot be separated by a bridge or router).
- The following VAXstation 4000 computer parameters must be set:
 - A console password
 - MOP, TRIGGER

Once the Model 60 is set up, perform the following steps from the other VMS operating system to connect to the console:

1. Log in to a user account (no special privileges are required).
2. Type the following commands:

| Command | Action |
|--|---|
| \$ MC NCP | Enters the Network Control Program (NCP). |
| NCP> SHOW KNOWN CIRCUITS | Shows available circuits you can connect through. |
| NCP> CONNECT VIA circuit SERVICE PASSWORD xxxxxxxxxxxxxxxx PHYSICAL ADDRESS 08-00-2B-XX-XX-XX | Connects to the console. |
| >>> console commands | Performs console functions. |
| >>> CTRL/D | Disconnects console. |
| NCP> EXIT | Exits NCP. |
| \$ LO | Logs off the system. |

Example 4-3 shows each step involved in the process.

NOTE

Do not run memory test. It causes the console to hang and you will have to power off the system.

Example 4-3 Network Console Session

\$ MC NCP

NCP>SHOW KNOWN CIRCUITS

Known Circuit Volatile Summary as of 27-MAR-1991 13:50:02

| Circuit | State | Loopback Name | Adjacent Routing Node |
|---------|-------|---------------|-----------------------|
| SVA-0 | on | | 25.14 |

NCP>CONNECT VIA SVA-0 SERVICE PASSWORD 1111111111111111 -
 _ PHYSICAL ADDRESS 08-00-2B-1B-48-E3
 Console connected (press CTRL/D when finished)
 >>> (At the >>> prompt, type LOGIN and **RETURN** if the PSE was set to 1. At the PSWD0>>> prompt, type the password.)

>>> SHOW CONFIG

KA46-A BL3-186-B3.1 ! System type and firmware revision
 08-00-2B-F3-31-03 ! Ethernet hardware address
 16 MB ! Total memory

| DEVNBR | DEVNAM | INFO | |
|--------|--------|--|-----------------------------------|
| 1 | NVR | OK | ! Non-volatile RAM |
| 2 | LCG | OK | ! 2D high res. color graphics rev |
| | | HR - 8 PLN FB - 2.7 | |
| 3 | DZ | OK | ! Serial line controller |
| 4 | CACHE | OK | ! Cache memory |
| 5 | MEM | OK | ! Memory configuration |
| | | 16MB = SY=8MB, S0/S1=8MB, S2/S3=0MB, S4/S5=0MB | |
| 6 | FPU | OK | ! Floating point accelerator |
| 7 | IT | OK | ! Interval timer |
| 8 | SYS | OK | ! Other system functions |
| 9 | NI | OK | ! Ethernet |
| 10 | SCSI | OK | ! SCSI and drives |
| | | 1-RZ23L 6-INITR | ! One RZ23L at ID 1, system at ID |
| 11 | AUD | OK | ! Sound |
| 12 | COMM | OK | ! DSW21 communications device |

CTRL/D

NCP> EXIT

\$

5

Diagnostic Testing

This chapter describes the diagnostic testing and test commands that are used with the Model 60 system. It includes procedures for setting up the diagnostic environments, running self-tests and system tests, and invoking utilities. The following topics are included in this chapter:

| | |
|--|---|
| Section 5.1 | Diagnostic Functions |
| Section 5.2 | Interpreting the System Power Up Test Results |
| Section 5.3 | Displaying System Configuration |
| Section 5.4 | Displaying Additional Error Information |
| Section 5.5 | Setting Up Diagnostic Environment |
| Section 5.6 | List of Device Tests |
| Section 5.7 | Running a Self-Test on a Device |
| Section 5.8 | Descriptions of Self-Tests |
| Section 5.9 | Setting Up System Test Environments |
| Section 5.10 | System Test Monitor |
| Section 5.10.2.1 to Section 5.10.2.4 | Descriptions of System Tests |
| Section 5.11 | Utilities |

For this troubleshooting process it is assumed that problems are not caused by such things as faulty power cords or loose modules and connectors.

Actual error codes and their meanings are provided in Appendix A.

5.1 Diagnostic Functions

The system firmware provides the diagnostic functions listed in Table 5-1.

Table 5-1 Diagnostic Functions

| Function | Description |
|--------------------|---|
| Power-up test | Tests initialization and all devices. |
| Extended self-test | Tests devices in the system sequentially with the TEST command. |
| System test | Test all devices in the system interactively. |
| Utilities | Functions for visual screen test, mass storage devices, and the network listener. |
| Error reporting | Displays error messages on the console when errors are found during power-up tests, self-tests, and system tests. |

5.2 System Power-up Test

The power-up self-test sequentially tests the devices in the system. This test takes about one minute to complete for an 8MB base system. When the test successfully completes, the console prompt is displayed. Figure 5-1 shows the prompt.

Factors increasing the test time are:

- Additional memory
Each additional 8 Mbytes adds about eight seconds.
- Additional time is required for SCSI devices.

The time to execute the power-up self-test can be reduced by setting the FBOOT parameter to 1. The system then will not test memory on power-up.

5.2.1 Power-up Sequence

Figure 5-1 and Figure 5-2 show the console screens shown when successful and unsuccessful power-up tests occur.

Refer to Section B.1.2 for a list of the power-up initialization diagnostic LED codes.

The following events summarize the power-up sequence:

- If the system finds a fatal error prior to initializing the console, the error can only be decoded from the eight error LEDs located on the lights and switches board.
Refer to the error codes in this manual. If all of the error LEDs remain on, the ROM code does not start.
- If the graphics subsystem fails self-test, the system assumes that a console terminal is connected to the console/printer port.
- If the alternate console switch located on the light and switches board is set to alternate console (switch in the up position), the system assumes that a console terminal is connected to the console/printer port.
- At the end of the power-up sequence the system enters console mode as indicated by the >>> prompt if the HALT parameter is set to 3. If the HALT parameter is set to 1 or 2, the system tries to boot the default boot device.
- During initialization, the system is configured by creating the Master Configuration Table (MCT) and the Device Configuration Table (DCT).

Figure 5-1 Successful Power-Up Self-Text





Figure 5-2 Unsuccessful Power-Up

LJ-00635-T10

The general format for error information is:

```
Fru Dev_nbr Dev_nam Err_nbr
```

Where:

- ?? - indicates a fatal error; ? indicates a non-fatal error
- Fru - the field replaceable unit of the device that failed (see Appendix D for a list of FRUs)
- Dev_nbr - the device number of the failing function
- Dev_nam - the device name of the failing function
- Err_nbr - a decimal number that corresponds to a specific device failure. This error code number indicates the function or the FRU that caused the error. Refer to Appendix A for error code descriptions.

5.3 Displaying System Configuration

The Model 60 firmware provides two configuration commands, SHOW DEVICE and SHOW CONFIG.

SHOW DEVICE determines what type of mass storage devices are included in the system.

SHOW CONFIG determines the overall system configuration.

5.3.1 SHOW DEVICE

To determine the presence of storage devices such as a hard disk, diskette drives, or other drives, at the console prompt enter:

```
>>> SHOW DEVICE Return
```

The system shows a display similar to the following:

Example 5-1 Displaying System Configuration

```
>>> SHOW DEVICE
```

| VMS/VMB | ADDR | DEVTYPE | NUMBYTES | RM/FX | WP | DEVNAM | REV |
|------------|-------------------|---------|----------|-------|----|--------|------|
| ----- | ---- | ----- | ----- | ----- | -- | ----- | --- |
| ESAO | 08-00-2B-17-EA-FD | | | | | | |
| DKA100 | A/1/0 | DISK | 121 MB | FX | | RZ23L | 1F25 |
| DKA300 | A/3/0 | RODISK | 594 MB | RM | WP | RRD42 | 1.1A |
| MKA500 | A/5/0 | TAPE | | RM | | TZK10 | 00AD |
| ..HostID.. | | INITR | | | | | |
| DKA700 | A/7/0 | DISK | 332 MB | FX | | RZ55 | 0900 |

| | |
|----------|--|
| VMS/VMB | Is operating system interpretation of what the device is. For example, with a VMS operating system, an RZ23 drive is interpreted as a DKA300. |
| ADDR | Indicates the location of the device. If the device is an Ethernet device, the ADDR column shows the Ethernet address. If the device is a system device, the first character shown is the bus (A or B); the second character represents the device number (3, 5, 6); the third field (00) is not used. |
| DEVTYPE | Shows the device type. |
| NUMBYTES | Gives the number of storage bytes |
| RM/FX | Indicates whether the media device is fixed or removable. |
| WP | Write protected, yes or no. |
| DEVNAM | Shows the device name. |

5.3.2 SHOW CONFIG

To determine the presence of devices other than internal storage devices, and to determine the quantity of memory in the system, enter:

```
>>>SHOW CONFIG Return
```

The system displays a configuration table similar to the one shown in Example 5-2.

Example 5-2 Configuration Table

```
KA46-A BL3-186-V1.0      ! System type and firmware revision
08-00-2B-F3-31-03       ! Ethernet hardware address
16 MB                    ! Total memory
```

| DEVNBR | DEVNAM | INFO | |
|--------|--------|--------------------|--------------------------------------|
| ----- | ----- | ---- | |
| 1 | NVR | OK | ! Non-volatile RAM |
| 2 | LCG | OK | ! 2D high res. color graphics rev 2. |
| | | HR ~ 8 PLN FB -2.7 | |
| 3 | DZ | OK | ! Serial line controller |
| 4 | CACHE | OK | ! Cache memory |
| 5 | MEM | OK | ! Memory configuration |

```
16MB = S0/S1=8MB, S2/S3=0MB, S4/S5=0MB
```

Example 5-2 (continued on next page)

Example 5-2 (Cont.) Configuration Table

| | | | |
|----|------|-----------------|--------------------------------------|
| 6 | FPU | OK | ! Floating point accelerator |
| 7 | IT | OK | ! Interval Timer |
| 8 | SYS | OK | ! Other system functions |
| 9 | NI | OK | ! Ethernet |
| 10 | SCSI | OK | ! SCSI and drives |
| | | 1-RZ23L 6-INITR | ! One RZ23L at ID 1, system at ID 6. |
| 11 | AUD | OK | ! Sound |
| 12 | COMM | OK | ! DSW21 communications device |

>>>

To determine the quantity of memory in the system, note line 5, the MEM line, in the example. This line shows 8 Mbytes for the system board and 8 Mbytes for memory module slots 0 and 1).

5.4 Displaying Additional Error Information

Use the SHOW ERROR utility to obtain detailed error information about any failing device. To determine if an error has occurred on a particular device, type SHOW ERROR followed by the device number. To show all of the system errors, type SHOW ERROR. If errors are present, a display similar to Example 5-3 is shown.

Example 5-3 SHOW ERROR

```
>>> SHOW ERROR

?? 001  03  DZ      0023
      001 0010    00000001 00000001 00003f30 00000001

?? 001  09  NI      0009
      001 0001    200e0000 00005555 00005515

>>>
```

The general format for error information is:

Fru Dev_nbr Dev_nam Err_nbr

Where:

- Fru - is the field replaceable unit of the failed device.
- Dev_nbr - is the number of the failing device.
- Dev_nam - is the name of the failing device.

- Err_nbr - is a decimal number corresponding to a specific device failure. This number is used to reference various error tables when performing problem isolation and repair procedures.

5.5 Setup Required for Self-Tests

You must do the following before running a self-test:

| Step | Action | Comment |
|------|------------------------------------|--|
| 1 | Put the system in console mode. | Shut down the operating system or power up the system if you do not have the console prompt. |
| 2 | Select the diagnostic environment. | See Table 5-2. |
| 3 | Attach loopbacks if required. | See Table 5-3. |

5.5.1 Selecting a Diagnostic Environment

The system diagnostics and utilities can run in one of three environments:

- Customer environment - requires no setup beyond installation of the system. Type SET DIAGENV 1 at the >>> prompt to access.
- Digital Services environment - requires loopbacks and setup, but provides a more comprehensive test. The Key utilities require must be run in this environment. Type SET DIAGENV 2 at the >>> prompt to access.
- Manufacturing environment - for manufacturing use. Type SET DIAGENV 3 at the >>> prompt to access. (**CAUTION: Do not use this environment for customers as it may destroy customer data.**)

To set the diagnostic environment, enter one of the console commands listed in Table 5-2.

Table 5-2 SET DIAGENV Command

| Command | Result |
|----------------------|---|
| SET DIAGENV 1 | Resets environment to Customer mode. |
| SET DIAGENV 2 | Sets environment to Digital Services mode. |
| SET DIAGENV 3 | Sets environment to Manufacturing mode. |
| SET DIAGENV 80000001 | Sets environment to loop on error in Digital Services mode. |
| SET DIAGENV 80000002 | Sets environment to loop on error in manufacturing mode. |

Example:

Example 5-4 SET DIAGENV

```
>>> SET DIAGENV 2
      DIAGENV = 2
>>> SHOW DIAGENV
      DIAGENV = 2
```

5.6 Device Tests

Table 5-3 lists the device tests and corresponding mnemonics, decimal ID, binary ID, and loopback requirements.

Table 5-3 Device Test IDs and Mnemonics

| Device | Mnemonic | Decimal ID | Binary ID | Loopback Required, Digital Services Env. |
|----------------------------------|-----------------|-------------------|------------------|---|
| Non-Volatile RAM | NVR | 1 | 0001 | No |
| 2D or other Graphics | LCG or xxx | 2 | 0010 | Monitor on low res. 2D |
| Serial line controller | DZ | 3 | 0011 | Yes, on comm. port |
| Cache system | CACHE | 4 | 0100 | No |
| Memory | MEM | 5 | 0101 | No |
| Floating point accelerator | FPU | 6 | 0110 | No |
| Interval timer | IT | 7 | 0111 | No |
| Other system board hardware | SYS | 8 | 1000 | No |
| Network interface | NI | 9 | 1001 | Yes, or connected to a network |
| SCSI Controller | SCSI | 10 | 1010 | No |
| Sound chip | AUD | 11 | 1011 | No |
| Synchronous comm or other option | COMM or xxx | 12 | 1100 | No, but H3199 required for Manufacturing environment. |

5.7 Running Self-Tests

This section describes the test command interface used to run the self-test on a device. Table 5-4 shows the general format for running the self-test using the test command.

Table 5-4 Running the Self-Test

| Command | Action |
|---------|---|
| T 1 | Run self-test on device number 1 |
| T 1:4 | Run self-test on devices numbered 1 through 4 |
| T 1,2 | Run self-test on devices 1 and 2 |

To test a range of devices, separate the device numbers being tested by a colon (:). To separate individual tests or ranges of devices, use a comma or space bar. For example,

T 8:10,6,3:5 tests devices 8 through 10, tests device 6, and then tests devices 3 through 5

Figure 5-3 gives an example of the console display when successful and unsuccessful self-tests have been run.

Figure 5-3 Successful and Unsuccessful Self-Test

| Successful | Unsuccessful |
|--|--|
| <pre>>>> T 10 8 +-----+ [REDACTED] >>></pre> | <pre>>>> T 10 8 +-----+ [REDACTED] ?? 001 09 NI 0022 >>></pre> |

LJ 00116 T10

The format of the error message is identical to the power-up self-test error message shown in Figure 5-3.

5.7.1 Running a Single Device Self-Test

To run a single device self-test, type the TEST command using the following syntax:

Example 5-5 TEST - Single

```
>>> TEST xxx
```

Where:

xxx is the device mnemonic or ID (decimal) listed in Table 5-3.

Example 5-6 Running a Single Device Test

```
>>> TEST MEM
```

This command tests main memory.

5.7.2 Running Multiple Device Self-Tests

Multiple device self-tests can be specified with the TEST command. The device tests are executed one at a time in the order specified in the command line.

The devices can be specified individually, or as a range using the conventions listed in Table 5-5:

Table 5-5 Multiple Test - Syntax Rules

| IDs | Syntax |
|---------------------------------------|--|
| Individual device IDs | Separate the device IDs with a comma. |
| A range of device IDs | Separate the range limits with a colon. |
| Combination ranges and individual IDs | Separate the ranges and individual IDs with a comma. |

Table 5-6 lists the formats for running multiple device tests.

Table 5-6 Formats for Running Multiple Tests

| Format/Example | Action |
|-----------------------|---|
| TEST xxx,yyy | Execute self-test on devices xxx and yyy. |
| TEST 1,5 | Execute self-test on main memory and the NVR. |
| TEST xxx:yyy | Execute self-tests on devices xxx through yyy. |
| TEST 1:4 | Execute self-tests on NVR, LCG, DZ and CACHE. |
| TEST xxx:yyy,zzz | Execute self-tests on devices xxx through yyy and device zzz. |
| TEST 1:4,6 | Execute self-tests on NVR, LCG, DZ, CACHE and FPU. |

5.7.3 Running a self-test Continuously

You can run a self-test sequence continuously using the console REPEAT command. The REPEAT command executes a command continuously until you type the **Ctrl** **C** key sequence at the console or until an error occurs:

Example 5-7 Running a Self-Test Continuously

```
>>> REPEAT TEST 1:4
```

In this example, device tests 1 through 4 run continuously until you type the **Ctrl** **C** key sequence at the console.

5.8 Descriptions of Self-Tests

This section describes the self-tests that are listed in Table 5-3.

NOTE

The self-tests are arranged by decimal ID. The self-test's decimal ID appears in parentheses.

5.8.1 TOY/NVR Self-Test (1)

Setup Notes

- There are no extended error messages for the NVR test.
- Non-fatal errors (indicated by a single question mark (?)) indicate the time in the NVR has not been set and is not a hardware fault.

The self-test includes the NVR/TOY self-tests.

NVR Test - Checks the NVR for valid data. If the NVR is not initialized, a register test is performed on all of the NVR locations and the NVR is initialized. If the NVR is not initialized, **ONLY** the temporary locations are tested in the NVR.

TOY Test - Checks to see if time has been set in the TOY. If not, a test of all the TOY registers is performed. This test writes/reads all possible values a TOY register can hold.

Refer to Table 5-4 and Table 5-3 for information on running the TOY/NVR self-test. Refer to Section A.2.1 for a list of the TOY/NVR error codes and Section B.1.3 for a list of the TOY/NVR diagnostic LED codes.

5.8.2 LCG Self-Test (2)

Setup Notes

- This test does not run in customer mode because it clears the console.
- A monitor must be connected to the low resolution graphics board.
- The console only uses the left port on the dual monitor board.
- The LCG test does not run extended tests in customer mode (DIAGENV 1) because it clears the console. Refer to Section 4.1.2.6 for information on DIAGENV parameters.
- DIAGENV = 2 and requires a 29-24795 total loopback connector installed in the communication port.

- The low resolution frame buffer clock jumpers must be installed correctly before power-up.
- The low resolution monitors must be connected during the LCG self-test.
- Only one port can be the console port on a dual head high resolution frame buffer.
- The panel Alternate Console switch must be in the DOWN position for graphics console or in the UP position for the DZ port.

The self-test includes the following tests:

Video Test - Tests the VRAM memory and the communication between the S-chip and VRAM. It initializes the Brooktree and sets up the video screen. It also sets up the video registers in the S-chip.

Register Test - Uses the longword format to read/write test all LCG S-chip registers.

FIFO Test - Creates a FIFO and clip list in the contiguous physical memory and tests set up packets, int/status bits, put/get pointers, FIFO and clip control flags, FIFO status bits; and makes sure that the FIFO can be reset.

AG Test - Calls all of the LCG address generator specific self-test routines. These routines test the drawing functions, logic unit functions and glyph functions.

Virtual Addressing Mode Test - Calls all the LCG virtual drawing specific self-test routines.

Refer to Table 5-4 and Table 5-3 for information on running the LCG self-test. Refer to Section A.2.17 for a list of the LCG self-test error codes and Section B.1.4 for a list of the LCG diagnostic LED codes.

5.8.3 DZ Self-Test (3)

Setup Notes

- The DZ interrupt test fails in the Digital Services or manufacturing environments if no external loopbacks are present on the communication port.
- The mouse test fails if the mouse is not plugged in and the console is a video device.
- The LK401 test fails if the LK401 is not plugged in and the console is a video device.

- A keyboard and pointing device must be plugged in, or an error is reported.
- When you are in the Digital Services or Manufacturing environments, loopbacks must be used on the standard communications port.

The self-test includes the following tests:

Reset Test - Resets the DZ chip and sets up its lines to their default values. An error occurs if the device does not reset or the line parameters do not get set up properly.

Polled Test - Tests each line in the internal loopback mode by using the chip in the polled mode. Characters are transmitted out a line and are expected to be looped back.

Interrupt Test - Tests each line running interrupt driven. If the diagnostic environment is Digital Services or manufacturing, the lines are tested using an external loopback device on the communication port. Interrupts are disabled and characters are sent out the lines not being used by the console device. The characters are expected to be looped back.

LK401 Test - Checks for the presence of an LK401 when the console device is a video device.

Mouse Test - Checks for the presence of a mouse when the console device is a video device.

Refer to Table 5-4 and Table 5-3 for information on running the DZ self-test. Refer to Section A.2.2 for a list of the DZ self-test error codes and Section B.1.5 for a list of the DZ diagnostic LED codes.

5.8.4 CACHE Self-Test (4)

The self-test includes the following tests:

DATA Store Test - Tests the data store in the Model 50 primary cache. A two pass memory test is performed on the data store. This test performs a read/compare/complement/write in both the forward and reverse directions. The data store is accessed through the I/O address space. Only the cache banks enabled in the BEHR are tested.

TAG Store Test - Tests the tag store in the Model 60 primary cache. A two pass memory test is performed on the tag store. This test performs a read/compare/complement/write in both the forward and reverse directions. The tag store is accessed through the I/O address space. Only the cache banks enabled in the BEHR are tested.

Refer to Table 5-4 and Table 5-3 for information on running the CACHE test. Refer to Section A.2.16 for a list of the CACHE test error codes and Section B.1.6 for a list of CACHE test diagnostic LED codes.

5.8.5 Memory Self-Test (5)

Setup Notes

- If memory modules are not configured correctly, the memory test fails, and the memory modules will not be configured. Memory modules must be installed in pairs, with the 16MB modules installed behind the 4 MB modules. Refer to Section 6.5.2 for further information on memory module configuration.

The self-test includes the following tests:

Byte Mask Test - Checks the byte mask signals that are generated by the CPU. This test is performed on each page boundary. Once the test is complete, all free memory is filled with AAh.

Memory Test (forward) - Performs a read/compare/complement/write on the memory in the forward direction. If a page is found to be bad, the appropriate bit in the memory bitmap is cleared.

Memory Test (reverse) - Starts at the last address to be tested and performs a read/compare/complement/write on memory. If a page is found to be bad, the appropriate bit in the memory bitmap is cleared.

Final Parity - Fills all of memory with a pattern of 01h (an odd bit pattern) to verify that the parity bit can be changed. This pattern is read and verified. A parity error occurs if the parity bit is not changed. The pattern 01010101h is the known stat of unused memory after power-up.

Refer to Table 5-4 and Table 5-3 for information on running the LCG test. Refer to Section A.2.3 for a list of the memory test error codes and Section B.1.7 for a list of the memory test diagnostic LED codes.

5.8.6 Floating Point Unit Self-Test (6)

The self-test includes the following tests:

Instruction Tests - These tests are performed on the FPU. A failure occurs if the instruction produces unexpected results or an unexpected exception occurs during the execution of the instruction.

Refer to Table 5-4 and Table 5-3 for information on running the FPU test. Refer to Section A.2.15 for a list of the FPU test error codes.

5.8.7 Interval Timer Self-Test (7)

The Interval timer self-test includes the following tests:

Interrupt Test - Enables the interval timer interrupts. It lowers the IPL for 30 ms and counts the number of interrupts. If there are too few or too many interrupts, an error occurs.

Refer to Table 5-4 and Table 5-3 for information on running the Interval Timer test. Refer to Section A.2.4 for a list of IT test error codes.

5.8.8 System Self-Test (8)

The system self-test includes the following tests:

System ROM - Checks the system ROMs one byte at a time to ensure that they contain the correct manufacturing check data and the correct checksum.

Filter RAM - Makes two passes on the invalidate filter RAMS. The test detects all stuck addressing and data faults.

Refer to Table 5-4 and Table 5-3 for information on running the system test. Refer to Section A.2.5 for a list of the system test error codes and Section B.1.8 for a list of the system test diagnostic LED codes.

5.8.9 Network Interconnect Self-Test (9)

Setup Notes

- You must install an external loopback connector or a network connection (cable) at the selected network port before running a self-test.

The NI self-test includes the following tests.

Refer to Section A.2.22 for a complete list of NI tests and their error codes.

Network Address ROM Test - Verifies the 32 byte network address ROM which contains the unique 6 byte network address along with the 2 byte checksum and test data byte. It checks for a null or multicast address, calculates/compares the checksum, and verifies the test data bytes.

LANCE Register Test - Tests the address and data paths to the LANCE register address port (RAP) and the register data port (RDP) for each of the four Control Status Registers (CSRs).

LANCE Initialization Test - Sets up the LANCE data structures and initializes the LANCE chip, which causes the LANCE to perform a single word DMA read to the system memory.

LANCE Internal Loopback - Verifies the correct operation of the LANCE transmitter and receiver during an internal loopback. It also verifies the burst-mode DMA read and write on non-word-aligned data buffers for packets of different lengths and data patterns.

LANCE Interrupt Test - Enables, forces, and services the LANCE interrupts for initialization, transmission and reception using internal loopback.

LANCE CRC Test - Tests the LANCE CRC generation on transmission. It checks for detection of a bad CRC on reception using internal loopback.

LANCE Receive MISS/BUFF Test - Checks LANCE operation for missed packets and buffer error during reception with internal loopback.

LANCE Collision Test - Verifies collision detection and retry during transmission with internal loopback.

LANCE Address Filtering Test - Tests the LANCE receiver address filtering for broadcast, promiscuous, and null destinations during internal loopback.

Refer to Table 5-4 and Table 5-3 for information on running the NI test. Refer to Section A.2.22 for a list of the NI test error codes and Section B.1.9 for a list of the NI test diagnostic LED codes.

5.8.10 SCSI Self-Test (10)

Setup Notes

- CDROM devices will fail in extended mode if media is not installed in removable media drives.
- If some or all devices do not show up in the configuration display after running the test, make sure all devices have a unique ID number. Make sure power is supplied to all devices and the system module. Check to make sure the SCSI cable is connected to the system module and devices, and that the bus is terminated.
- All expansion boxes must have power supplied **BEFORE** the system box is powered up, or the expansion box devices will not be configured.

- Common causes of errors or devices missing from the configuration include:
 - SCSI bus is not terminated.
 - All device IDs are not unique.
 - Internal cables to the drives are disconnected.

Refer to Table 5-4 and Table 5-3 for information on running the SCSI test. Refer to Section A.2.6 for a list of SCSI test error codes and to Section B.1.10 for a list of SCSI test diagnostic LED codes.

The self-test includes the following tests:

Register Test - Verifies that the 53C94B controller chip registers are fully functional. All read/write bits that can be written are written to. It also verifies the bits.

Interrupt Test - Verifies the SCSI bits in the interrupt mask register, interrupt request register, and the interrupt clear register. A SCSI interrupt is forced, with the SCSI bit in the interrupt mask first set and then cleared. This is repeated for both a high interrupt priority level and a low priority level.

Data Transfer Test - Verifies SCSI bus communication between the controller and the available peripherals and also the data path of the controller to the S-chip and to memory. A series of four inquiry commands are issued to each device. The commands are issued in the programmed I/O mode, asynchronous mode with DMA, asynchronous mode with the DMA starting on a non-word-aligned boundary and crossing a page boundary, and synchronous mode with DMA.

5.8.11 Audio Self-Test (11)

Refer to Table 5-4 and Table 5-3 for information on running the audio test. Refer to Section A.2.10 for a list of the audio test error codes and to Section B.1.11 for a list of audio test diagnostic LED codes.

The self-test includes the following tests:

Register Tests - Performs a write/read to registers in the 79C30 DSC chip.

Interrupt Test - Enables interrupts, sends and receives an 8-byte packet by way of internal loopback.

Audio Test - Generates and outputs a sequence of eight audible tones.

5.8.12 Synchronous Communication Self-Test (12)

Setup Notes

- If Digital Services environment is used (SET DIAGENV 2), an H3199 loopback should be used.

Refer to Table 5-4 and Table 5-3 for information on running the Synchronous Communication test. Refer to Section A.2.11 for a list of the synchronous communication test error codes and to Section B.1.12 for a list of the synchronous communication test diagnostic LED codes.

Test 1 - Checks the checksum; read 128 Kbyte ROM part and verify checksum.

Test 2 - Checks the static RAM; write, verify, complement, verify 256K RAM.

Test 3 - Performs the MC68302 test.

Test 4 - Checks the RAM dual access; shared RAM bus arbitration.

Test 5 - Checks the EPROM dual access; EPROM bus arbitration.

Test 6 - Checks the host interrupt; verifies option can interrupt the CPU.

Test 7 - Checks the host buffer loopback and interrupt; moves data from the CPU to the communication option, loops it back and waits for an interrupt.

Test 8 - Resets the communication options and waits for an interrupt.

5.9 System Test

The system test is a strenuous test of the workstation. All devices are exercised simultaneously to find system interaction problems. The system test can be used to find faults that only occur when the system interaction is high.

The system test can be run in three environments, which you select with the SET DIAGENV command. Refer to Section 5.5.1 for information on selecting the diagnostic environment.

Important points to note about the system test are:

- Runs under a modified VAXELN kernel which is loaded from ROM.
- Causes a worst case environment in terms of system interaction, using maximum DMA and interrupts.

5.10 System Test Monitor

This section describes the test command interface to be used for running the system test on a device or on the whole system. Table 5-7 shows the general format for running the system test with the test command.

Table 5-7 Running the System Test Using the Test Command

| Command | Action |
|--------------------|--|
| T 100 | Run system test in the Customer environment for two passes. |
| T 101 | Run system test in the Digital Services environment for two passes. |
| T 102 | Run system in the Digital Services environment. Type ^C to exit. |
| T 103 ¹ | Run system test in the Manufacturing environment. Type Ctrl C to exit. |
| T 106 | Run system test for specific devices. System prompts for specific device. 1=Yes, 0=No. |

¹This test writes over data on hard disks. Do not use in the customer environment; it erases customer data. This test runs the system test in the Manufacturing environment. Type **Ctrl** **C** to exit.

NOTE

Make sure that loopback connectors are installed while in the Digital Services environment. SET DIAGENV 2 to run in Digital Services mode. (Table 4-2 and Table 5-2 contain descriptions and commands for the diagnostic environments)

The following examples show the output from system test commands.

Example 5-8 System Test Commands


```
>>> T 101          !Runs two passes of system
                    test in customer mode.

>>> T 106          !Runs system test for specific
                    devices. System will prompt for
                    specific device. 1 = yes; 0 = no.
```

5.10.1 Display from the System Test

Figure 5-4 shows the output from a successful system test.

Figure 5-4 Successful System Test




Where:

- KA46-A - is the system module ID.
- V1.0 - is the ROM version.
- CU - is the environment in which the test is running.
- 00 00:02:00.03 - is the CPU time used during testing.

Figure 5-5 shows the display when the system test is unsuccessful.

Figure 5-5 Unsuccessful System Test



LJ 00119 T10

When a device fails, the device status line in the display becomes the error message. You can get extended error information using the **SHOW ERROR** command. Interpretation of the error code is explained in Appendix A.

5.10.2 System Test Summary Screens

You can get summary information about the most recent system test using either of the following two methods:

- By interrupting system test by entering the **Ctrl C** key sequence. This stops the system test and displays summary screens for the devices. The display prompts for each summary screen. It can take a few moments after entering **Ctrl C** to view the summary screens. This time is needed to clean up the interrupted system test.
- By typing **>>> SHOW ESTAT** from the console prompt. This displays the summary from the most recent system test since power up. The display prompts for each summary screen.

A sample summary screen is in Figure 5-6.

Each system diagnostic is also able to display extended status and error information on its own summary screen. Figure 5-6 shows an example of the summary screen with a SCSI failure.

Figure 5-6 Summary Screen

| 10 SCSI 000101 000125 00 00:01:56:01 | | | | | |
|---|--------|-----|------|--------|--------|
| targ | devnam | rds | wrts | snddia | sfterr |
| 0 | RZ24 | 123 | 123 | 35 | 0 |
| 1 | RZ56 | 123 | 0 | 34 | 0 |
| 3 | RRD42 | 123 | 0 | 35 | 0 |
| Ext err | | | | | |
| 00000045 00301004 45670000 00004543 08003589 98001234 | | | | | |

5.10.2.1 DZ System Test

NOTE

Be sure that loopback connectors are installed when in the Digital Services environment.

Functional Mode - Tests all the lines other than the lines dedicated to the console. Loopback testing is done in all legal combinations of baud rate, parity, and character width. In Digital Services mode, external loopback testing is performed.

Burst Mode - Performs in the same way as functional mode except the lines are tested at 19.2K baud, 8 bit characters, and parity is odd.

The following is an example of the DZ system test error.

```
?? 001 3 DZ 0220
```

This error code means that not all characters were received on line 1 and line 2.

The following is an example of the DZ system test summary screen:

| Line | L_Param | Chr_Xmt | Chr_Rec | Error |
|------|---------|---------|---------|-------------------|
| 0 | 1fc8 | 25 | 25 | ***** No Err *** |
| 1 | 1fc9 | 25 | 22 | ?? Xfr Timeout |
| 2 | 1fca | 25 | 24 | ?? Xfr Timeout |
| 3 | 1fcd | 0 | 0 | * Not Tstd - Cons |

The summary screen gives information about the DZ test. The first column lists the serial line number that corresponds to the following devices:

- Line 0 - Keyboard port
- Line 1 - Mouse/Pointing device port
- Line 2 - Communications port
- Line 3 - Printer/Console port

5.10.2.2 Network Interconnect System Test

Setup Notes

- The selected NI port must be connected to a network, or have a loopback installed.
- A more thorough test is done if the system is connected to a live network and MOP is enabled.
- Maximum testing of hardware occurs on a live network with MOP enabled.

The network system test tests the network port using external loopback packets. The packets vary in size from 1 byte of data to 32 bytes of data. The pattern for the packets comes from a set of 8 patterns: AA, 55, 34, CB, 99, 66, 43, and BC.

The following is an example of a network system test error:

Example 5-9 System Test Error - Network

```
?? 9 NI 0001 xxxx 8:15:02
    where xxxx is the error code
```

5.10.2.3 SCSI System Test

CAUTION

Do not use manufacturing mode in the field; this erases customer data on hard disks, excluding the system disk.

Setup Notes

- If some or all devices do not show up in the summary screen after running system test, that all devices have unique ID numbers.
- Make sure the power cable is connected to the devices and the system module.
- Make sure the SCSI cable is connected to the system and the devices terminate and terminate the SCSI bus.
- When in Digital Services or manufacturing mode, media must be present in the removable media drives, otherwise an error occurs.
- When in manufacturing mode, removable media must be write protected when present in the drives, otherwise an error occurs.

- In order for destructive testing to be performed in Digital Services mode, a key pattern must be on the removable media disks and tapes.

The system test includes the following tests:

Inquiries Test - Performs inquiries to find out which devices are connected to the SCSI bus.

Size Bus Test - Spins up all the hard disk drives, makes sure the drives are ready (if not in customer mode), forces disk block sizes to 600 bytes, and obtains the capacity of the drives. This test also checks that removable media are write protected; checks that key pattern is present on removable media in Digital Services mode, and that VMS boot block is present on the hard disk drives when in manufacturing mode.

Data Transfer Test - Verifies SCSI bus communication between the controller and available peripherals. It also verifies the data path of the controller to the S-chip and to memory.

Device Test - Verifies the peripheral devices attached to the SCSI bus, and the DMA data path. Interrupts are enabled.

The following is an example of a successful SCSI system test display:

```
10 SCSI ##### 4
```

The following example shows an unsuccessful (error) SCSI system test display:

```
?? 10 SCSI 150 0076 8:18:41
```

The display shows an error on ID 5.

The following is an example of the SCSI system test summary display.

Example 5-10 System Test Summary Screen - Display

| ADR | RDS | WRTS | ERR | FRU | CMD | PHS | INF | LBNSTRT | XFERSIZ |
|-------|-------|------|-----|-----|-----|-----|-----|---------|---------|
| 1/0 | 10987 | 0 | | | | | | | |
| 3/0 | 5643 | 5643 | | | | | 36 | 1378 | 119 |
| 4/0 | 28 | 28 | 160 | 150 | 28 | 1 | | | |
| ----- | | | | | | | | | |
| 4/0 | XX | XX | XX | XX | XX | XX | XX | XX | XX |

Data is destroyed on hard disks in the manufacturing environment, except for disks with factory installed software.

Data is not be destroyed on hard disks in the Digital Services environment.

All expansion boxes must have power supplied **BEFORE** the system box is powered up, or the expansion box devices will not be configured.

Common causes of errors or devices missing from the configuration include:

- SCSI bus not terminated.
- All device IDs are not unique.
- Internal cables to the drives are disconnected.

The summary screen lists the test results by device ID.

When in the Digital Services environment, media must be present in all removable media devices.

In order for writes to occur, a key pattern must be installed on writable removable media (floppies and tapes). The key pattern is put on the media via the SCSI utilities. This is described in Section 5.11.6.

5.10.2.4 DSW21 Communication System Test

The system test loads and runs 68302 test/scheduler.

The following shows a DSW21 communication system test error:

```
?? 12 COMM 020 001E 0 00:00:15.00
```

The following is an example of the DSW21 communication system test summary:

Example 5-11 Communication System Test - Display

```
COMM Test Summary Screen....
-----
SCC1 Tx:          36 Rx:          36 Err:          0 INT-NOCABLE
SCC2 Tx:          36 Rx:          36 Err:          0 EXT-H3199
SCC3 Tx:          36 Rx:          36 Err:          0 INT-NOCABLE
```

Example 5-11 (continued on next page)

Example 5-11 (Cont.) Communication System Test - Display

```
Status Block:
-----
FRU: 14 FTY: 6
CSR: 30 STA: 1
HWV: 2 SWV: 5
CC1: F CC2: 0
MOD: 1 CNT: 1
CHN: 2 SEL: 2
PROT: 3 SCM: 9CF
```

5.11 Utilities

TEST commands run or display available utilities. Utilities can either be run with all parameters input at the command line or the utilities prompt for additional input. The format for a utility test that runs completely from the command line is shown below:

```
>>> T [EST/UT[ility] dev_nbr util_nbr opt_p1,...,opt_pn
```

Where:

- **dev_nbr** - is the number of the device on which you want to run the utility.
- **util_nbr** - is the number of the utility you want to run. The devices can have more than one utility.
- **opt_p1,...,opt_pn** - is the optional parameters that could be needed by a utility. For example, a SCSI utility could need to know the target ID of the device on which to run the utility.

If you are not familiar with the utilities a device has available, enter the **TEST/UTILITY** command followed by a device number or utility mnemonic (such as LCG or SCSI). The utility prompts for additional information, if needed. For example, to run an LCG utility, do the following:

1. Type **T/UT 2**.

The LCG's main utility routine displays a list of the available utilities (as shown in Figure 5-7) and then displays the prompt **LCG_util>>>**.

2. Enter the utility number that you want to run.

In the following example, utility 8 was selected.

Figure 5-7 Utilities List

```

>>> T/UT 2

0 - LCG-wh-scrn
1 - LCG-rd-scrn
2 - LCG-bl-scrn
3 - LCG-gn-scrn
4 - LCG-4c-cbar
5 - LCG-8c-cbar
6 - LCG-8g-gscl
7 - LCG-ee-scrn
8 - LCG-ci-xhct
9 - LCG-sc-hhhs

LCG util>>> 8

```

LJ 00117 T10

You may exit the utility from the prompt by pressing **Return**.

Press the space bar to return to the utility menu after it has run.

Control returns to the console if an invalid utility number is entered.

Enter the **Ctrl** **C** key sequence to exit the utility after the test has run.

If you run a utility that will destroy the contents of a mass storage device, the following displays:

```
dev_nam OK ?
```

Where:

- dev_nam - is the device whose contents will be lost.

Enter the letters "OK" followed by **Return** to start the utility. If any other combination of keys is entered, the control is returned to the console.

The console firmware provides the following utilities:

| Utility Group | Functions |
|---------------|---|
| LCG | Provides colored screens and geometric patterns. |
| NI | Set and show commands for: <ul style="list-style-type: none"> • MOP - NI listener • Trigger - Entity-Based Module (EMB) |
| SCSI | Key utilities, floppy formatter, and disk eraser |

5.11.1 LCG Utilities

The LCG Utilities provide ten screens of color bars and geometric programs. The following table describes how to use and exit the LCG Utility:

| Action | Command |
|--|---|
| Enter the LCG Utility | >>> TEST/UTIL LCG |
| Display a screen | Enter a command number at the LCG_util >>> prompt. |
| Go back to the LCG menu | Press the space bar |
| Go back to the LCG menu and clear the screen | Enter the Ctrl C key sequence. |
| Exit the LCG utility | Enter the Ctrl Y key sequence while a pattern is active |

5.11.2 LCG Utility Menu

The following example shows the LCG Utilities menu:

Example 5-12 LCG Utilities Menu

```

0 - LCG-wh-scrn      !White screen
1 - LCG-rd-scrn      !Red screen
2 - LCG-bl-scrn      !Blue screen
3 - LCG-gr-scrn      !Green screen
4 - LCG-4c-cbar      !4 color bars
5 - LCG-8c-cbar      !8 color bars
6 - LCG-8g-gscl      !8 gray scale bars
7 - LCG-ee-scrn      !Screen of EEs
8 - LCG-ci-xhct      !Cross hatch with circle
9 - LCG-sc-hhhs      !Screen of scrolling HHs

LCG_util >>>      !LCG utility prompt

```

5.11.3 NI Utilities

The NI utilities are invoked by SET or SHOW commands, not by the TEST/UTIL command. The NI utility functions are:

- SET/SHOW MOP - enable/disable NI listener
- SET/SHOW TRIGGER - enable/Disable EMB

5.11.4 NI Listener

The NI listener can send and receive messages while the system is in console mode. The operation of the NI listener is transparent to the console, and NI listener errors are not reported. Listener failure can only be detected with the use of a network monitor device. The default is NI listener enabled.

To enable the listener, type the following:

Example 5-13 Enabling Listener

```
>>> SET MOP 1
```

To disable the listener, type the following:

Example 5-14 Disabling Listener

```
>>> SET MOP 0
```

5.11.5 EMB

The EMB (Entity-Based Module) is used to enable the remote console and remote boot. Remote boot allows another system to send a boot message to the workstation to start the bootloader. The remote console is presented in Section 4.2.2.

To enable the MOP boot type the following:

Example 5-15 Enabling MOP

```
>>> SET TRIGGER 1
```

To disable the MOP boot type the following:

Example 5-16 Disable MOP

```
>>> SET TRIGGER 0
```

5.11.6 SCSI Utilities

The SCSI utilities are as follows:

| | |
|--------------------------|---|
| SHOW DEVICE | This is a console command that displays information about the Ethernet controller and the SCSI drives attached to the system. This is described in Section 4.1.2.5. |
| Floppy Key Utility | This utility is used in Digital Services mode. The key utility writes a key on block 0 of the floppy media. The key is used by System Test in Digital Services mode. If the key is found on the media, the System Test writes to the media during the test. If the key is not found during the system test, only reads are done to the media. |
| Tape Key Utility | This utility is used in Digital Services mode. The key utility writes a key at the beginning of the tape media. The key is used by the system test in Digital Services mode. If the key is found on the media, the System Test writes to the media. If the key is not found, only reads are done to the media. |
| Hard Disk Erase Utility | This utility erases all data from a hard disk. The pattern AA (hexadecimal) is written to all bytes on the disk. Any bad blocks are revectorred. |
| Floppy Formatter Utility | This utility formats a floppy disk and erases it. |

5.11.7 Invoking SCSI Utilities

To invoke the SCSI utilities, perform the following steps:

| Step | Action | Result |
|------|-------------------------------|---|
| 1 | Enter TEST/UTIL SCSI command. | Displays the SCSI Utility Menu |
| 2 | Enter utility number | Selects the utility. |
| 3 | Enter SCSI ID | Selects the drive. |
| 4 | Enter SCSI LUN (always 0) | Logical unit number (LUN) |
| 5 | Enter OK if requested | Verifies action for formatter and erases utilities. |

5.11.8 SCSI Utility Menu

Example 5-17 SCSI Utilities Sample Session

```
>>> T/UT 10                ! Type in this command (or T/UT SCSI)

1 - SCSI-flp_key            ! Floppy key utility.
2 - SCSI-tp_key             ! Tape key utility.
3 - SCSI-hd_dis_eras        ! Hard disk erase.
4 - SCSI-flp_fmt            ! Floppy formatter.

SCSI_util>>> 3              ! Type in utility number
SCSI_id(0-7)>>> 5           ! Type in SCSI device ID
SCSI_lun(0-7)>>> 0          ! Type SCSI logical unit
                             number (always 0).


    SCSI HD_DSK_ERAS_UTIL

DKA500 OK ? ok              ! Confirm the action.

#####                     ! Progress banner on ERASE
                             and FORMAT only.

SCSI_util_succ              ! Utility finished.
```

Figure 5-8 SCSI Utilities Display



LJ 01469 T10

5.11.9 SCSI Utility Notes

Follow these guidelines about the SCSI utilities:

- The key utilities can only be run from Digital Services mode. An error code of 181 displays if you run the key utilities from Customer mode.
- Never run a SCSI utility on the Host ID (ID = 6).
- An error mnemonic of SCSI_E_type indicates you cannot perform the utility on the specified device, for example, running the tape key utility on a fixed disk.
- On the formatter and erase utilities, you must type OK at the DKAxix OK prompt, or an error appears.
- An error occurs if an invalid device ID and logical unit number (always 0) are entered. Type SHOW DEVICE from the console prompt for the correct IDs.
- If a drive is not listed in the SHOW DEVICE table, check SCSI and power connections, and for duplicate device IDs.

6

FRUs Removal and Replacement

This chapter describes how to remove and replace the field replaceable units (FRUs) in the Model 60 system box. Appendix D lists the Model 60 FRUs and their part numbers.

Each section describes the removal procedure for the FRU. Unless otherwise specified, you can install a FRU by reversing the steps in the removal procedure. The topics covered in this chapter are:

| | |
|-------------|---|
| Section 6.1 | Precautions |
| Section 6.2 | System Preparation |
| Section 6.3 | Mass Storage Drive Removal and Replacement |
| Section 6.4 | Power Supply Removal and Replacement |
| Section 6.5 | Module Removal and Replacement |
| Section 6.6 | DSW21 Communications Option Removal and Replacement |
| Section 6.7 | Bezel Removal and Replacement |
| Section 6.8 | Clearing System Password |
| Section 6.9 | Testing the System |

6.1 Precautions

Only qualified service personnel should remove or install FRUs.

NOTE

It is the customer's responsibility to back up the software before Digital Services personnel arrive at the site. This is important to ensure that data is not lost during the service process. The customer should also shut down the workstation software. Before performing any maintenance work, Digital Services personnel must confirm that the customer has completed both of these tasks.

CAUTION

Electrostatic discharge (ESD) can damage integrated circuits. Always use a grounded wrist strap (part number 29-11762-00) and work-surface-to-earth ground when working with the internal parts of the workstation.

6.1.1 System FRU Removal

Perform these preliminary steps before removing and replacing a FRU.

- Verify that the symptom is not caused by improper configuration or a loose cable.
- Confirm with the customer that data has been backed up. If not, the data could be lost (when a hard disk is at fault).
- Be sure that the operating system is shut down before turning off the sytem or halting the CPU.
- Use the SHOW CONFIG command and write down the following information:
 - System ROM version
 - Graphics type
 - Memory configuration.

Make sure this configuration agrees with the amount and type of memory modules present. If the configuration does not agree, check that the memory modules are installed correctly.

— SCSI devices and IDs


Make sure this configuration agrees with the actual hardware.
If the configuration does not agree, make sure the following are true:

SCSI IDs are all unique.
Cables are correctly installed.
The expansion box power is turned on first.

— Wait three minutes after turning off a monitor before you move or service it.

Figure 6-1 shows the location of the system FRUs.

Figure 6-1 System FRU Locations




6.2 System Preparation

Prepare the system for removing or replacing FRUs by following these next steps.

1. Shut down the operating system.
2. Put the system into console mode by pressing the halt button (Figure 6-2) on the front of the system box (behind the door on the lower right).

Figure 6-2 Halt Button



ML O-005090

- At the console prompt, set the system to halt on future power-ups. Self tests are completed by typing:

```
>>> SET HALT 3 Return
>>>
```

NOTE

After adding the new device or module, halt the system when you first turn it on. Use the diagnostic tests described in Chapter 5 to determine if the new device or module is connected correctly.

- Before adding a new device or module, review the current system configuration. Record the current system configuration information for reference. After adding the new device or module, compare the new configuration with the previous one to help verify that all devices are present and functioning correctly.

To determine the presence of devices, test status, and to determine the quantity of memory inside the system, enter the following command:

```
>>>SHOW CONFIG Return
```

A configuration display similar to the following appears:

```
KA46-A BL3-186-B3.1          ! System type and firmware revision
08-00-2B-F3-31-03           ! Ethernet hardware address
16 MB                        ! Total memory

DEVNBR  DEVNAM  INFO
-----  -
1      NVR      OK          ! Non-volatile RAM
2      LCG      OK
                HR - 8 PLN FB - 2.7  ! 2D high res. color graphics rev 1
3      DZ       OK          ! Serial line controller
4      CACHE    OK          ! Cache memory
5      MEM      OK          ! Memory configuration
                16MB = SY=8MB, S0/S1=8MB, S2/S3=0MB, S4/S5=0MB

6      FPU      OK          ! Floating point accelerator
7      IT       OK          ! Interval Timer
8      SYS      OK          ! Other system functions
9      NI       OK          ! Ethernet
10     SCSI     OK          ! SCSI and drives
                1-RZ23L 6-INITR      ! ONE RZ23L AT ID 1, SYSTEM AT ID 0
11     AUD      OK          ! SOUND
12     COMM     OK          ! DSW21 communications device
```

To determine the quantity of memory in the system, look at the MEM line. The memory line (line 5) shows that there are 16MB of memory. There are 8MB of memory on the system board and 8MB of memory in memory module slots 0 and 1 (4MB in each slot).

5. Turn power to the system off (0).
6. Disconnect the system power cord from the wall outlet and then from the system.

WARNING

Turn the monitor power off for at least three minutes before removing the power cord. Remove the power cord before moving the monitor.

The monitor is heavy and may require two people to lift it.

7. Remove the monitor from the top of the system and set it aside.
8. Remove the system cover by gently pulling out on the tabs on right side of the cover, and lift the cover up and away (Figure 6-1).

6.3 Mass Storage Drive Removal

This section describes how to remove mass storage devices from the VAXstation 4000 Model 60 workstation.

Mass storage devices installed in the system share the same SCSI and dc power cable. Each device has its own connector on the power cable.

NOTE

Refer Section 6.2 before removing or replacing a device or module.

6.3.1 Hard Disk Drive Removal

This section describes how to remove a hard disk drive from its bracket. Figure 6-1 shows the mounting areas for drives.

To remove a hard disk drive, perform the following steps:

1. Pull the colored tab on the drive bracket toward the front of the system. The tab is located at the upper left corner of the bracket.
2. Lift the drive(s) and bracket from the system box.
3. Disconnect both the SCSI and dc power cable from the drive(s).
4. Push down on the plastic tab at the end of the bracket (opposite to where the SCSI and power cables connect to the drive).

5. Slide the drive over the plastic tab until the metal peg on each side of the drive is aligned with the vertical slot on the bracket.
6. Lift the drive from the bracket.
7. Match the SCSI ID with the error code to verify that the failed drive was removed. Figure 6-3 and Figure 6-4 show the disk drive ID jumper locations. Table 6-1 contains the SCSI jumper settings.
8. Remove the drive mounting plate.
9. Remove the second hard disk drive from the bracket if one is present.


6.3.1.1 Hard Disk Drive Replacement

Use the following procedure to replace hard disk drives in the system box:

1. Verify the SCSI ID setting on the drive.


The SCSI jumpers allow you to select a distinct ID number for each SCSI device. It is essential that each device have a unique SCSI ID (0-7). Figure 6-3 shows the location of the RZ23L hard disk drive SCSI ID jumpers (ID number 4 selected). Figure 6-4 shows the location of the RZ24 disk drive SCSI ID jumpers.

Figure 6-3 RZ23L Disk Drive SCSI ID Jumper Location



MLO-005907

Figure 6-4 RZ24 Disk Drive SCSI ID Jumper Location



LJ 00622 T10

2. Set the SCSI ID jumpers of the top disk drive as specified in Table 6-1. The jumpers are used in the following manner:
 - Install the jumper for IN
 - Remove the jumper for OUT

Table 6-1 Hard Disk Drive SCSI Jumper Settings

| SCSI ID | E1 | E2 | E3 | Comment |
|---------|-----|-----|-----|--------------------------------------|
| 0 | Out | Out | Out | |
| 1 | In | Out | Out | |
| 2 | Out | In | Out | |
| 3 | In | In | Out | |
| 4 | Out | Out | In | |
| 5 | In | Out | In | |
| 6 | Out | In | In | Usually reserved for SCSI controller |
| 7 | In | In | In | |

The following is a table for standard ID numbers for the SCSI devices.

Table 6-2 Standard IDs for SCSI Devices

| ID Number | Device Type | Example |
|-------------|-------------------------|----------------------|
| 0 through 3 | Hard disk | RZ23L, RZ24, RZ5x |
| 4 | CDROM | RRD42 |
| 5 | Tape or floppy | RX26, TLZ04, TZK10 |
| 6 | Reserved for the system | KA46 SCSI controller |
| 7 | Any drive | 2nd tape or floppy |

3. Install a new drive in its bracket by reversing the steps in Section 6.3.1.

NOTE

When installing a drive into the bracket, you must apply pressure on the drive for it to seat properly.

6.3.2 RRD42 CDROM Drive Removal

This section describes how to remove a RRD42 CDROM drive. Figure 6-1 shows the RRD42 CDROM drive.


To remove the drive, perform the following steps:

1. Push the colored tab at the right upper front of the bracket toward the power supply, and the tab behind the screw hole at the bottom left center of the bracket to the right.
2. Lift the drive and drive bracket from the system box.
3. Disconnect the SCSI and dc power cables from the drive.
4. Remove the drive from the bracket by releasing the colored latches on each side of the bracket and lifting the drive from the bracket.
5. Match up the SCSI ID with the error code to verify that the failed drive was removed. Refer to Figure 6-3 and Figure 6-4 for the disk drive ID jumper locations. Refer to Table 6-1 for the SCSI jumper settings.
6. Remove the drive mounting plate.

6.3.2.1 RRD42 CDROM Drive Replacement

Before installing the new drive, verify the SCSI ID setting on the drive. Use the following procedure to verify or set the SCSI ID jumpers on the drive:

1. Locate the set of SCSI ID jumpers 0, 1, and 2 at the rear of the drive. The jumpers should be to the left side of the drive as shown in Figure 6-5.

Figure 6-5 RRD42 (CDROM) Jumper Settings

The jumpers are removable electrical connectors on the ID settings.

2. The SCSI ID jumpers should be in the factory set positions for SCSI ID 4. This is the default SCSI ID setting for the drive. Verify that the jumpers are set to the following positions (left to right) for SCSI ID 4: OFF, OFF, ON.

To set the SCSI ID jumper in the OFF position, remove the jumper from its seating. To set a jumper in the ON position, leave the jumper in place.

NOTE

Never set two devices to the same SCSI ID; the system cannot service devices with identical IDs.

To install a new drive, reverse the steps in Section 6.3.2. You do not need to push the tabs to insert the bracket. The bracket snaps into place if positioned properly.

6.3.3 RX26 (Diskette) Drive Removal

This section describes how to remove the diskette drive. Figure 6-1 shows the drive location.


To remove the drive, perform the following steps:

1. Pull the colored tab on the drive bracket toward the front of the system. The tab is located at the upper front right corner of the bracket.
2. Push the colored tab at the lower front of the bracket and the tab behind the screw hole at the bottom left center of the bracket to the right.
3. Lift the drive and drive bracket from the system box.
4. Disconnect the SCSI and dc power cable from the drive.
5. Remove the drive from the removable media bracket by releasing the colored latches on each side of the bracket. Lift the drive and secondary bracket (RX26 bracket) from the bracket.

6.3.3.1 RX26 (Diskette) Drive Replacement

Before installing the new drive, verify the drive type number setting on the drive. Figure 6-6 shows the drive type switch location for the diskette drive. Use the following procedure to verify or set the drive type number switches.

1. Locate the ID number switches 0, 1, and 2 on the drive, as shown in Figure 6-6.

Figure 6-6 Setting the RX26 (Diskette) Drive ID Number

SHR-XR0122-90

2. The SCSI ID switches should be in the factory set positions for SCSI ID 5. This is the default SCSI ID setting for the drive. Verify that the switches are set to the following positions (left to right) for SCSI ID 5: 2 = IN, 1 = OUT, 0 = IN.

To set the SCSI ID switch in the OFF position, remove the switch from its seating. To set a switch to the ON position, leave the switch in place.

3. Use a pen or small pointed object to move the switches side to side. The switch should be set to 0.


CAUTION

Do not use a pencil. Graphite particles can damage the switches.

Figure 6-7 shows the SCSI ID switch location for an RX26 drive,

To install a new drive, reverse the steps in Section 6.3.3. You do not need to push the tabs to insert the bracket. The bracket snaps into place if positioned properly.

Figure 6-7 RX26 (Diskette) Drive SCSI ID Switch Location



6.3.4 TLZ04 Cassette Tape Drive Removal

To remove the TLZ04 drive, do the following:

1. Disconnect the SCSI cable and dc power cable from the drive.
2. Remove the screws that secure the drive bracket to the bottom of the box.
3. Lift the bracket and drive from the box.
4. Remove the drive from the bracket by removing the screws that secure the drive to the bracket. The screws are located to the side of the bracket.
5. Lift the drive from the bracket.


6.3.4.1 TLZ04 Cassette Tape Drive Replacement

When replacing the TLZ04 drive, make sure you do the following:

1. Verify the SCSI ID jumper settings for the TLZ04 drive before you replace it in the system box.
2. Locate the SCSI ID jumpers P, 4, 2, and 1, which are on the back of the drive, on the left. See Figure 6-8.
3. Make sure the jumpers are set to the following positions (right to left) for SCSI ID 5: ON, OFF, ON, OFF. Parity is always set to 0.

4. Reverse the removal steps in Section 6.3.4 to replace the TLZ04 drive in the system box.

Figure 6-8 TLZ04 Tape Drive SCSI ID Jumper Location



MLO-005776

NOTE

Never set two devices to the same SCSI ID; the system cannot service devices with identical IDs.

6.3.5 TZK10 QIC Tape Drive Removal

This section describes how to remove the TZK10 tape drive. Figure 6-1 shows the drive location.

To remove the drive, perform the following steps:

1. Push the colored tab at the lower front of the bracket and the tab behind the screw hole at the bottom left center of the bracket to the right.
2. Lift the drive and drive bracket from the system box.
3. Disconnect the SCSI and dc power cable from the drive.
4. Remove the drive from the removable media bracket by releasing the colored latches on each side of the bracket. Lift the drive from the bracket.


6.3.5.1 TZK10 (Tape) Drive Replacement

Before installing the new drive, verify the drive ID number setting on the drive. Figure 6-9 shows the drive type switch location for the tape drive. Use the following procedure to verify or set the drive type number switches.

1. Verify the ID number switches on the rear of the drive, as shown in Figure 6-9.
2. Use a pen or small pointed object to move the switches from side to side. The drive should be set to 5.

CAUTION

Do not use a pencil. Graphite particles can damage the switches.

Figure 6-9 TZK10 (QIC) Tape Drive SCSI ID Jumper Location

MLO-006156

To install a new drive, reverse the steps in Section 6.3.5.

6.4 Power Supply Removal

NOTE

Refer to Section 6.2 before removing or replacing a device or module.

This section describes how to remove the system power supply (H7819-AA) from the system box. Figure 6-1 shows the system power supply.

WARNING

Do not attempt to open the power supply. There are dangerous voltages inside the power supply, and there are no user-serviceable parts.

To remove the power supply, perform the following steps:

1. Disconnect the power cords (monitor and power supply) from the two ac connectors at the rear of the unit.
2. Perform the steps in Section 6.3.1.
3. Remove the bracket for the RZ drives to gain access to the power supply tab.
4. Pull forward on the blue tab (on the right, toward the front of the box) just under the supply and lift the front of the supply slightly.
5. Lift the rear of the power supply and remove the supply from the system box.

6.4.1 Power Supply Replacement

To install a new power supply, reverse the steps in Section 6.4. Installation is the reverse of Section 6.4 with the exception of pulling the tabs.

When replacing the power supply, ensure that you do the following:

1. Install an H7819-AA power supply.
2. Align the two guides (one on the right front of the supply, and one on the right rear) with the slots on the system box.
3. Push the supply down into place. The power supply snaps into place if positioned properly.

6.5 Module Removal

NOTE

Refer to Section 6.2 before removing or replacing a device or module.

The following sections describe how to remove and replace the VAXstation 4000 Model 60 system modules.

CAUTION

Wear an anti-static wrist strap and place modules on an anti-static mat when removing and replacing system modules.

6.5.1 Light and Switches Module Removal

This section describes how to remove the light and switches module from the system.

NOTE

Refer to Section 6.2 before removing or replacing a device or module.

To remove the light and switches module, perform the following steps:

1. Perform the steps in Section 6.3.1 (Hard Disk Drive Removal) and Section 6.3.2 (RRD42 Disk Removal) or Section 6.3.3 (RX26 Drive Removal) and Section 6.3.5 (TZK10 Drive Removal).
2. Disconnect the module connector from the system module by lifting up on the module where it overlaps the system module.
3. Lift the module away from the front of the system.

6.5.1.1 Light and Switches Module Replacement

To replace the light and switches module, perform the following steps:

1. Align the switches with their respective holes in the front bezel.
2. Align the connector on the lower side of the module with the connector on the system module and seat the connector.

NOTE


When installing a new module, be sure to align the module jacks and switches with the cutouts in the front panel.

6.5.2 Memory Module Identification

Three types of memory modules are available: 4 Mbyte (MS44-AA), 4 Mbyte Reduced Cost (MS44L), and 16 Mbyte (MS44-CA). The VAXstation 4000 Model 60 can use any of the three memory modules. Memory modules must be installed in pairs of two, 4 Mbyte modules or two, 16 Mbyte modules.

Make sure that you have the correct memory module before installation. To identify a memory module, locate the etch on the left side of the memory module. The 4 Mbyte modules have AA or AL on the etch board, and the 16 Mbyte modules have CA on the etch board. Figure 6-10 shows the location of the memory module ID number.

Figure 6-10 Memory Module Identification



6.5.3 MS44 Memory Module Removal

This section describes how to remove the MS44 memory modules from the system.

NOTE

The MS44 memory modules are an option for the VAXstation 4000 Model 60 system. These modules are not installed in all systems. Installation depends on configuration ordered and system upgrades.

CAUTION

Memory components are easily damaged with static electricity. An antistatic wrist strap should always be worn when installing or removing memory components.

CAUTION

The memory modules are keyed and should be installed in only one direction. Excessive force applied to the modules when they are not properly aligned with the connector can cause permanent damage to either the modules or to the connector.

NOTE

Memory modules must always be removed starting from the rear of the system. For example, to replace the module at the front of the system board, you must remove any modules at the back of the board and work toward the front. Memory modules are numbered on the right edge of the memory connectors located on the system board.

The location of the memory modules is shown in Figure 6-1.

To remove the MS44 memory modules, perform the following steps:

1. Release the two metal retainers at each end of the memory module connector.
2. Rotate the module back approximately 55 degrees to the rear of the unit and lift it out of the slot.

CAUTION

Failure to release the two module retainers will permanently damage the module connector located on the system board.

6.5.3.1 MS44 Memory Module Replacement

NOTE

When installing both 4 Mbyte and 16 Mbyte memory module pairs, install the 4 Mbyte pairs (MS44-AA or MS44-AL) in the first slots, toward the front of the system box. The 16 Mbyte module pairs (MS44-CA) must be installed behind the last pair of MS44-AA or MS44L memory modules.

To install a new MS44 memory module, perform the following steps:

1. Place the memory module in the connector and lean the module approximately 55 degrees backwards. Make sure the double notched lower corner of the memory module is toward the power supply.
2. Pivot the memory module upward until the metal tabs connect with the memory module.


6.5.4 Graphics Module Removal

CAUTION

Wear an antistatic wrist strap and place an antistatic mat under the system when removing and replacing any modules.

The LCG graphics module is located at the rear of the system box, next to the power supply. Figure 6-1 shows its location in the system box. To remove it from the system box, use the following procedure:

1. Remove any external cable that is attached to the graphics port on the rear of the system unit.
2. Remove the existing board by releasing the two tabs, as shown in Figure 6-11, and lifting the board out.

Figure 6-11 Removing the LCG Graphics Module


MLO-006444

6.5.5 Replacing the LCG Graphics Module

1. Place the new graphics module in the system box, as shown in Figure 6-12. Press down firmly on the edge of the board until it latches.

2. Reconnect any cable that you removed from the graphics port.

Figure 6-12 Replacing the LCG Graphics Module



MLO-006443

6.5.6 System Module (CPU) Removal

This section describes how to remove the system module from the system.

CAUTION

Wear an antistatic wrist strap and place an antistatic mat under the system when removing and replacing any modules.

To remove the system module (CPU), perform the following steps:

1. Disconnect the cables attached to the module at the rear of the system.
2. Remove the MS44 memory modules.
3. Remove the optional graphics module (if applicable).
4. Remove the optional synchronous communications module (if applicable).
5. Remove the removable media bracket, with drives. Refer to Section 6.3.2 or Section 6.3.
6. Remove the lights and switches module. Refer to Section 6.5.1.
7. Remove the hard disk bracket, with drives. Refer to Section 6.3.1.
8. Remove the power supply. Refer to Section 6.4.
9. Remove the system module (CPU) by lifting it slightly, so that it clears the two guides at the front right and left of the module.
10. Using the large center connector, pull module toward the front of the system box and lift it out.

NOTE

When the system module is replaced, the Ethernet ROM must be removed and installed on the new system module.

NVR settings are lost on system module replacement.

6.5.6.1 System Module (CPU) Replacement

To install a new system module (CPU), reverse the steps in Section 6.5.6. Make sure the 5 slots in the module are aligned with the 5 latches on the base of the system box.

6.6 DSW21 Communications Device Removal

To remove the DSW21 from the system box, perform the following steps:

1. Remove the system box cover.
2. Disconnect the SCSI cable, located directly in front of the DSW21.
3. Disconnect the communications cable or terminator from the back of the system box.
4. Lift the DSW21 (directly in front of the SCSI connector), front end first.

6.6.1 DSW21 Communications Device Replacement

NOTE

Before replacing the DSW21, make sure the SCSI and communications cables have been disconnected.

1. Place the DSW21 in the right rear corner of the system box.
2. Apply pressure to the connector underneath the DSW21 and push the DSW21 down toward the rear of the system box until it clears the SCSI cable connector and lines up with the communications connector on the system module.
3. Reconnect the SCSI cable in the SCSI connector.
4. Reconnect the communications cable.

6.7 Bezel Removal

Do the following to remove the system bezel. Figure 6-1 shows the bezel location:

1. Remove the cover.
2. Remove the removable media bracket, with drives. Refer to Section 6.3.2 or Section 6.3.3.
3. Remove the lights and switches module (Section 6.5.1).
4. Slide the bezel up out of its guides.

6.7.1 Bezel Replacement

To install a new bezel, reverse the steps in Section 6.7.

6.8 Clearing System Password

NOTE

Power to the system must be off to perform this procedure.

To clear the system password, ground the two triangles on the system module with a screwdriver. The triangles are located to the rear left of the memory module connectors. Figure 1-1 shows the location of the triangles.

6.9 Testing the VAXstation 4000 Model 60 System

This section describes how to test the system after completing the removal or replacement process.

6.9.1 Restore the System

Before you can test the system, you must restore the system to its previous operating state. To restore the system, perform the following steps:

1. Replace the system cover. Align the teeth of the cover with the teeth on the side of the system enclosure and lower the cover until it clicks into place.
2. If you disconnected cables at the rear of the system, reconnect them.
3. Plug the system power cord into the wall outlet.
4. Reconnect the monitor.
5. Power up the system.

6.9.2 Testing the System

Test the system to confirm that all devices and modules are connected correctly. You can verify system operation by running any tests or procedures that exhibited the failure symptoms. In the course of testing the system, do the following:

1. Note any power-up error or status messages on the monitor screen.
2. Display the system device configuration by using the **SHOW CONFIG** command. (See Section 6.2.) Compare the latest configuration display with the configuration display you viewed during system preparation. You should see the new device and the other devices present in the system. Verify that no error messages appear on the monitor screen.
3. Verify that all devices are interacting properly by using the **TEST 100** command to run the system exerciser.

NOTE

A loopback connector is needed on the communication port to run TEST 100.

4. Verify that drives are set to the correct SCSI IDs using the **SHOW DEVICE** command.
5. If problems occur, be sure that:

All cables inside and outside the system are connected.

All modules are fully seated in their connectors.

SCSI IDs are set correctly. There should not be any duplicate SCSI IDs. Refer to Table 6-2 for standard SCSI ID settings.

A

Interpreting Error Codes

The system firmware always tries to report any detected hardware errors to the console device and to the LEDs located on the front of the system box. Errors are reported as a result of failures during the powerup tests or during user initiated tests. The error codes identify the device and the test that failed. This chapter covers the following topics:

| | |
|---------------|-----------------------|
| Section A.1 | Error Messages |
| Section A.1.2 | FRU Codes |
| Section A.2 | Self-Test Error Codes |

A.1 Error Messages

The console reports two types of errors.

- Immediate error message

Errors displayed immediately after running a test without additional user intervention.

- Extended error display

These errors display more error information in a different format. To get the extended error information, enter the **SHOW ERROR** command at the console prompt (>>>).

Immediate Error Message Format

The following example shows the format for immediate error messages:

```
?? 150 10 SCSI 0050
```

Where:

- ?? - indicates whether the failure is fatal or non-fatal.
 - A double question mark (??) indicates a fatal error.
 - A single question mark (?) indicates a non-fatal error.
- 150 - Field replaceable unit (FRU). See Table A-1. In this case it is a SCSI drive with the device ID set to 5.
- 10 - Device identification (decimal). This value corresponds to the left bank of four LEDs (hexadecimal). This ID also corresponds to the mnemonic (next field). Use Table 5-3 to correlate the error code to a device.
- SCSI - Mnemonic of device ID.
- 50 - The error code displayed following the test is in decimal. The extended message error codes have a hexadecimal format. When you look up an error code in the error code tables, be sure you know whether the code is in hexadecimal or decimal.

A.1.1 Extended Error Message

You can display the extended error messages by entering the **SHOW ERROR** command at the console prompt following the completion of a test. The extended error display has two lines.

- An error line similar to the immediate error code. The error code (last field of the first line) is in hexadecimal.
- A second line with up to eight longwords of error information.

Extended Error Message Format

The extended error messages appear in the following format:

```
?? 150 10 SCSI 0032
150 000E 00000005 001D001D 03200000 00000024
(cont.) 00000002 00000000 00000004
```

Where:

First line of error message

- ?? Indicates whether the failure is fatal or non-fatal.
- A double question mark (??) indicates a fatal error.
 - A single question mark (?) indicates a non-fatal error.

- 150 Field replaceable unit (FRU). See Table A-1.
- 10 Device identification (Value is given in decimal. Translates to SCSI)
- SCSI Mnemonic of failed module
- 32 Error Code in hexadecimal

Second line of error message

- 150 Field Replaceable Unit (FRU)
- 000E Error code format. The format dictates the meaning of the remaining longwords of error information. This remaining information is not normally required for service.

A.1.2 FRU Codes

The FRU code identifies the field replaceable unit that failed. FRU codes and names are listed in the following table.

Table A-1 FRU Codes

| FRU Code | FRU |
|------------------------------------|--|
| 001 | System module. The mnemonic identifies the device. |
| 002 | Keyboard |
| 003 | Mouse |
| 004 | Monitor #1 |
| 005 | Monitor #2 |
| 010-019 | Graphics modules |
| 020-029 | COMM options |
| 030-039 | BUS adapters |
| Memory Module Codes 040-049 | |
| FRU Code | Module Location |
| 040 | J25 |
| 041 | J24 |
| 042 | J23 |
| 043 | J22 |
| 044 | J21 |
| 045 | J20 |

Table A-1 (Cont.) FRU Codes

| FRU Code | FRU |
|---------------------------------|----------------------|
| SCSI Drive Codes 100-199 | |
| FRU Code | Drive with ID |
| 100 | 0 |
| 110 | 1 |
| 120 | 2 |
| 130 | 3 |
| 140 | 4 |
| 150 | 5 |
| 160 | 6 |
| 170 | 7 |

A.2 Self-Test Error Codes

The system reports two kinds of self-test errors. Those that displays on the console immediately after running the self test and extended test errors. The first type of error consists of one or two question marks to indicate a nonfatal or fatal error, the failing FRU, the device that failed, and a general error code. The second type of error message (extended), displays more detailed information. To view an extended error message, enter the **SHOW ERROR** command at the console prompt, after the test has reported an error.

A.2.1 TOY/NVR Self-Test Error Messages

The TOY/NVR self-test produces the error messages in the following table:

Table A-2 TOY/NVR Test Error Messages

| Error | | |
|---------|-------------|--|
| Decimal | Hexadecimal | Meaning |
| 4 | 4 | Battery was found to be bad |
| 8 | 8 | NVR register test has failed |
| 12 | C | Battery down and NVR register test has failed |
| 16 | 10 | TOY register test has failed |
| 32 | 20 | Valid RAM and time bit have failed to set |
| 36 | 24 | VRT bit failure and battery was found to be bad |
| 44 | 2C | Battery down, VRT failure, and NVR test has failed |
| 48 | 30 | TOY register test and VRT have failed |
| 64 | 40 | Battery check test has failed; hard error |
| 65 | 41 | Battery check test has failed; soft error |
| 72 | 48 | Battery check test and NVR register test have failed |
| 96 | 60 | VRT bit failure and battery check test has failed |
| 104 | 68 | Battery check, VRT, and NVR test have failed |
| 128 | 80 | Update in progress has failed to clear; hard error |
| 129 | 81 | Update in progress has failed to clear; soft error |
| 160 | A0 | Update in progress has failed and VRT bit failure |

A.2.2 DZ Self-Test Error Codes

Table A-3 DZ Self-Test error codes

| Error | | |
|---------|-------------|--|
| Decimal | Hexadecimal | Meaning |
| 16 | 10 | DZ reset test has failed |
| 32 | 20 | DZ read LPR test has failed |
| 48 | 30 | DZ modem test has failed |
| 64 | 40 | DZ polled test has failed |
| 80 | 50 | DZ interrupt driver transfer test has failed |
| 96 | 60 | DZ LK401 test has failed |
| 112 | 70 | DZ mouse test has failed |
| 128 | 80 | DZ INIT DRIVER has failed |
| 144 | 90 | No memory to use for data area |

The DZ self-test does not display extended error information when an error occurs. Enter the **SHOW ERROR** command to view the extended error information. The extended error code format is shown in the following example.

Extended Error Format:

This extended error message is returned by the DZ read LPR test or if a character comparison error occurs in the other DZ tests. The second field (4-digit field) is the extended error format.

```
001 000a ssssssss cccccccc lprlprlp llllllll rrrrrrrr eeeeeeee
```

Where:

- ssssssss - is the suberror code
- cccccccc - is the value of the DZ CSR
- lprlprlp - is the contents of the line parameter register
- llllllll - is the line number
- rrrrrrrr - is the data read back
- eeeeeeee - is the expected data

A-8 Interpreting Error Codes

The extended error code returned by polled and interrupt test when a transfer times out is in the following format:

```
001 000b ssssssss cccccccc lprlprlp llllllll xxxxxxxx tttttttt
```

Where:

- ssssssss - is the suberror code
- cccccccc - is the value of the DZ CSR
- lprlprlp - is the contents of the line parameter register
- llllllll - is the line number
- xxxxxxxx - is the number of characters transmitted
- tttttttt - is the value of the DZ transmit control register

The suberror codes reported by the DZ self-test are as follows:

Table A-4 DZ suberror codes

| Suberror- hexadecimal | Meaning |
|----------------------------------|---|
| 21 | Read LPR baud rate is incorrectly set |
| 22 | Read LPR character width is incorrectly set |
| 23 | Read LPR parity bit is incorrectly set |
| 24 | Read LPR receiver on bit is incorrectly set |
| 31 | DZ modem test - failed RTS <-> CTS loopback |
| 32 | DZ modem test - failed DSRS <-> DSR & CD loopback |
| 33 | DZ modem test - failed LLBK <-> SPDML loopback |
| 34 | DZ modem test - failed DTR <-> RI loopback |
| 41 | DZ polled test - transfer has timed out |
| 42 | DZ polled test - data is not valid |
| 43 | DZ polled test - parity error |
| 44 | DZ polled test - framing error |
| 45 | DZ polled test - overrun error |
| 46 | DZ polled test - character received != character transmitted |
| 51 | DZ interrupt test - transfer has timed out |
| 52 | DZ interrupt test - data is not valid |
| 53 | DZ interrupt test - parity error |
| 54 | DZ interrupt test - framing error |
| 55 | DZ interrupt test - overrun error |
| 56 | DZ interrupt test - character received != character transmitted |
| 61 | DZ LK401 test - transfer has timed out |
| 62 | DZ LK401 test - LK0401 has failed self-test |
| 71 | DZ mouse test - transfer has timed out |
| 72 | DZ mouse test - mouse has failed self-test |

The following are error codes for the system test DZ module:

```
?? DZ    0      ABCD    0 00:00:00.00
```


A-10 Interpreting Error Codes

ABCD are the four DZ lines. The error codes are identical for each line.

- A (line 3) printer port
- B (line 2) 25-pin connector
- C (line 1) mouse
- D (line 0) keyboard

There are eight error codes possible for each line.

- 1 - not all characters transmitted
- 2 - first character not received
- 3 - timeout
- 4 - more characters received than expected
- 5 - parity error
- 6 - framing error
- 7 - overrun error
- 8 - data compare error

These errors are translated by the summary screen. The summary screen for the DZ module uses the following format for each line:

| Line | L_Param | Chr_Xmt | Chr_Rec | Error |
|------|---------|---------|---------|-------|
|------|---------|---------|---------|-------|

Where:

- Line - is the line number
- L_Param - are the line parameters
- Chr_Xmt - is the last character transmitted
- Chr_Rec - is the last character received
- Error - text message for error code from main screen for this line.

A.2.3 Memory Test Error Codes

Table A-5 Memory Test Error Codes

| Error | | |
|---------|-------------|---|
| Decimal | Hexadecimal | Meaning |
| 64 | 40H | A 16 Mbyte memory module and a 4 Mbyte memory module are plugged in as a pair |
| 66 | 42H | A gap was found between memory module pairs |
| 70 | 46H | 4 Mbyte memory modules found after 16 Mbyte memory modules |
| 72 | 48H | Memory modules not plugged in as pairs |
| 256 | 100H | Failure has occurred in the byte mask test |
| 260 | 104H | A parity error occurred during the byte mask test |
| 514 | 202H | A data compare error occurred during the forward pass |
| 516 | 204H | A parity error occurred during the forward pass |
| 770 | 302H | A data compare error occurred during the reverse pass |
| 772 | 304H | A parity error occurred during the reverse pass |
| 1028 | 404H | A parity error occurred during parity test 1 |
| 1288 | 504H | A parity error occurred during parity test 2 |

The memory test does not display extended error information when an error occurs. Enter the **SHOW ERROR** command to view the extended error information. The extended error code format is shown next.

Extended Error Format:

```
xxx 4 MEM yyyy
xxx 00a bbbbbbbb cccccccc dddddddd eeeeeeee
```

Where:

- xxx - is the FRU that failed
- yyyy - is the error code in hexadecimal
- 00a - is the extended error information format type

A-12 Interpreting Error Codes

- bbbbbbbb - is the contents of the memory system error register (MSER)
- cccccccc - is the failing address
- dddddddd - is the expected data
- eeeeeeee - is the data that was read

Table A-6 MEM Memory Module FRU Values

| FRU | Module | Bank |
|-----|--------|------|
| 040 | 1 | 0 |
| 041 | 2 | 0 |
| 042 | 1 | 1 |
| 043 | 2 | 1 |
| 044 | 1 | 2 |
| 045 | 2 | 2 |

A.2.4 Interval Timer Test Error Codes

Table A-7 Interval Timer Test Error Codes

| Error | | |
|---------|-------------|--|
| Decimal | Hexadecimal | Meaning |
| 2 | 2 | Interval timer is not interrupting at the correct rate |

A.2.5 System Device Self-Test Error Codes

Table A-8 System Device Self-Test Error Codes

| Error | | |
|---------|-------------|---|
| Decimal | Hexadecimal | Meaning |
| 128 | 80 | Invalidate filter RAM error |
| 256 | 100 | ROM illegal data path value |
| 512 | 200 | ROM checksum error |
| 768 | 300 | ROM manufacturing check data error |
| 1024 | 400 | ROM index number did not agree with address |

If the invalidate filter RAM error occurs, an extended error message displays. The extended error code format is shown in the next example.

Extended Error Format:

This format displays when there is an invalidate filter RAM error.

```
001 0010 aaaaaaaaa rrrrrrrr eeeeeeee
```

Where:

- 001 - is the FRU number (system board)
- 0010 - is the format number
- aaaaaaaaa - is the failing invalidate filter address
- rrrrrrrr - is the data read
- eeeeeeee - is the data expected

A.2.6 SCSI Self-Test Error Codes

Table A-9 SCSI Self-Test Error Codes

| Error | | |
|-------------------------------------|--------------------|---|
| Decimal | Hexadecimal | Meaning |
| 2 | 2 | SCSI reset register test has failed |
| 4 | 4 | SCSI configuration registers test has failed |
| 6 | 6 | SCSI FIFO register test has failed |
| 8 | 8 | SCSI transfer count registers test has failed |
| SCSI Interrupt Test Failures | | |
| 10 | 10 | Status registers test has failed |
| 20 | 14 | No cause has failed |
| 22 | 16 | High I/O, mask disabled has failed |
| 24 | 18 | High I/O, mask enabled has failed |
| 26 | 1A | Low I/O, mask disabled has failed |
| 28 | 1C | Low I/O, mask enabled has failed |

Table A-9 (Cont.) SCSI Self-Test Error Codes

| Error | | |
|---|--------------------|-------------------------------------|
| Decimal | Hexadecimal | Meaning |
| SCSI Data Transfer Test Failures | | |
| 30 | 1E | PROM function has failed |
| 32 | 20 | DMA mapping has failed |
| 34 | 22 | Non-DMA inquiry has failed |
| 36 | 24 | Not enough data returned failure |
| 38 | 26 | DMA inquiry has failed |
| 40 | 28 | Non-DMA/DMA miscompare |
| 42 | 2A | DMA inquiry nonaligned has failed |
| 44 | 2C | Non-DMA/DMA nonaligned miscompare |
| 46 | 2E | Synchronous inquiry has failed |
| 48 | 30 | Non-DMA/synchronous miscompare |
| 50 | 32 | SCSI minimal device test has failed |
| SCSI Map Error Test Failures | | |
| 60 | 3C | DMA mapping has failed |
| 62 | 3E | DMA inquiry has failed |
| 64 | 40 | Map error will not clear |
| 66 | 42 | Map error will not set |
| 68 | 44 | Parity error will not clear |
| 70 | 46 | PROM function has failed |
| 80 | 50 | SCSI PROM function has failed |
| 82 | 52 | SCSI INIT driver has failed |

The SCSI test does not display extended error information when an error occurs. Enter the **SHOW ERROR** command to view the extended error information. The extended error code is shown in the following example:

Extended Error Format 0001:

This format is used by the register test.

```
001 0001 aaaaaaaaa bbbbbbbb cccccc ddddddd
```

Where:

- aaaaaaaaa - is the error code
- bbbbbbbb - is the address of the register or location being accessed
- cccccc - is the expected data or data written
- ddddddd - is the actual data or data read

Extended Error Format 000B:

This format is used by the register test.

```
001 000B aaaaaaaaa bbbbbbbb cccccc
```

Where:

- aaaaaaaaa - is the error code
- bbbbbbbb - is the address of the register or location being accessed
- cccccc - is information about the error

Extended Error Format 000C:

This format is used by the interrupt test.

```
001 000C aaaaaaaaa bbbbbbbb cccccc ddddddd eeeeeee ffffffff
```

Where:

- aaaaaaaaa - is the error code
- bbbbbbbb - is information about the error
- cccccc - is contents of interrupt mask register
- ddddddd - is contents of interrupt request register
- eeeeeee - is contents of controller status register
- ffffffff - is contents of the controller interrupt register

Extended Error Format 000D:

This format is used when not enough data are returned to the self-test after a SCSI command is executed.

```
aaa 000D bbbbcccc ddddeeee ffffgggg hhhhhhhh
```

Where:

- aaa - is the FRU
- bbbb - is the logical unit number
- cccc - is the device ID
- dddd - is the actual command opcode
- eeee - is the current command opcode
- ffff - is the error code
- gggg - is the mode of operation
- hhhhhhhh - is the number of data bytes received

Extended Error Format 000E:

This format is used when execution of a SCSI command fails.

```
aaa 000E bbbbcccc ddddeeee ffffgggg hhhhiiii jjjjjjjj kkkkllll mmmmmmmmm
```

Where:

- aaa - is the FRU
- bbbb - is the logical unit number
- cccc - is the device ID
- dddd - is the actual command opcode
- eeee - is the current command opcode
- ffff - is the error code
- gggg - is the mode of operation
- hhhh - is byte 14 of the request sense packet (device FRU)
- iiii - is information about the error
- jjjjjj - is SCSI bus phase at the time of the error
- kkkk - is the contents of the controller status register at the time of the error

- **llll** - is the contents of the controller interrupt register at the time of the error
- **mmmmmmmm** - is the request sense key

Extended Error Format 000F:

This format is used when the status phase returns a bad status, or when a bad sense key is seen after a request sense.

aaa 000F bbbbcccc ddddeeee ffffgggg hhhhiiii jjjjjjjj kkkkkkkk

Where:

- **aaa** - is the FRU
- **bbbb** - is the logical unit number
- **cccc** - is the device ID
- **dddd** - is the actual command opcode
- **eeee** - is the current command opcode
- **fff** - is the error code
- **gggg** - is the mode of operation
- **hhhh** - is byte 14 of the request sense packet (device FRU)
- **iiii** - is information about the error
- **jjjjjj** - is the status byte returned in the status phase
- **kkkkkkkk** - is the request sense key

Extended Error Format 0010:

This format is used when a request sense command is executed, but not enough sense bytes are received.

aaa 0010 bbbbcccc ddddeeee ffffgggg hhhhiiii jjjjjjjj kkkkkkkk

Where:

- **aaa** - is the FRU
- **bbbb** - is the logical unit number
- **cccc** - is the device ID
- **dddd** - is the actual command opcode
- **eeee** - is the current command opcode

- ffff - is the error code
- gggg - is the mode of operation
- hhhh - is byte 14 of the request sense packet (device FRU)
- iiii - is information about the error
- jjjjjjj - is the number of bytes of sense data returned from the request sense
- kkkkkkkk - is the request sense key

Extended Error Format 0011:

This format is used when the data out phase sends fewer bytes than expected.

```
aaa 0011 bbbccccc ddddeeee ffffgggg hhhhiiii jjjjkkkk llllllll mmmmmmmmm
```

Where:

- aaa - is the FRU
- bbbb - is the logical unit number
- cccc - is the device ID
- dddd - is the actual command opcode
- eeee - is the current command opcode
- ffff - is the error code
- gggg - is the mode of operation
- hhhh - is byte 14 of the request sense packet (device FRU)
- iiii - is information about the error
- jjjj - is the contents of the controller status register at the time of the error
- kkkk - is the contents of the controller interrupt register at the time of the error
- llllll - is the number of bytes actually sent in the data in/out phase
- mmmmmmmm - is the number of bytes that should have been sent in the data in/out phase

Extended Error Format 0012:

This format is used when an unsupported message is seen.

aaa 0012 bbbbcccc ddddeeee ffffgggg hhhhiiii jjjjjjjj kkkkllll mmmmmmmm

Where:

- aaa - is the FRU
- bbbb - is the logical unit number
- cccc - is the device ID
- dddd - is the actual command opcode
- eeee - is the current command opcode
- ffff - is the error code
- gggg - is the mode of operation
- hhhh - is byte 14 of the request sense packet (device FRU)
- iiii - is information about the error
- jjjjjj - is the first message byte of the message in the phase that the error occurred
- kkkk - is the contents of the controller interrupt register at the time of the error
- llll - is the contents of the controller status register at the time of the error
- mmmmmmmm - is the request sense key

Extended Error Format 0013:

This format is used by the map error test.

```
aaa 0013 bbbbcccc dddddddd eeeeeeee ffffffff gggggggg hhhhhhhh iiiiii
```

Where:

- aaa - is the FRU
- bbbb - is the logical unit number
- cccc - is the device ID
- dddddddd - is the DMA address where the SCSI command is located
- eeeeeeee - is the DMA address where the SCSI data is located
- ffffffff - is the contents of the parity control register
- gggggggg - is the map register address
- hhhhhhhh - is the contents of the map register
- iiiiii - is the error code

Extended Error Format 0014:

This format is used by the data transfer test when the numbers received from two transfers are different.

```
aaa 0014 bbbbbbbb cccccccc dddddddd
```

Where:

- aaa - is the FRU
- bbbbbbbb - is the first number of the bytes
- cccccccc - is the second number of the bytes
- dddddddd - is the error code

Extended Error Format 0015:

This format is used by the data transfer test when the data bytes received from two transfers are compared and found to be different.

```
aaa 0015 bbbbbbbb cccccccc
```

Where:

- aaa - is the FRU
- bbbbbbbb - is the number of the byte that failed
- cccccccc - is the error code

The FRU reported by all error formats is either 1 for the system board FRU, or $(100 + \text{device_id} * 10 + \text{logical unit number})$.

The informaton values reported by some extended SCSI self-test errors are as follows (hexadecimal values are used for self-test):

Table A-10 SCSI Information Values

| Information | | |
|-------------|-------------|--|
| Decimal | Hexadecimal | Meaning |
| 1 | 1 | Valid group code bit clear in controller status register |
| 2 | 2 | Valid group code bit set in controller status register |
| 3 | 3 | Terminal count bit clear in controller status register |
| 4 | 4 | Terminal count bit set in controller status register |
| 5 | 5 | Parity error bit clear in controller status register |
| 6 | 6 | Parity error bit set in controller status register |
| 7 | 7 | Gross error bit clear in controller status register |
| 8 | 8 | Gross error bit set in controller status register |
| 9 | 9 | Interrupt bit clear in controller status register |
| 10 | A | Interrupt bit set in controller status register |
| 11 | B | Selected bit clear in controller interrupt register |

Table A-10 (Cont.) SCSI Information Values

| Information | | |
|--------------------|--------------------|--|
| Decimal | Hexadecimal | Meaning |
| 12 | C | Selected bit clear in controller interrupt register |
| 13 | D | Select with attention bit clear in controller interrupt register |
| 14 | E | Select with attention bit set in controller interrupt register |
| 15 | F | Reselected bit clear in controller interrupt register |
| 16 | 10 | Reselected bit set in controller interrupt register |
| 17 | 11 | Function complete bit clear in controller interrupt register |
| 18 | 12 | Function complete bit set in controller interrupt register |
| 19 | 13 | Bus service bit clear in controller interrupt register |
| 20 | 14 | Bus service bit set in controller interrupt register |
| 21 | 15 | Disconnect bit clear in controller interrupt register |
| 22 | 16 | Disconnect bit set in controller interrupt register |
| 23 | 17 | Illegal command bit clear in controller interrupt register |
| 24 | 18 | Illegal command bit set in controller interrupt register |
| 25 | 19 | SCSI reset bit clear in controller interrupt register |
| 26 | 1A | SCSI reset bit set in controller interrupt register |
| 27 | 1B | Arbitration not won |
| 28 | 1C | Selection timeout |
| 29 | 1D | Invalid sequence in sequence step register |

Table A-10 (Cont.) SCSI Information Values

| Information | | |
|--------------------|--------------------|---|
| Decimal | Hexadecimal | Meaning |
| 30 | 1E | FIFO flags are not clear |
| 31 | 1F | FIFO flags are clear |
| 32 | 20 | Unexpected ISR hit |
| 33 | 21 | SCSI interrupt request set in system interrupt request register |
| 34 | 22 | SCSI bit set unexpectedly in controller status register |
| 35 | 23 | Interrupt service routine was not entered |
| 36 | 24 | No SCSI interrupt request was seen |
| 37 | 25 | Interrupt bit in controller status register will not clear |
| 38 | 26 | SCSI bit in system interrupt request register will not clear |
| 39 | 27 | Bad request sense key |
| 40 | 28 | Bad status returned from status phase |
| 41 | 29 | Not enough sense data returned from a request sense command |
| 42 | 2A | Phase did not go to command phase |
| 43 | 2B | Phase did not go to message out phase |
| 44 | 2C | Phase did not go to message in phase |
| 45 | 2D | Command phase changed too soon |
| 46 | 2E | Data out phase changed too soon |
| 47 | 2F | Message in phase changed too soon |
| 48 | 30 | Message out phase changed too soon |
| 49 | 31 | Stuck in command phase |
| 50 | 32 | Stuck in message in phase |
| 51 | 33 | Stuck in message out phase |
| 52 | 34 | Stuck in data out phase |

Table A-10 (Cont.) SCSI Information Values

| Information | | |
|--------------------|--------------------|---|
| Decimal | Hexadecimal | Meaning |
| 53 | 35 | Stuck in data in phase |
| 54 | 36 | Should not be in message out phase |
| 55 | 37 | No interrupt after sending SCSI command |
| 56 | 38 | No interrupt after sending command complete |
| 57 | 39 | No interrupt after sending message accepted |
| 58 | 3A | No interrupt after sending transfer information |
| 59 | 3B | All data out bytes were not sent |
| 60 | 3C | Command complete message was sent but device did not drop off bus |
| 61 | 3D | Unexpected message reject from device |
| 62 | 3E | FIFO flag count is wrong |
| 63 | 3F | Message is unsupported |
| 64 | 40 | Bus device reset was sent, but device did not drop off bus |
| 65 | 41 | Illegal phase |
| 66 | 42 | Should not be in data in phase |
| 67 | 43 | Problem with a device trying to reconnect |
| 68 | 44 | Unexpected disconnect message received |
| 69 | 45 | Device not seen before trying to reconnect |
| 70 | 46 | Bad identify message received on reconnection |
| 71 | 47 | Out of re-tries for this command |
| 72 | 48 | Too many bytes sent in data out phase |
| 73 | 49 | Too many bytes sent in data in phase |
| 74 | 4A | Reconnection timeout |
| 75 | 4B | SCSI parity error |
| 76 | 4C | SCSI map error |

The mode values reported by some extended SCSI self-test errors are as follows:

Table A-11 SCSI Mode Values

| Mode - Hexadecimal | Meaning |
|-------------------------------|---------------------------------------|
| 0 | Asynchronous mode with programmed I/O |
| 1 | Asynchronous mode with DMA |
| 2 | Synchronous mode with DMA |

A.2.7 SCSI Utilities Messages

The following table describes error messages returned by a SCSI utility. All SCSI utility errors appear in the format *text_message informaiton_value*.

Table A-12 Text Messages for SCSI Utilities

| Text | Meaning |
|-------------------|------------------------------------|
| SCSI_E_badparam | Bad parameter entered by the user |
| SCSI_E_err | Generic utility error |
| SCSI_E_devtyp | Wrong device type for this utility |
| SCSI_E_media | Problem with the media |
| SCSI_E_lun | Logical unit is not present |
| SCSI_E_inq_err | Error in inquiry command |
| SCSI_E_modsns_err | Error in mode sense command |
| SCSI_E_modsel_err | Error in mode select command |
| SCSI_E_tur_err | Error in test unit ready command |
| SCSI_E_rwnd_err | Error in rewind command |
| SCSI_E_wrt_err | Error in write command |
| SCSI_E_rd_err | Error in read command |
| SCSI_E_rdcap_err | Error in read capacity command |
| SCSI_E_st_unt_err | Error in start unit command |

Table A-12 (Cont.) Text Messages for SCSI Utilities

| Text | Meaning |
|--------------------|------------------------------|
| SCSI_E_ver_ | Error in verify command |
| SCSI_E_fmt_unt_err | Error in format unit command |
| SCSI_E_reass_err | Error in reassign command |

In addition to the information values reported by the extended SCSI self test errors, there are the following information values reported in decimal.

Table A-13 Additional SCSI Information Values for Utilities

| Information | |
|--------------------|---|
| Decimal | Meaning |
| 176 | Bad utility number received from the user |
| 177 | Bad device number received from the user |
| 178 | Bad logical unit number received from the user |
| 180 | Device number entered by the user is the same as the controller |
| 181 | Utility cannot be executed in this mode of operation |
| 182 | Not enough data was returned from a SCSI command |
| 183 | Device is not a disk |
| 184 | Device is not a tape |
| 185 | Media is not removable |
| 186 | Media is removable |
| 187 | Media is write-protected |
| 188 | Device is not ready |
| 189 | Wrong data read back from a SCSI command |
| 190 | Logical unit is not present |
| 191 | Initialize driver failed |
| 192 | Error in format page |

Table A-13 (Cont.) Additional SCSI Information Values for Utilities

Information

Decimal Meaning

| | |
|-----|--|
| 193 | Error in flexible page |
| 194 | PROM function error |
| 195 | Disk capacity is too small |
| 196 | Error receiving character from console |
| 197 | Illegal floppy drive |
| 198 | Illegal floppy media |

A.2.8 SCSI System Test Error Codes

The following error codes are returned by the SCSI system test:

Table A-14 SCSI System Test Error Codes

| Error | | |
|----------------|--------------------|---|
| Decimal | Hexadecimal | Meaning |
| 90 | 5A | WST call failed |
| 92 | 5C | ELN call failed |
| 100 | 64 | Inquiry failed when sizing bus |
| 102 | 66 | Not enough inquirey data returned when sizing bus |
| 104 | 68 | Start unit failed when sizing bus |
| 106 | 6A | Test unit ready failed when sizing bus |
| 108 | 6C | Mode select failed when sizing bus |
| 110 | 6E | Read capacity failed when sizing bus |
| 112 | 70 | Mode sense failed when sizing bus |
| 114 | 72 | Media is write-protected in manufacturing mode |

Table A-14 (Cont.) SCSI System Test Error Codes

| Error | | |
|----------------|--------------------|--|
| Decimal | Hexadecimal | Meaning |
| 116 | 74 | Not enough mode sense data returned when sizing bus |
| 118 | 76 | Read failed when sizing bus |
| 120 | 78 | Not enough read data when sizing bus |
| 122 | 7A | Verify failed when sizing bus |
| 130 | 82 | Read failed when checking for key |
| 132 | 84 | Rewind failed when checking for key |
| 134 | 86 | Wrong number bytes read when checking for boot block |
| 140 | 8C | Read failed when checking for boot block |
| 142 | 8E | Wrong number bytes read when checking for boot block |
| 150 | 96 | Non-DMA inquiry failed in data transfer test |
| 152 | 98 | Synchronous DMA inquiry failed in data transfer test |
| 154 | 9A | Number bytes miscompare in data transfer test |
| 156 | 9C | Data miscompare in data transfer test |
| 160 | A0 | Device test failed |
| 162 | A2 | Wrong number bytes read in device test |
| 164 | A4 | Wrong number bytes written in device test |
| 166 | A6 | Data miscompare in device test |
| 168 | A8 | Reselection timeout in device test |

A.2.9 SCSI System Test Summary Screen

The SCSI summary screen displays the following information:

ADR RDS WRTS ERR FRU CMD PHS INF LBNSTRT XFERSIZ

Where:

- ADR - is ID and lun
- RDS - is number of reads performed on this device (decimal)
- WRTS - is number of writes performed on this device (decimal)
- ERR - is the error code (hexadecimal)
- FRU - is the Field Replaceable Unit (hexadecimal if FRU received from request sense packet)
- CMD - is the SCSI command that failed (hexadecimal)
- PHS - is the SCSI bus phase at time of error
- INF - is informational value (same as those reported by the self-test; hexadecimal)
- LBNSTRT - is the starting logical block number of failed transfer (hexadecimal)
- XFERSIZ - is the transfer size in blocks of failed transfer (hexadecimal)

A.2.10 Audio Test Error Codes

The audio self-test (AUD) is divided into three main sections.

- Register tests
- Audio tests
- Interrupt tests

Registers are tested by writing data, then reading back the data, or reading the read_only registers.

The audio test generates a sequence of eight tones and sends them to the speaker. It also does an internal digital loopback through the MAP. This tests the three MUX channels and corresponds to the three AUD\$MAP_DIGITAL_LOOPBACK errors.

The interrupt test generates interrupts by loading eight bytes into the D-channel transmit buffer and reading them back through the receiver buffer (eight interrupts are generated).

Table A-15 Audio Self-Test Error Codes

| Error | | |
|---------|-------------|--|
| Decimal | Hexadecimal | Meaning |
| 2 | 2 | AUD\$LIU_LSR_SAE register test has failed |
| 4 | 4 | AUD\$LIU_LPR_SAE register test has failed |
| 6 | 6 | AUD\$LIU_LPR_NZE register test has failed |
| 8 | 8 | AUD\$LIU_LMR1_SAE register test has failed |
| 10 | A | AUD\$LIU_LMR2_SAE register test has failed |
| 16 | 10 | AUD\$MUX_MCR1_SAE register test has failed |
| 18 | 12 | AUD\$MUX_MCR2_SAE register test has failed |
| 20 | 14 | AUD\$MUX_MCR3_SAE register test has failed |
| 32 | 20 | AUD\$MAP_MMR1_SAE register test has failed |
| 34 | 22 | AUD\$MAP_MMR2_SAE register test has failed |
| 36 | 24 | AUD\$MAP_DIGITAL_LOOPBACK1 test has failed |
| 38 | 26 | AUD\$MAP_DIGITAL_LOOPBACK2 test has failed |
| 40 | 28 | AUD\$MAP_DIGITAL_LOOPBACK3 test has failed |
| 48 | 30 | AUD\$INTR_RECEIVE_BYTE_AVAILABLE test has failed |
| 50 | 32 | AUD\$INTR_BAD_DLC_LOOPBACK_DATA test has failed |
| 52 | 34 | AUD\$INTR_TIME_OUT test has failed |
| 56 | 36 | AUD\$INTR_INVALID_IR_VALUE test has failed |
| 58 | 38 | AUD\$INTR_NO_INT_GENERATED test has failed |
| 60 | 3A | AUD\$INTR_NOT_ALL_INTS_RCVD test has failed |
| 62 | 3C | AUD\$INTR_NOT_DISABLED test has failed |

The AUD test does not display extended error information in decimal when an error occurs. Enter the **SHOW ERROR** command to view the extended error information in hexadecimal. The extended error codes can be of several types as shown in the following examples.

Extended Error Format 0010:

This format is used by all the audio register tests.

```
aaa 0010 bbbbbbbb cccccccc dddddddd
```

Where:

- aaa - is the FRU
- bbbbbbbb - is the error number
- cccccccc - is the contents of the data register (DR)
- dddddddd - TBS

Extended Error Format 0011:

This format is used by all the audio register tests.

```
aaa 0011 bbbbbbbb cccccccc dddddddd
```

Where:

- aaa - is the FRU
- bbbbbbbb - is the error number
- cccccccc - is the contents of D channel status register 2 (DSR2)
- dddddddd - TBS

Extended Error Format 0012:

This format is used by all the audio register tests.

```
aaa 0012 bbbbbbbb cccccccc dddddddd
```

Where:

- aaa - is the FRU
- bbbbbbbb - is the error number
- cccccccc - 0
- dddddddd - TBS

A.2.11 DSW21 Communications Device Test Error Codes**Table A-16 DSW21 Device Test Error Codes**

| Error | | |
|---------|-------------|----------------------------|
| Decimal | Hexadecimal | Meaning |
| 1 | 1 | Self-test was unsuccessful |
| 2 | 2 | Transmit underflow |
| 4 | 4 | Transmitter busy |
| 6 | 6 | Receiver busy |
| 8 | 8 | Transmitter error |
| 10 | A | Carrier detect loss |

Table A-16 (Cont.) DSW21 Device Test Error Codes

| Error | | |
|-----------------------------------|--------------------|-----------------------------------|
| Decimal | Hexadecimal | Meaning |
| Sync Comm Receive Failures | | |
| 12 | C | Receive overflow |
| 14 | E | Receive CRC error |
| 16 | 10 | Receive abort |
| 18 | 12 | Receive non-octet aligned |
| 20 | 14 | Receive parity error |
| 22 | 16 | Receive frame error |
| 24 | 18 | Receive length too large |
| 26 | 1C | Receive DLE follow |
| 30 | 1E | No external loopback connector |
| 32 | 20 | Invalid test specified |
| 34 | 22 | PVAX timeout waiting for response |
| 36 | 24 | Comm module timeout waiting |
| 38 | 26 | PVAX invalid test |

Table A-16 (Cont.) DSW21 Device Test Error Codes

| Error | | |
|------------------------------------|--------------------|--|
| Decimal | Hexadecimal | Meaning |
| DSW21 Comm. Device Failures | | |
| 40 | 28 | Comm option test failure |
| 42 | 2A | Comm option copy to RAM failed |
| 44 | 2C | Comm option RAM test failed |
| 46 | 2E | Comm option dual RAM access test |
| 48 | 30 | Comm option interrupt test |
| 50 | 32 | Comm option reset test |
| 52 | 34 | Comm option internal loopback |
| 54 | 36 | Comm option external loopback |
| 56 | 38 | Comm option modem signal test |
| 58 | 3A | Comm option H3199 failure |
| 60 | 3C | Comm option H3248 failure |
| 62 | 3E | Comm option H3250 failure |
| 64 | 40 | Comm option H3047 failure |
| 66 | 42 | Comm option host internal buffer failure |
| 68 | 44 | Comm option external buffer loop |
| 70 | 46 | Data compare error |

Table A-16 (Cont.) DSW21 Device Test Error Codes

| Error | | |
|---------------------------------|--------------------|--------------------------|
| Decimal | Hexadecimal | Meaning |
| DSW21 Comm. IMP Failures | | |
| 128 | 80 | IMP IDMA timeout |
| 130 | 82 | IMP SCC transmit timeout |
| 132 | 84 | IMP SCC receive timeout |
| 134 | 86 | IMP command timeout |
| 136 | 88 | IMP ERR timeout |
| 138 | 8A | IMP PB8 timeout |
| 140 | 8C | IMP SMC2 timeout |
| 142 | 8E | IMP SMC1 timeout |

Table A-16 (Cont.) DSW21 Device Test Error Codes

| Error | | |
|---------------------------------|--------------------|-----------------------------------|
| Decimal | Hexadecimal | Meaning |
| DSW21 Comm. IMP Failures | | |
| 144 | 90 | IMP watchdog timeout |
| 146 | 92 | IMP SCP timeout |
| 148 | 94 | IMP timer 2 timeout |
| 150 | 96 | IMP SCC3 timeout |
| 152 | 98 | IMP PB9 timeout |
| 154 | 9A | IMP timer 1 timeout |
| 156 | 9C | IMP SCC2 timeout |
| 158 | 9E | IMP IDMA timeout |
| 160 | A0 | IMP SDMA timeout |
| 162 | A2 | IMP SCC1 timeout |
| 164 | A4 | IMP PB10 timeout |
| 166 | A6 | IMP PB11 timeout |
| 168 | A8 | IMP internal loopback system test |
| 170 | AA | IMP external loopback system test |
| 172 | AC | IMP timer 1 timeout |
| 174 | AE | IMP timer 2 timeout |
| 176 | B0 | IMP transmit ready timeout |

Table A-16 (Cont.) DSW21 Device Test Error Codes

| Error | | |
|---------------------------------|--------------------|-------------------------------------|
| Decimal | Hexadecimal | Meaning |
| DSW21 Comm. IMP Failures | | |
| 178 | B2 | IMP receive ready timeout |
| 180 | B4 | IMP invalid SCC channel |
| 182 | B6 | PVAX data compare error |
| 184 | B8 | IMP carrier detect assert timeout |
| 186 | BA | IMP carrier detect deassert timeout |
| 188 | BC | IMP CTS assert timeout |
| 190 | BE | IMP CTS deassert timeout |
| 192 | C0 | IMP IDL assert timeout |
| 194 | C2 | IMP IDL deassert timeout |
| 196 | C4 | IMP invalid cable attached |
| 198 | C6 | IMP no test indicator |
| 200 | C8 | IMP no data set ready |
| 202 | CA | IMP no ring indicator |
| 204 | CC | IMP no speed indicator |
| 206 | CE | IMP no carrier detect |
| 208 | D0 | IMP no clear to send |
| 210 | D4 | IMP power up block initialization |
| 212 | D6 | IMP DSR assert timeout |
| 214 | D6 | IMP DSR deassert timeout |
| 216 | D8 | IMP reset error |
| 218 | DA | IMP mode initialization error |
| 220 | DC | PVAX memory allocation error |
| 222 | DE | PVAX memory free error |
| 224 | E0 | UTIL invalid utility number |

Table A-16 (Cont.) DSW21 Device Test Error Codes

| Error | | |
|-------------------------------------|--------------------|--|
| Decimal | Hexadecimal | Meaning |
| 226 | E2 | UTIL invalid cable code |
| DSW21 Comm. Timeout Failures | | |
| 228 | E4 | Timeout comm option set response RA |
| 230 | E6 | Timeout comm option clear command CA |
| 232 | E8 | Timeout comm option set scheduler run SR |
| 234 | EA | Timeout comm option set transmit ready TR |
| 236 | EC | Timeout comm option set receive ready RR |
| 238 | EE | Comm option exception occurred |
| 240 | F0 | Comm option command register timeout |
| 242 | F2 | Comm option transmit clear to send lost |
| 244 | F4 | PVAX test memory allocation error |
| 246 | F6 | PVAX test memory free error |
| 248 | F8 | Comm option reported invalid configuration |
| 250 | FA | PVAX ROM test |
| 252 | FC | PVAX ROM checksum error |
| 254 | FE | PVAX control C entered at console |
| 256 | 100 | Comm option receive error-CRC follow error |
| 258 | 102 | Comm option MC68302 component is not REV B |
| 260 | 104 | Test request sequence error |

Table A-16 (Cont.) DSW21 Device Test Error Codes

| Error | | |
|----------------|--------------------|--|
| Decimal | Hexadecimal | Meaning |
| 262 | 106 | IMP timeout waiting for host to clear RA |
| 264 | 108 | IMP timeout waiting for host to clear SR |
| 266 | 10A | ROM test error |
| 268 | 10C | FBUG secure error-reserved operation |
| 270 | 10E | Port PB3 signal stuck high |
| 272 | 110 | Timer 3 not counting |
| 274 | 112 | Comm option diagnostics did not complete |
| 276 | 114 | Comm option SDMA bus error occurred |
| 278 | 116 | Timeout waiting for IRQ assertion |
| 280 | 118 | Transmit restart of 10 exceeded |

A.2.12 DSW21 Communications Device Test Numbers

Table A-17 lists the test sequence numbers reported by the DSW21 during self-test. The sequence number is reported in location 2C02F604 of the status block. The table also lists the test routines in addition to those of the M68302.

Table A-17 DSW21 Communications Self-Test Sequence Numbers

| Test Number | | | |
|--------------------|--------------------|----------------|--------------------------------------|
| Decimal | Hexadecimal | Routine | Description |
| 01 | 01 | imp_exc | Exception vector initialization |
| 02 | 02 | imp_vec | User interrupt vector initialization |
| 03 | 03 | imp_rdb | Local register RDB initialization |

Table A-17 (Cont.) DSW21 Communications Self-Test Sequence Numbers

| Test Number | | Routine | Description |
|--------------------|--------------------|-----------------|--|
| Decimal | Hexadecimal | | |
| 04 | 04 | imp_pub_init | Up block initialization |
| 05 | 05 | imp_op_init | Option register initialization |
| 06 | 06 | imp_br_init | Base register initialization |
| 07 | 07 | imp_cs_switch | Power-up switch initialization |
| 08 | 08 | imp_cfg | Get hardware configuration |
| 09 | 09 | imp_scr_init | System control register initialization |
| 10 | 0A | imp_core | MC68302 core confidence test |
| 11 | 0B | imp_dwn | Watchdog timer counter clear |
| 12 | 0C | imp_aptort_init | Port A initialization |
| 13 | 0D | imp_bport_init | Port B initialization |
| 14 | 0E | imp_cisdn | ISDN configuration |
| 15 | 0F | imp_loc_init | Local scratch RAM SCR initialization |
| 16 | 10 | imp_idb_init | Interrupt data block initialization |
| 17 | 11 | imp_pcb_init | Process control block initialization |
| 18 | 12 | imp_ic_init | Interrupt controller initialization |
| 19 | 13 | imp_cable_code | Read cable code |
| 20 | 14 | imp_dma_test | IDMA transfers test |

Table A-17 (Cont.) DSW21 Communications Self-Test Sequence Numbers

| Test Number | | Routine | Description |
|--------------------|--------------------|----------------|--|
| Decimal | Hexadecimal | | |
| 21 | 15 | imp_rings | Initialize rings |
| 22 | 16 | imp_s1_inte | SCC1 ISR enable |
| 23 | 17 | imp_s2_inte | SCC2 ISR enable |
| 24 | 18 | imp_s3_inte | SCC3 ISR enable |
| 25 | 19 | imp_it1_test | Timer 1 test |
| 26 | 1A | imp_it2_test | Timer 2 test |
| 27 | 1B | imp_imode | Initialize mode |
| 28 | 1C | imp_reset | Initialize CP |
| 29 | 1D | imp_ilb_test | SCC internal loop |
| 30 | 1E | imp_modem_test | Modem signal test |
| 31 | 1F | imp_elb_test | SCC external loop |
| 32 | 20 | imp_isdn_test | ISDN test |
| 33 | 21 | imp_rdb | Runtime register RDB initialization |
| 34 | 22 | imp_loc_init | Runtime SCR RAM initialization |
| 35 | 23 | imp_cable_code | Runtime read adapter cable code |
| 36 | 24 | imp_ic_init | Runtime interrupt controller initialization |
| 37 | 25 | imp_idb_init | Runtime IDB initialization |
| 38 | 26 | imp_pcb_init | Runtime PCB initialization |
| 39 | 27 | imp_reset | Runtime communication processor initialization |
| 40 | 28 | imp_rings | Runtime initialize transmit and receive rings |

Table A-17 (Cont.) DSW21 Communications Self-Test Sequence Numbers

| Test Number | | Routine | Description |
|-------------|-------------|--------------|--|
| Decimal | Hexadecimal | | |
| 41 | 29 | imp_s1_inte | Runtime SCC1 ISR |
| 42 | 2A | imp_s2_inte | Runtime SCC2 ISR |
| 43 | 2B | imp_s3_inte | Runtime SCC3 ISR |
| 44 | 2C | imp_t1_start | Runtime timer 1 start |
| 45 | 2D | imp_t2_start | Runtime timer 2 start |
| 46 | 2E | imp_t3_start | Runtime timer 3 start |
| 47 | 2F | imp_dainit | Runtime RAM dual access initialization |
| 48 | 30 | imp_xvec | Runtime transfer vector initialization |

The DSW21 communications device test does not display extended error information in decimal when an error occurs. Enter the **SHOW ERROR** command to view the extended error information in hexadecimal. The extended error codes can be of several types as shown in the following example.

Extended Error Format 0001:

This format is used by the synchronous communication option RAM test.

```
0020 0001 aaaa0000 00000000 00000000 00000000 bbbb0000 ccccdddd eeeeff:
```

Where:

- 0014 - is the FRU for the communications option.
- 0001 - is the format type for the RAM test.
- aaaa - is the test status.
- bbbb - is the data size (1=byte access, 2=word access, 4=long access).
- cccc - is address low.
- dddd - is address high.
- eeee - is the actual data.

- ffff - is the expected data.

Extended Error Format 0002:

This format is used by the DSW21 communications device self-tests.

```
0020 0002 aaaabbbb ccddeeff gghhiijj kkkkl111 mmmnnnnn ooooopppp  
qqqqrrrr
```

Where:

- 0020 - is the FRU for the communications option.
- 0002 - is the format type for the test.
- aaaa - is the test status.
- bbbb - is the MC68302 diagnostic test number.
- cc - is the cable code for channel 1 SCC1.
- dd - is the cable code for channel 2 SCC2.
- ee - is the current hardware revision.
- ff - is the current software revision.
- gg - is the current channel under test (1, 2, 3).
- hh - is the current electrical interface.
- ii - is the internal loopback mode (0=internal, 1=external).
- jj - is the external channel count.
- kkkk - is the current SCC mode.
- llll - is the current protocol.
- mmmm - is the data size.
- nnnn - is the current channel speed.
- oooo - is address low.
- pppp - is address high.
- qqqq - is the expected data.
- rrrr - is the actual data.

Extended Error Format 0003:

This format is used by the DSW21 communications device dual access tests.

0020 0003 aaaaabbbb ccddeeff gghhiijj kkkkl111 mmmnnnnn ooooopppp qqqr1rrr

Where:

- 0020 - is the FRU for the DSW21 communications device.
- 0003 - is the format type for the test.
- aaaa - is the test status.
- bbbb - is the MC68302 diagnostic test number.
- cc - is the cable code for channel 1 SCC1.
- dd - is the cable code for channel 2 SCC2.
- ee - is the current hardware revision.
- ff - is the current software revision.
- gg - is the current channel under test (1, 2, 3).
- hh - is the current electrical interface.
- ii - is the internal loopback mode (0=internal, 1=external).
- jj - is the external channel count.
- kkkk - is the current SCC mode.
- llll - is the current protocol.
- mmmm - is the data size.
- nnnn - is the current channel speed.
- oooo - is address low.
- pppp - is address high.
- qqqq - is the expected data.
- rrrr - is the actual data.

Extended Error Format 0004:

This format is used by the DSW21 communications device interrupt test.

0020 0004 aaaabbbb ccddeeff gghhijj kkkkl111 mmmnnnnn oooooopp qqqrnn

Where:

- 0020 - is the FRU for the DSW21 communications device.
- 0004 - is the format type for the self-test.
- aaaa - is the test status.
- bbbb - is the MC68302 diagnostic test number.
- cc - is the cable code for channel 1 SCC1.
- dd - is the cable code for channel 2 SCC2.
- ee - is the current hardware revision.
- ff - is the current software revision.
- gg - is the current channel under test (1, 2, 3).
- hh - is the current electrical interface.
- ii - is the internal loopback mode (0=internal, 1=external).
- jj - is the external channel count.
- kkkk - is the current SCC mode.
- llll - is the current protocol.
- mmmm - is the data size.
- nnnn - is the current channel speed.
- oooo - is address low.
- pppp - is address high.
- qqqr - is the expected data.
- rrrr - is the actual data.

Extended Error Format 0005:

This format is used by the DSW21 communications device modem signal tests.

```
0020 0005 aaaabbbb ccddeeff gghhii jj kkkkl111 mmmnnnnn ooooo pppp qqqr
```

Where:

- 0020 - is the FRU for the DSW21 communications device.
- 0005 - is the format type for the test.
- aaaa - is the test status.
- bbbb - is the MC68302 diagnostic test number.
- cc - is the cable code for channel 1 SCC1.
- dd - is the cable code for channel 2 SCC2.
- ee - is the current hardware revision.
- ff - is the current software revision.
- gg - is the current channel under test (1, 2, 3).
- hh - is the current electrical interface.
- ii - is the internal loopback mode (0=internal, 1=external).
- jj - is the external channel count.
- kkkk - is the current SCC mode.
- llll - is the current protocol.
- mmmm - is the data size.
- nnnn - is the current channel speed.
- oooo - is address low.
- pppp - is address high.
- qqqr - is the expected data.
- rrrr - is the actual data.

Extended Error Format 0006:

This format is used by the DSW21 communications device loopback tests.

```
0020 0006 aaaabbbb ccddeeff gghhii jj kkkkl111 mmmnnnnn ooooo pppp qqqr
```

Where:

- 0020 - is the FRU for the DSW21 communications device.
- 0006 - is the format type for the self-test.
- aaaa - is the test status.
- bbbb - is the MC68302 diagnostic test number.
- cc - is the cable code for channel 1 SCC1.
- dd - is the cable code for channel 2 SCC2.
- ee - is the current hardware revision.
- ff - is the current software revision.
- gg - is the current channel under test (1, 2, 3).
- hh - is the current electrical interface.
- ii - is the internal loopback mode (0=internal, 1=external).
- jj - is the external channel count.
- kkkk - is the current SCC mode.
- llll - is the current protocol.
- mmmm - is the data size.
- nnnn - is the current channel speed.
- oooo - is address low.
- pppp - is address high.
- qqqq - is the expected data.
- rrrr - is the actual data.

Extended Error Format 0007:

This format is used by the DSW21 communications device reset test. The reset test only returns a timeout status if it does not get a posted interrupt controller.

0020 0007 00070000 00000000 00000000 00000000 00000000 00000000 00000000

Where:

- 0020 - is the FRU for the DSW21 communications device.
- 0007 - is the format type.

- 0007 - currently running reset test.

Extended Error Format 0008:

This format is used by the synchronous communication option null request.

```
0020 0008 0008 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
0000 0000
```

Where:

- 0020 - is the FRU for the DSW21 communications device.
- 0008 - is the format type.
- 0008 - currently running null request.

Extended Error Format 0009:

This format is used by the DSW21 communications device when an exception occurs.

```
0020 0009 00EEaaaa bbbbcccc dddd0000 00000000 0000eeee ffffgggg 00000000
```

Where:

- 0020 - is the FRU for the DSW21 communications device.
- 0009 - is the format type.
- aaaa - is the command status register.
- bbbb - is the stack pointer high.
- cccc - is the exception vector
- dddd - is the stack pointer low.
- eeee - is the status register.
- ffff - is the PC low.
- gggg - is the PC high.

Extended Error Format 10:

This format is used by the DSW21 communications device when it first executes code, and is used to verify that the 68K is executing instructions.

```
0020 000A 00040003 00060005 00080007 00100009 00120011 00140013
00160015
```

Where:

- 0020 - is the FRU for the DSW21 communications device.
- 000A - is the format type.

A.2.13 DSW21 Communications Utilities Error Codes

Table A-18 DSW21 Communications Utilities Error Codes

| | | |
|-----|----|-------------------------|
| 224 | E0 | Invalid utility request |
| 226 | E2 | Invalid test request |
| 255 | FF | Control C entered |

A.2.14 DSW21 Communications Device System Test Error Codes

Errors reported for the system test are the same as reported for the extended test, in addition to errors that may be reported by the VAXeln kernel service.

A.2.15 Floating Point Unit (FPU) Test Error Codes

Table A-19 FPU Test Error Codes

| Error | | |
|---------|-------------|--|
| Decimal | Hexadecimal | Meaning |
| 258 | 102 | MOVF instruction test has failed |
| 260 | 104 | Unexpected exception has occurred during MOVF test |
| 514 | 202 | MNEGF instruction test has failed |
| 516 | 204 | Unexpected exception has occurred during MNEGF test |
| 770 | 302 | ACBF instruction test has failed |
| 772 | 304 | Unexpected exception has occurred during ACBF test |
| 1026 | 402 | ADDF2/ADDF3 instruction test has failed |
| 1028 | 404 | Unexpected exception has occurred during ADDFx test |
| 1282 | 502 | CMPF instruction test has failed |
| 1284 | 504 | Unexpected exception has occurred during CMPF test |
| 1538 | 602 | CVTFD/CVTFG instruction test has failed |
| 1540 | 604 | Unexpected exception has occurred during CVTFD or CVTFG test |
| 1794 | 702 | CVTFx instruction test has failed |
| 1796 | 704 | Unexpected exception has occurred during CVTFx test |
| 2050 | 802 | CVTFx instruction test has failed |
| 2052 | 804 | Unexpected exception has occurred during CVTFx test |
| 2306 | 902 | DIVF2/DIVF3 instruction test has failed |
| 2308 | 904 | Unexpected exception has occurred during DIVFx test |
| 2562 | A02 | EMODF instruction test has failed |

Table A-19 (Cont.) FPU Test Error Codes

| Error | | |
|----------------|--------------------|---|
| Decimal | Hexadecimal | Meaning |
| 2564 | A04 | Unexpected exception has occurred during EMOF test |
| 2818 | B02 | MULF2/MULF3 instruction test has failed |
| 2820 | B04 | Unexpected exception has occurred during MULFx test |
| 3074 | C02 | POLYF instruction test has failed |
| 3076 | C04 | Unexpected exception has occurred during POLYF test |
| 3330 | D02 | SUBF2/SUBF3 instruction test has failed |
| 3332 | D04 | Unexpected exception has occurred during SUBFx test |
| 3586 | E02 | TSTF instruction test has failed |
| 3588 | E04 | Unexpected exception has occurred during TSTF test |

The FPU test does not display extended error information when an error occurs. Enter the SHOW ERROR command to view the extended error information. The extended error code formats are shown in the following examples.

Extended Error Format:

This format is used by the FPU test when it receives an exception while running one of the floating point tests.

```
001 000 VVVVVVVV EEEEEEEE EEEEEEEE EEEEEEEE EEEEEEEE EEEEEEEE EEEEEEEE
```

Where:

- VVVVVVVV - is the vector of the unexpected interrupt.
- EEEEEEEE - is other exception data and is ONLY printed out on machine checks and arithmetic traps.

The following table lists the vectors that the floating point test detects during unexpected interrupts.

Table A-20 FP Exception Vectors

| Vector | Description |
|--------|--------------------------------------|
| 004 | Machine check vector number |
| 010 | Privileged instruction vector |
| 014 | Customer reserved instruction vector |
| 018 | Reserved operand vector |
| 01c | Reserved addressing mode vector |
| 034 | Arithmetic trap vector |

A.2.16 CACHE Test Error Codes

Table A-21 CACHE Test Error Codes

| Error-decimal | Error-hexadecimal | Meaning |
|----------------------|--------------------------|--|
| 512 | 200 | Error in write/read to the DATA store |
| 768 | 300 | Error in write/read to the TAG store |
| 1024 | 400 | Valid bit is not set when it should be |
| 1280 | 500 | TAG does not contain TAG for diagnostic space |
| 1536 | 600 | Unexpected TAG parity error |
| 1792 | 700 | Cache did not provide expected data during a cache hit |
| 2048 | 800 | Cache DATA parity error |
| 2304 | 900 | Tag not valid during cache hit testing |
| 2560 | A00 | Data not valid during cache hit testing |
| 2816 | B00 | Cache data write through test failed because of invalid data in the cache data store |
| 3072 | C00 | Cache data write through test failed because of invalid data in memory |

The CACHE test does not display extended error information when an error occurs. Enter the **SHOW ERROR** command to view the extended error information. The extended error format is shown in the following example:

Extended Error Format:

This format is use by the CACHE test.

```
001 000a aaaaaaaaa eeeeeeee rrrrrrrr
```

Where:

- aaaaaaaaa - is the address within the DATA or TAG store that failed
- eeeeeeee - is the expected value of the data pattern
- rrrrrrrr - is the data that was read from the failing address

A.2.17 LCG Self-Test Error Codes

The following table contains the error codes returned by the LCG self-test. Note that the error first displayed at the console are in decimal. If the extended error message display when you enter the **SHOW ERROR** command, the error number displays in hexadecimal. Both numbers are listed in the table. (0 indicates LED off; 1 indicates LED on.)

Table A-22 LCG Self-Test Error Codes

| Error | | | |
|-------------------------------|--------------------|-----------------|---------------------------------|
| Decimal | Hexadecimal | LCG Code | Meaning |
| 2 | 2 | 0010 0010 | LCG register test has failed |
| LCG FIFO Test Failures | | | |
| 16 | 10 | 0010 0100 | FIFO status bits error |
| 18 | 12 | 0010 0100 | FIFO setup packet error |
| 20 | 14 | 0010 0100 | FIFO interrupt status bit error |
| 22 | 16 | 0010 0100 | FIFO control status bit error |
| 24 | 18 | 0010 0100 | FIFO memory pointers error |
| 26 | 1A | 0010 0100 | FIFO data flow error |
| 28 | 1C | 0010 0100 | FIFO clip list pointers error |

Table A-22 (Cont.) LCG Self-Test Error Codes

| Error | | | |
|------------------------------------|--------------------|-----------------|---|
| Decimal | Hexadecimal | LCG Code | Meaning |
| LCG Interrupt Test Failures | | | |
| 32 | 20 | 0010 1000 | Write protect not set |
| 34 | 22 | 0010 1000 | Write protect not cleared |
| 36 | 24 | 0010 1000 | Bad opcode interrupt not set |
| 38 | 26 | 0010 1000 | Bad opcode interrupt not cleared |
| 40 | 28 | 0010 1000 | Clip list wrap interrupt not set |
| 42 | 2A | 0010 1000 | Clip list wrap interrupt not cleared |
| 44 | 2C | 0010 1000 | Packet breakpoint interrupt not set |
| 46 | 2E | 0010 1000 | Packet breakpoint interrupt not cleared |
| 48 | 30 | 0010 1000 | Packet breakpoint single step |
| 50 | 32 | 0010 1000 | Address breakpoint not set |
| 52 | 34 | 0010 1000 | Address breakpoint not cleared |
| 54 | 36 | 0010 1000 | Address breakpoint not cancelled |
| 56 | 38 | 0010 1000 | Access breakpoint not set |
| 58 | 3A | 0010 1000 | Access breakpoint not cleared |
| 60 | 3C | 0010 1000 | Access breakpoint single step |
| 62 | 3E | 0010 1000 | Nop interrupt not set |
| 64 | 40 | 0010 1000 | Nop interrupt not cleared |
| 66 | 42 | 0010 1000 | Halt interrupt not set |
| 68 | 44 | 0010 1000 | Halt interrupt not cleared |
| 70 | 46 | 0010 1000 | LCG interrupt line |
| 72 | 48 | 0010 1000 | LCG memory error interrupt |

Table A-22 (Cont.) LCG Self-Test Error Codes

| Error | | | |
|---|--------------------|-----------------|--|
| Decimal | Hexadecimal | LCG Code | Meaning |
| Video Option Board VRAM Test Failures | | | |
| 80 | 50 | 0010 0001 | Pass 1 failed |
| 82 | 52 | 0010 0001 | Pass 2 failed |
| 84 | 54 | 0010 0001 | Pass 3 failed |
| 86 | 56 | 0010 0001 | Address pass test failed |
| Video Option Board Brooktree Test Failures | | | |
| 88 | 58 | 0010 0001 | BT read mask register |
| 90 | 5A | 0010 0001 | BT blink mask register |
| 92 | 5C | 0010 0001 | BT command register |
| 94 | 5E | 0010 0001 | BT test register |
| 96 | 60 | 0010 0001 | BT palette red entry |
| 98 | 62 | 0010 0001 | BT palette green entry |
| 100 | 64 | 0010 0001 | BT palette blue entry |
| 102 | 66 | 0010 0001 | BT overlay red entry |
| 104 | 68 | 0010 0001 | BT overlay green entry |
| 106 | 6A | 0010 0001 | BT overlay blue entry |
| 108 | 6C | 0010 0001 | Video option board of unknown type |
| 110 | 6E | 0010 0001 | Video option board video readback test failed |
| | 6F | 0010 0001 | This is a soft error, same as 6E |
| LCG Video Timing Test Failures | | | |
| 112 | 70 | 0010 0001 | Vertical retrace never detected |
| 114 | 72 | 0010 0001 | LCG video counters not counting |
| 116 | 74 | 0010 0001 | LCG video timing test has failed - VSTATE or HSTATE not changing |

Table A-22 (Cont.) LCG Self-Test Error Codes

| Error | | | |
|---|--------------------|-----------------|---|
| Decimal | Hexadecimal | LCG Code | Meaning |
| 118 | 76 | 0010 0001 | LCG plane mask test has failed - LCG plane mask error |
| 160 | A0 | 0010 0001 | BT463 cursor color error |
| 162 | A2 | 0010 0001 | BT463 ID REG error - wrong part |
| 164 | A4 | 0010 0001 | BT463 command REG error |
| 166 | A6 | 0010 0001 | BT463 blink mask REG error |
| 168 | A9 | 0010 0001 | BT463 test REG error |
| 170 | AA | 0010 0001 | BT463 revision REG error - wrong part rev. |
| 172 | AC | 0010 0001 | BT463 window type REG error |
| 174 | AE | 0010 0001 | BT463 color palette error |
| LCG Virtual Drawing Test Failures | | | |
| 128 | 80 | 0010 1010 | Virtual status bits error |
| 130 | 82 | 0010 1010 | Virtual translation error |
| 132 | 84 | 0010 1010 | Virtual rasterop error |
| 134 | 86 | 0010 1010 | Virtual fault error |
| 136 | 88 | 0010 1010 | Virtual invalidate error |
| LCG Physical Drawing Test Failures | | | |
| 144 | 90 | 0010 1001 | Physical rasterop error |
| 146 | 92 | 0010 1001 | Logical function error |
| 148 | 94 | 0010 1001 | Action code error |

The LCG test does not display extended error information when an error occurs. Enter the **SHOW ERROR** command to view the extended error information. The extended error codes can be displayed in the following formats. For all formats, the first field is the field replaceable unit, either 001 for the system board or 10 (hexadecimal) for the frame buffer board. The next field is the extended error format, one of the seven formats listed in the following examples.

Extended Error Format 0001:

This format is used by the LCG register test, LCG FIFO test, LCG video test, and the LCG virtual test.

```
xxx 0001 aaaaaaaaa bbbbbbbb ccccccc ddddddd
```

Where:

- xxx - is the FRU
- aaaaaaaaa - is the error code
- bbbbbbbb - is the address of the register or location being accessed
- ccccccc - is the expected data or data written
- ddddddd - is the actual data or data read

Extended Error Format 000B:

This format is used by the LCG FIFO test.

```
001 000B aaaaaaaaa bbbbbbbb ccccccc ddddddd eeeeeee
```

Where:

- 001 - is the FRU
- aaaaaaaaa - is the error code
- bbb0bbb - is the FIFO control flag being tested
- ccccccc - is the address of the register
- ddddddd - is the expected register content
- eeeeeee - is the register content

Extended Error Format 000C:

This format is used by the LCG FIFO test.

```
001 000C aaaaaaaaa bbbbbbbb ccccccc ddddddd eeeeeee
```

Where:

- 001 - is the FRU
- aaaaaaaaa - is the error code
- bbbbbbbb - is the LCG command packet being tested
- ccccccc - is the address of the register

- dddddddd - is the expected register content
- eeeeeeee - is the register content

Extended Error Format 000D:

This format is used by the LCG FIFO test, LCG interrupt test, LCG video test, and the LCG virtual drawing test.

```
xxx 000D aaaaaaaaa bbbbbbbb ccccccc ddddddd
```

Where:

- xxx - is the FRU
- aaaaaaaaa - is the error code
- bbbbbbbb - are the LCG status bits of interest
- ccccccc - is the address of the LCG status register
- ddddddd - is the LCG status register content

Extended Error Format 000E:

This format is used by the LCG FIFO test and the LCG virtual drawing test.

```
001 000E aaaaaaaaa bbbbbbbb ccccccc ddddddd eeeeeee ffffffff
```

Where:

- 001 - is the FRU
- aaaaaaaaa - is the error code
- bbbbbbbb - are the LCG FIFO control flags
- ccccccc - are the LCG status bits
- ddddddd - is the LCG status register address
- eeeeeee - is the LCG status register contents
- ffffffff - is the expected state of status bits

Extended Error Format 000F:

This format is used by the video option board readback test for four and eight plane modules.

```
xxx 000F aaaaaaaaa bbbbbbbb ccccccc ddddddd eeeeeee
```

Where:

- xxx - is the FRU
- aaaaaaaaa - is the error code
- bbbbbbbb - is the color the Brooktree is programmed
- cccccc - is the value of the video option board readback register
- dddddddd - is the expected value of the video board readback register
- eeeeeeee - head/failure (10-16 for one head, 21-23 for two heads)

Table A-23 Color Compare Failures - One Head

| Error # | Description |
|---------|---------------|
| 10 | red > blue |
| 11 | red <= blue |
| 12 | blue > green |
| 13 | blue <= green |
| 14 | green > red |
| 15 | green <= red |
| 16 | sync < green |

Table A-24 Color Compare Failures - Two Heads

| Error # | Description |
|---------|---------------|
| 20 | blue > green |
| 21 | blue <= green |
| 22 | green > red |
| 23 | green <= red |

Extended Error Format 000F:

This format is used by the video option board readback test for 24 plane modules.

```
xxx 000F aaaaaaaaa bbbbbbbb ccccccc dddddddd eeeeeeee
```

Where:

- xxx - is the FRU
- aaaaaaaaa - is the programmed test mode, colors
- bbbbbbbb - is the result read from the Brooktree test reg
- ccccccc - is the expected value of the Brooktree test reg
- dddddddd - 0

Extended Error Format 0010:

This format is used by the LCG virtual drawing test and the LCG physical drawing test.

```
001 0010 aaaaaaaaa bbbbbbbb ccccccc dddddddd eeeeeeee ffffffff
```

Where:

- 001 - is the FRU
- aaaaaaaaa - LCG (31:24) op_code, (23:16) flags
- bbbbbbbb - is the physical address for operation
- ccccccc - are the expected pixel values
- dddddddd - are the pixel values read
- eeeeeeee - is the LCG-LU function
- ffffffff - is the LCG-action code (ag_test), op_setup (_virtual tests)

A.2.18 LCG Utilities

LCG utilities can be used for visual verification of some functions of the graphics subsystem. No tests are performed. The utilities allow a user to verify screen alignment and adjust or verify screen colors and gray scales.

Table A-25 LCG Utilities

| Utility # | Description |
|-----------|-------------------------|
| 0 | White screen |
| 1 | Red screen |
| 2 | Blue screen |
| 3 | Green screen |
| 4 | Four color bars |
| 5 | Eight color bars |
| 6 | Eight gray scale bars |
| 7 | Screen of EEs |
| 8 | Cross hatch with circle |
| 9 | Screen of scrolling HHs |

A.2.18.1 LCG Utility Commands

The following table lists the LCG utility commands.

Table A-26 LCG Utility Commands

| Command | Meaning |
|----------------------|--|
| T/UT LCG | Start the utility in menu mode |
| T/UT LCG # # #... | Start the utility specified by the first number, then execute the next utility number when the space bar is pressed, loop on the list. |
| Control C | Exit the utility and erase the screen |
| Control Y | Exit the utility |

A.2.19 LCG System Test Overview

The LCG system test sets up the LCG to execute drawing commands from the LCG FIFO and clip list command buffers. The first pass draws a checkerboard on the screen by copying a "box" from main memory to each of the 24 box locations in the checkerboard, inverting every other box. Subsequent passes copy each box from the next box, and the last box from the first box on each pass. After 50 passes, the pattern is checked a byte at a time. The first error is flagged and testing stops.

A.2.20 LCG System Test Error Codes

The following table lists possible error codes that can be generated by the LCG system test.

Table A-27 LCG System Test Error Codes

| | |
|------|---|
| F001 | Initialize the test module, set up communication links with the monitor |
| F002 | MAP VRAM 1 memory for checkerboard |
| F003 | MAP LUT in VRAM 1 0x21800000 |
| F004 | MAP VRAM 2 memory for checkerboard |
| F005 | MAP LUT in VRAM 2 0x21800000 |
| F006 | MAP VRAM 3 memory for checkerboard |
| F007 | MAP LUT in VRAM 3 0x21800000 |
| F008 | MAP VRAM 4 memory for checkerboard |
| F009 | MAP LUT in VRAM 4 0x21800000 |
| F00A | Creat the video device |
| F00B | Time out, no interrupt occurred |
| F00C | Allocate system memory space for the drawing source |
| F00D | Allocate space in main memory for drawing the checkerboard |
| F00E | Error WST\$_SEND_SUMMARY |
| F00F | Error WST\$_CHECK |
| F010 | De-allocate space for the drawing source |
| F011 | FIFO BAD_OPCODE |
| F012 | MAP the LCG FIFO registers |

Table A-27 (Cont.) LCG System Test Error Codes

| | |
|------|---|
| F013 | MAP the LCG int registers |
| F014 | MAP the interrupt registers |
| F015 | MAP the LCG go register |
| F016 | MAP the FIFO I/O range |
| F017 | MAP the EDAL addresses |
| F018 | MAP the video_ref_base reg 0x20100e34 |
| F019 | MAP the configuration and test reg 20020000 |
| F0F0 | Check checkerboard error, bad read from the VRAM 1 |
| F0F1 | Check checkerboard error, bad read from the VRAM 2 |
| F1F1 | Check checkerboard error, bad read from the main memory |

A.2.21 LCG System Test Summary Screen

```

***** FST EXT_ERRPT   2LCG       0 00:12:30 *****
  LCG error summary -      Pass count = 0000002B

-----
error code          no error
-----
checker board      address  expect  read
-----
main mem error
vram error

checker board start in main mem = 00180000
vram offset to checker board   = 000A6000
box width                     = 000000A0
box height                     = 000000A5
FIFO start                     = 00140000
CLIP start                   = 00160000
Graphics int status           =

```


To find the error on the screen, note that VRAM on_screen memory starts at 21800000 (or 22800000) for head 1. Each additional head is offset by 200000.

22800000 - head 1
 22A00000 - head 2
 22C00000 - head 3
 22D00000 - head 4

The "vram offset to checker board" is added to the VRAM start to find the beginning of the checkerboard.

Each block begins one "box width" after the previous one.

A.2.22 NI Self-Test Error Codes

The following tables contain error codes returned by the Network Interface (NI) self-test. If an NI error occurs, first verify that a loopback connector is installed on the selected network port on the back of the system box or that the network cable is firmly connected. Re-execute the NI self-test if necessary.

Table A-28 NI Self-Test Error Codes

| Error | | |
|---|-------------|--|
| Decimal | Hexadecimal | Meaning |
| Network Address ROM Test Failure | | |
| 16 | 10 | Read access failed |
| 18 | 12 | Null address failure |
| 20 | 14 | Bad group address |
| 22 | 16 | Bad checksum |
| 24 | 18 | Bad group 2 |
| 26 | 1A | Bad group 3 |
| 28 | 1C | Bad test patterns |
| 32 | 20 | LANCE register address port read/write error |
| 32 | 20 | LANCE register address port R/W error |

Table A-28 (Cont.) NI Self-Test Error Codes

| Error | | |
|--|--------------------|-----------------------------|
| Decimal | Hexadecimal | Meaning |
| LANCE CSR Test Failures | | |
| 34 | 22 | LANCE CSR0 read/write error |
| 36 | 24 | LANCE CSR1 read/write error |
| 38 | 26 | LANCE CSR2 read/write error |
| 40 | 28 | LANCE CSR3 read/write error |
| LANCE Initialization Test Failures | | |
| 48 | 30 | Initialization failed |
| 50 | 32 | Receiver disabled |
| 52 | 34 | Transmitter disabled |
| 54 | 36 | Receiver enabled |
| 56 | 38 | Transmitter enabled |
| LANCE Internal Loopback/DMA Test Failures | | |
| 64 | 40 | Initialization failed |
| 66 | 42 | Transmit failed |
| 68 | 44 | Receive failed |
| 70 | 46 | Packet comparsion failed |
| 72 | 48 | Initialization DMA error |
| 74 | 4A | Transmit DMA error |
| 76 | 4C | Receive DMA error |
| 78 | 4E | Unknown tx of rx error |

Table A-28 (Cont.) NI Self-Test Error Codes

| Error | | |
|--------------------------------------|--------------------|--------------------------------------|
| Decimal | Hexadecimal | Meaning |
| LANCE Interrupt Test Failures | | |
| 80 | 50 | Initialization failed |
| 82 | 52 | Transmit failed |
| 84 | 54 | Receive failed |
| 86 | 56 | Packet comparison failed |
| 88 | 58 | NI bit in INT_REQ register not set |
| 90 | 5A | NI bit in INT_REQ register not clear |
| 92 | 5C | NI ISR not entered |
| 94 | 5E | NI ISR entered multiple times |
| LANCE CRC Test Failures | | |
| 96 | 60 | Initialization failed |
| 98 | 62 | Transmit failed |
| 100 | 64 | Receive failed |
| 102 | 66 | Packet comparison failed |
| 104 | 68 | LANCE generated bad CRC |
| 106 | 6A | LANCE rejected good CRC |
| 108 | 6C | LANCE accepted bad CRC |
| 110 | 6E | Other error |

Table A-28 (Cont.) NI Self-Test Error Codes

| Error | | |
|--|--------------------|-------------------------------|
| Decimal | Hexadecimal | Meaning |
| LANCE rx MISS/BUFF Test Failures | | |
| 112 | 70 | Initialization failed |
| 114 | 72 | Transmit failed |
| 116 | 74 | Unknown receive error |
| 118 | 76 | MISS error not flagged |
| 120 | 78 | BUFF error not flagged |
| LANCE Collision Test Failures | | |
| 128 | 80 | Initialization failed |
| 130 | 82 | Unknown transmit error |
| 132 | 84 | RETRY not flagged |
| 134 | 86 | Transmitter disabled |
| LANCE Address Filtering Test Failures | | |
| 144 | 90 | Initialization failed |
| 146 | 92 | Transmit failed |
| 148 | 94 | Receive failed |
| 150 | 96 | Packet comparison failed |
| 152 | 98 | Broadcast filtering failed |
| 154 | 9A | Promiscuous mode failed |
| 156 | 9C | Null destination accepted |
| 158 | 9E | Good logical address rejected |

Table A-28 (Cont.) NI Self-Test Error Codes

| Error | | |
|--|--------------------|--|
| Decimal | Hexadecimal | Meaning |
| LANCE External Loopback Test Failures | | |
| 160 | A0 | Initialization failed |
| 162 | A2 | Transmit failed |
| 164 | A4 | Receive failed |
| 166 | A6 | Packet comparison failed |
| 168 | A8 | Unknown transmit error |
| 170 | AA | Unknown receive error |
| 172 | AC | Check NI port loopback connector |
| LANCE tx BUFF Test Failures | | |
| 176 | B0 | Initialization failed |
| 178 | B2 | BUFF error not flagged |
| 180 | B4 | Transmitter enabled |
| 182 | B6 | Unknown transmit error |
| DMA Registers Test Failures | | |
| 208 | D0 | MAP_BASE register error |
| 210 | D2 | I/O write access to map registers failed |
| 212 | D4 | I/O read access to map registers failed |
| 214 | D6 | Parity error not flagged |

Table A-28 (Cont.) NI Self-Test Error Codes

| Error | | |
|--------------------------------|--------------------|----------------------------------|
| Decimal | Hexadecimal | Meaning |
| LANCE DMA Test Failures | | |
| 224 | E0 | Non-existent DMA not flagged |
| 226 | E2 | Invalid DMA not flagged |
| 228 | E4 | Valid DMA failed |
| 230 | E6 | DMA failed during initialization |
| 232 | E8 | DMA failed during transmit |
| 234 | EA | DMA failed during receive |

The NI test does not display extended error information when an error occurs. Enter the **SHOW ERROR** command to view the extended error information. The extended error code is shown in the following example.

Extended Error Format 0001:

This format is used by the register test.

```
0001 0001 aaaaaaaaa bbbbbbbb cccccccc
```

Where:

- aaaaaaaaa - is the register address
- bbbbbbbb - is the expected data or data written
- cccccccc - is the actual data or data read

Extended Error Format 0002:

This format is used when a DMA error occurs.

```
0001 0002 0000aaaa bbbbbbbb cccccccc dddddddd eeeeeeee ffffffff
```

Where:

- aaaa - is the actual value of the LANCE CSR0
- bbbbbbbb - is the contents of the parity control (PAR_CTL) register
- cccccccc - is the device DMA address (24 bits)
- dddddddd - is the map register physical address

- eeeeeeee - is the map register contents
- ffffffff - is the interrupt register contents

Extended Error Format 000B:

This format is used when there is a network address ROM address group error.

```
0001 000B aaaaaaaaa bbbbbbbb cccccc 0000dddd
```

Where:

- aaaaaaaaa - is the base address of the network address ROM
- bbbbbbbb - are the first four bytes of the network address
- cccccc - are the next two bytes of the network address and the two byte checksum
- dddd - is the calculated checksum

Extended Error Format 000C:

This format is used when there is a network address ROM test pattern error.

```
0001 000C aaaaaaaaa bbbbbbbb cccccc
```

Where:

- aaaaaaaaa - is the base address of the network address ROM test pattern
- bbbbbbbb - are the first four bytes of the test patterns
- cccccc - are the last four bytes of the test patterns

Extended Error Format 000D:

This format is used when there is an initialization error.

```
0001 000D 0000aaaa bbbbbbbb 0000cccc dddddddd eeeeeeee
```

Where:

- aaaa - is the actual value of the LANCE CSR0
- bbbbbbbb - is the physical address of the initialization block
- cccc - is the initialization block mode
- dddddddd - is the upper longword of the logical address filter

- eeeeeeee - is the lower longword of the logical address filter

Extended Error Format 000E:

This format is used when there is a transmit error.

```
0001 000E 0000aaaa bbbbbbbb cccccccc dddddddd
```

Where:

- aaaa - is the actual value of LANCE CSR0
- bbbbbbbb - is the physical address of the current transmit descriptor
- cccccccc - is the first longword of the transmit descriptor
- dddddddd - is the second longword of the transmit descriptor

Extended Error Format 000F:

This format is used when there is a receive error.

```
0001 000F 0000aaaa bbbbbbbb cccccccc dddddddd
```

Where:

- aaaa - is the actual value of LANCE CSR0
- bbbbbbbb - is the physical address of the current receive descriptor
- cccccccc - is the first longword of the receive descriptor
- dddddddd - is the second longword of the receive descriptor

Extended Error Format 0010:

This format is used when there is a packet error.

```
0001 0010 0000aaaa bbbbbbbb cccccccc dddddddd
```

Where:

- aaaa - is the actual value of LANCE CSR0
- bbbbbbbb - is the packet length
- cccccccc - is the packet pattern or packet index
- dddddddd - is the packet CRC

Extended Error Format 0011:

This format is used when there is an interrupt error.

```
0001 0011 0000aaaa bbbbbbbb cccccccc
```


Where:

- aaaa - is the actual value of LANCE CSRO
- bbbbbbbb - is the contents of the interrupt mask (INT_MSK) register
- cccccc - is the contents of the interrupt request (INT_REQ) register

A.2.23 NI System Test Error Codes

The following example and table explain and list NI system test error messages.

```
?? 9 NI      X      00YY      0 00:00:00.00
```

In the example, X is the source of the error:

- 1 - Test
- 2 - System test monitor
- 3 - Device driver
- 4 - VAXELN
- 5 - System

YY indicates the specific error code (shown in Table A-29).

Table A-29 NI System Test Error Codes

| Error Source (X) | Error Code (YY) | Meaning |
|------------------|-----------------|--------------------------|
| 1 | 02 | Initialization failed |
| 1 | 04 | LANCE underflow reported |
| 1 | 06 | DMA transmit failed |
| 1 | 08 | Unknown transmit error |
| 1 | 0A | Receive failed |
| 1 | 12 | DMA receive failed |
| 1 | 14 | Unknown receive error |
| 1 | 16 | Data compare error |
| 2 | 02 | WST\$INIT failed |
| 4 | 02 | Bad memory allocation |

Table A-29 (Cont.) NI System Test Error Codes

| Error Source (X) | Error Code (YY) | Meaning |
|-------------------------|------------------------|---------------------------------------|
| 4 | 04 | Create device failed |
| 4 | 06 | Create area failed |
| 5 | 02 | Unknown transmit error |
| 5 | 04 | Bad transmit status |
| 5 | 06 | Transmit own bit says LANCE |
| 5 | 08 | Bad receive status from LANCE |
| 5 | 0A | Timeout waiting for receive interrupt |
| 5 | 0C | Memory error on initialization |
| 5 | 0E | BABL error on initialization |
| 5 | 10 | MISS error on initialization |
| 5 | 12 | Parity error on initialization |
| 5 | 14 | MAP error on initialization |
| 5 | 16 | Memory error on receive |
| 5 | 18 | BABL error on receive |
| 5 | 1A | MISS error on receive |
| 5 | 1C | Parity error on receive |
| 5 | 1E | MAP error on receive |
| 5 | 20 | Memory error on transmit |
| 5 | 22 | BABL error on transmit |
| 5 | 24 | MISS error on transmit |
| 5 | 26 | Parity error on transmit |
| 5 | 28 | MAP error on transmit |

B

Reading the Diagnostic LED Codes

This chapter describes how to interpret the diagnostic LEDs on the console control panel. The LED codes covered in this chapter are:

| | |
|----------------|---------------------------------------|
| Section B.1 | Diagnostic LEDs Overview |
| Section B.1.1 | LED Error Codes |
| Section B.1.2 | Power-up and Initialization LED Codes |
| Section B.1.3 | TOY/NVR LED Codes |
| Section B.1.4 | LCG LED Codes |
| Section B.1.5 | DZ LED Codes |
| Section B.1.6 | CACHE LED Codes |
| Section B.1.7 | Memory LED Codes |
| Section B.1.8 | System Device LED Codes |
| Section B.1.9 | NI Device LED Codes |
| Section B.1.10 | SCSI Device FRU LED Codes |
| Section B.1.11 | Audio Device LED Codes |
| Section B.1.12 | DSW21 Communications Device LED Codes |

B.1 Diagnostic LED Codes

The system uses the eight LEDs on the control panel to indicate the currently executing test. When power is turned on, all the LEDs light (LED code is FF(h)), and then display different codes as the devices are tested.

The LED codes are divided into two fields. The left-most four LEDs represent the device number and the right-most four LEDs represent a substate that the device test is currently in. LED codes E0h - FFh are reserved for the console.

The system LED codes are listed in the following tables.

B.1.1 LED Error Codes

The eight LEDs on the lights and switches board can be translated into two hexadecimal or binary digits of the form:

X X X X Y Y Y Y

Where:

- X X X X is the device number (binary) currently under test. Use Table 5-3 to match the code from the LEDs to a device.
- Y Y Y Y is the subtest at which the diagnostic hung.

The LEDs can be used for troubleshooting when the console device is inoperable.

B.1.2 Power-up/Initialization LED Codes

Table B-1 Power-up and Initialization LED Codes (1111 XXXX)

| LED Depiction¹ | LED Code | Description | FRU |
|----------------------------------|-----------------|---|--------------------------------|
| 1111 1111 | FFh | Power has been applied but no instruction has been run | System module |
| 1111 1110 | FEh | ROM has been entered and initialization and testing have started | System module |
| 1111 1101 | FDh | Waiting for memory to initialize | System module, Memory modules |
| 1111 1100 | FCh | Sizing memory in the system | System module, Memory modules |
| 1111 1011 | FBh | Running a byte mask test on the memory needed by the console | System module, Memory modules |
| 1111 1010 | FAh | A full memory data path test is being performed on the memory needed by the console | System module, Memory modules |
| 1111 1001 | F9h | Initializing the console data structures | System module |
| 1111 1000 | F8h | Performing auto configuration on the machine | System module |
| 1111 0111 | F7h | Testing the NVR device | System module |
| 1111 0110 | F6h | Testing the DZ device | System module, Mouse, Keyboard |

¹In this column, 1 indicates the LED is on; 0 indicates the LED is off; X indicates either 1 or 0.

Table B-1 (Cont.) Power-up and Initialization LED Codes (1111 XXXX)

| LED Depiction¹ | LED Code | Description | FRU |
|----------------------------------|-----------------|------------------------------------|-------------------------|
| 1111 0101 | F5h | Testing the graphics output device | System module, Graphics |
| 1111 0100 | F4h | Initializing the console device | System module, Graphics |
| 1111 0011 | F3h | Entering the console program | System module |

¹In this column, 1 indicates the LED is on; 0 indicates the LED is off; X indicates either 1 or 0.

B.1.3 TOY/NVR LED Codes

Table B-2 TOY and NVR LED Codes (0001 XXXX)

| LED Depiction | LED Code | Description | FRU |
|----------------------|-----------------|-----------------------------------|---------------|
| 0001 0000 | 10h | TOY and NVR clock test has failed | System module |
| 0001 0001 | 11h | TOY and NVR test has failed | System module |

B.1.4 LCG LED Codes

Table B-3 LCG LED Codes (0010 XXXX)

| LED Depiction | LED Code | Description | FRU |
|---------------|----------|---------------------------------------|-------------------------|
| 0010 0000 | 20h | LCG test has been entered | System module, Graphics |
| 0010 0001 | 21h | LCG video RAM test has failed | System module, Graphics |
| 0010 0010 | 22h | LCG register test has failed | System module, Graphics |
| 0010 0011 | 23h | LCG FIFO test has failed | System module, Graphics |
| 0010 0100 | 24h | LCG interrupt test has failed | System module, Graphics |
| 0010 0101 | 25h | LCG address generator test has failed | System module, Graphics |
| 0010 0110 | 26h | LCG virtual test has failed | System module, Graphics |

If the graphics option fails, the system may not give you a console error message. In this case you must use the error LEDs on the lights and switches module to isolate the fault.

B.1.5 DZ LED Codes

Table B-4 DZ LED Codes (0011 XXXX)

| LED Depiction | LED Code | Description | FRU |
|----------------------|-----------------|------------------------------|-------------------------|
| 0011 0000 | 30h | DZ test has been entered | System module |
| 0011 0001 | 31h | DZ reset test has failed | System module |
| 0011 0010 | 32h | DZ modem test has failed | System module |
| 0011 0011 | 33h | DZ polled test has failed | System module |
| 0011 0010 | 34h | DZ interrupt test has failed | System module |
| 0011 0101 | 35h | LK401 test has failed | Keyboard, System module |
| 0011 0110 | 36h | Mouse test has failed | Keyboard, System module |

B.1.6 CACHE LED Codes

Table B-5 Cache LED Codes (0100 XXXX)

| LED Depiction | LED Code | Description | FRU |
|---------------|----------|--|---------------|
| 0100 0001 | 41h | Error in the data store read/write | System module |
| 0100 0010 | 42h | Error in the read /write to the tag area | System module |
| 0100 0011 | 43h | The cache did not contain the proper state of the valid bit | System module |
| 0100 0100 | 44h | Error during the cache tag validation | System module |
| 0100 0101 | 45h | Unexpected TAG parity error | System module |
| 0100 0110 | 46h | Cache did not provide the expected data during cache hit testing | System module |
| 0100 0111 | 47h | Parity not what was expected | System module |
| 0100 1000 | 48h | Tag not valid during cache hit test | System module |
| 0100 1001 | 49h | Data not expected during cache hit test | System module |
| 0100 1010 | 4Ah | Cache write through test failed. The information in the data store did not agree with the information it was to receive. | System module |

Table B-5 (Cont.) Cache LED Codes (0100 XXXX)

| LED Depiction | LED Code | Description | FRU |
|----------------------|-----------------|--|---------------|
| 0100 1011 | 4Bh | Cache write through test failed. The information in the memory did not agree with the information it was to receive. | System module |
| 0100 1011 | 4Ch | Write miss failed | System module |

B.1.7 Memory LED Codes

Table B-6 Memory FRU LED Codes (0101 XXXX)

| LED Depiction | LED Code | Description | FRU |
|----------------------|-----------------|---|---------------------------------|
| 0101 0000 | 50h | Memory byte mask test has failed | System module or memory modules |
| 0101 0001 | 51h | Memory error occurred in the forward pass | System module or memory modules |
| 0101 0010 | 52h | Memory error occurred in the reverse pass | System module or memory modules |
| 0101 0011 | 53h | Memory error in parity test 1 | System module or memory modules |
| 0101 0100 | 54h | Memory error in parity test 2 | System module or memory modules |

B.1.8 System Device LED Codes

Table B-7 System Device LED Codes (1000 XXXX)

| LED Depiction | LED Code | Description | FRU |
|---------------|----------|--|---------------|
| 1000 0000 | 80h | ROM verify test has failed | System module |
| 1000 0001 | 81h | Interrupt controller test has failed | System module |
| 1000 0010 | 82h | Invalidate filter test has failed | System module |

B.1.9 NI Device LED Codes

Table B-8 NI LED Codes (1001 XXXX)

| LED Depiction | LED Code | Description | FRU |
|---------------|----------|--|----------------------------------|
| 1001 0000 | 90h | NI test has been entered | System module |
| 1001 0001 | 91h | Network address test has failed | System module |
| 1001 0010 | 92h | NI register test has failed | System module |
| 1001 0011 | 93h | NI initialization test has failed | System module |
| 1001 0100 | 94h | NI internal loopback/DMA test has failed | System module |
| 1001 0101 | 95h | NI interrupt test has failed | System module |
| 1001 0110 | 96h | NI CRC test has failed | System module |
| 1001 0111 | 97h | NI receive MISS /BUFFER test has failed | System module |
| 1001 1000 | 98h | NI collision test has failed | System module |
| 1010 1001 | 99h | NI address filtering test has failed | System module |
| 1001 1010 | 9Ah | NI external loopback test has failed | Network, Loopback, System module |
| 1001 1011 | 9Bh | NI transmit buffer test has failed | System module |

B.1.10 SCSI Device FRU LED Codes**Table B-9 SCSI Device LED Codes (1010 XXXX)**

| LED Depiction | LED Code | Description | FRU |
|----------------------|-----------------|-------------------------------------|-----------------------|
| 1010 0000 | A0h | SCSI test has been entered | System module |
| 1010 0001 | A1h | SCSI register test has failed | System module |
| 1010 0010 | A2h | SCSI interrupt test has failed | System module |
| 1010 0011 | A3h | SCSI data transfer test has failed | System module |
| 1010 0100 | A4h | SCSI map error test has failed | System module |
| 1010 0101 | A5h | SCSI minimal device test has failed | Device, System module |


B.1.11 Audio Device LED Codes**Table B-10 Audio Device LED Codes (1011 XXXX)**

| LED Depiction | LED Code | Description |
|----------------------|-----------------|---|
| 1011 0000 | B0h | Audio test has been entered |
| 1011 0001 | B1h | Audio LIU test has failed |
| 1011 0010 | B2h | Audio MU1 register test has failed |
| 1011 0011 | B3h | Audio MAP register test has failed |
| 1011 0100 | B4h | Audio DLC register test has failed |
| 1011 0101 | B5h | Audio test generating an interrupt |
| 1011 0110 | B6h | Audio test verifying interrupts |
| 1011 0111 | B7h | Audio test disabling interrupts |
| 1011 1000 | B8h | Audio internal loopback test has failed |
| 1011 1001 | B9h | Audio test is sending out an audio signal |
| 1011 1010 | BAh | Audio test is evaluating audio input |

B.1.12 DSW21 Communications Device LED Codes**Table B-11 DSW21 Communication Device LED Codes (1100 XXXX)**

| LED Depiction | LED Code | Description | FRU |
|----------------------|-----------------|---|----------------------|
| 1100 0000 | C0h | Comm option code entered | DSW21, System module |
| 1100 0001 | C1h | Comm option ROM test has failed | DSW21, System module |
| 1100 0010 | C2h | Comm option RAM test has failed | DSW21, System module |
| 1100 0011 | C3h | Comm option self-test has failed | DSW21, System module |
| 1100 0100 | C4h | Comm option dual RAM access test has failed | DSW21, System module |
| 1100 0101 | C5h | Comm option dual ROM_RAM access test has failed | DSW21, System module |
| 1100 0110 | C6h | Comm option interrupt test has failed | DSW21, System module |
| 1100 0111 | C7h | Comm option integrated loopback test has failed | DSW21, System module |
| 1100 1000 | C8h | Comm option reset test has failed | DSW21, System module |

APP

[illegible]

C

Troubleshooting

This chapter contains a troubleshooting table that lists symptoms, possible causes, and corrective actions for the following components:

- System
- Monitor
- Mouse/Tablet
- Keyboard
- Drives
- Network
- Audio
- Expansion Box

C.1 Troubleshooting Overview

Troubleshooting is the process of isolating and diagnosing problems with the system. When the system does not operate as described in the *VAXstation 4000 Model 60 Owner's Guide* (EK-PVAX2-OM), use the information in this section to help diagnose the problem.

If the power-up tests complete, you can use the console error messages to identify the failed FRU, or you can run the self-test, system test, and utility tests in Digital Services mode to help isolate the failing FRU. The console error messages are interpreted in Appendix A.

Use the diagnostic LEDs (listed in Appendix B) on the front of the system to help diagnose problems when the system is unable to set up the console.

The troubleshooting techniques described in Table C-1 do not identify all possible problems with the system, nor do the suggested corrective actions remedy all problems.

Table C-1 Symptoms, Causes, and Action

| Symptom | Possible Cause | Corrective Action |
|---|--|--|
| System Problems | | |
| System fan is off | Power cord is not connected. | Check the power cord connections at both ends. |
| | Faulty power cord. | Replace power cord. |
| | Power supply fan has failed. | Replace the power supply. |
| Power light is off. | Power cord is not connected. | Check the power cord connections at both ends. |
| | Wall socket may not be operative. | Try a different wall socket, or try an electrical device that you know works in the wall socket. |
| | | Turn the system off for 10 seconds and then back on. Turn the system off. Unplug the video cable, communication cable, and printer. Then plug all cables back in and turn the system on. |
| Power-up display does not show after two minutes. | Defective power supply. | Replace the power supply. |
| | Monitor is not turned on. | Turn on the monitor. |
| | Monitor brightness and contrast controls are too dark to see the screen display. | Adjust the monitor brightness and contrast controls. Verify that the monitor power switch is on (1). |
| | Monitor cable or video cable is not connected. | Check that the monitor cable and video cable are plugged in at both ends. |

Table C-1 (Cont.) Symptoms, Causes, and Action

| Symptom | Possible Cause | Corrective Action |
|---|--|---|
| System Problems | | |
| | Alternate console switch is in wrong position. | Turn the power off. Change alternate console switch to down (off) position. Use a small pointed object. Do NOT use a pencil to set the switch. Turn the power back on. |
| | Monitor fuse is blown. | See the monitor guide for fuse replacement instructions. |
| | Wall socket may not be operative. | Try a different wall socket, or try an electrical device that you know works in the wall socket. |
| | | Check the diagnostic LED code. Compare the code to the LED error code tables in <i>VAXstation 4000 Service Information Kit Model 60 Base System</i> . Replace monitor failed FRU. Refer to the monitor service manual for instructions on how to replace the FRU. |
| | Color monitor is installed, but the color graphics board is not installed. | Check the graphic module part number, check to see that the monitor is designed to work with that graphics module. |
| Power-up display contains an error message. | Possible system error. | Do the "SHOW ERROR" command. Refer to the error code tables in the <i>VAXstation 4000 Service Information Kit Model 60 Base System</i> to interpret the error code. |

Table C-1 (Cont.) Symptoms, Causes, and Action

| Symptom | Possible Cause | Corrective Action |
|-----------------------------------|--|---|
| System Problems | | |
| | | Interpret the diagnostic LEDs at the front of the system. Refer to the LED error code tables in <i>VAXstation 4000 Service Information Kit Model 60 Base System</i> for the diagnostic LED error code meanings. |
| System does not boot on power-up. | Software is not installed. | Install the system software. Refer to the software documentation for installation instructions. |
| | Default recovery action is set to halt. | Change the default recovery action to boot the system from the system disk. |
| | Incorrect boot device was specified. | Change the default recovery action to boot the system from the system disk. |
| | Expansion boxes were not powered on first. | Turn the system box off, make sure the expansion boxes are on, and then turn on the system box. |
| | Boot device is not properly configured. | Do the "SHOW DEVICE" command and check to see that all devices are configured properly. If not, check SCSI IDs and SCSI cables |
| | Faulty boot device. | Run system exerciser, replace drive if defective. |
| | Unable to boot off the network (ESA0). | Refer to the network section of this table. |

Table C-1 (Cont.) Symptoms, Causes, and Action

| Symptom | Possible Cause | Corrective Action |
|---|--|---|
| Monitor Problems | | |
| No display appears on the monitor screen. | Monitor is not turned on. | Check the monitor on/off switch. Check that the monitor power cord is connected at both ends. |
| | Contrast and brightness controls are too dark to see the screen display. | Adjust the contrast and brightness controls. Refer to the monitor guide for more information. |
| | Alternate console switch is not set correctly. | Power down the system. Change the alternate console switch to the down (off) position. Use a small pointed object. Do NOT use a pencil to set the switch. Power up the system. Turn on the system box last. |
| | System board or graphics board failure. | Use the diagnostics LEDs on the front to interpret the error code and identify the failed FRU. |
| Mouse/Tablet Problems | | |
| System boots but mouse or optional tablet pointer does not appear on the screen, or monitor does not respond to pointing device commands. | Pointing device cable is installed incorrectly or is loose. | Turn off the system. Unplug and then replug the cable to rest the device. Turn on the system. |
| | The system is halted; no pointer appears on the screen. | Reboot the system. |
| | Pointing device is faulty. | Replace the pointing device. |

Table C-1 (Cont.) Symptoms, Causes, and Action

| Symptom | Possible Cause | Corrective Action |
|--------------------------|---|--|
| Keyboard Problems | | |
| Keys do not work. | Hold Screen key is active. Hold screen light is on. | Press the Hold Screen key to release hold on screen. |
| | Keyboard cable is loose or not connected. | Check the keyboard cable at both ends. |
| | Keyboard has failed. | Replace the keyboard. |

Table C-1 (Cont.) Symptoms, Causes, and Action

| Symptom | Possible Cause | Corrective Action |
|---|---|---|
| Drive Problems | | |
| Software does not work from the diskette drive, or a diskette read or write error message is displayed. | No diskette is in the diskette drive. | Insert a diskette with software. Use the instruction in the software documentation. |
| | Diskette was inserted incorrectly. | Check that the write-protect notch on the diskette is to your left when you insert the diskette and that the label is up. |
| | Diskette is damaged or does not contain software. | Try another diskette that contains software. |
| | Two SCSI identifiers are set to the same ID number. | Reset the SCSI IDs to a unique number. |
| | Loose cables. | Check to make sure all cables are connected. |
| Drive does not work. | Defective drive. | Run diagnostics to isolate fault. Replace FRU. |
| | Two SCSI identifiers are set to the same IN number. | Reset the SCSI IDs to a unique number. |
| | Loose cables. | Check to make sure all cables are connected. |
| | Defective drive. | Run diagnostics to isolate fault. Replace FRU. |

Table C-1 (Cont.) Symptoms, Causes, and Action

| Symptom | Possible Cause | Corrective Action |
|--|---|--|
| Network Problems | | |
| NI error message is displayed when verifying Ethernet. | No ThinWire or ThickWire terminator or cable was installed. | Attach a ThinWire or Standard Ethernet terminator. |
| | Network switch is not set properly. | If Ethernet is not being used, move the network switch to the left, toward standard Ethernet. |
| | Terminator is missing from network. | Check to see if a ThinWire cable was removed. If so, replace the cable with a terminator. |
| | Cable connection is loose. | Check that all connections on the Ethernet segment are secure. |
| Lights 7,4,3, and 0 on the front of the system are on. | Power supply failure. | Replace the power supply. |
| | T-connector is disconnected. | Make sure that the T-connector is disconnected to an operating ThinWire Ethernet segment. |
| Cannot boot from the network. | Local network problem. | Problem is most likely caused by the customer server system or the network. |
| | Defective NI interface. | Run diagnostics (TEST NI command) with terminators attached. Replace faulty FRU if test fails. |

Table C-1 (Cont.) Symptoms, Causes, and Action

| Symptom | Possible Cause | Corrective Action |
|--|-----------------------------------|--|
| Audio Problems | | |
| No audio tone (beep) when the system is turned on. | Speaker is turned off. | Turn on speaker using the switch located on the front of the system box. |
| | Audio speaker is not working. | Turn off the system. Plug in the headset and turn the system on. If you hear an audio tone from the headset, then there is a problem with the speaker. Replace the lights and switches module. |
| | Defective sound chip. | Run diagnostics. Replace failed FRU. |
| Expansion Box Problems | | |
| Expansion box fan is off. | Power cord is not connected. | Check the power cord connections at both ends. |
| | Faulty power cord. | Replace power cord. |
| | Power supply fan has failed. | Replace the power supply. |
| Power light is off. | Power cord is not connected. | Check the power cord connections at both ends. |
| | Wall socket may not be operative. | Try a different wall socket, or try an electrical device that you know works in the wall socket. |
| | Defective power supply. | Turn the system off for 10 seconds and then back on. Turn the system off. Replace the power supply. |
| Drive does not work. | Loose cables. | Make sure all cables are connected. |

Table C-1 (Cont.) Symptoms, Causes, and Action

| Symptom | Possible Cause | Corrective Action |
|-------------------------------|---|---|
| Expansion Box Problems | | |
| | Two SCSI identifiers are set to the same ID number. | Reset the SCSI IDs to a unique number. (See <i>BA46 Storage Expansion Box Owner's Guide</i> for SCSI settings.) |
| | Defective drive. | Run diagnostics to isolate fault. Replace FRU. |

D

FRU Part Numbers

The tables in this chapter provide the names and part numbers for the Field Replaceable Units (FRUs) for the Model 60 system box. The tables in this chapter are organized as follows:

| | |
|-----------|---|
| Table D-1 | Model 60 System Box FRUs |
| Table D-2 | Model 60 System Box Miscellaneous Hardware |
| Table D-3 | System and Expansion Box Cables and Terminators |
| Table D-5 | External System Devices and Their Cables |
| Table D-4 | Internal System Devices and Their Cables |
| Table D-6 | Expansion Box FRUs |
| Table D-7 | Monitor and Graphic Module Cross Reference |

Refer to Chapter 6 for instructions on removing and replacing FRUs.

D.1 Precautions

- Only qualified service personnel should remove or install FRUs.
- **Electrostatic discharge (ESD)** can damage integrated circuits. Always use a grounded wrist strap (part number 29-11762-00) and grounded work surface when working with the internal parts of the workstation.

NOTE

It is the customer's responsibility to back up the software before Digital Services personnel arrive at the site. This is important to ensure that data is not lost during the service process. The customer should also shut down the workstation software. Before performing any maintenance work, Digital Services personnel must confirm that the customer has completed both of these tasks.

Refer to Figure 6-1 for the location of the system FRUs.

D.2 Model 60 System Box FRUs

Table D-1 contains the part numbers for the Model 60 FRUs. These FRUs may be ordered through Digital Services.

Table D-1 Model 60 System Box FRUs

| FRU | Part Number |
|--------------------------------------|--------------------|
| Model 60 Power Supply | H7819-AA |
| 14" Monochrome | PC4XV-A2 |
| 19" Monochrome | VR262 |
| 19" Color | VR299 |
| 13" Color | VRT13-DA,D3,D4 |
| 16" Color | VRT16-DA,D4 |
| 19" Monochrome | VR319-DA,D4 |
| 19" Color | VR320-CA,C4 |
| 19" Color | VRT19-DA,D3,D4 |
| 17" Color | VRM17-AA,A3,A4 |
| VS4000 Model 60 System Module (KA46) | 54-20346-01 |

Table D-1 (Cont.) Model 60 System Box FRUs

| FRU | Part Number |
|--|--------------------|
| Lights and Switches Module | 54-20377-01 |
| DSW21 Communications Module | 54-20377-01 |
| Memory, 4MB Module (MS44-AA) | 54-19103-AA |
| Memory, 4MB Reduced Cost Module (MS44L-AL) | |
| Memory, 16MB Module (MS44-CA) | 54-19103-CA |
| Monochrome Graphics Module | 54-20361-01 |
| LCG Low Resolution Module Monochrome | 54-20363-01 |
| LCG High Resolution Frame Buffer Color | 54-20365-01 |
| LCG High Resolution Frame Buffer Monochrome | 54-20365-03 |
| SCSI-FDI Controller w/RX26 Support | 54-20764-01 |
| RX26 Diskette Drive | 54-20764-02 |
| RX26 Diskette Drive Assembly | 70-28100-01 |
| RZ23L 100MB Drive | 70-28115-01 |
| RZ24 200MB Drive | 70-28115-02 |
| RRD42 CDROM Reader | RRD42-AA |
| RRD42 CDROM Drive | RRD42-AD |
| TZ30 Tape Drive | TZ30-AX |
| TZK10 QIC Tape Drive | TZK10-AA |
| TLZ04 Cassette Tape Drive RDAT | TLZ04-AA |
| Bracket, 3.5 Disk Storage | 74-40429-01 |
| Bracket, 5.25 in Mounting | 74-40430-01 |
| Bracket, 3.5 Dual | 74-40431-01 |
| Bracket, RX26 Half-height Removable Media and FDI Module | 74-41127-01 |

Table D-2 lists miscellaneous hardware, which may be ordered through manufacturing.

D-4 FRU Part Numbers

Table D-2 Model 60 System Box Miscellaneous Hardware

| FRU | Part Number |
|--------------------------------|--------------------|
| Multiple Box Stand | H9855-AA |
| SCSI Bracket Assembly | 70-28097-01 |
| Front Bezel Blank | 70-28099-01 |
| Front Bezel for 3 1/2 in drive | 70-28099-03 |
| Front Bezel for 5 1/4 in drive | 70-28099-02 |
| Base Plastic Assembly | 70-28096-01 |
| Top Plastic Cover, I/O (CPU) | 70-28107-01 |
| Shield, I/O (KA46) | 74-40964-02 |
| Bracket, I/O (CPU) | 74-40967-01 |
| LK401 Keyboard | LK401-AA |
| Tablet | VSXXX-AB |
| Logitech Mouse | VSXXX-AA |
| Rear Opening Filler | 74-41472-01 |
| Rear Opening RFI Shield Filler | 74-41473-01 |

Table D-3 System and Expansion Box Cables and Terminators

| FRU | Part Number |
|--|--------------------|
| Ethernet Terminator (ThickWire) | 12-22196-01/02 |
| Ethernet Terminator (ThinWire) | 12-25869-01 |
| SCSI System and Expansion Box Terminator | 12-30552-01 |
| Cable High Resolution 3' Cable | 17-02720-02 |
| Cable High Resolution 10' Cable | 17-02720-01 |
| Internal Power Cable | 17-02906-01 |
| Internal SCSI Data Cable | 70-28108-01 |
| Expansion Box Internal SCSI Data Cable | 70-28109-01 |
| Expansion Box SCSI ID Select Cable | 17-02445-01 |
| Expansion Box Internal Power Harness Cable | 17-02876-02 |

Table D-4 Internal System Devices and Their Cables

| System Device | Cable P/N | Description |
|------------------------------|------------------|---|
| 3 SCSI devices | 17-02875-01 | Three 50-pin IDC to 50-pin champ (external) |
| SCSI device dc power harness | 17-02876-01 | Four 4-pin Mat-N-Loks to 4-pin mini |

Table D-5 External System Devices and Their Cables

| System Devices | Cable P/N | Description |
|-------------------------------------|------------------|--|
| System to monitor | BC27R-03 | 3 coax Dsub. to 3 BNC 39 in (99.1 cm) |
| System to VRT13 | | 3 row 15-pin Dsub. to 9-pin Dsub. 3 ft (.91 m) |
| Remote video | BC27R-10 | 3 coax Dsub. to 3 BNC 10 ft (3.0 m) |
| Remote LK/VSXXX (mouse/keyboard) | 17-02640-01 | 15-pin Dsub. to LK/VSXXX 10 ft (3.0 m) |
| Synchronous comm. option | | 50-pin Dsub. to ??-pin 2 ft (.61 m) |
| External SCSI | BC19J-03 | 50-pin champ to 50-pin champ 3 ft (.91 m) |
| AC power input (to power supply) | 17-00606-10 | IEC to 3 prong AC 6 ft (1.83 m) |
| AC power output (system to monitor) | 17-00442-25 | IEC to IEC, 39 in (99.1 cm) |

Table D-6 Expansion Box FRUs

| FRU | Part Number |
|---|--------------------|
| Expansion Box SCSI ID Select Switch Module | 54-19325-02 |
| Expansion Box Load Module | 54-20422-01 |
| RRD42 | 74-40961-02 |
| Bracket, Dual Half-height for TZK10 and RRD42 | 74-41175-01 |

Table D-7 contains a cross reference for each monitor and graphic module available for the Model 60.

Table D-7 Monitor and Graphic Module Cross Reference

| Monitor | Graphic Module |
|--|-----------------------|
| Monochrome 4 Plane Greyscale Graphic Systems 19" Monitor (VR319) | PV631-B3/BD/BE |
| Color 8 Plane Graphic Systems 16" Trinitron Monitor (VRT16) | PV631-DK/DL/DM |
| 19" Trinitron Monitor (VRT19) | PV631-DN/DP/DR |
| SPXG 8 Plane Color 3D Graphic Systems 19" Trinitron Monitor (VRT19) | PV630-RN/RP/RR |
| Monochrome 4 Plane Greyscale Graphic Systems 17" Monitor (VRM17) | PV61A-BE/BF/BH |
| 19" Monitor (VR319) | PV61A-AA/AB/AC |
| Color 8 Plane Graphic Systems 16" Trinitron Monitor (VRT16) | PV61A-AD/AE/AF |
| 19" Monitor (VR320) | PV61A-AX/AY/BA |
| 19" Trinitron Monitor (VRT19) | PV61A-AH/AJ/AK |
| SPXG 8 Plane Color 3D Graphic Systems 16" Trinitron Monitor (VRT16) | PV61A-AL/AM/AN |
| 19" Trinitron Monitor (VRT19) | PV61A-AP/AR/AS |
| SPXGT 24 Plane Color 3D Graphic Systems 19" Trinitron Monitor (VRT19) | PV61A-AT/AV/AW |
| Dual Color Screen Graphic System One 19" Trinitron Monitor (VRT19) | |

A

AC power switch, 3-9
Addressing, 1-8
Alternate consoles
 during power-up, 2-2
 Network console, 4-18
 example, 4-19
 printer port, 4-18
Alternate console switch, 3-9
Audio (AUD) self-test, 5-21
Audio in/out connector, 3-9
Audio self-test
 error codes, A-30 to A-33
AVS
 See Voltage select

B

Broadcast address, 1-27

C

Cabling
 external, 3-12, D-5
 internal, 3-6 to 3-7
CACHE
 error codes, A-54
CACHE Self-test, 5-17
Configuration
 displaying, 5-6 to 5-8
Configuration table
 device, 2-14 to 2-17
 main, 2-13 to 2-14
 overview, 2-12
Connectors, 1-4 to 1-5
Console
 error codes
 FRU, A-4

Console (cont'd)
 password, 4-11
Console commands, 4-1
 additional commands, 4-2
 HELP or ?, 4-2
 LOGIN, 4-2
 REPEAT, 4-2
memory, 4-1
Memory, 4-13
 DEPOSIT, 4-13
 EXAMINE, 4-14
processor control, 4-1
Processor control, 4-15
 BOOT, 4-16
 CONTINUE, 4-17
 INITIALIZE and UNJAM,
 4-17
 START, 4-17
SET/SHOW, 4-1, 4-3
 BFLG, 4-4
 BOOT, 4-4
 CONFIG, 4-5
 DEVICE, 4-6
 DIAGENV, 4-7
 ERROR, 4-8
 ESTAT, 4-8
 ETHER, 4-9
 FBOOT, 4-9
 HALT, 4-9
 KBD, 4-10
 MEM, 4-10
 MOP, 4-11
 PSE and PWSD, 4-11
 SCSI, 4-12
 TRIGGER, 4-12
Console devices, 2-3
Console driver interface, 2-22
Console mode, 2-3
Console port driver, 2-25

Control panel, 3-8
CPU chip, 1-6
CPU module
 removal, 6-25
 replacement, 6-25
CPU overview, 1-6

D

Data path size definitions, 2-17
Data types, 1-13
DECwindows, 1-21
Device tests, 5-11
 sequence, 2-2
 Setup required for, 5-9
Diagnostic drivers
 interfacing to, 2-20
Diagnostic environments, 4-7, 5-9
 DIAGENV command, 5-10
Diagnostic functions, 5-2
Diagnostic LED codes, B-2
 Audio device, B-12
 CACHE, B-7
 DSW21 communications device,
 B-13
 DZ, B-6
 LCG, B-5
 Memory, B-8
 NI, B-10
 Power-up/initialization, B-3
 SCSI device, B-11
 System device, B-9
 TOY and NVR, B-4
Diagnostic LEDs
 location, 3-9
Directory type definitions, 2-17
DMA devices
 address translation, 1-19
DMA mapping, 1-19
Driver descriptor
 fields, 2-19
 overview, 2-19
Drive removal, 6-6

DSW21 communications device
 error codes, A-33 to A-50
 removal, 6-26
 replacement, 6-26
 system test
 error codes, A-50
 utilities error codes, A-50
DSW21 communication system test,
 5-30
DZ Self-test, 5-16
DZ system test, 5-27

E

Entity-Based Module (EMB), 5-35
Error codes
 audio, A-30 to A-33
 Audio extended codes, A-32
 CACHE, A-54
 CACHE extended codes, A-54
 DSW21 communications device,
 A-33 to A-50
 DZ, A-7
 DZ extended code, A-7
 DZ suberror, A-8
 Floating Point Unit test (FPU),
 A-51
 Floating Point Unit test(FPU),
 A-53
 FPU extended code, A-52
 Interval timer, A-12
 LCG extended codes, A-58
 LCG self-test, A-55
 LCG system test, A-64
 LED error codes, B-2
 memory, A-11
 memory extended code, A-11
 NI extended code, A-71
 NI self-test, A-66
 SCSI, A-14
 SCSI extended code, A-16
 System device, A-13
 SYS test extended code, A-13
 TOY/NVR, A-6

Error messages
 displaying, 5-8
 extended, A-2
 format, A-2
 immediate, A-2
 Error reporting
 console error codes
 FRU, A-4

Ethernet network
 addresses, 1-27
 connection, 1-26
 packet format, 1-26
 Extended self-test
 sequence, 2-4

F

Fault isolation, C-1 to C-10
 Field replaceable units
 codes, A-4
 Field Replaceable Units
 part numbers, D-1
 removal and replacement, 6-1
 Flag definitions, 2-17
 Floating Point Unit (FPU) test
 error codes, A-51 to A-53
 Floating Point Unit test
 vectors, A-53
 Floating point unit test (FPU), 5-18
 FRUs
 see Field Replaceable Units

G

Graphics controller
 clip list, 1-22
 communication, 1-22
 overview, 1-21
 screen formats, 1-22
 graphics ROM, 1-22
 Graphics module
 removal, 6-22
 replacement, 6-23

H

Halt, 2-3
 Halt switch, 3-9
 Hard disk drive
 removal, 6-6
 replacement, 6-7

I

I/O panel, 3-10, 3-11
 Instruction set, 1-13 to 1-14
 Internal cabling, 3-7
 Internal processor registers, 1-8 to 1-12
 Interrupt controller, 1-14
 Interrupt signal sources, 1-16
 Interrupt sources and ranking, 1-15
 Interrupt vector
 generation, 1-15
 Interrupt vectors, 1-16
 Interval timer self-test IT, 5-19
 Interval timer test
 error codes, A-12

K

KA46 system module
 See System module

L

LANCE Ethernet controller chip,
 1-26
 LCG Self-test
 error codes, A-55
 LCG Self-Test, 5-15
 LCG system test
 error codes, A-64
 overview, A-64
 summary screen, A-65

LCG utilities, 5-33, A-63

 commands, A-63

 Menu, 5-34

LED error codes, B-2

Light and switches module

 removal, 6-19

 replacement, 6-19

Loopback connectors, 4-7

M

Main memory, 1-18

 address translation, 1-19

 LCG common FIFO, 1-22

 priority of requests, 1-19

 size, 1-17

 testing, 5-13

Map Base Address Register, 1-19 to 1-20

MARR gate array chip, 1-6, 1-17

Mass storage devices

 mounting areas, 3-2

Memory

 commands, 4-1, 4-13

 memory error codes, A-11

Memory module

 identification, 6-20

 removal, 6-21

 replacement, 6-22

Memory modules, 1-18

Memory self-test, 5-18

Module removal

 CPU module, 6-25

 graphics module, 6-22

 light and switches module, 6-19

 memory module, 6-21

Module replacement

 CPU module, 6-25

 graphics module, 6-23

 light and switches module, 6-19

 memory module, 6-22

Multicast address, 1-27

Multicast-group address, 1-27

N

Network address, 1-21, 1-27

Network console, 4-18

 example, 4-19

Network controller

 overview, 1-26

Network interconnect self-test, 5-19

Network interconnect system test, 5-28

NI listener utility, 5-34

NI self-test

 error codes, A-66

NI system test

 error codes, A-74

 Network interconnect system test, 5-28

NI test

 see Network interconnect test

NI utilities, 5-34

NVR Self-Test, 5-15

O

Option ROM

 overview, 2-9

 part format, 2-9

 set format, 2-11

P

Packet format, 1-22, 1-26

Password

 console, 4-11

 features, 4-11

 system

 clearing, 6-27

Physical address, 1-27

Physical addresses

 system ROM, 2-8

Power LED, 3-9

Power supply, 1-2

 overview, 3-3

Power supply (cont'd)

- physical dimensions, 3-5
- removal, 6-18
- replacement, 6-18
- specifications, 3-4 to 3-5
- voltage, 3-3

Power-up initialization code

- overview, 2-2
- scratch RAM, 2-12

Power-up sequence, 2-2 to 2-3, 5-3**Power-up test, 5-2****Printer port console, 4-18****Processor control**

- commands, 4-1, 4-15

Processor state, 1-8

R

Registers

- internal processor, 1-8 to 1-12

Removal and replacement

- CPU module, 6-25
- mass storage drives, 6-6
- precautions, 6-2
- system modules, 6-19 to 6-25
- system preparation, 6-4
- system testing, 6-27

ROM

- memory, 1-20
- network address, 1-21
- physical addresses, 1-20
- system, 1-20

RRD42 (CDROM) drive

- replacement, 6-10

RRD42 CDROM drive

- removal, 6-10

RX26 (diskette) drive

- removal, 6-12
- replacement, 6-12

S

S-chip

- address translation, 1-19
- buses, 1-18
- graphics controller, 1-21
- interrupt controller, 1-14
- invalidate filter, 1-18

SCIA

- See Shared console interface area

SCSI

- error codes, A-14
- information values, A-22, A-27
- mode values, A-26

SCSI bus signals, 1-29 to 1-30**SCSI bus termination, 1-28****SCSI controller, 1-28****SCSI device connections, 1-28****SCSI device IDs, 1-28****SCSI Self-test, 5-20****SCSI system test, 5-28**

- error codes, A-28
- summary screen, A-30

SCSI utilities, 5-36

- error messages, A-26
- invoking, 5-36
- menu example, 5-37

Secondary cache

- data store diagnostic, 1-17
- diagnostic mode, 1-17
- overview, 1-17
- tag store diagnostic, 1-17

Self-test

- CACHE, 5-17
- COMM, 5-22
- commands, 5-12
- DZ, 5-16
- error codes, A-5
- LCG, 5-15
- list of devices, 5-11
- MEM, 5-18
- NVR, 5-15

Self-test (cont'd)

- running continuously, 5-14
 - example, 5-14

- Running multiple device tests, 5-13

- Running single device test, 5-13
 - example, 5-13

- SCSI, 5-20

Serial line controller

- line usage, 1-23
- registers, 1-23

Shared console interface area

- overview, 2-23

SHOW

- ERROR, A-3

Speaker/Headset switch, 3-9

Specifications

- power supply, 3-4 to 3-5

Sync comm test

- see Synchronous communication self-test, 5-22

Synchronous communication self-test, 5-22

System box

- control panel, 3-8
- external cabling, 3-12, D-5
- I/O panel, 3-10
- internal cabling, 3-6 to 3-7
- mass storage device areas, 3-2
- overview, 3-2
- specifications, 3-13

System console commands

- see Console commands

System cover

- removal, 6-6
- replacement, 6-27

System devices

- external, 3-12, D-5
- internal, 3-6, D-4

System exerciser

- command, 6-28

System firmware

- overview, 2-1

System module

- components, 1-2 to 1-3
- connectors, 1-4

System power-up sequence, 5-2

System ROM

- overview, 2-7
- part format, 2-7
- physical addresses, 2-8
- set format, 2-8

System self-test, 5-19

System test, 5-22

- commands, 5-23
- display of, 5-24
- environments, 2-6, 5-22
- overview, 2-6
- Running
 - example, 5-24
 - summary screens, 5-26

System testing

- after removal and replacement, 6-27

SYS test

- see System self-test, 5-19

T

Tag store diagnostic access, 1-17

Time-of-year clock

- battery backup, 1-24
- chip registers, 1-24 to 1-25

Time-of-Year clock, 1-24

TLZ04 cassette tape drive

- removal, 6-14
- replacement, 6-14

TOY

- See Time-of-Year clock

TOY Self-Test, 5-15

TRIGGER, 5-35

Troubleshooting, C-1 to C-10

- diagnostic testing, 5-1

TZK10 (QIC) tape drive

- removal, 6-16
- replacement, 6-16
- SCSI ID setting, 6-16

U

UNJAM, 2-20

Utilities, 5-32

 LCG, 5-33, 5-34

 NI, 5-34

 SCSI, 5-36

Utilities test, 5-31

 overview, 2-5

V

Video option modules, 1-21

Voltage select, 3-3

W

Wrist strap, 6-2