

SunATM™ Application Programmer's Interface and Man Pages



THE NETWORK IS THE COMPUTER™

Sun Microsystems, Inc.
901 San Antonio Road
Palo Alto, CA 94303-4900 USA
650 960-1300 Fax 650 969-9131

Part No. 805-4477-10
August 1998, Revision A

Send comments about this document to: docfeedback@sun.com

Copyright 1998 Sun Microsystems, Inc., 901 San Antonio Road • Palo Alto, CA 94303 USA. All rights reserved.

This product or document is protected by copyright and distributed under licenses restricting its use, copying, distribution, and decompilation. No part of this product or document may be reproduced in any form by any means without prior written authorization of Sun and its licensors, if any. Third-party software, including font technology, is copyrighted and licensed from Sun suppliers.

Parts of the product may be derived from Berkeley BSD systems, licensed from the University of California. UNIX is a registered trademark in the U.S. and other countries, exclusively licensed through X/Open Company, Ltd.

Sun, Sun Microsystems, the Sun logo, AnswerBook, SunDocs, SunATM, and Solaris are trademarks, registered trademarks, or service marks of Sun Microsystems, Inc. in the U.S. and other countries. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. in the U.S. and other countries. Products bearing SPARC trademarks are based upon an architecture developed by Sun Microsystems, Inc.

The OPEN LOOK and Sun™ Graphical User Interface was developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

RESTRICTED RIGHTS: Use, duplication, or disclosure by the U.S. Government is subject to restrictions of FAR 52.227-14(g)(2)(6/87) and FAR 52.227-19(6/87), or DFAR 252.227-7015(b)(6/95) and DFAR 227.7202-3(a).

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

Copyright 1998 Sun Microsystems, Inc., 901 San Antonio Road • Palo Alto, CA 94303 Etats-Unis. Tous droits réservés.

Ce produit ou document est protégé par un copyright et distribué avec des licences qui en restreignent l'utilisation, la copie, la distribution, et la décompilation. Aucune partie de ce produit ou document ne peut être reproduite sous aucune forme, par quelque moyen que ce soit, sans l'autorisation préalable et écrite de Sun et de ses bailleurs de licence, s'il y en a. Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun.

Des parties de ce produit pourront être dérivées des systèmes Berkeley BSD licenciés par l'Université de Californie. UNIX est une marque déposée aux Etats-Unis et dans d'autres pays et licenciée exclusivement par X/Open Company, Ltd.

Sun, Sun Microsystems, le logo Sun, AnswerBook, SunDocs, SunATM, et Solaris sont des marques de fabrique ou des marques déposées, ou marques de service, de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays. Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays. Les produits portant les marques SPARC sont basés sur une architecture développée par Sun Microsystems, Inc.

L'interface d'utilisation graphique OPEN LOOK et Sun™ a été développée par Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox pour la recherche et le développement du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une licence non exclusive de Xerox sur l'interface d'utilisation graphique Xerox, cette licence couvrant également les licenciés de Sun qui mettent en place l'interface d'utilisation graphique OPEN LOOK et qui en outre se conforment aux licences écrites de Sun.

CETTE PUBLICATION EST FOURNIE "EN L'ETAT" ET AUCUNE GARANTIE, EXPRESSE OU IMPLICITE, N'EST ACCORDEE, Y COMPRIS DES GARANTIES CONCERNANT LA VALEUR MARCHANDE, L'APTITUDE DE LA PUBLICATION A REpondre A UNE UTILISATION PARTICULIERE, OU LE FAIT QU'ELLE NE SOIT PAS CONTREFAISANTE DE PRODUIT DE TIERS. CE DENI DE GARANTIE NE S'APPLIQUERAIT PAS, DANS LA MESURE OU IL SERAIT TENU JURIDIQUEMENT NUL ET NON AVENU.



Adobe PostScript

Contents

- 1. Application Programmers' Interface 1**
 - Using the SunATM API with the q93b and the ATM Device Drivers 2
 - Q.93b Driver Interface 2
 - Establishing a Connection to the q93b Driver 3
 - Setting up an ATM Connection Over a Switched Virtual Circuit (SVC) 3
 - Call Setup 7
 - Release Procedure 7
 - Exception Conditions 7
 - Connecting, Sending, and Receiving Data with the ATM Device Driver 9
 - Raw Mode Connections 10
 - DLPI Encapsulated Connections 10

- 2. C Library Functions 13**
 - `atm_util(3)` 19
 - `qcc_bld(3)` 28
 - `qcc_create(3)` 36
 - `qcc_len(3)` 45
 - `qcc_pack(3)` 48
 - `qcc_parse(3)` 52
 - `qcc_set_ie(3)` 60

qcc_unpack(3) 66

qcc_util(3) 71

3. File Formats 75

aarconfig(4) 76

acl.cfg(4) 85

agent.cnf(4) 87

atmconfig(4) 89

context.cfg(4) 91

ilmi.cnf(4) 94

laneconfig(4) 95

mib.rt(4) 103

party.cfg(4) 105

view.cfg(4) 108

4. Special Files 111

ba(7) 112

q93b(7) 119

5. DDI and DKI Kernel Functions 123

qcc_bld(9F) 127

qcc_create(9F) 135

qcc_pack(9F) 144

qcc_parse(9F) 148

qcc_set_ie(9F) 156

qcc_unpack(9F) 162

6. Maintenance Commands 167

aarsetup(1M) 168

aarstat(1M) 171

atmadmin(1M) 173

atmarp(1M)	178
atmgetmac(1M)	180
atmreg(1M)	181
atmsetup(1M)	183
atmsnmpd(1M)	185
atmsnoop(1M)	188
atmspeed(1M)	192
atmstat(1M)	194
ilmid(1M)	202
lanearp(1M)	205
lanesetup(1M)	208
lanestat(1M)	210
qccstat(1M)	214
Index	217

Figures

- FIGURE 1-1 ATM Signalling 2
- FIGURE 1-2 Message Format 5
- FIGURE 1-3 Normal Call Setup and Tear Down 8

Tables

TABLE 1-1	Messages Between the User and the q93b Driver	3
TABLE 1-2	Fields in the M_PROTO mblock	5
TABLE 1-3	qcc Functions	6
TABLE 1-4	atm_util Function Overview	9
TABLE 2-1	C Library Functions	13
TABLE 3-1	File Format Man Pages	75
TABLE 4-1	Special Files Man Pages	111
TABLE 5-1	DDI and DKI Kernel Function Man Pages	123
TABLE 6-1	Maintenance Command Man Pages	167

Code Samples

CODE EXAMPLE 2-1	<code>atm_util(3)</code>	Man Page	19
CODE EXAMPLE 2-2	<code>qcc_bld(3)</code>	Man Page	28
CODE EXAMPLE 2-3	<code>qcc_create(3)</code>	Man Page	36
CODE EXAMPLE 2-4	<code>qcc_len(3)</code>	Man Page	45
CODE EXAMPLE 2-5	<code>qcc_pack(3)</code>	Man Page	48
CODE EXAMPLE 2-6	<code>qcc_parse(3)</code>	Man Page	52
CODE EXAMPLE 2-7	<code>qcc_set_ie(3)</code>	Man Page	60
CODE EXAMPLE 2-8	<code>qcc_unpack(3)</code>	Man Page	66
CODE EXAMPLE 2-9	<code>qcc_util(3)</code>	Man Page	71
CODE EXAMPLE 3-1	<code>aarconfig(4)</code>	Man Page	76
CODE EXAMPLE 3-2	<code>acl.cfg(4)</code>	Man Page	85
CODE EXAMPLE 3-3	<code>agent.cnf(4)</code>	Man Page	87
CODE EXAMPLE 3-4	<code>atmconfig(4)</code>	Man Page	89
CODE EXAMPLE 3-5	<code>context.cfg(4)</code>	Man Page	91
CODE EXAMPLE 3-6	<code>ilmi.cnf(4)</code>	Man Page	94
CODE EXAMPLE 3-7	<code>laneconfig(4)</code>	Man Page	95
CODE EXAMPLE 3-8	<code>mib.rt(4)</code>	Man Page	103
CODE EXAMPLE 3-9	<code>party.cfg(4)</code>	Man Page	105
CODE EXAMPLE 3-10	<code>view.cfg(4)</code>	Man Page	108

CODE EXAMPLE 4-1	ba(7) Man Page	112
CODE EXAMPLE 4-2	q93b(7) Man Page	119
CODE EXAMPLE 5-1	qcc_bld(9F) Man Page	127
CODE EXAMPLE 5-2	qcc_create(9F) Man Page	135
CODE EXAMPLE 5-3	qcc_pack(9F) Man Page	144
CODE EXAMPLE 5-4	qcc_parse(9F) Man Page	148
CODE EXAMPLE 5-5	qcc_set_ie(9F) Man Page	156
CODE EXAMPLE 5-6	qcc_unpack(9F) Man Page	162
CODE EXAMPLE 6-1	aarsetup(1M) Man Page	168
CODE EXAMPLE 6-2	aarstat(1M) Man Page	171
CODE EXAMPLE 6-3	atmadmin(1M) Man Page	173
CODE EXAMPLE 6-4	atmarp(1M) Man Page	178
CODE EXAMPLE 6-5	atmgetmac(1M) Man Page	180
CODE EXAMPLE 6-6	atmreg(1M) Man Page	181
CODE EXAMPLE 6-7	atmsetup(1M) Man Page	183
CODE EXAMPLE 6-8	atmsnmpd(1M) Man Page	185
CODE EXAMPLE 6-9	atmsnoop(1M) Man Page	188
CODE EXAMPLE 6-10	atmspeed(1M) Man Page	192
CODE EXAMPLE 6-11	atmstat(1M) Man Page	194
CODE EXAMPLE 6-12	ilmid(1M) Man Page	202
CODE EXAMPLE 6-13	lanearp(1M) Man Page	205
CODE EXAMPLE 6-14	lanesetup(1M) Man Page	208
CODE EXAMPLE 6-15	lanestat(1M) Man Page	210
CODE EXAMPLE 6-16	qccstat(1M) Man Page	214

Preface

SunATM Application Programmer's Interface and Man Pages combines Appendix E, "Application Programmer's Interface," of the *SunATM 3.0 Installation and User's Guide* (805-0331-10) and the man pages that were shipped with the SunATM™ 3.0 software.

Note – This manual does not contain any hardware or software installation instructions. For these instructions, refer to the *SunATM 3.0 Installation and User's Guide*.

Using UNIX Commands

This document may not contain information on basic UNIX® commands and procedures such as shutting down the system, booting the system, and configuring devices.

See one or more of the following for this information:

- *Solaris 2.x Handbook for SMCC Peripherals*
- AnswerBook™ online documentation for the Solaris™ 2.x software environment
- Other software documentation that you received with your system

Typographic Conventions

TABLE P-1 Typographic Conventions

Typeface or Symbol	Meaning	Examples
AaBbCc123	The names of commands, files, and directories; on-screen computer output.	Edit your <code>.login</code> file. Use <code>ls -a</code> to list all files. % You have mail.
AaBbCc123	What you type, when contrasted with on-screen computer output.	% su Password:
<i>AaBbCc123</i>	Book titles, new words or terms, words to be emphasized. Command-line variable; replace with a real name or value.	Read Chapter 6 in the <i>User's Guide</i> . These are called <i>class</i> options. You <i>must</i> be <code>root</code> to do this. To delete a file, type <code>rm filename</code> .

Shell Prompts

TABLE P-2 Shell Prompts

Shell	Prompt
C shell	<i>machine_name%</i>
C shell superuser	<i>machine_name#</i>
Bourne shell and Korn shell	\$
Bourne shell and Korn shell superuser	#

Related Documentation

TABLE P-3 Related Documentation

Application	Title	Part Number
Installation and Service	<i>SunATM 3.0 Installation and User's Guides</i>	801-0331
Release Information	<i>SunATM 3.0 Release Notes</i>	801-3472

Sun Welcomes Your Comments

We are interested in improving our documentation and welcome your comments and suggestions. You can email your comments to us at:

`smcc-docs@sun.com`.

Please include the part number of your document in the subject line of your email.

Application Programmers' Interface

The Application Programmers' Interface (API) that is provided with this software release is an interim API from Sun which can be used on Sun Platforms.

In the ATM environment, data is sent between hosts over Virtual Circuits (VCs). VCs are point-to-point (or point-to-multipoint) connections between two or more ATM hosts.

VCs can be created in one of two ways:

- Manual configuration at each host and each intermediate network point, also known as Permanent Virtual Circuits (PVC)
- ATM signalling, also known as Switched Virtual Circuits (SVC)

The ATM Forum's User Network Interface protocol is based on the ITU's Q.2931 specification.

After the VC has been determined, the application must notify the SunATM `ba` driver that it will be sending and receiving data on the new VC.

- If using a PVC, this is the only configuration required on the Sun host.
- If using an SVC, there are two required actions:
 - Create the SVC with the `q93b` driver.
 - Establish the data connection with the `ba` driver.

Note – For historical reasons, Q.93B and Q.2931 are used interchangeably.

Using the SunATM API with the q93b and the ATM Device Drivers

The architecture illustrated in FIGURE 1-1 must be established on a SunATM system in order to perform Q.2931 signalling and send data over established connections. The ATM device driver, SSCOP modules, and q93b driver are “plumbed” at boot time. The task remaining for application developers is to create the connections between their application and the q93b and ATM device drivers.

Both the q93b and ATM device driver are STREAMS drivers; connecting to them is for the most part no different than connecting to other STREAMS drivers. The following sections describe the steps required to connect to each driver, use the drivers to establish ATM connections, and send data over those connections.

For examples of user applications that use the SunATM API, see the sample programs installed in `/opt/SUNWatm/examples`




FIGURE 1-1 ATM Signalling

Q.93b Driver Interface

The signalling API, called Q.2931 Call Control (qcc), consists of two sets of similar functions: one for applications running in the kernel, and one for applications running in user space. Each set provides functions to build and parse Q.2931 signalling messages, which are required to set up and tear down connections.

One additional function is provided to assist applications in establishing appropriate connections to the q93b driver. `q_ioc_bind` associates a service access point (SAP) with the specified connection to the q93b driver. The SAP is used by the driver to direct incoming messages to applications.

Establishing a Connection to the q93b Driver

The `open(2)` system call should be used first to obtain a file descriptor to the driver. After opening the driver, `q_ioc_bind` should be called, associating in the q93b driver a service access point (SAP) with this application. Finally, if the application is a kernel driver, it should be linked above the q93b driver, using the `I_LINK` or `I_PLINK` ioctl (refer to the `streamio(7)` man page for information about this ioctl).

Setting up an ATM Connection Over a Switched Virtual Circuit (SVC)

After connecting to the q93b driver, either by directly calling the functions as a user application, or by having a setup program connect your application driver as described in the preceding section, the q93b driver is available to your application to establish switched virtual circuits (SVCs) using the Q.2931 signalling protocol. The Q.2931 message set is displayed in TABLE 1-1.

TABLE 1-1 Messages Between the User and the q93b Driver

Message Type	Direction*
SETUP	BOTH
SETUP_ACK	UP
CALL_PROCEEDING	BOTH
ALERTING	BOTH
CONNECT	BOTH
CONNECT_ACK	UP
RELEASE	DOWN
RELEASE_COMPLETE	BOTH
STATUS_ENQUIRY	DOWN
STATUS	UP

*UP is from q93b to user;
DOWN is from user to q93b

TABLE 1-1 Messages Between the User and the q93b Driver

Message Type	Direction*
NOTIFY	BOTH
RESTART	BOTH
RESTART_ACK	BOTH
ADD_PARTY	BOTH
ADD_PARTY_ACK	BOTH
ADD_PARTY_REJECT	BOTH
PARTY_ALERTING	BOTH
DROP_PARTY	BOTH
DROP_PARTY_ACK	BOTH
LEAF_SETUP_FAIL	BOTH
LEAF_SETUP_REQ	BOTH

*UP is from q93b to user;
DOWN is from user to q93b

The q93b driver is an M-to-N mux STREAMS driver. Multiple application programs can be plumbed above the driver, and multiple physical interfaces can be connected below q93b. Applications can access any or all of the physical interfaces, and messages received on the physical interfaces may be directed to any of the applications. In order to direct messages through the q93b driver, messages from applications must include a physical interface name to identify the outgoing interface, and a SAP to identify the application to which the message should be directed on the receiving host.

Messages sent to q93b by applications should be sent in the format illustrated in FIGURE 1-2; kernel applications should use `put(9f)` to send the mblocks shown, and user applications should send two corresponding strbufs using `putmsg(2)`.




FIGURE 1-2 Message Format

TABLE 1-2 Fields in the M_PROTO mblock

Message	Explanation
Ifname	A null-terminated string containing the device name
Call_ID	A unique number from q93b per interface.
Type	The same as the Q.2931 message type except there is a local Non-Q.2931 message type SETUP_ACK. The SETUP_ACK message is used to provide the Call_ID to the user.
Error_Code	The error returned from q93b when an erroneous message is received from the user. The exact same mblock chain shall be returned to the user with the Error_Code field set. The user must always clear this field
Call_Tag	A number assigned by the calling application layer to a SETUP message. When a SETUP_ACK is received from q93b, the Call_ID has been set; the Call_Tag field can be used to identify the acknowledgment (ack) with the original request. From that point on, the Call_ID value should be used to identify the call.

The structure that is included in the M_PROTO mblock is defined as the `qcc_hdr_t` structure in the `<atm/qccotypes.h>` header file. In the second mblock, the application should leave the Q.2931 header portion (9 bytes) of the Q.2931 message blank; this information is filled in by the q93b driver. The application should also reserve 16 bytes at the end of the second mblock for the layer 2 (Q.SAAL) protocol performance. The `qcc` functions can be used to create messages in this format.

The following sections give a brief overview of Q.2931 signalling procedures, from the perspective of an application using the SunATM API. For more details on the procedures, refer to the ATM Forum's User Network Interface Specification, version 3.0, 3.1, or 4.0. For further information on the `qcc` functions, which are outlined in TABLE 1-3, see the appropriate man pages in Section 3 (for user applications) or section 9F (for kernel applications). The man pages can be accessed under the function group name, or any specific function name. For example, the man page

which documents the `qcc_bld_*` function group may be accessed by one of the following at a command prompt: `man qcc_bld`, `man qcc_bld_setup`, or `man qcc_bld_connect`. The message flow during typical call setup and tear down is diagrammed in FIGURE 1-3.

TABLE 1-3 qcc Functions

Name	Functionality	Input	Output
<code>qcc_bld_*</code>	Creates and encodes a message; enables customization of a limited set of values, depending on the message type. Configurable values are passed in as parameters.	Parameter values	Encoded Q.2931 message (in the format shown in FIGURE 1-2)
<code>qcc_parse_*</code>	Extracts a defined set of values from an encoded message	Encoded Q.2931 message (in the format shown in FIGURE 1-2)	Parameter values
<code>qcc_len_*</code>	Returns the maximum length of the buffer that should be allocated for the second <code>strbuf</code> in a Q.2931 message. Only applicable to user space applications; the kernel API allocates the buffers inside the <code>qcc_bld/qcc_pack</code> functions.	none	Maximum length of the message.
<code>qcc_create_*</code>	Creates a message structure with the required values set. The structure can then be further customized using <code>qcc_set_ie</code> .	Default parameter values	Message structure (defined in <code><atm/qcctypes.h></code>)
<code>qcc_set_ie</code>	Updates or inserts values for an information element into a message structure.	Message structure and IE structure (defined in <code><atm/qcctypes.h></code>)	Updated message structure
<code>qcc_pack_*</code>	Takes a message structure and encodes it into an actual Q.2931 message, consisting of the two <code>mblks</code> (or <code>strbufs</code>) illustrated in FIGURE 1-2.	Message structure (defined in <code><atm/qcctypes.h></code>)	Encoded Q.2931 message (in the format shown in FIGURE 1-2)
<code>qcc_unpack_*</code>	The reverse of <code>qcc_pack_*</code> : takes an encoded message and decodes the data into a message structure.	Encoded Q.2931 message (in the format shown in FIGURE 1-2)	Message structure (defined in <code><atm/qcctypes.h></code>)
<code>qcc_get_ie</code>	Extracts a single information element structure from a message structure.	Message structure and empty IE structure (defined in <code><atm/qcctypes.h></code>)	Updated IE structure

Call Setup

When the user decides to make a call, the user sends a SETUP message down to q93b and waits for a SETUP_ACK from q93b. The SETUP message should include a Broadband Higher Layer Information (BHLLI) information element which contains a four-octet SAP identified as User Specific Information. The SAP is used to identify the application to which the message should be directed by q93b on the receiving host. After receiving a SETUP_ACK with a 0 error field, the user waits for either a CALL_PROCEEDING, ALERTING, CONNECT, or RELEASE_COMPLETE message from q93b (all other messages are ignored by q93b). After the CONNECT message is received, the user can use the virtual channel.

When the user receives a SETUP message from q93b, the user responds with either a CALL_PROCEEDING, ALERTING, CONNECT, or RELEASE_COMPLETE message to q93b. After the CONNECT_ACK message is received, the user can use the virtual channel.

Release Procedure

To clear an active call or a call in progress, the user should send a RELEASE message down to q93b and wait for a RELEASE_COMPLETE from q93b. Any time the user receives a RELEASE_COMPLETE message from q93b, the user releases the virtual channel if the call is active or in progress.

q93b never sends a RELEASE message to the user; it will always send a RELEASE_COMPLETE. The user only sends the RELEASE_COMPLETE message when rejecting a call in response to a SETUP message from q93b. At any other time, to reject or tear down a call, the user sends a RELEASE message to q93b.

Exception Conditions

If for any reason q93b cannot process a SETUP message received from a user, the SETUP_ACK is returned with an error value set, and call setup is not continued. The error value will be one of the cause codes specified in the ATM Forum UNI standard.




FIGURE 1-3 Normal Call Setup and Tear Down

Connecting, Sending, and Receiving Data with the ATM Device Driver

Connecting to the ATM device driver involves several steps, which include several ioctl calls. In order to create a more standardized interface for user space applications, a set of `atm_util` functions is available to application writers. An overview of those functions is provided in TABLE 1-4. For more detailed information, refer to the `atm_util(3)` man page. The `ba(7)` man page contains a more detailed discussion of the driver-supported IOCTLS.

TABLE 1-4 `atm_util` Function Overview

Name	Functionality	Kernel Equivalent
<code>atm_open</code>	Open a stream to the ATM device driver	Must be done by a user space setup program
<code>atm_close</code>	Close a stream to the ATM device driver	Must be done by a user space setup program
<code>atm_attach</code>	Attach to a physical interface	Must be done by a user space setup program
<code>atm_detach</code>	Detach from a physical interface	Must be done by a user space setup program
<code>atm_bind</code>	Bind to a Service Access Point	send <code>DL_BIND_REQ</code>
<code>atm_unbind</code>	Unbind from a Service Access Point	send <code>DL_UNBIND_REQ</code>
<code>atm_setraw</code>	Set the encapsulation mode to raw	Send <code>DLIOCRAW</code>
<code>atm_add_vpci</code>	Associate a vpci with this connection	<code>A_ADDVC</code> ioctl
<code>atm_delete_vpci</code>	Dissociate a vpci from this connection	<code>A_DELVC</code> ioctl
<code>atm_allocate_bw</code>	Allocate constant bit rate bandwidth for this connection	<code>A_ALLOCBW</code> ioctl
<code>atm_allocate_cbr_bw</code>	Allocate constant bit rate bandwidth with more granularity than <code>atm_allocate_bw</code>	<code>A_ALLOCBW_CBR</code> ioctl
<code>atm_allocate_vbr_bw</code>	Allocate variable bit rate bandwidth	<code>A_ALLOCBW_VBR</code> ioctl
<code>atm_release_bw</code>	Release previously allocated bandwidth	<code>A_RELSE_BW</code> ioctl

Note – In the following discussion, the user space function names are used. Refer to TABLE 1-4 for the corresponding kernel space function or ioctl.

To establish a data path, the application must first open the ATM driver and attach to a specific physical interface using `atm_open()` and `atm_attach()`. Next, the connection should be associated with one or more VC(s), using `atm_add_vpci()`. If a call has been established using Q.2931 signalling, the vpci provided to `atm_add_vpci()` should be the vpci that was included in the Q.2931 signalling messages received while establishing the call.

An encapsulation method must also be selected. The SunATM device driver supports raw (null) and DLPI encapsulation. Messages sent in raw mode are sent as data only, with just a four-byte vpci as a header; DLPI mode messages are LLC-encapsulated. By default, a connection is in DLPI mode; to change the encapsulation to raw, `DLIOCRAW` should be set using `atm_setraw()`. The remaining steps depend on the encapsulation mode selected.

Raw Mode Connections

If raw mode is chosen, the only remaining configuration step is to allocate an amount of bandwidth for the use of this connection, using `atm_allocate_bw()`, `atm_allocate_cbr_bw()`, or `atm_allocate_vbr_bw()`.

From the perspective of the application/driver interface, raw mode implies that only a single message buffer (pointed to by `dataptr` in `putmsg(2)`) should be sent to the driver, containing a 4-byte vpci followed by the data. When a message is received on a vpci running in raw mode, it will be directed to an application based on the vpci. When sending a received message up to the application, the driver will strip the 4-byte vpci from the message if the application has not set `DLIOCRAW` with a call to `atm_setraw`; if `DLIOCRAW` has been set, the 4-byte vpci will be included in the message sent up to the application.

DLPI Encapsulated Connections

If DLPI mode is chosen, a SAP must be associated with the connection using `atm_bind()`. Optionally, a specific amount of bandwidth may be allocated for the connection using `atm_allocate_bw()`, `atm_allocate_cbr_bw()`, or `atm_allocate_vbr_bw()`. If bandwidth is not explicitly allocated, IP's bandwidth (which includes all available unallocated bandwidth) will be shared by the connection.

DLPI mode implies that two message buffers will be sent to the driver. The first, pointed to by `ctlptr` in `putmsg(3)`, contains the dlpi message type, which is `dl_unitdata_req` for transmit and `dl_unitdata_ind` for receive. The `vpci` is included in this buffer as well; the format for the buffer is defined in the header file `<sys/dlpi.h>`. The second buffer, pointed to by `dataptr` in `putmsg(3)`, contains the data. When the driver receives the two buffers from the application, it will remove the first buffer, add a LLC header containing the SAP which has been bound to this stream to the data buffer, and transmit it. On receive, the LLC header is stripped, the control buffer is added with the DLPI header, and the two buffers are sent up to the application indicated by the SAP in the LLC header.

C Library Functions

The man pages in this chapter describe the C library functions found in the SunATM software. Function declarations can be obtained from the `#include` files indicated on each man page.

TABLE 2-1 C Library Functions

Man Page	Description	Page Number
<code>atm_util(3)</code>	SunATM driver utilities, including: <code>atm_add_vpci(3)</code> , <code>atm_allocate_bw(3)</code> , <code>atm_allocate_cbr_bw(3)</code> , <code>atm_allocate_vbr_bw(3)</code> , <code>atm_attach(3)</code> , <code>atm_bind(3)</code> , <code>atm_close(3)</code> , <code>atm_delete_vpci(3)</code> , <code>atm_detach(3)</code> , <code>atm_open(3)</code> , <code>atm_release_bw(3)</code> , <code>atm_setraw(3)</code> , <code>atm_unbind(3)</code>	page 19
<code>qcc_bld(3)</code>	Build Q.2931 messages, with these commands: <code>qcc_bld_add_party(3)</code> , <code>qcc_bld_add_party_ack(3)</code> , <code>qcc_bld_add_party_ack_dataalen(3)</code> ,	page 28

TABLE 2-1 C Library Functions (Continued)

Man Page	Description	Page Number
	qcc_bld_add_party_dataalen(3), qcc_bld_add_party_reject(3), qcc_bld_add_party_reject_dataalen(3), qcc_bld_call_proceeding(3), qcc_bld_call_proceeding_dataalen(3), qcc_bld_connect(3), qcc_bld_connect_ack_dataalen(3), qcc_bld_connect_dataalen(3), qcc_bld_drop_party(3), qcc_bld_drop_party_ack(3), qcc_bld_drop_party_ack_dataalen(3), qcc_bld_drop_party_dataalen(3), qcc_bld_release(3), qcc_bld_release_complete(3), qcc_bld_release_complete_dataalen(3), qcc_bld_release_dataalen(3), qcc_bld_restart(3), qcc_bld_restart_ack(3), qcc_bld_restart_ack_dataalen(3), qcc_bld_restart_dataalen(3), qcc_bld_setup(3), qcc_bld_setup_dataalen(3), qcc_bld_status(3), qcc_bld_status_dataalen(3), qcc_bld_status_enquiry(3), qcc_bld_status_enquiry_dataalen(3),	
qcc_create(3)	Create Q.2931 message structures, with these commands: qcc_create_add_party(3), qcc_create_add_party_ack(3), qcc_create_add_party_reject(3),	page 36

TABLE 2-1 C Library Functions (Continued)

Man Page	Description	Page Number
qcc_len(3)	<p>qcc_create_call_proceeding(3), qcc_create_connect(3), qcc_create_connect_ack(3), qcc_create_drop_party(3), qcc_create_drop_party_ack(3), qcc_create_release(3), qcc_create_release_complete(3), qcc_create_restart(3), qcc_create_restart_ack(3), qcc_create_setup(3), qcc_create_status(3), qcc_create_status_enq(3)</p> <p>Get length of Q.2931 messages, with these commands:</p> <p>qcc_bld_add_party(3), qcc_bld_add_party_ack(3), qcc_bld_add_party_ack_dataalen(3), qcc_bld_add_party_dataalen(3), qcc_bld_add_party_reject(3), qcc_bld_add_party_reject_dataalen(3), qcc_bld_call_proceeding(3), qcc_bld_call_proceeding_dataalen(3), qcc_bld_connect(3), qcc_bld_connect_ack_dataalen(3), qcc_bld_connect_dataalen(3), qcc_bld_drop_party(3), qcc_bld_drop_party_ack(3), qcc_bld_drop_party_ack_dataalen(3), qcc_bld_drop_party_dataalen(3), qcc_bld_release(3), qcc_bld_release_complete(3),</p>	page 45

TABLE 2-1 C Library Functions (Continued)

Man Page	Description	Page Number
	qcc_bld_release_complete_dataalen(3), qcc_bld_release_dataalen(3), qcc_bld_restart(3), qcc_bld_restart_ack(3), qcc_bld_restart_ack_dataalen(3), qcc_bld_restart_dataalen(3), qcc_bld_setup(3), qcc_bld_setup_dataalen(3), qcc_bld_status(3), qcc_bld_status_dataalen(3), qcc_bld_status_enquiry(3), qcc_bld_status_enquiry_dataalen(3), qcc_ctl_len(3), qcc_len(3), qcc_max_bld_dataalen(3)	
qcc_pack(3)	Encode Q.2931 message structure information and pack into streams buffers, with these commands: qcc_pack_add_party(3), qcc_pack_add_party_ack(3), qcc_pack_add_party_reject(3), qcc_pack_call_proceeding(3), qcc_pack_connect(3), qcc_pack_connect_ack(3), qcc_pack_drop_party(3), qcc_pack_drop_party_ack(3), qcc_pack_release(3), qcc_pack_release_complete(3), qcc_pack_restart(3), qcc_pack_restart_ack(3), qcc_pack_setup(3), qcc_pack_status(3),	page 48

TABLE 2-1 C Library Functions (Continued)

Man Page	Description	Page Number
qcc_parse(3)	<p>qcc_pack_status_enq(3)</p> <p>Parse Q.2931 messages, including:</p> <p>qcc_parse_add_party(3),</p> <p>qcc_parse_add_party_ack(3),</p> <p>qcc_parse_add_party_reject(3),</p> <p>qcc_parse_call_proceeding(3),</p> <p>qcc_parse_connect(3),</p> <p>qcc_parse_drop_party(3),</p> <p>qcc_parse_drop_party_ack(3),</p> <p>qcc_parse_release(3),</p> <p>qcc_parse_release_complete(3),</p> <p>qcc_parse_restart(3),</p> <p>qcc_parse_restart_ack(3),</p> <p>qcc_parse_setup(3),</p> <p>qcc_parse_status(3),</p> <p>qcc_parse_status_enquiry(3),</p> <p>qcc_get_hdr(3)</p>	page 52
qcc_set_ie(3)	Add or update Information Elements in a Q.2931 message structure	page 60
qcc_unpack(3)	<p>Decode Q.2931 messages and unpack into message structures, with these commands:</p> <p>qcc_unpack(3),</p> <p>qcc_unpack_add_party(3),</p> <p>qcc_unpack_add_party_ack(3),</p> <p>qcc_unpack_add_party_reject(3),</p> <p>qcc_unpack_call_proceeding(3),</p> <p>qcc_unpack_connect(3),</p> <p>qcc_unpack_connect_ack(3),</p> <p>qcc_unpack_drop_party(3),</p> <p>qcc_unpack_drop_party_ack(3),</p> <p>qcc_unpack_release(3),</p>	page 66

TABLE 2-1 C Library Functions (*Continued*)

Man Page	Description	Page Number
	qcc_unpack_release_complete(3), qcc_unpack_restart(3), qcc_unpack_restart_ack(3), qcc_unpack_setup(3), qcc_unpack_status(3), qcc_unpack_status_enq(3)	
qcc_util(3)	Functional interfaces to q93b driver ioctls, including: q_ioc_bind, q_ioc_bind_lijid, q_ioc_unbind_lijid	page 71

atm_util(3)

CODE EXAMPLE 2-1 atm_util(3) Man Page

```
atm_util(3)           C Library Functions           atm_util(3)
```

NAME

atm_util, atm_open, atm_close, atm_attach, atm_detach, atm_bind, atm_unbind, atm_setraw, atm_add_vpci, atm_delete_vpci, atm_allocate_bw, atm_allocate_cbr_bw, atm_allocate_vbr_bw, atm_release_bw - Sun ATM driver utilities

SYNOPSIS

```
cc [ flag ... ] file ... -latm [ library ... ]
```

```
#include <atm/atm.h>
```

```
int atm_open(register char *interface);
```

```
int atm_close(int fd);
```

```
int atm_attach(int fd, u_long ppa, int timeout);
```

```
int atm_detach(int fd, int timeout);
```

```
int atm_bind(int fd, u_long sap, int timeout);
```

```
int atm_unbind(int fd, int timeout);
```

```
int atm_setraw(int fd);
```

```
int atm_add_vpci(int fd, vci_t vpci, int encap,  
                int buf_type);
```

```
int atm_delete_vpci(int fd, vci_t vpci);
```

```
int atm_allocate_bw(int fd, int bw);
```

```
int atm_allocate_cbr_bw(int fd, int bw);
```

```
int atm_allocate_vbr_bw(int fd, int peakbw, int avgbw,
```

CODE EXAMPLE 2-1 atm_util(3) Man Page (Continued)

```
int maxburst, int priority);  
  
int atm_release_bw(int fd);
```

MT-LEVEL

Safe.

AVAILABILITY

The functionality described in this man page is available in the SUNWatma package included with a SunATM adapter board. The libatm.a library, which is located in /opt/SUNWatm/lib, must be included at compile time as indicated in the synopsis.

DESCRIPTION

These utilities perform various operations on the SunATM device driver, ba. They may be used by application programs that need to transmit and receive data over an ATM connection to set up a data stream to the ATM driver.

Data may be transmitted over a vc connection in one of two modes: raw mode, or dlpi mode. The default is dlpi mode. Raw mode may be requested by sending down a DLIOCRAW ioctl, which is accomplished with a call to atm_setraw(). The mode chosen defines the format in which data should be sent to the driver.

Raw mode implies that only a single mblock will be sent to the driver, containing a four-byte vpci followed by the data. When a message is received on a vpci running in raw mode, the four-byte vpci will be sent up with the data.

DLPI mode implies that two mblocks will be sent to the driver. The first, of type M_PROTO, contains the dlpi message type, which is dl_unitdata_req for transmit and dl_unitdata_ind for receive. The vpci is included in this mblock as well. The dl_unitdata_req and dl_unitdata_ind header formats are defined in the header file <sys/dlpi.h>. The second mblock is of type M_DATA and contains the message. When the driver gets a message of this type from the upper layer, it will remove the first mblock, and transmit the message. On receive, the M_PROTO mblock is added, and the two-mblock structure is sent up to the user.

A method of encapsulation must also be chosen; the method of encapsulation is specified when the VC is associated with a stream (using the A_ADDVC ioctl or the atm_add_vpci() func-

tion call). Currently, null and LLC encapsulation are supported. Null encapsulation implies that a message consists only of data preceded by a four-byte vpci. This type of encapsulation is most commonly used with raw mode. LLC encapsulation implies that an LLC header precedes the data. This header will include the SAP associated with the application's stream (using the atm_bind() function call). This type of encapsulation is typically used with dlpi mode traffic.

For LLC-encapsulated traffic, the driver will automatically add the LLC header on transmit if the stream is running in dlpi mode. The driver will also strip the LLC header from incoming traffic before sending it up a dlpi mode stream. In raw mode, however, the driver does not modify the packets at all; this includes the LLC header. Thus, an application using raw mode and LLC encapsulation must include its own LLC headers on transmit and will receive data with the LLC header intact.

Received packets are directed to application streams by the driver based on the type of encapsulation. If a packet is null-encapsulated, it will be sent up the stream associated with the vpci on which the packet was received. If a packet is LLC-encapsulated, it will be sent to the stream which has bound (using atm_bind()) the SAP found in the LLC header.

NOTE: If the application is running in user space rather than kernel space, the M_PROTO and M_DATA mblocks correspond to the ctl and data buffers, respectively, which are passed into putmsg(2) or received from getmsg(2).

atm_open() opens a stream to the physical interface (i.e. ba0, ba1, etc.) passed in as a null-terminated string in interface. On success, the file descriptor (> 0) is returned.

atm_close() closes the stream specified by its file descriptor, fd.

atm_attach() associates a physical point of attachment, ppa, with an opened ba device specified by its file descriptor, fd. The ppa is usually defined as the physical interface number (0 for ba0, 1 for ba1, etc.). timeout may optionally be used to specify an amount of time in milliseconds to wait

CODE EXAMPLE 2-1 atm_util(3) Man Page (Continued)

for the function to complete. The function will fail if it does not complete in the specified amount of time. Possible values for timeout are -1, which blocks until completion, 0, which returns immediately, or a number greater than 0 which specifies a number of milliseconds to wait. This value will be rounded up to an implementation-dependent minimum value, which is currently at approximately 100 ms.

atm_detach() detaches the stream specified by its file descriptor fd from its ppa. Values of timeout apply as described in atm_attach().

atm_allocate_bw() specifies a constant bit rate bandwidth amount in megabits per second (Mbps), passed in as bw. The amount of bandwidth specified will be allocated for transmitting data from the stream identified by the file descriptor fd. All unallocated bandwidth is assigned to IP and LLC-encapsulated traffic. This step is not necessary if a stream is only to be used to receive data; nor is it necessary to allocate bandwidth for a stream which is sending LLC-encapsulated traffic.

By default, LLC-encapsulated traffic shares all unallocated bandwidth with IP. See the table below for the amount of bandwidth available to be allocated by the user. Bandwidth may be allocated to a finer granularity using atm_allocate_cbr_bw().

atm_allocate_cbr_bw() specifies an amount of constant bit rate bandwidth in units of 64 kilobits per second (Kbps), passed in as bw. The amount of bandwidth specified will be allocated for transmitting data from the stream identified by the file descriptor fd. All unallocated bandwidth is assigned to IP and LLP-encapsulated traffic. Allocation of bandwidth is not necessary if a stream is only to be used to receive data; nor is it necessary to allocate bandwidth for a stream running in raw mode. By default, dlpi mode traffic shares all unallocated bandwidth with IP. See the table below for the amount of bandwidth available to be allocated by the user. Bandwidth may be allocated with less granularity (in units of megabits per second) using atm_allocate_bw().

atm_allocate_vbr_bw() specifies an amount of variable bit rate bandwidth to allocate for the stream identified by the file descriptor fd. Variable bit rate traffic is implemented by the SunATM hardware according to the GCRA (Generic Cell

CODE EXAMPLE 2-1 atm_util(3) Man Page (Continued)

Rate Algorithm) as defined by the ATM Forum UNI 3.0 specification. The parameters peakbw and avgbw are passed in units of 64 kilobits per second (Kbps), and represent the Peak Cell Rate and Sustainable Cell Rate, respectively. The Sustainable Cell Rate must be available within the bandwidth parameters of the hardware, which are described in the following table. The maxburst parameter specifies the number of cells which may be sent back to back on the media, corresponding to the Maximum Burst Size in the UNI spec. Finally, priority may be AVBR_HIGH_PRI or AVBR_LO_PRI; AVBR_HIGH_PRI will always get the requested bandwidth, while AVBR_LO_PRI can starve if other users request all available bandwidth.

Available Bandwidth

Product	SunATM-155		SunATM-622	
Unit of Measure	Mbps	64 Kbps	Mbps	64 Kbps
Total Bandwidth	155	2480	622	9952
Cell Header/Phy Layer Overhead	20	320	88	1408
Reserved by Software	0.125	2	0.125	2
Available to User	134.875	2158	533.875	8542

atm_release_bw() releases all bandwidth that has been previously allocated to the stream identified by fd.

atm_add_vpci() adds the given virtual path connection identifier, vpci, to those recognized on the specified stream (identified by its file descriptor, fd). The type of encapsulation that is being used on this connection must also be specified in encap; the possible values are NULL_ENCAP, LLC_ENCAP, and NLPID_ENCAP, as defined in <atm/atmioctl.h>.

CODE EXAMPLE 2-1 atm_util(3) Man Page (Continued)

Finally, the buffer type must be specified in `buf_type`; definitions may also be found in `<atm/atmiocctl.h>` for the possible types `SMALL_BUF_TYPE`, `BIG_BUF_TYPE`, and `HUGE_BUF_TYPE`.

`atm_delete_vpci()` deletes given virtual path connection identifier, `vpci`, from the specified stream (identified by its file descriptor, `fd`).

`atm_bind()` binds a service access point, `sap`, to an opened stream, specified by its file descriptor, `fd`. `sap` values of `0x800` and `0x806` are reserved for IP and ARP traffic, respectively; the user shall not use these values. The `sap` is used by the driver to direct traffic to upper layers if LLC encapsulation is used. This function also has a timeout parameter; the values of timeout described in `atm_attach()` apply in `atm_bind()` as well.

`atm_unbind()` disassociates a stream-to-`sap` binding. The stream is specified by its file descriptor, `fd`. Values of timeout apply as described in `atm_attach()`.

`atm_setraw()` indicates to the driver that the stream specified by the file descriptor `fd` will be transmitting and receiving raw data which will be interpreted directly by the application at the stream head. The only header information included in messages passed down the stream will be the 4-byte virtual path connection identifier. When a message is received, the `vpci` will be used to direct the message to upper layers.

The ordering of the atm utility function calls is important. After calling `atm_open()`, the order must be `atm_attach()`, followed by `atm_add_vpci()`. Next, depending on the type of encapsulation used on this stream, should be either `atm_bind()` for LLC encapsulation (dlpi mode) or `atm_setraw()` for null encapsulation (raw mode). Finally, bandwidth may be allocated with a call to `atm_alloc_bw()`, `atm_alloc_cbr_bw()`, or `atm_alloc_vbr_bw()`. All functions must be called only once per interface, with the exception of `atm_add_vpci()`, which may be called multiple times to support multiple `vpcis`.

RETURN VALUES

All functions return `-1` on error. With the exception of `atm_open`, which returns the file descriptor on success, all functions return `0` on success.

EXAMPLES

The following example opens a stream to ba0 and sets up that stream to communicate over vpci 0x100 at 10 Mbits/sec in raw mode.

```

#include <stdio.h>
#include <sys/types.h>
#include <sys/stropts.h>
#include <sys/errno.h>
#include <atm/atm.h>

main()
{
    char    interface[] = "ba0";
    int     fd;
    int     ppa;
    int     bw = 10;
    int     vpci = 0x100;
    char    ctlbuf[256];
    char    databuf[256];
    struct strbuf    ctl, data;
    ctl.buf = ctlbuf;
    data.buf = databuf;
    ctl.maxlen = data.maxlen = 256;

    ppa = atoi(&interface[strlen (interface) - 1]);
    if ((fd = atm_open(interface)) < 0) {
        perror("open");
        exit(-1);
    }
    atm_attach(fd, ppa);

    if (atm_add_vpci(fd, vpci, LLC_ENCAP, BIG_BUF_TYPE) < 0) {
        perror("atm_add_vpci");
        exit(-1);
    }
    if (atm_setraw(fd) < 0) {
        perror("atm_setraw");
        exit(-1);
    }

    <construct a message to pass down in ctlbuf and databuf>

    if (putmsg(fd, &ctl, &data, 0) < 0) {
        perror("putmsg");
    }
}

```

CODE EXAMPLE 2-1 atm_util(3) Man Page (Continued)

```
        exit(-1);
    }
}
```

The following example opens a stream to ba0 and sets up that stream to communicate over vpci 0x100, using sap 0x100, in dlpi mode.

```
#include <stdio.h>
#include <sys/types.h>
#include <sys/stropts.h>
#include <sys/errno.h>
#include <sys/dlpi.h>
#include <atm/atm.h>

main()
{
    char    interface[] = "ba0";
    int     fd;
    int     ppa;
    int     vpci = 0x100;
    int     *vpcip;
    int     sap = 0x100;
    char    ctlbuf[256];
    char    databuf[256];
    struct strbuf    ctl, data;
    dl_unitdata_req_t    *dludp;
    ctl.buf = ctlbuf;
    data.buf = databuf;
    ctl.maxlen = data.maxlen = 256;

    ppa = atoi(&interface[strlen (interface) - 1]);
    if ((fd = atm_open(interface)) < 0) {
        perror("open");
        exit(-1);
    }
    atm_attach(fd, ppa);

    if (atm_add_vpci(fd, vpci, LLC_ENCAP, BIG_BUF_TYPE) < 0) {
        perror("atm_add_vpci");
        exit(-1);
    }
    atm_bind(fd, sap);

    <construct the message in databuf>
```

CODE EXAMPLE 2-1 atm_util(3) Man Page (Continued)

```
        ctllen = sizeof (dl_unitdata_req_t) + 4;
        memset(ctlbuf, 0, ctllen);
        dludp = (dl_unitdata_req_t *) ctlbuf;
        dludp->dlprimitive = DL_UNITDATA_REQ;
        dludp->dl_dest_addr_length = 4;
        dludp->dl_dest_addr_offset = sizeof (dl_unitdata_req_t);
        vpcip = (int *) &ctlbuf[sizeof (dl_unitdata_req_t)];
        *vpcip = vpci;

        if (putmsg(fd, &ctl, &data, 0) < 0) {
            perror("putmsg");
            exit(-1);
        }
    }
```

SEE ALSO

dlpi(7), ba(7)

qcc_bld(3)

CODE EXAMPLE 2-2 qcc_bld(3) Man Page

qcc_bld(3) C Library Functions qcc_bld(3)

NAME

qcc_bld, qcc_bld_setup, qcc_bld_alerting,
qcc_bld_call_proceeding, qcc_bld_connect, qcc_bld_release,
qcc_bld_release_complete, qcc_bld_status,
qcc_bld_status_enquiry, qcc_bld_notify, qcc_bld_restart,
qcc_bld_restart_ack, qcc_bld_add_party,
qcc_bld_add_party_ack, qcc_bld_party_alerting,
qcc_bld_add_party_reject, qcc_bld_drop_party,
qcc_bld_drop_party_ack, qcc_bld_leaf_setup_fail,
qcc_bld_leaf_setup_req - build Q.2931 messages

SYNOPSIS

```
cc [ flag ... ] file ... -latm [ library ... ]
```

```
#include <atm/types.h>
```

```
#include <atm/qcc.h>
```

```
int qcc_bld_setup(strbuf_t *ctlp, strbuf_t *datap,  
char *ifname, int calltag, int vci,  
int forward_sdu_size, int backward_sdu_size,  
atm_addr_t *src_addrp, atm_addr_t *dst_addrp,  
int sap, int endpt_ref);
```

```
int qcc_bld_alerting(strbuf_t *ctlp, strbuf_t *datap,  
char *ifname, int callid, int vci, int endpt_ref);
```

```
int qcc_bld_call_proceeding(strbuf_t *ctlp, strbuf_t *datap,  
char *ifname, int callid, int vci, int endpt_ref);
```

```
int qcc_bld_connect(strbuf_t *ctlp, strbuf_t *datap,  
char *ifname, int callid, int vci,  
int forward_sdu_size, int backward_sdu_size,  
int endpt_ref);
```

```
int qcc_bld_release(strbuf_t *ctlp, strbuf_t *datap,  
char *ifname, int callid, int cause);
```

CODE EXAMPLE 2-2 qcc_bld(3) Man Page (Continued)

```
int qcc_bld_release_complete(strbuf_t *ctlp,
    strbuf_t *datap, char *ifname, int callid, int cause);

int qcc_bld_status_enquiry(strbuf_t *ctlp, strbuf_t *datap,
    char *ifname, int callid, int endpt_ref);

int qcc_bld_status(strbuf_t *ctlp, strbuf_t *datap,
    char *ifname, int callid, int callstate, int cause,
    int endpt_ref, int endpt_state);

int qcc_bld_notify(strbuf_t *ctlp, strbuf_t *datap,
    char *ifname, int callid, int contentlen,
    u_char *contentp, int endpt_ref);

int qcc_bld_restart(strbuf_t *ctlp, strbuf_t *datap,
    char *ifname, int callid, int vci, int rstall);

int qcc_bld_restart_ack(strbuf_t *ctlp, strbuf_t *datap,
    char *ifname, int callid, int vci, int rstall);

int qcc_bld_add_party(strbuf_t *ctlp, strbuf_t *datap,
    char *ifname, int callid, int forward_sdu_size,
    int backward_sdu_size, atm_address_t *src_addrp,
    atm_address_t *dst_addrp, int sap, int endpt_ref);

int qcc_bld_add_party_ack(strbuf_t *ctlp, strbuf_t *datap,
    char *ifname, int callid, int endpt_ref);

int qcc_bld_party_alerting(strbuf_t *ctlp, strbuf_t *datap,
    char *ifname, int callid, int endpt_ref);

int qcc_bld_add_party_reject(strbuf_t *ctlp,
    strbuf_t *datap, char *ifname, int callid, int cause,
    int endpt_ref);

int qcc_bld_drop_party(strbuf_t *ctlp, strbuf_t *datap,
    char *ifname, int callid, int cause, int endpt_ref);

int qcc_bld_drop_party_ack(strbuf_t *ctlp, strbuf_t *datap,
    char *ifname, int callid, int cause, int endpt_ref);

int qcc_bld_leaf_setup_fail(strbuf_t *ctlp, strbuf_t *datap,
    char *ifname, int callid, int cause,
    atm_address_t *dst_addrp, int leaf_num);
```

CODE EXAMPLE 2-2 qcc_bld(3) Man Page (Continued)

```
int qcc_bld_leaf_setup_req(strbuf_t *ctlp, strbuf_t *datap,  
    char *ifname, int leaftag, atm_address_t *src_addrp,  
    atm_address_t *dst_addrp, int lij_callid);
```

MT-LEVEL

Safe.

AVAILABILITY

The functionality described in this man page is available in the SUNWatma package included with the SunATM adapter board. The libatm.a library, which is located in /usr/lib, must be included at compile time as indicated in the synopsis.

DESCRIPTION

These functions build the various messages that make up the Q.2931 protocol which is used for ATM signalling. A full description of the message format and use can be found in the ATM Forum's User Network Interface Specification, V3.0, V3.1, or V4.0. The messages built will conform to the version of the UNI Specification which is configured on the indicated interface. The functions may be used by processes which are running in user space.

In general, no error checking is performed on the data that is passed in. Whatever data is passed in will be placed in the message that is built without examination. The only exceptions to this are mentioned in the function descriptions.

Each function requires a minimum of 4 parameters: ctlp and datap, which are pointers to strbuf_t buffers; ifname, which is a string containing the physical interface (such as ba0); and an integer, either calltag or callid, depending on the message type. calltag is used in the setup message only; it is a reference number that is assigned by the calling application. callid is used in all other messages; it is assigned by the lower layer and will be sent up to the user, with the calltag, in the setup_ack message.

ctlp and datap make up the control and data portions of the constructed message, corresponding to the M_PROTO and M_DATA blocks of the message that will be passed downstream. The buffer fields in the structures which ctlp and datap point to (ctlp->buf and datap->buf) must be allocated before calling a qcc_bld* function; size information may be obtained using the qcc_bld*_datalen() functions (see qcc_len(3)).

CODE EXAMPLE 2-2 qcc_bld(3) Man Page (Continued)

After successful return from a `qcc_bld*` function, the message may be passed down an open stream using the `putmsg(2)` function, with `ctlp` and `datap` as the buffer parameters for `putmsg`.

Other parameters for each function depend on the type of information required for each message type, and are defined in the paragraphs describing each function call.

After a message has been built, the user may add IEs that are not built into the message; however, the size information returned by the `qcc_len` functions only includes the IEs documented here. The user must allocate enough additional space and correct the message length value in the Q.2931 header if additional IEs are required in the message.

`qcc_bld_setup()` constructs a setup message containing some or all of the following Information Elements: AAL parameters, ATM user cell rate, broadband bearer capability, called party number, calling party number, quality of service parameter, and endpoint reference. The user must pass in the forward and backward sdu sizes for the AAL parameter IE, an ATM address for the destination for the called party number IE, and one for itself for the calling party number IE (`atm_address_t` format is defined in the `<atm/qcc.h>` header file). The value passed in the `sap` parameter is placed in a broadband higher layer IE. The higher layer IE indicates the sap to which received messages should be directed. If the user passes in a positive `vci`, a connection identifier IE will be included; if the user passes in a non-negative `endpt_ref` value (0 is valid), an endpoint reference IE is included. The endpoint reference IE indicates that this is a point-to-multipoint call.

`qcc_bld_alerting()` is specific to UNI 4.0. It builds an alerting message containing a connection identifier IE if a positive `vci` is passed in, and an endpoint reference IE if a non-negative `endpt_ref` is passed in. An endpoint reference IE should only appear if the call is a point-to-multipoint call. The alerting message is only supported under UNI 4.0.

`qcc_bld_call_proceeding()` includes a connection identifier IE if a positive `vci` is passed in, and an endpoint reference IE if a non-negative `endpt_ref` is passed in. An endpoint reference IE should only appear if the call is a point-to-multipoint call.

qcc_bld_connect() includes an AAL parameters IE, requiring the forward_ and backward_sdu_size values, a connection identifier IE if a positive vci value is passed in, and an endpoint reference IE if a non-negative endpt_ref value is passed in. An endpoint reference IE should only appear if the call is a point-to-multipoint call.

qcc_bld_release() includes a cause IE for which the user must pass in a cause value. The possible values can be found in the <atm/qcc.h> header file. The same is true for qcc_bld_release_complete().

qcc_bld_status_enquiry() includes only an endpoint reference IE if a non-negative endpt_ref value is passed in. An endpoint reference IE should only appear if the call is a point-to-multipoint call.

qcc_bld_status() includes a call state IE, requiring the user pass in the callstate parameter; possible values can be found in the <atm/qcc.h> header file. It also includes a cause IE; the cause value must also be passed in. Its possible values may also be found in the <atm/qcc.h> header file. Finally, if the call is a point-to-multipoint call, endpoint reference and endpoint state IEs may also be included; they are included if a non-negative endpt_ref value is passed in. The endpt_state parameter is used in the endpoint state IE; possible party state values may be found in <atm/qcc.h>.

qcc_bld_notify() is specific to UNI 4.0. It builds a notify message, including a notification indicator IE, which contains a buffer of user-defined information up to a maximum length of 16 bytes (defined by contentlen and contentp), and an endpoint reference IE if a non-negative endpt_ref value is passed in. An endpoint reference IE should only appear if the call is a point-to-multipoint call. The notify message is only valid under UNI 4.0.

qcc_bld_restart() includes a restart indicator IE, which is used to determine whether an individual call or all calls on an interface should be restarted. If rstall is 0, only the call identified by vci should be restarted; in this case, a connection identifier IE will also be included. If rstall is non-zero, all calls will be restarted. The same format applies to the qcc_bld_restart_ack() function.

CODE EXAMPLE 2-2 qcc_bld(3) Man Page (Continued)

`qcc_bld_add_party()` constructs an add party message for a point-to-multipoint call. The message constructed will contain an AAL parameters IE, which includes the `forward_` and `backward_sdu` parameters, a calling party number IE, which includes the value pointed to by `src_addrp`, a called party number IE, which includes the value pointed to by `dst_addrp`, a broadband higher layer information IE, which includes the `sap` parameter, and an endpoint reference IE, which includes the `endpt_ref` parameter. The `sap` value in the broadband higher layer information IE indicates the `sap` to which the message should be passed by the receiving host.

`qcc_bld_add_party_ack()` constructs an add party ack message which includes an endpoint reference IE, for which the `endpt_ref` parameter is required.

`qcc_bld_party_alerting()` is specific to UNI 4.0. It builds a party alerting message, containing an endpoint reference IE, for which the `endpt_ref` parameter is required.

`qcc_bld_add_party_reject()` includes a cause IE, containing the cause value passed in. The possible cause values may be found in the `<atm/qcc.h>` header file. An endpoint reference IE is also included, which requires the `endpt_ref` parameter.

`qcc_bld_drop_party()` constructs a drop party message. The message constructed will contain two IEs: a cause IE, which requires the cause parameter, and an endpoint reference IE, which requires the `endpt_ref` parameter. Possible cause values may be found in the header file `<atm/qcc.h>`.

`qcc_bld_drop_party_ack()` contains an endpoint reference IE, requiring the `endpt_ref` parameter, and optionally, a cause IE. The cause IE will be included if a positive cause value is passed in. Possible cause values may be found in the `<atm/qcc.h>` header file.

`qcc_bld_leaf_setup_fail()` is specific to UNI 4.0. It contains a cause IE if a non-negative cause value is passed in; a called number IE if a non-null `dst_addrp` is passed in; and a leaf number IE, for which the `leaf_num` parameter is required. This message type is only valid under UNI 4.0.

`qcc_bld_leaf_setup_req()` is specific to UNI 4.0. It contains Calling Number and Called Number IEs if non-null

CODE EXAMPLE 2-2 qcc_bld(3) Man Page (Continued)

src_addrp and dst_addrp are passed in, respectively; it also contains a leaf initiated join call identifier IE for which lij_callid is required, and a leaf number IE. The leaf number is assigned by the q93b driver. Because the leaf number is assigned by the q93b driver, a mechanism similar to that used in the setup and setup_ack messages is used with the leaf number: the user must provide a 'leaftag' parameter in the call to qcc_bld_leaf_setup_req(); this tag is inserted in the calltag field of the qcc header. When the message is received and accepted by the q93b driver, a leaf_setup_ack message is returned, containing both the leaftag, in the calltag field of the qcc header, and the driver-assigned leaf number, in the callref field. The leaf_setup_req and leaf_setup_ack messages are the only messages which will not contain a call reference value in the callref field; this is because the messages are not tied to a specific call. This message, and the leaf-initiated join functionality, are only supported under UNI 4.0.

RETURN VALUES

All functions return 0 on success and -1 on error.

EXAMPLES

The following code fragment builds a setup message and sends it downstream.

```
#include <atm/limits.h>
#include <atm/qcc.h>

char    ifname[QCC_MAX_IFNAME_LEN] = "ba0";
int     calltag = 0x1234;
int     vci = 0x100;
int     forward_sdusize = 0x2378;
int     backward_sdusize = 0x2378;
int     sap = 0x100;

atm_addr_t    src_addr = {
    0x45, 0x00, 0x00, 0x00, 0x00, 0x00, 0x00,
    0x00, 0x0f, 0x00, 0x00, 0x00, 0x00,
    0x08, 0x00, 0x20, 0x1a, 0xe1, 0x53, 0x00
};

atm_addr_t    dst_addr = {
    0x45, 0x00, 0x00, 0x00, 0x00, 0x00, 0x00,
    0x00, 0x0f, 0x00, 0x00, 0x00, 0x00,
    0x08, 0x00, 0x20, 0x1a, 0xb6, 0xb9, 0x00
};
```

CODE EXAMPLE 2-2 qcc_bld(3) Man Page (Continued)

```
};

struct strbuf  ctl, data;
char          ctlbuf[QCC_MAX_CTL_LEN];
char          databuf[QCC_MAX_DATA_LEN];

ctl.buf = ctlbuf;
data.buf = databuf;
ctl.maxlen = QCC_MAX_CTL_LEN;
data.maxlen = QCC_MAX_DATA_LEN;

if ((qcc_bld_setup(&ctl, &data, ifname, calltag, vci,
                  forward_sdusize, backward_sdusize,
                  &src_addr, &dst_addr, sap, -1)) < 0) {
    printf("qcc_bld_setup failed\n");
    exit (-1);
}

if (putmsg(fd, &ctl, &data, 0) < 0) {
    perror("putmsg");
    exit (-1);
}
```

SEE ALSO

qcc_len(3), qcc_parse(3), qcc_util(3), q93b(7)

"ATM User-Network Interface Specification, V3.0," ATM Forum.

"ATM User-Network Interface Specification, V3.1," ATM Forum.

"ATM User-Network Interface Specification, V4.0," ATM Forum.

NOTES

This API is an interim solution until the ATM Forum has standardized an API. At that time, Sun will implement that API, and support for the Q.2931 Call Control library may not be continued.

The additional support of the UNI 4.0 signalling specification includes the addition of several new message types which are not supported in the earlier versions of the UNI specification. These message types, if sent on an interface configured for UNI 3.0 or 3.1, will be discarded by the q93b driver and will not be sent out to the network. The UNI 4.0-specific messages are Alerting, Notify, Party Alerting, Leaf Setup Fail, and Leaf Setup Request, and are identified in the applicable function descriptions.

qcc_create(3)

CODE EXAMPLE 2-3 qcc_create(3) Man Page

qcc_create(3) C Library Functions qcc_create(3)

NAME

qcc_create, qcc_create_setup, qcc_create_alerting,
qcc_create_call_proceeding, qcc_create_connect,
qcc_create_connect_ack, qcc_create_release,
qcc_create_release_complete, qcc_create_status,
qcc_create_status_enq, qcc_create_notify,
qcc_create_restart, qcc_create_restart_ack,
qcc_create_add_party, qcc_create_add_party_ack,
qcc_create_party_alerting, qcc_create_add_party_reject,
qcc_create_drop_party, qcc_create_drop_party_ack,
qcc_create_leaf_setup_fail, qcc_create_leaf_setup_req -
create Q.2931 message structures

SYNOPSIS

```
cc [ flag ... ] file ... -latm [ library ... ]
```

```
#include <atm/qcc.h>  
#include <atm/qcctypes.h>
```

```
int qcc_create_setup(qcc_setup_t *msgp, char *ifname,  
                    int calltag, atm_address_t *dst_addrp);
```

```
int qcc_create_alerting(qcc_alerting_t *msgp, char *ifname,  
                       int callid);
```

```
int qcc_create_call_proceeding(qcc_call_proc_t *msgp,  
                               char *ifname, int callid);
```

```
int qcc_create_connect(qcc_connect_t *msgp, char *ifname,  
                       int callid);
```

```
int qcc_create_connect_ack(qcc_connect_ack_t *msgp,  
                           char *ifname, int callid);
```

```
int qcc_create_release(qcc_release_t *msgp, char *ifname,  
                       int callid, int cause);
```

CODE EXAMPLE 2-3 qcc_create(3) Man Page (Continued)

```
int qcc_create_release_complete(qcc_release_complete_t *
    msgp, char *ifname, int callid);

int qcc_create_status_enq(qcc_status_enq_t *msgp,
    char *ifname, int callid);

int qcc_create_status(qcc_status_t *msgp, char *ifname,
    int callid, int callstate, int cause);

int qcc_create_notify(qcc_notify_t *msgp, char *ifname,
    int callid, int contentlen, u_char *contentp);

int qcc_create_restart(qcc_restart_t *msgp, char *ifname,
    int callid, int indicator, int vci);

int qcc_create_restart_ack(qcc_restart_ack_t *msgp,
    char *ifname, int callid, int indicator, int vci);

int qcc_create_add_party(qcc_add_party_t *msgp,
    char *ifname, int callid, atm_address_t *dst_addrp,
    int endpt_ref);

int qcc_create_add_party_ack(qcc_add_party_ack_t *msgp,
    char *ifname, int callid, int endpt_ref);

int qcc_create_party_alerting(qcc_party_alerting_t *msgp,
    char *ifname, int callid, int endpt_ref);

int qcc_create_add_party_reject(qcc_add_party_reject_t *
    msgp, char *ifname, int callid, int cause,
    int endpt_ref);

int qcc_create_drop_party(qcc_drop_party_t *msgp,
    char *ifname, int callid, int cause, int endpt_ref);

int qcc_create_drop_party_ack(qcc_drop_party_ack_t *msgp,
    char *ifname, int callid, int endpt_ref);

int qcc_create_leaf_setup_fail(qcc_leaf_setup_fail_t *msgp,
    char *ifname, int callid, int cause,
    atm_address_t *dst_addrp, int leaf_num);

int qcc_create_leaf_setup_req(qcc_leaf_setup_req_t *msgp,
    char *ifname, int leaftag, atm_address_t *src_addrp,
    atm_address_t *dst_addrp, int lij_callid);
```

MT-LEVEL

Safe.

AVAILABILITY

The functionality described in this man page is available in the SUNWatma package included with the SunATM adapter board. The libatm.a library, which is located in /usr/lib, must be included at compile time as indicated in the synopsis.

DESCRIPTION

These functions create message structures representing the various messages that make up the Q.2931 protocol, which is used for ATM signalling. A full description of the message format and use can be found in the ATM Forum's User Network Interface Specification, V3.0, V3.1, or V4.0. The content of the created message structures will conform to the version of the UNI Specification which is configured on the indicated interface. The functions may be used by processes which are running in user space.

After a message structure has been created, non-default Information Elements (IEs) may be added or existing IEs may be changed using the qcc_set_ie(3) function. When the message structure has been completely specified, the corresponding qcc_pack(3) function should be called to translate the message structure into the correct encoded format, contained in streams buffers which may be passed to the putmsg(2) function.

In general, no error checking is performed on the data that is passed in. Whatever data is passed in will be placed in the message that is built without examination. The only exceptions to this are mentioned in the function descriptions.

Each function requires a minimum of 3 parameters: msgp, which is a pointer to the appropriate message structure type; ifname, which is a string containing the physical interface (such as ba0); and an integer, either calltag or callid, depending on the message type. calltag is used in the setup message only; it is a reference number that is assigned by the calling application. callid is used in all other messages; it is assigned by the lower layer and will be sent up to the user, with the calltag, in the setup_ack message.

The structure to which `msgp` points must be allocated by the calling user. There is a unique structure for each message type; the message structures are defined in `<atm/qcctypes.h>`.

Only the mandatory IEs for each message type are added to the message structure by the `qcc_create` call. The additional parameters to the `qcc_create` functions allow the user to define most of the information contained in those mandatory IEs; however, in some cases default values are assumed. Those values, as well as the additional parameters for each function, are indicated in the following paragraphs describing each function call.

`qcc_create_setup()` creates a setup message structure containing the following Information Elements: ATM traffic descriptor (called ATM cell rate in UNI 3.0), broadband bearer capability, called party number, and quality of service parameter. The user must pass in the destination ATM address for the called party number IE (`atm_address_t` format is defined in the `<atm/types.h>` header file). The following default values are used for the remaining Information Elements:

ATM Traffic Descriptor:

best effort; line rate is used for the forward and backward peak rates

Broadband Bearer Capability:

Bearer Class X, no indication for traffic type and timing requirements, not susceptible to clipping, and point-to-point user plane

Called Party Number:

ATM Endsystem (NSAP) address type

Quality of Service:

Forward and backward class unspecified

`qcc_create_alerting()` creates the structure for an alerting message, which is supported only under UNI 4.0. The alerting message contains no mandatory IEs; only the message header is filled in.

`qcc_create_call_proceeding()` creates the structure for a

CODE EXAMPLE 2-3 qcc_create(3) Man Page (Continued)

call proceeding message, which contains no mandatory IEs. Only the message header is filled in.

qcc_create_connect() creates the structure for a connect message, which also contains no mandatory IEs. Again, only the required header is filled in. The same is true for qcc_create_connect_ack.

qcc_create_release() creates a release message structure containing a cause IE, for which the user must pass in a cause value. The possible values can be found in the <atm/qccdefs.h> header file. By default, no diagnostic is included and the user location is assigned.

qcc_create_release_complete() creates the structure for a release complete message, which contains no mandatory IEs. Only the message header is filled in.

qcc_create_status_enquiry() creates a status enquiry message structure, which contains no mandatory IEs. Only the message header is filled in.

qcc_create_status() builds a status message structure, containing two mandatory IEs: call state and cause. The user should pass in value for both the callstate and the cause; possible values may be found in the <atm/qccdefs.h> header file. In the cause IE, no diagnostic is included and the user location is assigned.

qcc_create_notify() builds a notify message structure, which is only supported under UNI 4.0. The message contains a single mandatory IE, the notification indicator, which contains a buffer of user-specified data. The maximum size of the buffer is 16 bytes, defined as QCC_MAX_NOTIFICATION_LEN in <atm/qcc.h>. The user should allocate a buffer and pass in the buffer length, contentlen, and a pointer to the buffer, contentp.

qcc_create_restart() creates a restart message structure, containing the mandatory restart indicator IE, and optionally the connection identifier IE. The user should pass in a value for the restart indicator, either RESTART_INDICATED_VC or RESTART_ALL_VCS. If a non-zero vci parameter is passed in, the connection identifier IE is also included in the message, using a default vpci of 0 and the vci parameter value.

qcc_create_add_party() constructs an add party message structure. It includes the mandatory called party number and endpoint reference IEs. The user should pass in a pointer to the called number and an endpoint reference value; for the called party number, ATM Endsystem (NSAP) address type is assumed.

qcc_create_add_party_ack() fills in an add party ack message structure with the endpoint reference IE. The endpt_ref parameter value is used.

qcc_create_party_alerting() creates a party alerting message structure with the endpoint reference IE, which uses the endpt_ref parameter. This message type is only supported under UNI 4.0.

qcc_create_add_party_reject() fills the cause and endpoint reference IEs into an add party reject structure. The user should provide the cause and endpoint reference value; possible cause values are defined in the <atm/qccdefs.h> header file. By default, no diagnostic is included and the user location is assigned in the cause IE.

qcc_create_drop_party() fills the cause and endpoint reference IEs into a drop party structure. The user should pass in the cause and endpoint reference values; possible cause values are defined in the <atm/qccdefs.h> header file. By default, no diagnostic is included and the user location is assigned in the cause IE.

qcc_create_drop_party_ack() fills in only the mandatory endpoint reference IE, requiring the endpt_ref parameter.

qcc_create_leaf_setup_fail() creates a leaf setup fail message structure, with three mandatory IEs. The cause IE requires the cause parameter, which should be one of the cause values defined in <atm/qccdefs.h>; the called number IE requires the destination ATM address, dst_addrp; and the leaf number IE requires the leaf_num parameter. This message is only supported under UNI 4.0.

qcc_create_leaf_setup_req() creates a leaf setup request message structure, with four mandatory IEs. Both the calling party and called party number IEs are required, using the source and destination ATM addresses, passed in in the

CODE EXAMPLE 2-3 qcc_create(3) Man Page (Continued)

src_addrp and dst_addrp parameters, respectively. The leaf initiated join call identifier IE requires the lij_callid parameter. The final required IE, the leaf number IE, is inserted as a placeholder; the actual leaf number will be assigned and filled in by the q93b driver. It will be returned in the callref field of the qcc header of a leaf_setup_ack message, much as the call reference is returned in a setup_ack message in the setup case. Refer to the description of the qcc_bld_leaf_setup_req() function for more details on this process. This message is only supported under UNI 4.0.

RETURN VALUES

All functions return 0 on success and -1 on error.

EXAMPLES

The following code fragment creates a setup message, adds an optional AAL Parameters IE, packs the message into streams buffers, and sends it downstream.

```
#include <atm/limits.h>
#include <atm/qcc.h>
#include <atm/qcctypes.h>

char    ifname[QCC_MAX_IFNAME_LEN] = "ba0";
int     calltag = 0x1234;
int     forward_sdusize = 0x2378;
int     backward_sdusize = 0x2378;
qcc_msg_t      msgstruct;
qcc_setup_t    setup;
qcc_ie_t       iestruct;
qcc_aal_params_t  aal;
struct strbuf  ctl, data;
char          ctlbuf[QCC_MAX_CTL_LEN];
char          databuf[QCC_MAX_DATA_LEN];

atm_addr_t     dst_addr = {
    0x45, 0x00, 0x00, 0x00, 0x00, 0x00, 0x00, 0x00,
    0x00, 0x0f, 0x00, 0x00, 0x00, 0x00, 0x00,
    0x08, 0x00, 0x20, 0x1a, 0xb6, 0xb9, 0x00
};

ctl.buf = ctlbuf;
data.buf = databuf;
ctl.maxlen = QCC_MAX_CTL_LEN;
data.maxlen = QCC_MAX_DATA_LEN;
```

CODE EXAMPLE 2-3 qcc_create(3) Man Page (Continued)

```
if ((qcc_create_setup(&setup, ifname,
                    calltag, dst_addr)) < 0) {
    printf("qcc_create_setup failed\n");
    exit (-1);
}

msgstruct.type = QCC_SETUP;
msgstruct.msg.setup = &setup;

aal.type = AAL_TYPE_5;
aal.info.aal5.forward_max = forward_sdu_size;
aal.info.aal5.backward_max = backward_sdu_size;
aal.info.aal5.mode = MESSAGE_MODE;
aal.info.aal5.sscs_type = SCS_TYPE_NULL;

iestruct.type = QCC_AAL_PARAMETERS;
iestruct.ie.aal_params = &aal;

if ((qcc_set_ie(&msgstruct, &iestruct)) < 0) {
    printf("qcc_set_ie failed\n");
    exit (-1);
}

if ((qcc_pack_setup(&ctl, &data,
                  msgstruct.msg.setup)) < 0) {
    printf("qcc_pack_setup failed\n");
    exit (-1);
}

if (putmsg(fd, &ctl, &data, 0) < 0) {
    perror("putmsg");
    exit (-1);
}
```

SEE ALSO

qcc_set_ie(3), qcc_pack(3), qcc_unpack(3), qcc_parse(3),
qcc_util(3), q93b(7)

"ATM User-Network Interface Specification, V3.0," ATM Forum.
"ATM User-Network Interface Specification, V3.1," ATM Forum.
"ATM User-Network Interface Specification, V4.0," ATM Forum.

NOTES

This API is an interim solution until the ATM Forum has standardized an API. At that time, Sun will implement that

CODE EXAMPLE 2-3 `qcc_create(3)` Man Page (Continued)

API, and support for the Q.2931 Call Control library may not be continued.

The additional support of the UNI 4.0 signalling specification includes the addition of several new message types which are not supported in the earlier versions of the UNI specification. These message types, if sent on an interface configured for UNI 3.0 or 3.1, will be discarded by the q93b driver and will not be sent out to the network. The UNI 4.0-specific messages are Alerting, Notify, Party Alerting, Leaf Setup Fail, and Leaf Setup Request, and are identified in the applicable function descriptions.

qcc_len(3)

CODE EXAMPLE 2-4 qcc_len(3) Man Page

```
qcc_len(3)                C Library Functions                qcc_len(3)
```

NAME

```
qcc_len, qcc_bld_setup_dataalen, qcc_bld_alerting_dataalen,
qcc_bld_call_proceeding_dataalen, qcc_bld_connect_dataalen,
qcc_bld_connect_ack_dataalen, qcc_bld_release_dataalen,
qcc_bld_release_complete_dataalen,
qcc_bld_status_enquiry_dataalen, qcc_bld_notify_dataalen,
qcc_bld_status_dataalen, qcc_bld_restart_dataalen,
qcc_bld_restart_ack_dataalen, qcc_bld_add_party_dataalen,
qcc_bld_add_party_ack_dataalen,
qcc_bld_party_alerting_dataalen,
qcc_bld_add_party_reject_dataalen,
qcc_bld_drop_party_dataalen, qcc_bld_drop_party_ack_dataalen,
qcc_bld_leaf_setup_fail_dataalen,
qcc_bld_leaf_setup_req_dataalen, qcc_max_bld_dataalen,
qcc_ctl_len - get length of Q.2931 messages
```

SYNOPSIS

```
cc [ flag ... ] file ... -latm [ library ... ]

#include <atm/qcc.h> #include <atm/limits.h>

size_t qcc_bld_setup_dataalen();

size_t qcc_bld_alerting_dataalen();

size_t qcc_bld_call_proceeding_dataalen();

size_t qcc_bld_connect_dataalen();

size_t qcc_bld_connect_ack_dataalen();

size_t qcc_bld_release_dataalen();

size_t qcc_bld_release_complete_dataalen();

size_t qcc_bld_status_enquiry_dataalen();
```

CODE EXAMPLE 2-4 qcc_len(3) Man Page (Continued)

```
size_t qcc_bld_notify_dataalen();  
size_t qcc_bld_status_dataalen();  
size_t qcc_bld_restart_dataalen();  
size_t qcc_bld_restart_ack_dataalen();  
size_t qcc_bld_add_party_dataalen();  
size_t qcc_bld_add_party_ack_dataalen();  
size_t qcc_bld_party_alerting_dataalen();  
size_t qcc_bld_add_party_reject_dataalen();  
size_t qcc_bld_drop_party_dataalen();  
size_t qcc_bld_drop_party_ack_dataalen();  
size_t qcc_bld_leaf_setup_fail_dataalen();  
size_t qcc_bld_leaf_setup_req_dataalen();  
size_t qcc_max_bld_dataalen();  
size_t qcc_ctl_len();
```

MT-LEVEL

Safe.

AVAILABILITY

The functionality described in this man page is available in the SUNWatma package included with the SunATM adapter board. The libatm.a library, which is located in /usr/lib, must be included at compile time as indicated in the synopsis.

DESCRIPTION

These functions may be used to determine appropriate buffer sizes for the control and data buffers that are passed into qcc_bld(3) functions. For the data buffer, the qcc_bld*_dataalen() functions will return the maximum size of a particular message type. qcc_max_bld_dataalen() returns the maximum size of all Q.2931 message types. A buffer allocated for this size will be able to hold any message

CODE EXAMPLE 2-4 `qcc_len(3)` Man Page (Continued)

type. For the control buffer, `qcc_ctl_len()` will return the required size.

SEE ALSO

`qcc_bld(3)`, `qcc_parse(3)`, `q93b(7)`

"ATM User-Network Interface Specification, V3.0," ATM Forum.
"ATM User-Network Interface Specification, V3.1," ATM Forum.
"ATM User-Network Interface Specification, V4.0," ATM Forum.

NOTES

The additional support of the UNI 4.0 signalling specification includes the addition of several new message types which are not supported in the earlier versions of the UNI specification. These message types will be ignored by the `q93b` driver if used on an interface which is configured for UNI 3.0 or 3.1. The UNI 4.0-specific messages are Alerting, Notify, Party Alerting, Leaf Setup Fail, and Leaf Setup Request.

qcc_pack(3)

CODE EXAMPLE 2-5 qcc_pack(3) Man Page

qcc_pack(3) C Library Functions qcc_pack(3)

NAME

qcc_pack, qcc_pack_setup, qcc_pack_alerting,
qcc_pack_call_proceeding, qcc_pack_connect,
qcc_pack_connect_ack, qcc_pack_release,
qcc_pack_release_complete, qcc_pack_status,
qcc_pack_status_enq, qcc_pack_notify, qcc_pack_restart,
qcc_pack_restart_ack, qcc_pack_add_party,
qcc_pack_add_party_ack, qcc_pack_party_alerting,
qcc_pack_add_party_reject, qcc_pack_drop_party,
qcc_pack_drop_party_ack, qcc_pack_leaf_setup_fail,
qcc_pack_leaf_setup_req - encode Q.2931 message structure
information and pack into streams buffers

SYNOPSIS

```
cc [ flag ... ] file ... -latm [ library ... ]
```

```
#include <atm/types.h>
```

```
#include <atm/qcc.h>
```

```
int qcc_pack_setup(strbuf_t *ctlp, strbuf_t *datap,  
qcc_setup_t *msgp);
```

```
int qcc_pack_alerting(strbuf_t *ctlp, strbuf_t *datap,  
qcc_alerting_t *msgp);
```

```
int qcc_pack_call_proceeding(strbuf_t *ctlp,  
strbuf_t *datap, qcc_call_proc_t *msgp);
```

```
int qcc_pack_connect(strbuf_t *ctlp, strbuf_t *datap,  
qcc_connect_t *msgp);
```

```
int qcc_pack_connect_ack(strbuf_t *ctlp, strbuf_t *datap,  
qcc_connect_ack_t *msgp);
```

```
int qcc_pack_release(strbuf_t *ctlp, strbuf_t *datap,  
qcc_release_t *msgp);
```


CODE EXAMPLE 2-5 qcc_pack(3) Man Page (Continued)

```
int qcc_pack_release_complete(strbuf_t *ctlp,  
    strbuf_t *datap, qcc_release_complete_t *msgp);  
  
int qcc_pack_status_enq(strbuf_t *ctlp, strbuf_t *datap,  
    qcc_status_enq_t *msgp);  
  
int qcc_pack_status(strbuf_t *ctlp, strbuf_t *datap,  
    qcc_status_t *msgp);  
  
int qcc_pack_notify(strbuf_t *ctlp, strbuf_t *datap,  
    qcc_notify_t *msgp);  
  
int qcc_pack_restart(strbuf_t *ctlp, strbuf_t *datap,  
    qcc_restart_t *msgp);  
  
int qcc_pack_restart_ack(strbuf_t *ctlp, strbuf_t *datap,  
    qcc_restart_ack_t *msgp);  
  
int qcc_pack_add_party(strbuf_t *ctlp, strbuf_t *datap,  
    qcc_add_party_t *msgp);  
  
int qcc_pack_add_party_ack(strbuf_t *ctlp, strbuf_t *datap,  
    qcc_add_party_ack_t *msgp);  
  
int qcc_pack_party_alerting(strbuf_t *ctlp, strbuf_t *datap,  
    qcc_party_alerting_t *msgp);  
  
int qcc_pack_add_party_reject(strbuf_t *ctlp,  
    strbuf_t *datap, qcc_add_party_reject_t *msgp);  
  
int qcc_pack_drop_party(strbuf_t *ctlp, strbuf_t *datap,  
    qcc_drop_party_t *msgp);  
  
int qcc_pack_drop_party_ack(strbuf_t *ctlp, strbuf_t *datap,  
    qcc_drop_party_ack_t *msgp);  
  
int qcc_pack_leaf_setup_fail(strbuf_t *ctlp,  
    strbuf_t *datap, qcc_leaf_setup_fail_t *msgp);  
  
int qcc_pack_leaf_setup_req(strbuf_t *ctlp, strbuf_t *datap,  
    qcc_leaf_setup_req_t *msgp);
```

MT-LEVEL
Safe.

AVAILABILITY

The functionality described in this man page is available in the SUNWatma package included with the SunATM adapter board. The libatm.a library, which is located in /usr/lib, must be included at compile time as indicated in the synopsis.

DESCRIPTION

These functions take message structures as input and encode the information contained in the structure to create a Q.2931 message, which is then packed into streams buffer structures. The Q.2931 protocol is used for ATM signalling; a full description of the message format and use can be found in the ATM Forum's User Network Interface Specification, V3.0, V3.1, or V4.0. The encoded messages will conform to the version of the UNI Specification which is configured on the indicated interface. The functions may be used by processes which are running in user space.

Message structures should be filled using the `qcc_create(3)` and `qcc_set_ie(3)` functions before calling `qcc_pack` functions.

In general, no error checking is performed on the data that is passed in. Whatever data is contained in the message structure will be placed in the encoded message without examination.

Each function requires 3 parameters: `ctlp` and `datap`, which are pointers to `strbuf_t` buffers; and `msgp`, which is a pointer to the appropriate message structure.

`ctlp` and `datap` make up the control and data portions of the constructed message, corresponding to the `M_PROTO` and `M_DATA` blocks of the message that will be passed downstream. The buffer fields in the structures which `ctlp` and `datap` point to (`ctlp->buf` and `datap->buf`) must be allocated before calling a `qcc_pack_*` function; size information may be obtained using the `qcc_bld_*_datalen()` functions (see `qcc_len(3)`). After successful return from a `qcc_pack_*` function, the message may be passed down an open stream using the `putmsg(2)` function, with `ctlp` and `datap` as the buffer parameters for `putmsg`.

RETURN VALUES

All functions return 0 on success and -1 on error.

CODE EXAMPLE 2-5 `qcc_pack(3)` Man Page (Continued)

EXAMPLES

For an example using `qcc_pack_setup`, see the example in the `qcc_create(3)` man page.

SEE ALSO

`qcc_len(3)`, `qcc_create(3)`, `qcc_set_ie(3)`, `qcc_util(3)`,
`q93b(7)`

"ATM User-Network Interface Specification, V3.0," ATM Forum.
"ATM User-Network Interface Specification, V3.1," ATM Forum.
"ATM User-Network Interface Specification, V4.0," ATM Forum.

NOTES

This API is an interim solution until the ATM Forum has standardized an API. At that time, Sun will implement that API, and support for the Q.2931 Call Control library may not be continued.

The additional support of the UNI 4.0 signalling specification includes the addition of several new message types which are not supported in the earlier versions of the UNI specification. These message types will be ignored by the `q93b` driver if used on an interface which is configured for UNI 3.0 or 3.1. The UNI 4.0-specific messages are Alerting, Notify, Party Alerting, Leaf Setup Fail, and Leaf Setup Request.

qcc_parse(3)

CODE EXAMPLE 2-6 qcc_parse(3) Man Page

qcc_parse(3) C Library Functions qcc_parse(3)

NAME

qcc_parse, qcc_parse_setup, qcc_parse_alerting,
qcc_parse_call_proceeding, qcc_parse_connect,
qcc_parse_release, qcc_parse_release_complete,
qcc_parse_status_enquiry, qcc_parse_notify,
qcc_parse_status, qcc_parse_restart, qcc_parse_restart_ack,
qcc_parse_add_party, qcc_parse_add_party_ack,
qcc_parse_party_alerting, qcc_parse_add_party_reject,
qcc_parse_drop_party, qcc_parse_drop_party_ack,
qcc_parse_leaf_setup_fail, qcc_parse_leaf_setup_req,
qcc_get_hdr - parse Q.2931 messages

SYNOPSIS

```
cc [ flag ... ] file ... -latm [ library ... ]
```

```
#include <atm/types.h>  
#include <atm/qcc.h>
```

```
int qcc_parse_setup(strbuf_t *datap, int *vcip,  
    int *forward_sdusizep, int *backward_sdusizep,  
    atm_addr_t *src_addrp, atm_addr_t *dst_addrp,  
    int *sapp, int *endpt_refp);
```

```
int qcc_parse_alerting(strbuf_t *datap, int *vcip,  
    int *endpt_refp);
```

```
int qcc_parse_call_proceeding(strbuf_t *datap, int *vcip,  
    int *endpt_refp);
```

```
int qcc_parse_connect(strbuf_t *datap, int *vcip,  
    int *forward_sdusizep, int *backward_sdusizep,  
    int *endpt_refp);
```

```
int qcc_parse_release(strbuf_t *datap, int *causep);
```

```
int qcc_parse_release_complete(strbuf_t *datap,
```

CODE EXAMPLE 2-6 qcc_parse(3) Man Page (Continued)

```
    int *causep);

int qcc_parse_status_enquiry(strbuf_t *datap,
    int *endpt_refp);

int qcc_parse_notify(strbuf_t *datap, int *contentlenp,
    u_char *contentp, int *endpt_refp);

int qcc_parse_status(strbuf_t *datap, int *callstatep,
    int *causep, int *endpt_refp, int *endpt_statep);

int qcc_parse_restart(strbuf_t *datap, int *vcip,
    int *rstallp);

int qcc_parse_restart_ack(strbuf_t *datap, int *vcip,
    int *rstallp);

int qcc_parse_add_party(strbuf_t *datap,
    int *forward_sdusize, int *backward_sdusize,
    atm_address_t *src_addrp, atm_address_t *dst_addrp,
    int *sapp, int *endpt_refp);

int qcc_parse_add_party_ack(strbuf_t *datap,
    int *endpt_refp);

int qcc_parse_party_alerting(strbuf_t *datap,
    int *endpt_refp);

int qcc_parse_add_party_reject(strbuf_t *datap, int *causep,
    int *endpt_refp);

int qcc_parse_drop_party(strbuf_t *datap, int *causep,
    int *endpt_refp);

int qcc_parse_drop_party_ack(strbuf_t *datap, int *causep,
    int *endpt_refp);

int qcc_parse_leaf_setup_fail(strbuf_t *datap, int *causep,
    atm_address_t *dst_addrp, int *leaf_nump);

int qcc_parse_leaf_setup_req(strbuf_t *datap,
    atm_address_t *src_addrp, atm_address_t *dst_addrp,
    int *lij_callidp, int *leaf_nump);

qcc_hdr_t *qcc_get_hdr(strbuf_t *ctlp);
```

MT-LEVEL
Safe.

AVAILABILITY

The functionality described in this man page is available in the SUNWatma package included with the SunATM adapter board. The libatm.a library, which is located in /usr/lib, must be included at compile time as indicated in the synopsis.

DESCRIPTION

These functions parse the various messages that make up the Q.2931 protocol which is used for ATM signalling. A full description of the message format and use can be found in the ATM Forum's User Network Interface Specification, V3.0, V3.1, or V4.0. Messages conforming to both versions will be parsed. The functions may be used by processes which are running in user space.

Each function requires a minimum of 1 parameter: datap, which is a pointer to a strbuf_t buffer, or in the case of qcc_get_hdr, ctlp, which is also a pointer to a strbuf_t buffer.

datap is the data portion of a STREAMS message, corresponding to the M_DATA block of the message that is received from downstream. After receiving a message using the getmsg(2) function, the message type may be examined and an appropriate parsing routine called to extract information from the signalling message.

ctlp is the control portion of a STREAMS message, corresponding to the M_PROTO block of the message that is received from downstream. After receiving a message using the getmsg(2) function, qcc_get_hdr may be used to extract the Q.2931 header structure from the control buffer received from getmsg(2). The Q.2931 header type, qcc_hdr_t, is defined in <atm/types.h>.

Other parameters for each function depend on the type of information that is available in each message type. In all cases, certain IEs are examined in each message, as indicated below. If those IEs exist, the data that is expected from them is retrieved, but no error message is sent if they do not exist; the value of the parameter is set to -1 for any data that was expected from that particular IE. Also, IEs that are not expected are ignored. If the user wishes to

CODE EXAMPLE 2-6 qcc_parse(3) Man Page (Continued)

ignore any of the parameters of a parse function, passing in a NULL pointer for that parameter is allowed so that space need not be allocated for the unnecessary parameter.

qcc_parse_setup() parses a setup message containing the following Information Elements: AAL parameters, ATM user cell rate, broadband bearer capability, called party number, calling party number, quality of service parameter, connection identifier, broadband higher layer information, and endpoint reference. The endpoint reference IE is only included in setup messages for point-to-multipoint calls, The following table matches the data that is retrieved from the message with the IE from which it is parsed.

DATA RETRIEVED	INFORMATION ELEMENT
vci	connection identifier
forward sdu size	AAL parameters
backward sdu size	AAL parameters
source address	calling party number
destination address	called party number
sap	broadband higher layer
endpoint reference id	endpoint reference

qcc_parse_alerting() parses an alerting message. The alerting message is new in UNI 4.0; if received on an interface configured for uni 3.0 or 3.1, it will be dropped by the q93b driver. The IEs examined by this function are the connection identifier IE, from which the vci is parsed, and the endpoint reference IE, from which the endpt_ref parameter is parsed. The endpoint reference IE is only included in alerting messages for point-to-multipoint calls.

qcc_parse_call_proceeding() parses a call proceeding message containing a connection identifier IE, which is used to set the value of vci, and an endpoint reference IE, setting the value of endpt_ref. The endpoint reference IE is only included in call proceeding messages for point-to-multipoint calls.

qcc_parse_connect() parses a connect message containing an AAL parameters IE, setting the forward and backward sdu size values, a connection identifier IE, setting the value of vci, and an endpoint reference IE, setting the value of endpt_ref. The endpoint reference IE is only included in connect messages for point-to-multipoint calls.

qcc_parse_release() parses a cause IE, setting the cause value. A listing of the possible values can be found in the <atm/qcc.h> header file. The same is true for qcc_parse_release_complete.

qcc_parse_status_enquiry() parses a status enquiry message containing an endpoint reference IE, setting the value of endpt_ref. The endpoint reference IE is only included when enquiring about a party state in a point-to-multipoint call.

qcc_parse_status() parses a status message. The IEs that are parsed are call state, cause, endpoint reference, and endpoint state. The call state and cause IEs are used to set the value of the parameters callstate and cause; possible values for both parameters may be found in the <atm/qcc.h> header file. The endpoint reference and endpoint state IEs will be used to set the values of the endpt_ref and endpt_state parameters; they are included if an enquiry is made about a party state in a point-to-multipoint call or to report an error condition in a point-to-multipoint call.

qcc_parse_notify() parses a notify message, which is only supported under UNI 4.0. The notification indicator and endpoint reference IEs are parsed; from the notification indicator, the contentlenp and contentp parameters are filled in, with the maximum buffer size copied being 16 bytes. If the size contained in the message is greater than 16 bytes (QCC_MAX_NOTIFICATION_LEN, defined in <atm/qcc.h>), the first 16 bytes are copied, contentlenp is set to contain the copied length of 16 bytes, and the overflow flag is set. From the endpoint reference IE, endpt_refp is filled in. The endpoint reference IE is only present on point-to-multipoint calls.

qcc_parse_restart() parses a restart message containing two possible IEs: connection identifier and restart indicator. The restart indicator IE is used to set the value of rstall; this parameter indicates whether a particular vci or all vcis are to be restarted (rstall = 1 implies all vcis, rstall = 0 implies a particular vci). The connection identifier identifies the particular vci. In this case, the value of the parameter vci is set to 0 if there is no connection identifier IE in the message. The same format applies to the qcc_parse_restart_ack() function.

qcc_parse_add_party() parses an add party message containing

CODE EXAMPLE 2-6 `qcc_parse(3)` Man Page (Continued)

several possible IEs. They include AAL parameters, calling party number, called party number, broadband higher layer information, and endpoint reference. The following table matches the data that is retrieved from the message with the IE from which it is parsed.

DATA RETRIEVED	INFORMATION ELEMENT
forward sdu size	AAL parameters
backward sdu size	AAL parameters
source address	calling party number
destination address	called party number
sap	broadband higher layer
endpoint reference id	endpoint reference

`qcc_parse_add_party_ack()` extracts an endpoint reference value from the endpoint reference IE in an add party ack message.

`qcc_parse_party_alerting()` extracts an endpoint reference value from the endpoint reference IE in a party alerting message. This message is specific to UNI 4.0.

`qcc_parse_add_party_reject()` parses an add party reject message possibly containing a cause IE, from which it extracts the cause value, and an endpoint reference IE, from which it extracts the endpoint reference value. Possible cause values may be found in the header file `<atm/qcc.h>`.

`qcc_parse_drop_party()` extracts an endpoint reference value and a cause value from those respective IEs in a drop party message. The same is true for `qcc_parse_drop_party_ack()`.

`qcc_parse_leaf_setup_fail()` extracts a cause value (defined in `<atm/qcc.h>`) from the cause IE; a destination address from the called number IE; and a leaf number from the leaf number IE. The leaf setup fail message is specific to UNI 4.0.

`qcc_parse_leaf_setup_req()` parses a leaf setup request message, which is specific to UNI 4.0. The calling number and called number IEs are parsed, yielding the source and destination ATM addresses, respectively; in addition, the leaf initiated join call identifier IE is parsed to obtain the leaf initiated join callid, and the leaf number IE is parsed for the leaf number.

CODE EXAMPLE 2-6 qcc_parse(3) Man Page (Continued)

`qcc_get_hdr()` extracts the Q.2931 header from the control buffer received in `getmsg(2)`. A pointer to this buffer, `ctlp`, is passed in to the function, and a pointer to the header of type `qcc_hdr_t` is returned on success. On failure, a null pointer is returned.

RETURN VALUES

All functions, with the exception of `qcc_get_hdr`, return 0 on success and -1 on error. The return values for `qcc_get_hdr` are described above.

EXAMPLES

The following code fragment receives and parses a setup message.

```
#include <atm/types.h>
#include <atm/qcc.h>
#include <atm/limits.h>

void
wait_for_setup(int fd);
{
    int          vci;
    int          forward_sdu_size;
    int          backward_sdu_size;
    int          sap;
    int          flags = 0;
    atm_addr_t   src_addr;
    atm_addr_t   dst_addr;
    qcc_hdr_t    *hdrp;
    struct strbuf ctl, data;
    char         ctlbuf[QCC_MAX_CTL_LEN];
    char         databuf[QCC_MAX_DATA_LEN];

    ctl.buf = ctlbuf;
    data.buf = databuf;
    ctl.len = data.len = 0;
    ctl.maxlen = QCC_MAX_CTL_LEN;
    data.maxlen = QCC_MAX_DATA_LEN;

    if (getmsg(fd, &ctl, &data, &flags) < 0) {
        perror("getmsg");
        exit (-1);
    }

    hdrp = qcc_get_hdr(&ctl);
```

CODE EXAMPLE 2-6 qcc_parse(3) Man Page (Continued)

```
    if ((hdrp) && (hdrp->type == QCC_SETUP)) {
        if ((qcc_parse_setup(&data, &vci, &forward_sdu_size,
            &backward_sdu_size, &src_addr,
            &dst_addr, &sap, NULL)) < 0) {
            printf("parse_setup failed\n");
            exit (-1);
        }
        printf("parse_setup: vci = 0x%x, sap = 0x%x\n",
            vci, sap);
    }
}
```

SEE ALSO

qcc_bld(3), qcc_len(3), qcc_util(3), q93b(7)

"ATM User-Network Interface Specification, V3.0," ATM Forum.
"ATM User-Network Interface Specification, V3.1," ATM Forum.
"ATM User-Network Interface Specification, V4.0," ATM Forum.

NOTES

This API is an interim solution until the ATM Forum has standardized an API. At that time, Sun will implement that API, and support for the Q.2931 Call Control library may not be continued.

The additional support of the UNI 4.0 signalling specification includes the addition of several new message types which are not supported in the earlier versions of the UNI specification. These message types, if received on an interface configured for UNI 3.0 or 3.1, will be discarded by the q93b driver and will not be sent up to the user applications. The UNI 4.0-specific messages are Alerting, Notify, Party Alerting, Leaf Setup Fail, and Leaf Setup Req, and are identified in the applicable function descriptions.

qcc_set_ie(3)

CODE EXAMPLE 2-7 qcc_set_ie(3) Man Page

qcc_set_ie(3) C Library Functions qcc_set_ie(3)

NAME

qcc_set_ie - add or update Information Elements in a Q.2931 message structure

SYNOPSIS

```
cc [ flag ... ] file ... -latm [ library ... ]

#include <atm/qcc.h>
#include <atm/qcctypes.h>

int qcc_set_ie(qcc_msg_t *msgp, qcc_ie_t *iep);
```

MT-LEVEL

Safe.

AVAILABILITY

The functionality described in this man page is available in the SUNWatma package included with the SunATM adapter board. The libatm.a library, which is located in /usr/lib, must be included at compile time as indicated in the synopsis.

DESCRIPTION

This function adds a new or changes an existing Information Element in Q.2931 messages. The Q.2931 protocol is used for ATM signalling. A full description of the message format and use can be found in the ATM Forum's User Network Interface Specification, V3.0 or V3.1. The function may be used by processes which are running in user space.

A message structure should first be created using the appropriate qcc_create(3) function call. IEs may then be added or changed using qcc_set_ie. When the message structure has been completely specified, the corresponding qcc_pack(3) function should be called to translate the message structure into the correct encoded format, contained in streams buffers which may be passed to the putmsg(2) func-

tion.

In general, no error checking is performed on the data that is passed in. Whatever data is passed in will be placed in the message that is built without examination. The user should insure that the values passed in in the IE structure conform with the UNI version (3.0 or 3.1) that is running.

The function requires 2 parameters: msgp, which is a pointer to the appropriate message structure; and iep, which is a pointer to the new IE structure. The message and IE structure types are defined in the <atm/qcctypes.h> header file.

The structure to which msgp points must be allocated by the calling user. The structure pointed to by iep should have the desired values filled in to its fields, and the "valid" field should be set to 1. A value of 0 in the "valid" field indicates that the IE should not be included in the message.

The fields of each Information Element structure and their interpretations are described in the following paragraphs. Possible values for IE fields are defined in the <atm/qccdefs.h> header file.

qcc_aal_params_t

Currently, the only ATM Adaptation Layer supported on SunATM products is AAL 5. However, to allow for future changes, the aal parameters ie type consists of a field identifying the aal and a union of structures for each aal, called "info." The aal 5 structure contains 4 fields: forward_max and backward_max for the SDU sizes, mode, and sscs_type. The sscs_type is only valid in UNI 3.0; therefore, a value of 0 for sscs_type indicates that that field should not be included.

qcc_traffic_desc_t

The ATM Traffic Descriptor IE (called User Cell Rate in UNI 3.0) contains a large set of traffic parameter values. Two parameters do not have numeric values associated; they are either included or not. They are represented by two fields, best_effort and tagging, that are either set to 1 if the parameter is to be included or set to 0 if it is not. The remaining parameters all have numeric values associated with them. Since 0 is a valid value for these parameters, an additional field, params, is included in the IE

CODE EXAMPLE 2-7 qcc_set_ie(3) Man Page (Continued)

structure which indicates which of these should be included in the message. Each parameter has a corresponding bit in the params field, which, when set, indicates that the parameter should be included. Flags are defined for this field in the <atm/qccdefs.h> header file.

qcc_bbc_t

The Broadband Bearer Capability IE fields correspond directly to the options for this IE. The fields are:

class	Bearer Class
type	Traffic Type
timing	Timing Requirements
clipping	Susceptibility to Clipping
userplane	User plane connection configuration

qcc_bhli_t

The Broadband High Layer Information IE structure contains 3 fields which specify the IE contents. They are type, which identifies the High Layer Information Type; infolen, which indicates the number of octets of high layer information is to be included in the message (the maximum is 8 octets), and finally an array of bytes called info which contains the information octets, called info. The octets should be placed in the first infolen elements of the array.

qcc_blli_t

The Broadband Low Layer Information IE contains 2 fields to specify the IE contents. The first, layer, is an integer which specifies which layer protocol is being specified, layer 1, 2, or 3. The second is a union, with unique structures for layer 2 and layer 3. For both layer 2 and layer 3 IEs, the protocol value will be examined and the correct coding format will be used for that protocol. Therefore, only the applicable fields from the layer structure will be used for the specified protocol type.

Layer 2 fields:

protocol	User information layer 2 protocol
mode	Mode of operation
window size	Window size (k)
userspec	User specified layer 2 protocol information

Layer 3 fields:

protocol	User information layer 3 protocol
mode	Mode of operation
pktsize	Default packet size
windowsize	Packet window size
userspec	User specified layer 3 protocol information
ipi	8-bit Initial Protocol Identifier for ISO/IEC TR 9577
oui	24-bit organization unique identifier for ISO/IEC TR 9577 and IEEE 802.1 SNAP
pid	16-bit protocol identifier for ISO/IEC TR 9577 and IEEE 802.1 SNAP

qcc_call_state_t

There is only one informational field in the Call State IE structure: state, specifying the call state.

qcc_called_num_t

The Called Party Number IE structure contains a planid field, which specifies the Addressing/Numbering Plan Identification. The Type of Number is based on this value as well. There is also an address field, to specify a 20-byte address.

qcc_called_subaddr_t

The Called Party Subaddress IE structure contains a type field, which specifies the Type of Subaddress, and a 20-byte address field.

qcc_calling_num_t

In addition to the 20-byte address field, the Calling Party Number IE structure contains several fields to describe the intended interpretation of the address. They are:

planid	Addressing/Numbering Plan Identification
presentation	Presentation indicator
screening	Screening indicator

qcc_calling_subaddr_t

The structure for the Calling Party Subaddress IE is

CODE EXAMPLE 2-7 `qcc_set_ie(3)` Man Page (Continued)

identical to that of the Called Party Subaddress IE.

`qcc_cause_t`

The Cause IE structure contains a location field and a cause field. In addition, it contains an array of 28 octets, `diag`, for diagnostic information. The number of diagnostic octets included in the array should be specified in the `diaglen` field.

`qcc_conn_id_t`

The Connection Identifier IE structure contains a `vpci` and a `vci` field. Note that currently, the SunATM software only supports `vpci` 0, although any value may be placed in the `vpci` field and will be encoded into the message.

`qcc_qos_t`

The Quality of Service IE has 3 informational fields: `codingstd`, specifying the Coding Standard value; and `forward_class` and `backward_class`, specifying the Forward and Backward QoS Class.

`qcc_restart_ind_t`

There is only one informational field in the Restart Indicator IE structure: `class`, which specifies the class of the facility to be restarted.

`qcc_transit_t`

The Transit Network Selection IE structure contains an array of up to four octets to specify the Carrier Identification Code value.

`qcc_endpt_ref_t`

The Endpoint Reference IE structure contains an `endptref` field, which specifies the endpoint reference value.

`qcc_endpt_state_t`

The Endpoint State IE structure contains a state field, which identifies the endpoint state value.

RETURN VALUES

The function returns 0 on success and -1 on error.

EXAMPLES

See the Example section of the `qcc_create(3)` man page for an

CODE EXAMPLE 2-7 `qcc_set_ie(3)` Man Page (Continued)

example using `qcc_set_ie`.

SEE ALSO

`qcc_create(3)`, `qcc_pack(3)`, `qcc_unpack(3)`, `qcc_parse(3)`,
`qcc_util(3)`, `q93b(7)`

"ATM User-Network Interface Specification, V3.0," ATM Forum.

NOTES

This API is an interim solution until the ATM Forum has standardized an API. At that time, Sun will implement that API, and support for the Q.2931 Call Control library may not be continued.

qcc_unpack(3)

CODE EXAMPLE 2-8 qcc_unpack(3) Man Page

qcc_unpack(3) C Library Functions qcc_unpack(3)

NAME

qcc_unpack, qcc_unpack_setup, qcc_unpack_alerting,
qcc_unpack_call_proceeding, qcc_unpack_connect,
qcc_unpack_connect_ack, qcc_unpack_release,
qcc_unpack_release_complete, qcc_unpack_status,
qcc_unpack_status_enq, qcc_unpack_notify,
qcc_unpack_restart, qcc_unpack_restart_ack,
qcc_unpack_add_party, qcc_unpack_add_party_ack,
qcc_unpack_party_alerting, qcc_unpack_add_party_reject,
qcc_unpack_drop_party, qcc_unpack_drop_party_ack,
qcc_unpack_leaf_setup_fail, qcc_unpack_leaf_setup_req -
decode Q.2931 messages and unpack into message structures

SYNOPSIS

```
cc [ flag ... ] file ... -latm [ library ... ]
```

```
#include <atm/types.h>
```

```
#include <atm/qcc.h>
```

```
int qcc_unpack_setup(qcc_setup_t *msgp, strbuf_t *ctlp,  
                    strbuf_t *datap);
```

```
int qcc_unpack_alerting(qcc_alerting *msgp, strbuf_t *ctlp,  
                       strbuf_t *datap);
```

```
int qcc_unpack_call_proceeding(qcc_call_proc_t *msgp,  
                               strbuf_t *ctlp, strbuf_t *datap);
```

```
int qcc_unpack_connect(qcc_connect_t *msgp, strbuf_t *ctlp,  
                      strbuf_t *datap);
```

```
int qcc_unpack_connect_ack(qcc_connect_ack_t *msgp,  
                          strbuf_t *ctlp, strbuf_t *datap);
```

```
int qcc_unpack_release(qcc_release_t *msgp, strbuf_t *ctlp,  
                      strbuf_t *datap);
```

CODE EXAMPLE 2-8 qcc_unpack(3) Man Page (Continued)

```
int qcc_unpack_release_complete(qcc_release_complete_t *
    msgp, strbuf_t *ctlp, strbuf_t *datap);

int qcc_unpack_status_enq(qcc_status_enq_t *msgp,
    strbuf_t *ctlp, strbuf_t *datap);

int qcc_unpack_status(qcc_status_t *msgp, strbuf_t *ctlp,
    strbuf_t *datap);

int qcc_unpack_notify(qcc_notify_t *msgp, strbuf_t *ctlp,
    strbuf_t *datap);

int qcc_unpack_restart(qcc_restart_t *msgp, strbuf_t *ctlp,
    strbuf_t *datap);

int qcc_unpack_restart_ack(qcc_restart_ack_t *msgp,
    strbuf_t *ctlp, strbuf_t *datap);

int qcc_unpack_add_party(qcc_add_party_t *msgp,
    strbuf_t *ctlp, strbuf_t *datap);

int qcc_unpack_add_party_ack(qcc_add_party_ack_t *msgp,
    strbuf_t *ctlp, strbuf_t *datap);

int qcc_unpack_party_alerting(qcc_party_alerting_t *msgp,
    strbuf_t *ctlp, strbuf_t *datap);

int qcc_unpack_add_party_reject(qcc_add_party_reject_t *
    msgp, strbuf_t *ctlp, strbuf_t *datap);

int qcc_unpack_drop_party(qcc_drop_party_t *msgp,
    strbuf_t *ctlp, strbuf_t *datap);

int qcc_unpack_drop_party_ack(qcc_drop_party_ack_t *msgp,
    strbuf_t *ctlp, strbuf_t *datap);

int qcc_unpack_leaf_setup_fail(qcc_leaf_setup_fail_t *msgp,
    strbuf_t *ctlp, strbuf_t *datap);

int qcc_unpack_leaf_setup_req(qcc_leaf_setup_req_t *msgp,
    strbuf_t *ctlp, strbuf_t *datap);
```

MT-LEVEL
Safe.

AVAILABILITY

The functionality described in this man page is available in the SUNWatma package included with the SunATM adapter board. The libatm.a library, which is located in /usr/lib, must be included at compile time as indicated in the synopsis.

DESCRIPTION

These functions take streams buffers containing encoded Q.2931 messages as input and decode the information, placing the extracted values into the appropriate message structure. The Q.2931 protocol is used for ATM signalling; a full description of the message format and use can be found in the ATM Forum's User Network Interface Specification, V3.0, V3.1, or V4.0. Messages conforming to both versions of the UNI standard will be decoded. The functions may be used by processes which are running in user space.

In general, no error checking is performed on the data that is extracted from the message. Whatever data is found will be placed in the message structure without examination.

Each function requires 3 parameters: msgp, which is a pointer to the appropriate message structure; and ctlp and datap, which are pointers to strbuf_t buffers.

ctlp is the control portion of a received message, corresponding to the M_CTL block of the message that was received from downstream. datap is the data portion of the message, corresponding to the M_DATA block.

The message structure pointed to by msgp should be allocated by the user program which calls a qcc_unpack function.

RETURN VALUES

All functions return 0 on success and -1 on error. The returned message structure contains an entry for each possible Information Element for that message type; if an Information Element is found in the received message, the "valid" field for that IE will be set to 1. If the IE was not found, the "valid" field will be 0.

EXAMPLES

The following code fragment receives a setup message and prints elements in the message structure.

```
#include <atm/types.h>
```

CODE EXAMPLE 2-8 qcc_unpack(3) Man Page (Continued)

```
#include <atm/qcc.h>
#include <atm/limits.h>

void
wait_for_setup(int fd);
{
    int          flags = 0;
    int          vci = -1;
    int          sap = -1;
    qcc_hdr_t    *hdrp;
    qcc_setup_t  setup;
    struct strbuf ctl, data;
    char         ctlbuf[QCC_MAX_CTL_LEN];
    char         databuf[QCC_MAX_DATA_LEN];

    ctl.buf = ctlbuf;
    data.buf = databuf;
    ctl.len = data.len = 0;
    ctl.maxlen = QCC_MAX_CTL_LEN;
    data.maxlen = QCC_MAX_DATA_LEN;

    if (getmsg(fd, &ctl, &data, &flags) < 0) {
        perror("getmsg");
        exit (-1);
    }

    hdrp = qcc_get_hdr(&ctl);
    if ((hdrp) && (hdrp->type == QCC_SETUP)) {
        if ((qcc_unpack_setup(&setup, &ctl, &data)) < 0) {
            printf("parse_setup failed\n");
            exit (-1);
        }
        if (setup.conn_id.valid)
            vci = setup.conn_id.vci;
        if (setup.bhli.valid)
            memcpy((caddr_t) &sap,
                   (caddr_t) setup.bhli.info, 4);

        printf("parse_setup: vci=0x%x, sap=0x%x\n",
              vci, sap);
    }
}
```

SEE ALSO

qcc_len(3), qcc_create(3), qcc_set_ie(3), qcc_pack(3),
qcc_util(3), q93b(7)

CODE EXAMPLE 2-8 `qcc_unpack(3)` Man Page (Continued)

```
"ATM User-Network Interface Specification, V3.0," ATM Forum.  
"ATM User-Network Interface Specification, V3.1," ATM Forum.  
"ATM User-Network Interface Specification, V4.0," ATM Forum.
```

NOTES

This API is an interim solution until the ATM Forum has standardized an API. At that time, Sun will implement that API, and support for the Q.2931 Call Control library may not be continued.

The additional support of the UNI 4.0 signalling specification includes the addition of several new message types which are not supported in the earlier versions of the UNI specification. These message types will be ignored by the q93b driver if used on an interface which is configured for UNI 3.0 or 3.1. The UNI 4.0-specific messages are Alerting, Notify, Party Alerting, Leaf Setup Fail, and Leaf Setup Request.

qcc_util(3)

CODE EXAMPLE 2-9 qcc_util(3) Man Page

```
qcc_util(3)                C Library Functions                qcc_util(3)
```

NAME

qcc_util, q_ioc_bind, q_ioc_bind_lijid, q_ioc_unbind_lijid - functional interfaces to q93b driver ioctls

SYNOPSIS

```
cc [ flag ... ] file ... -latm [ library ... ]
```

```
#include <atm/qcc.h>
```

```
int q_ioc_bind(int fd, int sap);
```

```
int q_ioc_bind_lijid(int fd, int lijid);
```

```
int q_ioc_unbind_lijid(int fd, int lijid);
```

MT-LEVEL

Safe.

AVAILABILITY

The functionality described in this man page is available in the SUNWatma package included with the SunATM adapter board. The libatm.a library, which is located in /usr/lib, must be included at compile time as indicated in the synopsis.

DESCRIPTION

These functions may be used to provide information about the user application to the q93b driver.

Before using these functions, a stream must be opened to the q93b driver, using the open(2) system call.

q_ioc_bind() binds a service access point, sap, to an opened stream, specified by its file descriptor, fd. This step is required so that incoming SETUP messages are directed to the correct application by the q93b driver. Q.2931 SETUP messages which are to be received by the application program

CODE EXAMPLE 2-9 qcc_util(3) Man Page (Continued)

must contain a Broadband Higher Layer Information IE identifying the sap to which the message should be directed.

`q_ioc_bind_ljtid()` binds a leaf-initiated join id, `ljtid`, to an opened stream, specified by its file descriptor, `fd`. This functionality is in support of a new feature in UNI 4.0, which allows endpoints to request to be added to specific point-to-multipoint calls, identified by the leaf-initiated join id. An application that wishes to be the root of a point-to-multipoint call which supports leaf-initiated join must associate its q93b stream with the call's leaf-initiated join id in one of two ways: by setting up a call in which the leaf-initiated join id is specified, or by calling this function.

`q_ioc_unbind_ljtid()` breaks the association between a leaf-initiated join id, `ljtid`, and a stream, specified by its file descriptor, `fd`.

RETURN VALUES

The functions return 0 on success and -1 on error.

EXAMPLES

The following example opens a stream to q93b and binds it to sap 0x100.

```
#include <atm/qcc.h>

setup_q93b();
{
    char    qdriver[] = "/dev/q93b";
    int     qfd;
    int     sap = 0x100;

    if ((qfd = open(qdriver, O_RDWR, 0)) < 0) {
        perror("open");
        exit(-1);
    }

    if (q_ioc_bind(qfd, sap) < 0) {
        perror("q_ioc_bind");
        exit(-1);
    }
}
```

SEE ALSO

CODE EXAMPLE 2-9 `qcc_util(3)` Man Page (*Continued*)

```
atm_util(3),    qcc_bld(3),    qcc_create(3),    qcc_len(3),  
qcc_pack(3),   qcc_parse(3),   qcc_unpack(3),   qcc_bld(9F),  
qcc_create(9F), qcc_len(9F),   qcc_pack(9F),   qcc_parse(9F),  
qcc_unpack(9F), q93b(7), ba(7)
```


File Formats

The man pages in this chapter describe the configuration files in the SunATM software.

TABLE 3-1 File Format Man Pages

Man Page	Description	Page Number
<code>aarconfig(4)</code>	ATM Address Resolver configuration file	page 76
<code>acl.cfg(4)</code>	SunATM SNMP access-privileges database group configuration file	page 85
<code>agent.cnf(4)</code>	SunATM SNMP agent configuration file	page 87
<code>atmconfig(4)</code>	SunATM interface configuration file	page 89
<code>context.cfg(4)</code>	SunATM SNMP contexts database group configuration file	page 91
<code>ilmi.cnf(4)</code>	SunATM SNMP agent configuration file for <code>ilmid(1M)</code>	page 94
<code>laneconfig(4)</code>	LAN Emulation configuration file	page 95
<code>mib.rt(4)</code>	SunATM SNMP agent utility file	page 103
<code>party.cfg(4)</code>	SunATM SNMP party database group configuration file	page 105
<code>view.cfg(4)</code>	SunATM SNMP MIB-view database group configuration file	page 108

aarconfig(4)

CODE EXAMPLE 3-1 aarconfig(4) Man Page

aarconfig(4) File Formats aarconfig(4)

NAME

aarconfig - ATM Address Resolver configuration file

SYNOPSIS

/etc/aarconfig

DESCRIPTION

The aarconfig file is a local database that associates ATM addresses with IP addresses. The file is used by the ATM Address Resolution setup program, aarsetup(1M), which manages the downloading of local information into the kernel. If changes are made to the aarconfig file, aarsetup(1M) must be rerun for the changes to take effect.

If an ATM ARP server does not exist on a subnet, an ATM/IP address pair must appear in each system's local aarconfig file in order for the system to communicate with that node.

An ATM ARP server solves the problem of having to explicitly enter ATM/IP address pairs into a table at each node. When client interfaces come up, they register with the ARP server, which then sends an inverse ARP request to the client. The client responds with its IP address; the server then enters the information into its kernel-resident table. Clients may then resolve addresses with the server, using ARP requests. If an ATM ARP server is being used in a subnet, clients only need local information and server information in their own configuration files.

The format of an entry in aarconfig is:

Interface	Hostname	ATM-Address	VC	Flags
-----------	----------	-------------	----	-------

Items are separated by any number of SPACE and/or TAB characters. The first item is the physical interface on the local system which is attached to the subnet for this entry.

CODE EXAMPLE 3-1 aarconfig(4) Man Page (Continued)

It should be of the form "device unit;" an example is ba0. Hostname can be an IP hostname or address in the standard dot notation. The ATM address is a 20 byte address; its format is hexadecimal bytes (2 characters) separated by one or more colons (additional colons may be used for readability, if desired). The VC field specifies the virtual connection identifier (VCI) for the connection to the host identified by this entry. The flag field gives information regarding the type of entry. Comment lines are allowed; they are indicated by a '#' at the beginning of the line.

ATM addresses are 20 bytes. The first 13 bytes (called the prefix) are used by the switch for routing purposes; in general, they will be the same for addresses connected to the same switch. The prefix is assigned by the switch and will be sent to the host during address registration (performed by ILMI) when the ATM interface on the host system is configured. The predefined variable 'prefix' (see Variables section below) will be assigned the value received by the host from the switch at configuration time; this value may be referenced in the aarconfig file as '\$prefix'.

The next 6 bytes (called the ESI) are used to uniquely identify a host system; in most of the examples given, the system's hardware MAC address is used. The MAC address may be referenced in the aarconfig file as '\$mac'. The final byte is a selector byte that may be used by the host for internal routing of data. Use of the predefined variable 'sel' will guarantee that an appropriate value for the given interface will be used.

Depending on the entry type, as determined by the flags field, some or all of the fields are required. All entries must have an interface and flags field; the host, atm address, and VC field vary depending on the entry type. An entry should never have both an ATM address field and a VC field; an ATM address indicates that Switched Virtual Circuits (SVCs) should be used for connections, and a VC indicates that Permanent Virtual Circuits (PVCs) should be used. The following section defines each flag type, and lists which of the host, atm address, and VC fields are required for that type. An empty field should be indicated by a hyphen '-'.

OPTIONS

Variables

CODE EXAMPLE 3-1 aarconfig(4) Man Page (Continued)

Because the prefix portion of an ATM address specifies the ATM switch, a number of hosts specified in an aarconfig file may have ATM addresses who share the same prefix. To simplify setting up the aarconfig file, one can define variables that contain part of an ATM address. A variable's name is an identifier consisting of a collection of no more than 32 letters, digits, and underscores (`_`). The value associated with the variable is denoted by a dollar sign (`\$`) followed immediately by the variable name.

Variables may only be used in the ATM address field. They may not be used in any of the other fields in an entry.

Multiple variables may be concatenated to represent a single ATM address expression. A colon must be used to concatenate the variables. Thus, if one variable, v1, is set to `11:22' and another, v2, is set to `33:44', the sequence \$v1:\$v2 represents `11:22:33:44'. Hexadecimal numbers may also be included with variables in the expression. The expression `45:\$v1:\$v2' would have the value `45:11:22:33:44'.

Variables are defined in the aarconfig file according to the following format:

```
set VARIABLE = EXPRESSION
```

where VARIABLE is the name of a variable and EXPRESSION is an expression concatenating one- or two-digit hexadecimal numbers and/or the values of variables that have been previously defined. The equal sign is optional, but the variable and expression must be separated by either whitespace (spaces or tabs), an equal sign, or both.

Several predefined variables are built in to the SunATM software. They include:

prefix the 13-byte prefix associated with the local switch.

mac the 6-byte MAC address associated with the local host or interface.

sel the default 1-byte Selector for the local interface.

macsel the concatenation of \$mac:\$sel.

CODE EXAMPLE 3-1 aarconfig(4) Man Page (Continued)

`myaddress` the concatenation of `$prefix:$mac:$sel`, resulting in the default address for the local interface.

`anymac` a wild card representing any 6-byte ESI. Should only be used in ``a'` entries.

`anymacsel` a wild card representing any 7-byte ESI and Selector combination. Should only be used in ``a'` entries.

`sunmacselN` the concatenation of one of a series of reserved MAC addresses and `$sel` to create a block of reserved 7-byte ESI and Selector combinations which may be used in ATM ARP server addresses. `N` should be a decimal number in the range 0 - 199.

`localswitch_server`
the concatenation of `$prefix`, a unique reserved MAC address, and `$sel`. When used as a server address, restricts server access to clients connected to the local switch only.

In most network configurations, the ATM address assigned to the local interface will be `myaddress`; using this variable in the ``l'` entry makes it possible to use identical `aarconfig` files on all clients using a given server.

The `sunmacselN` variables may be used to create well-known server addresses which are not bound to a particular system. The prefix portion is not included so the addresses may be used on systems connected to different switches. The ESI portion of a `sunmacselN` variable is one of a range of reserved MAC addresses. The base address is `08:00:20:75:48:10`; to calculate the MAC address for any `sunmacselN` variable, simply add the value of `N` (converted to a hexadecimal number) to the base address. For example, the ESI portion of `sunmacsel20` would be `08:00:20:75:48:10 + 0x14 = 08:00:20:75:48:24`.

Finally, `localswitch_server` may be used as a well-known server address in an isolated net, that is, one in which server access is restricted to clients on the local switch. Thus any host with a network prefix other than that of the

CODE EXAMPLE 3-1 aarconfig(4) Man Page (Continued)

local switch will be refused a connection to the ARP server if the ARP server's address is `localswitch_server`. The ESI portion of `localswitch_server` is the reserved MAC address 08:00:20:75:48:08.

Several rules apply to the use of variables in the `aarconfig` file:

Two variables cannot follow each other in an expression without an intervening colon. Thus, `$v1:$v2` is legal whereas `$v1$v2` is not.

Fields in each line in the `aarconfig` file are separated by whitespace. Therefore variables should not be separated from the rest of an ATM address with whitespace. For example, `$v1: $v2` is illegal.

Once a variable is defined by a set command, it may not be redefined later in the `aarconfig` file.

The reserved variable names may not be set. They include ``prefix'`, ``mac'`, ``sel'`, ``macsel'`, ``myaddress'`, ``anymac'`, ``anymacsel'`, ``summacselN'` (where N is a number between 0 and 199), and ``localswitch_server'`.

Basic Configuration Flags

l This flag identifies an entry for a local interface on an ARP client or system that does not use an ARP server.

If SVCs are to be used at all on this interface, the ATM address is required; an empty ATM address field indicates PVCs only on this interface. The host should not be entered; the system will locate the hostname assigned to this physical interface. No VC should be entered either, since there will typically be multiple VCs over the local interface.

L This flag identifies an entry for a local interface on an ARP server.

The ATM address is required. No host or VC should be entered.

t Adds this host to the local table.

CODE EXAMPLE 3-1 aarconfig(4) Man Page (Continued)

The host is required; either an ATM address or a VC field is required, depending on whether a SVC or a PVC connection is desired. If a mixture of SVC and PVC connections is desired, both an ATM address and a VC are allowed.

- s Specifies a connection to the ATM ARP Server. This identifies to the ARP client where it should make ARP (address resolution) requests for addresses that are not in its local table.

Either the atm address in the case of a SVC connection, or the VC in the case of a PVC connection, should appear (but not both); the host should not appear.

The required, optional, and illegal fields for the basic flag types are summarized in the following table:

Interface	Host	ATM-Addr	VCI	FLAGS
required	illegal	optional	illegal	l
required	illegal	required	illegal	L
required	required	or	or*	t
required	illegal	xor	xor**	s

* one or the other is required, but both are also legal.

** one or the other is required; both are illegal.

Advanced Configuration Flags

The basic configuration flags are sufficient for most standard network configurations. However, since networks are rarely homogeneous, there may be cases in which, for interoperability purposes, a network must be configured with different characteristics than the defaults that are built into the SunATM adapter, or with unusual addressing schemes that require more than the basic configuration flags described above. The following flags may also be used in the aarconfig file to alter the default behavior when necessary.

- a On an ARP server, represents an ATM address that may have access to this ARP server. If no 'a' entries appear in the server's aarconfig file, any ATM host may register with the ARP server. Including 'a' entries restricts access to known hosts. The wildcard variables described in the variable section ('anymac' and

CODE EXAMPLE 3-1 aarconfig(4) Man Page (Continued)

`anymacsel') may be used to specify groups of hosts connected to a common switch to be allowed access in a single entry, or specific addresses may listed. NOTE: If this value is changed, only a reboot will ensure that old addresses are not being cached.

The host and VC should not appear; an ATM address is required.

- m Specifies manual address configuration mode. This indicates to the system that ILMI is not being used on the specified interface. Entries for non-ILMI interfaces may not use the \$prefix variable, or variables which make use of \$prefix (such as \$myaddress and \$localswitch_server), since ilmid will not be able to provide this information.

Only the interface is required. The MAC address, ATM address, and VCI should not appear.

The required, optional, and illegal fields for the advanced flag types are summarized in the following table:

Interface	Host	ATM-Addr	VCI	FLAGS
required	illegal	required	illegal	a
required	illegal	illegal	illegal	m

EXAMPLES

The following lines show the simplest case aarconfig files for a single-switch network in which ARP clients use the default address for their interface and all hosts are allowed access to the server:

in the client's aarconfig:

```
ba0 - $myaddress - l
ba0 - $localswitch_server - s
```

in the server's aarconfig:

```
ba0 - $localswitch_server - L
```

CODE EXAMPLE 3-1 aarconfig(4) Man Page (Continued)

The following line defines the local interface for an ARP client which does not use the local MAC address for its ESI on its bal port:

```
ba1 - $prefix:08:00:20:1a:e1:53:$sel - l
```

The following lines would be placed in the aarconfig files on two machines connected back-to-back over PVC.

in the aarconfig of host1:

```
ba0 - - - l
ba0 host2 - 100 t
```

in the aarconfig of host2:

```
ba0 - - - l
ba0 host1 - 100 t
```

The following lines would be placed in the aarconfig file on a server to restrict access to those hosts connected to the local switch or an explicitly identified remote switch. The server is using a predefined server address.

```
set remote = 45:00:00:00:00:00:00:00:0f:01:02:03:04
```

```
ba0 - $prefix:$sunmacsel0 - L
```

```
ba0 - $prefix:$anymacsel - a
```

```
ba0 - $remote:$anymacsel - a
```

SEE ALSO

aarsetup(1M)

M. Laubach, RFC 1577: Classical IP and ARP over ATM, Network Working Group.

NOTES

In the current implementation, the entries must be grouped by type and in a particular order: the local (l or L) entry should be first, then the table (t) entries (if used), and finally server (s) entries. Other flag types may appear in any order. Also, the ordering need only be maintained among

CODE EXAMPLE 3-1 `aarconfig(4)` Man Page (*Continued*)

entries for each physical interface; for example, all of the `ba0` entries may appear first, and then all of the `ba0` entries. This requirement will likely be relaxed in future releases.

Each entry should be entered on one line with no breaks or carriage returns.

acl.cfg(4)

CODE EXAMPLE 3-2 acl.cfg(4) Man Page

```
acl.cfg(4)                File Formats                acl.cfg(4)
```

NAME

acl.cfg - SunATM SNMP access-privileges database group configuration file

SYNOPSIS

/etc/opt/SUNWatm/snmp/acl.cfg

DESCRIPTION

The acl.cfg file contains the access-privileges database for the SunATM SNMP agent, amtsnmpd(1M). The entries contained in this file are the conceptual rows of the aclTable (RFC 1447).

Each conceptual row contains the following entries:

aclTarget The SNMPv2 party which is the target of an access control policy.

aclSubject The SNMPv2 party which is the subject of an access control policy.

aclResources The SNMPv2 context in an access control policy.

aclPrivileges An integer in the range of 0-255 which specify what management operations a particular target party may perform with respect to a particular context when requested by a particular subject party. These privileges are specified as a sum of values, where each value specifies a SNMPv2 PDU type by which the subject party may request a permitted operation.

aclStorageType The storage type for this conceptual row in the aclTable. Takes on the values 1-4.

CODE EXAMPLE 3-2 acl.cfg(4) Man Page (Continued)

aclStatus The status of this conceptual row in the
 aclTable. Takes on the values valid (1) and
 invalid (2).

Each entry in the file is represented by 5 lines.

```
aclTarget
aclSubject
aclResources
aclStatus
aclStorageType (decimal) aclPrivileges (hex)
```

Symbolic names may be used as long as they appear in the
mib.rt(4) file. Otherwise the dotted object ids must be
used. ';' is the comment character. Comments may not be in
between sections of an acl.

EXAMPLES

The following is an example of a typical acl entry in the
acl.cfg file.

```
initialPartyId.127.0.0.1.1
initialPartyId.127.0.0.1.2
initialContextId.127.0.0.1.1
001
003 002b
```

This entry defines the aclTarget, the aclSubject and the
aclContext for this aclEntry, as well as an aclStatus of
active (1), aclStorageType nonVolatile (3) and aclPrivileges
Get, GetNext, GetBulk and Set (2b).

SEE ALSO

atmsnmpd(1M), view.cfg(4), party.cfg(4), context.cfg(4),
mib.rt(4)

agent.cnf(4)

CODE EXAMPLE 3-3 agent.cnf(4) Man Page

agent.cnf(4) File Formats agent.cnf(4)

NAME

agent.cnf - SunATM SNMP agent configuration file

SYNOPSIS

/etc/opt/SUNWatm/snmp/agent.cnf

DESCRIPTION

The agent.cnf file defines basic configuration information for the SunATM SNMP agent, amtsnmpd(1M).

Each entry contains a keyword, followed by a parameter string. The keyword should be in the first position in the line, and an entry must be contained in a single line. The keyword may be separated from parameters by whitespace (spaces or tabs), and comments are denoted by a '#' character.

OPTIONS

The following list contains the currently supported keywords.

syscontact The value to be used to answer queries for sysContact.

syslocation The value to be used to answer queries for sysLocation.

trap A list of hosts which should receive traps (one or more hosts may be included).

read-community The community name which should have read access.

write-community The community name which should have write access. Write access implies read access.

CODE EXAMPLE 3-3 agent.cnf(4) Man Page *(Continued)*

```
trap-community    The community name to be used in traps.
```

SEE ALSO

```
atmsnmpd(1M)
```


atmconfig(4)

CODE EXAMPLE 3-4 atmconfig(4) Man Page

atmconfig(4) File Formats atmconfig(4)

NAME

atmconfig - SunATM interface configuration file

SYNOPSIS

/etc/atmconfig

DESCRIPTION

The atmconfig file is a local database that defines the feature set required for each SunATM interface in a system. The file is used by the /etc/rc2.d/S00sunatm script, which runs at boot time to configure SunATM interfaces. If changes are made to the atmconfig file, the system must be rebooted for the changes to take effect.

The format of an entry in atmconfig is:

Physical Interface	UNI Ver/ Framing	C-IP Host	LANE Inst	LANE Host
-----------------------	---------------------	--------------	--------------	--------------

Items are separated by any number of SPACE and/or TAB characters. The first item is the physical interface on the local system. It should be of the form "device unit;" an example is ba0. UNI Version is the UNI version number that should be used on this interface; SunATM 2.1 supports 3.0 and 3.1. This field can also be used to specify the framing interface to be used on a particular SunATM physical interface; both the SONET and SDH protocols are supported. The default framing is sonet unless /etc/system indicates otherwise. The third field is the Classical IP hostname for this interface, if Classical IP is to be run on this interface. The fourth and fifth fields are used if LAN Emulation is to be run on this interface; these fields are the LAN Emulation instance number (each LAN Emulation interface must have a unique number, and interfaces will appear in ifconfig as laneN, where N is the instance number), and the IP hostname for the LAN Emulation interface.

CODE EXAMPLE 3-4 atmconfig(4) Man Page (Continued)

Depending on the IP protocols to be supported, some or all of the fields are required. Every interface that is to be configured must have at least one entry in /etc/atmconfig which contains a minimum of the interface name and the UNI version. In addition, the Classical IP Hostname is required if Classical IP (RFC 1577) is to be supported; and the LANE Instance is required if LAN Emulation is to be supported. Further entries for the same interface may be included after the entry containing the UNI version to specify multiple LAN Emulation instances, multiple logical interfaces or the framing. Refer to Chapter 5 in the SunATM 2.1 Manual for further information on multiple entries. In all entries, an empty field should be indicated by a hyphen '-'.

EXAMPLES

The following example shows the atmconfig file for a system with three SunATM interfaces. The first, ba0, supports UNI 3.1 and LAN Emulation. The second, ba1, supports UNI 3.1 and both Classical IP and LAN Emulation. The third interface, ba2, supports UNI 3.0 with Classical IP and uses SDH framing.

```
#
ba0      3.1      -      0      atm0
#
ba1      3.1      atm1    1      atm2
#
ba2      3.0      atm3    -      -
ba2      SDH     -      -      -
```

SEE ALSO

aarconfig(4), laneconfig(4)

NOTES

Each entry should be entered on one line with no breaks or carriage returns.

context.cfg(4)

CODE EXAMPLE 3-5 context.cfg(4) Man Page

```
context.cfg(4)           File Formats           context.cfg(4)
```

NAME

context.cfg - SunATM SNMP contexts database group configuration file

SYNOPSIS

/etc/opt/SUNWatm/snmp/context.cfg

DESCRIPTION

The context.cfg file contains the contexts database for the SunATM SNMP agent, amtsnmpd(1M). The entries contained in this file are the conceptual rows of the contextTable (RFC 1447).

Each conceptual row contains the following entries:

contextIdentity A context identifier uniquely identifying a particular SNMPv2 context.

contextLocal An indication of whether this context is realized by this SNMPv2 entity. Takes on the values true (1) or false (2).

contextStorageType The storage type of this conceptual row in the contextTable. Takes on the values 1-4.

contextStatus The status of this conceptual row in the contextTable. Takes on the values valid (1) and invalid (2).

contextViewIndex If zero, this row refers to a context which identifies a proxy relationship; otherwise, this row refers to a context that identifies a MIB view of a locally accessible entity.

CODE EXAMPLE 3-5 context.cfg(4) Man Page (Continued)

```
contextLocalEntity  If contextViewIndex is greater than
                    zero, this value identifies the local
                    entity whose management information is
                    in this context's MIB view. The empty
                    string indicates that the MIB view con-
                    tains the entity's own local management
                    information.

contextLocalTime    If contextViewIndex is greater than
                    zero, this value identifies the tem-
                    poral context of the management infor-
                    mation in the MIB view.

contextProxyDstParty  If contextViewIndex is equal to zero,
                    this value identifies a party that is
                    the proxy destination of a proxy rela-
                    tionship.

contextProxySrcParty  If contextViewIndex is equal to zero,
                    this value identifies a party that is
                    the proxy source of a proxy relation-
                    ship.

contextProxyContext  If contextViewIndex is equal to zero,
                    this value identifies the context of a
                    proxy relationship.
```

Each entry in the file is represented by 8 lines.

```
contextIdentity
contextStatus
contextLocal contextStorageType contextViewIndex
contextLocalEntity
contextLocalTime
contextProxyDstParty
contextProxySrcParty
contextProxyContext
```

Symbolic names may be used as long as they appear in the mib.rt(4) file. Otherwise the dotted object ids must be used. ';' is the comment character. Comments may not be in between sections of a context.

EXAMPLES

CODE EXAMPLE 3-5 context.cfg(4) Man Page (Continued)

The following is an example of a typical context entry in the context.cfg file.

```
initialContextId.127.0.0.1.1
001
001 003 00001
<empty line>
currentTime
<empty line>
<empty line>
<empty line>
```

This entry defines the contextIdentity object identifier for the specific contextEntry, contextStatus active (1), contextLocal true (1), contextStorageType nonVolatile (3), contextViewIndex the viewEntry with viewIndex 1, contextLocalEntity with value the empty string, contextLocalTime with object identifier currentTime referring to management information at the current time, and no entries for contextProxySrcParty, contextProxySrcParty and contextProxyContext (empty lines).

SEE ALSO

```
atmsnmpd(1M), view.cfg(4), party.cfg(4), acl.cfg(4),
mib.rt(4)
```

ilmi.cnf(4)

CODE EXAMPLE 3-6 ilmi.cnf(4) Man Page

ilmi.cnf(4) File Formats ilmi.cnf(4)

NAME

ilmi.cnf - SunATM SNMP agent configuration file for ilmid(1M).

SYNOPSIS

/etc/opt/SUNWatm/snmp/ilmi.cnf

DESCRIPTION

The `ilmi.cnf` file defines the community name used by `ilmid(1M)` to send requests to the SunATM SNMP agent, `atmsnmpd(1M)`.

Each entry consists of a keyword followed by a parameter string. The keyword should be in the first position in the line, and an entry must be contained in a single line. The keyword may be separated from parameters by whitespace (spaces or tabs), and comments are denoted by a '#' character.

OPTIONS

The following list contains the currently supported keywords.

`ilmi-community` The community name to be used by `ilmid(1M)`.

SEE ALSO

`atmsnmpd(1M)`

laneconfig(4)

CODE EXAMPLE 3-7 laneconfig(4) Man Page

```
laneconfig(4)                File Formats                laneconfig(4)
```

NAME

laneconfig - LAN Emulation configuration file

SYNOPSIS

/etc/laneconfig

DESCRIPTION

The laneconfig file is a local database that associates MAC addresses with ATM addresses. The file is used by the LAN Emulation setup program, lanesetup(1M), which manages the downloading of the information found in laneconfig into the kernel. If changes are made to the laneconfig file, lanesetup(1M) must be rerun for the changes to take effect.

The format of an entry in laneconfig is:

Interface	MAC-Address/ ELAN Name	ATM-Address	VC	Flags
-----------	---------------------------	-------------	----	-------

Items are separated by any number of SPACE and/or TAB characters. The first item is the LAN Emulation interface on the local system which is attached to the subnet for this entry. It should be of the form "lane unit;" an example is lane0. The MAC address is the 6 byte physical MAC address; it should be specified as 6 hexadecimal bytes (2 characters) separated by one or more colons (additional colons may be used for readability, if desired). In some entries, the second field will be an Emulated LAN name, which is a character string. The ATM address is a 20 byte address; its format is the same colon-separated hexadecimal format used for the MAC address. The VC field specifies the virtual connection identifier (VCI) for the connection to the host identified by this entry. The flag field gives information regarding the type of entry. Comment lines are allowed; they are indicated by a '#' at the beginning of the line.

ATM addresses are 20 bytes. The first 13 bytes (called the prefix) are used by the switch for routing purposes. The prefix is assigned by the switch and will be sent to the host when the ATM interface on the host system is configured. The predefined variable ``prefix'` (see Variables section below) will be assigned the value received by the host from the switch at configuration time; this value may be referenced in the laneconfig file as ``$prefix'`.

The next 6 bytes (called the ESI) are used to uniquely identify a host system; in most of the examples given, the system's hardware MAC address is used. The local MAC address may be referenced in the laneconfig file as ``$mac'`. The final byte is a selector byte that may be used by the host for internal routing of data. Use of the predefined variable ``sel'` will guarantee that an appropriate value for the given interface will be used.

Depending on the entry type, as determined by the flags field, some or all of the fields are required. All entries must have an interface and flags field; the MAC Address/ELAN Name, ATM Address, and VC field vary depending on the entry type. The following sections describe the use of variables in the laneconfig file, and the flag types, listing which of the MAC Address/ELAN Name, ATM Address, and VC fields are required for that type. In all entries, an empty field should be indicated by a hyphen ``-'`.

OPTIONS

Variables

Because the prefix portion of an ATM address specifies the ATM switch, a number of hosts specified in an laneconfig file may have ATM addresses who share the same prefix. To simplify setting up the laneconfig file, one can define variables that contain part of an ATM address. A variable's name is an identifier consisting of a collection of no more than 32 letters, digits, and underscores (``_'`). The value associated with the variable is denoted by a dollar sign (``$'`) followed immediately by the variable name.

Variables may only be used in the ATM and MAC address fields. They may not be used in any of the other fields in an entry.

Multiple variables may be concatenated to represent a single ATM address expression. A colon must be used to concatenate

CODE EXAMPLE 3-7 laneconfig(4) Man Page (Continued)

the variables. Thus, if one variable, `v1`, is set to ``11:22'` and another, `v2`, is set to ``33:44'`, the sequence ``${v1}:${v2}` represents ``11:22:33:44'`. Hexadecimal numbers may also be included with variables in the expression. The expression ``45:${v1}:${v2}'` would have the value ``45:11:22:33:44'`.

Variables are defined in the `laneconfig` file according to the following format:

```
set VARIABLE = EXPRESSION
```

where `VARIABLE` is the name of a variable and `EXPRESSION` is an expression concatenating one- or two-digit hexadecimal numbers and/or the values of variables that have been previously defined. The equal sign is optional, but the variable and expression must be separated by either whitespace (spaces or tabs), an equal sign, or both.

Several predefined variables are built in to the SunATM software. They include:

<code>prefix</code>	the 13-byte prefix associated with the local switch.
<code>mac</code>	the 6-byte MAC address associated with the local host or interface.
<code>sel</code>	the default 1-byte Selector for the local interface.
<code>macsel</code>	the concatenation of <code>`\${mac}:\${sel}</code> .
<code>myaddress</code>	the concatenation of <code>`\${prefix}:\${mac}:\${sel}</code> , resulting in the default address for the local interface.

In most network configurations, the ATM address assigned to the local interface will be `myaddress`; using this variable in the ``l'` entry makes it possible to use identical `laneconfig` files on all LAN Emulation clients in a given ATM network.

Several rules apply to the use of variables in the `laneconfig` file:

Two variables cannot follow each other in an expression

CODE EXAMPLE 3-7 laneconfig(4) Man Page (Continued)

without an intervening colon. Thus, \$v1:\$v2 is legal whereas \$v1\$v2 is not.

Fields in each line in the laneconfig file are separated by whitespace. Therefore variables should not be separated from the rest of an ATM address with whitespace. For example, \$v1: \$v2 is illegal.

Once a variable is defined by a set command, it may not be redefined later in the laneconfig file.

The reserved variable names may not be set. They include `prefix', `mac', `sel', `macsel', and `myaddress'.

Basic Configuration Flags

- l This flag identifies an entry for a local interface on a LAN Emulation client.

The ATM address is required. The MAC address should not be entered; the system will use the MAC address assigned to this physical interface. No VC should be entered either, since there will typically be multiple VCs over the local interface.

- t Adds this MAC-ATM address or MAC address-VC pair to the local table.

The MAC address is required; either an ATM address or a VC field is required, depending on whether a SVC or a PVC connection is desired. If a mixture of SVC and PVC connections is desired, both an ATM address and a VC are allowed.

- n Specifies the name of the Emulated LAN. Most LAN Emulation Services will fill the Emulated LAN name in in configuration and join requests from LAN Emulation Clients, but this is not always the case. If your LAN Emulation Services do not provide Emulated LAN names for client requests, you can include the name in the laneconfig file.

The Emulated LAN name is required; the ATM address and VC fields are illegal.

The required, optional, and illegal fields for the basic

CODE EXAMPLE 3-7 laneconfig(4) Man Page (Continued)

flag types are summarized in the following table:

Interface	MAC-Addr/ ELAN Name	ATM-Addr	VCI	FLAGS
required	illegal	required	illegal	l
required	MAC-Addr req.	xor	xor*	t
required	ELAN-Name req.	illegal	illegal	n

* one or the other is required; both are illegal.

Advanced Configuration Flags

The basic configuration flags are sufficient for most standard network configurations. However, since networks are rarely homogeneous, there may be cases in which, for interoperability purposes, a network must be configured with different characteristics than the defaults that are built into the SunATM adapter, or with unusual addressing schemes that require more than the basic configuration flags described above. The following flags may also be used in the laneconfig file to alter the default behavior when necessary.

- c Specifies an alternate LECS address. By default, the SunATM software uses ILMI to query the switch for the LECS address, then falls back to the well-known address if ILMI is not available or if the switch cannot provide the LECS address via ILMI. If, however, you wish to specify an alternate LECS, or you wish to connect to the LECS over a PVC, you may provide the alternate ATM address or VCI in this entry. If you wish to make a PVC connection, the VCI must be 17, as required by the LAN Emulation standard.

Either an ATM address or a VC field must appear; the MAC address should not appear.

- s Specifies the LES address or VCI, and instructs the system to contact the LES directly, and to use default subnet configuration information. This flag should be used if your ATM network does not have an LECS. By default (no `s' entry), the system first connects to the LECS, which provides the LES address and configuration information.

Either the ATM address or a VC is required. The MAC

address should not appear.

- a Specifies an address that may have access to this host. If no `a' entries appear in the laneconfig file, access to the host is unrestricted. Including `a' entries allows access to be restricted to known hosts. As an alternative to listing individual addresses, the ATM address field may contain a prefix, followed by the wildcard \$anymacsel, which matches any 7-byte ESI/Selector combination following the given prefix. This allows access by any host connected to the switch specified by the given prefix. NOTE: If this value is changed, only a reboot will ensure that old addresses are not being cached.

An ATM address is required; neither the MAC address nor the VCI should appear.

- m Specifies manual address configuration mode. This indicates to the system that ILMI is not being used on the specified interface. Entries for non-ILMI interfaces may not use the \$prefix variable, or variables which make use of \$prefix (such as \$myaddress and \$localswitch_server), since ilmid will not be able to provide this information.

Only the interface is required. The MAC address, ATM address, and VCI should not appear.

- M Specifies a larger MTU size. By default, the LAN Emulation software will be configured for a 1516-byte MTU. If a larger size is supported by and configured on your LAN Emulation services, it may be set in this entry. The valid values are 1516 (1500 bytes of data, 16 bytes of LANE header), 4544 (4528 bytes of data), and 9234 (9218 bytes of data).

The interface is required, and the MTU size should appear in the second field. The ATM address and VCI should not appear.

The required, optional, and illegal fields for the advanced flag types are summarized in the following table:

Interface	MAC-Addr/	ATM-Addr	VCI	FLAGS
-----------	-----------	----------	-----	-------

CODE EXAMPLE 3-7 laneconfig(4) Man Page (Continued)

ELAN Name				

required	illegal	xor	xor*	c
required	illegal	xor	xor*	s
required	illegal	required	illegal	a
required	illegal	illegal	illegal	m
required	MTU size	illegal	illegal	M

* one or the other is required; both are illegal.

EXAMPLES

The following example shows a basic LAN Emulation Client's laneconfig file. The local information is provided, as well as the addresses of a frequently used server. The use of variables is also demonstrated.

```
set srvr_mac = 08:00:20:01:02:03

ba0 -          $myaddress          - 1
ba0 $srvr_mac $prefix:$srvr_mac - t
```

The following example shows the laneconfig file for a LAN Emulation Client whose LECS requires that the client include the Emulated LAN name in its messages.

```
ba1 -          $myaddress          - 1
ba1 elan1      -                    - n
```

The following example shows the laneconfig file for a LAN Emulation Client whose ATM network does not include an LECS.

```
set les_mac = 01:02:03:04:05:06

ba0 -          $myaddress          - 1
ba0 -          $prefix:$les_mac    - s
```

SEE ALSO

lanesetup(1M)

ATM Forum, LAN Emulation Over ATM Specification Version 1.0,
LAN Emulation SWG Drafting Group.

NOTES

CODE EXAMPLE 3-7 laneconfig(4) Man Page *(Continued)*

Each entry should be entered on one line with no breaks or carriage returns.

mib.rt(4)

CODE EXAMPLE 3-8 mib.rt(4) Man Page

```
mib.rt(4)                                File Formats                                mib.rt(4)
```

NAME

mib.rt - SunATM SNMP agent utility file.

SYNOPSIS

```
/etc/opt/SUNWatm/snmp/mib.rt
```

DESCRIPTION

The mib.rt file contains a listing of object identifiers used by atmsnmpd(1M) to translate the symbolic names found in acl.cfg(4), context.cfg(4), party.cfg(4) and view.cfg(4).

Each line is of the form:

```
$obj <object-identifier> <descriptor>
```

where:

<object-identifier> is a sequence of non-negative integers separated by dots, and identifies the OBJECT IDENTIFIER of the symbolic name used in the configuration files mentioned above.

<descriptor> is the symbolic name associated with the OBJECT IDENTIFIER.

For example:

```
$obj      1.3.6.1.6      snmpV2
```

Whenever you want to use some descriptor in the configuration files that is not defined in the mib.rt file, you could extend this file to contain it. All the ancestors of the name that you are defining must be specified as well. For example, in order to add internet (1.3.6) you must also define dod (1.3) and iso (1).

CODE EXAMPLE 3-8 mib.rt(4) Man Page *(Continued)*

```
atmsnmpd(1M) builds a representation of this file in memory
when it is first started, so additions to this file or any
of the configuration files will not take effect unless
atmsnmpd(1M) is restarted.
```

SEE ALSO

```
atmsnmpd(1M), acl.cfg(4), context.cfg(4), party.cfg(4),
view.cfg(4)
```

party.cfg(4)

CODE EXAMPLE 3-9 party.cfg(4) Man Page

party.cfg(4) File Formats party.cfg(4)

NAME

party.cfg - SunATM SNMP party database group configuration file

SYNOPSIS

/etc/opt/SUNWatm/snmp/party.cfg

DESCRIPTION

The party.cfg file contains the party database for the SunATM SNMP agent, amtsnmpd(1M). The entries contained in this file are the conceptual rows of the partyTable (RFC 1447).

Each conceptual row contains the following entries:

partyIdentity	A unique object identifier for the party.
partyTDomain	Indicates transport service by which the party receives network management traffic.
partyTAddr	The transport service address of the party. For snmpUDPDomain, the address is formatted as a 4-octet IP address concatenated with a 2-octet UDP port number.
partyMaxMessageSize	An integer in the range 484 to 65,507 that represents the maximum message length in octets that this party will accept.
partyLocal	An indication of whether this party is local to the agent.

CODE EXAMPLE 3-9 party.cfg(4) Man Page (Continued)

partyAuthProtocol	Object identifier of the authentication protocol, if any.
partyAuthPrivate	An encoding of the party's private authentication key, or value, needed to support the authentication protocol.
partyAuthLifetime	A non-negative integer which is an upper bound of the lifetime of the message in seconds.
partyPrivProtocol	Object identifier of the privacy protocol, if any.
partyPrivPrivate	An encoding of the party's private encryption key, needed to support the privacy protocol.
partyStorageType	The storage type for this conceptual row in the partyTable. Takes on the values 1-4.
partyStatus	The status of this conceptual row in the partyTable. Takes on the values valid (1) and invalid (2).
partyAuthClock	The authentication clock which represents the local notion of the current time specific to the party. This value must not be decremented unless the party's private authentication key is changed simultaneously.
authTimestamp	Represents the time of the generation of the message according to the partyAuthClock of the SNMP party that originated it. The granularity of the clock, and therefore of this timestamp, is 1 second (RFC 1352).

Each entry in the file is represented by 10 lines.

```
partyIdentity
partyStatus
partyLocal partyStorageType partyMaxMessageSize
partyAuthLifetime authTimestamp partyAuthClock
```

CODE EXAMPLE 3-9 party.cfg(4) Man Page (Continued)

```
partyTDomain
partyTAddr
partyAuthProtocol
partyAuthPrivate (in hex)
partyPrivProtocol
partyPrivPrivate (in hex)
```

Symbolic names may be used as long as they appear in the mib.rt(4) file. Otherwise the dotted object ids must be used. ';' is the comment character. Comments may not be in between sections of a party.

EXAMPLES

The following is an example of a typical party entry in the party.cfg file.

```
initialPartyId.127.0.0.1.1
001
001 003 01400
000000000300 0000000000 0000000000
snmpUDPDomain
0000000000
noAuth
<empty line>
noPriv
<empty line>
```

This entry defines the partyIdentity object identifier, partyStatus active (1), partyLocal true (1), partyStorageType nonVolatile (3), partyMaxMessageSize 1400 bytes, partyAuthLifetime 300 seconds, authTimestamp zero (no authenticated message from the party has been received), partyAuthClock zero, partyAuthProtocol noAuth (no authentication), partyPrivProtocol noPriv (the protocol without privacy), and no authentication keys (partyAuthPrivate and partyPrivPrivate are the empty strings).

SEE ALSO

```
atmsnmpd(1M), view.cfg(4), acl.cfg(4), context.cfg(4),
mib.rt(4)
```

view.cfg(4)

CODE EXAMPLE 3-10 view.cfg(4) Man Page

```
view.cfg(4)                               File Formats                               view.cfg(4)
```

NAME

view.cfg - SunATM SNMP MIB-view database group configuration file

SYNOPSIS

/etc/opt/SUNWatm/snmp/view.cfg

DESCRIPTION

The view.cfg file contains the MIB-view database for the SunATM SNMP agent, amtsnmpd(1M). The entries contained in this file are the conceptual rows of the viewTable (RFC 1447).

Each conceptual row contains the following entries:

viewIndex	A unique value for each MIB view.
viewSubtree	A MIB Subtree.
viewMask	The bit mask which, in combination with the corresponding instance of viewSubtree, defines a family of view subtrees.
viewType	Takes on the values included (1), excluded (2). Indicates whether the corresponding family of view subtrees defined by viewSubtree and viewMask is included or excluded from the MIB view.
viewStorageType	The storage type for this conceptual row in the ViewTable. Takes on the values 1-4.
viewStatus	The status of this conceptual row in the viewTable. Takes on the values 1 (valid) and 2 (invalid).

CODE EXAMPLE 3-10 view.cfg(4) Man Page (Continued)

Each entry in the file is represented by 4 lines.

```
viewIndex:viewSubtree
viewStatus
viewStorageType viewType
viewMask
```

Symbolic names may be used as long as they appear in the mib.rt(4) file. Otherwise the dotted object ids must be used. ';' is the comment character. Comments may not be in between sections of a view.

EXAMPLES

The following is an example of a typical view entry in the view.cfg file.

```
1:dod
001
003 001
<empty line>
```

This entry defines a viewIndex (1) for the viewSubtree (dod), viewStatus active (1), viewStorageType nonVolatile (3), viewType included (1) and no viewMask (empty line)

SEE ALSO

atmsnmpd(1M), acl.cfg(4), party.cfg(4), context.cfg(4), mib.rt(4)

Special Files

The man pages in this chapter describe the various device and network interfaces available with the SunATM software.

TABLE 4-1 Special Files Man Pages

Man Page	Description	Page Number
ba(7)	SunATM device driver	page 112
q93b(7)	Multiplexing Driver supporting Q.2931 signalling	page 119

ba(7)

CODE EXAMPLE 4-1 ba(7) Man Page

ba(7) Device and Network Interfaces ba(7)

NAME

ba - Sun ATM device driver

SYNOPSIS

```
#include <sys/stropts.h>
#include <atm/atm.h>
#include <atm/atmioctl.h>
```

DESCRIPTION

The ba driver is a Solaris 2.x DDI/DKI compliant MT safe STREAMS device driver. It presents a DLPI interface to the upper layers and supports M_DATA fastpath and M_DATA raw. The hardware interface supports the SunATM-155 Fiber, SunATM-155 UTP, and SunATM-622 products.

The two modes of operation that should be used by application programs are raw mode and dlpi mode. The default is dlpi mode. By sending down a DLIOCRAW ioctl the raw mode is requested. The mode chosen defines the format in which data should be sent to the driver.

Raw mode implies that the four-byte vpci will be sent in the first mblk followed by data in the first and any subsequent mblks. When a message is received on a vpci running in raw mode, the four-byte vpci will be sent up with the data.

DLPI mode implies that two or more mblocks will be sent to the driver. The first, of type M_PROTO, contains the dlpi message type, which is dl_unitdata_req for transmit and dl_unitdata_ind for receive. The vpci is included in this mblock as well. The dl_unitdata_req and dl_unitdata_ind header formats are defined in the header file <sys/dlpi.h>. The second and subsequent mblocks are of type M_DATA and contain the message. When the driver gets the two mblocks from the upper layer, it will remove the first mblock, and transmit the message. On receive,

the M_PROTO mblock is added, and the two-mblock structure is sent up to the user.

A method of encapsulation must also be chosen; the method of encapsulation is specified when the VC is associated with a stream (using the A_ADDVC ioctl). Currently, null and LLC encapsulation are supported. Null encapsulation implies that a message consists only of data preceded by a four-byte vpci. This type of encapsulation is most commonly used with raw mode. LLC encapsulation implies that an LLC header precedes the data. This header will include the SAP associated with the application's stream (using DL_BIND_REQ). This type of encapsulation is typically used with dlpi mode traffic.

For LLC-encapsulated traffic, the driver will automatically add the LLC header on transmit if the stream is running in dlpi mode. The driver will also strip the LLC header from incoming traffic before sending it up a dlpi mode stream. In raw mode, however, the driver does not modify the packets at all; this includes the LLC header. Thus, an application using raw mode and LLC encapsulation must include its own LLC headers on transmit and will receive data with the LLC header intact.

Received packets are directed to application streams by the driver based on the type of encapsulation. If a packet is null-encapsulated, it will be sent up the stream associated with the vpci on which the packet was received. If a packet is LLC-encapsulated, it will be sent to the stream which has bound (using DL_BIND_REQ) the SAP found in the LLC header.

The driver supports several of the DLPI message types defined in the <sys/dlpi.h> header file. Specifically, users of the ba driver may use the DL_ATTACH_REQ, DL_DETACH_REQ, DL_BIND_REQ, DL_UNBIND_REQ, DL_UNITDATA_IND, and DL_UNITDATA_REQ. In addition, a Sun-specific dlpi ioctl is supported, DLIOCRAW. There is no data structure associated with the DLIOCRAW ioctl; simply a strioctl struct with ic_cmd set to DLIOCRAW may be used to set a stream to raw mode.

The driver also supports the ATM-specific ioctls described below. Definitions for the ioctl commands and structures may be found in <atm/atmioctl.h>.

IOCTLS

The driver supports a set of ioctl functions which are called using the I_STR ioctl and strioctl structure as the

CODE EXAMPLE 4-1 ba(7) Man Page (Continued)

argument. See the `streamio(7)` man page and the `<sys/stropts.h>` header file for more information on this type of `ioctl` call.

The commands supported in the `ic_cmd` field of the `strioctl` structure are described in the following paragraphs. The structures that the `ic_dp` field should point to are also described for each command.

A_ALLOCBW Allocate constant bit rate bandwidth for this stream. `ic_dp` should point to an `a_allocbw_t` structure, which is defined as:

```
typedef struct {
    int bw;
} a_allocbw_t;
```

In this `ioctl` the bandwidth amount is expressed as an integer number of megabits per second (Mbps). See the table below for the amount of bandwidth available to be allocated by the user. All unallocated bandwidth is given to IP and `dlpi` mode traffic. The `A_ALLOCBW` `ioctl` is supported for compatibility with software written for SunATM 1.0. The `A_ALLOCBW_CBR` `ioctl` provides a finer granularity in bandwidth allocation.

A_ALLOCBW_CBR Allocate constant bit rate bandwidth for this stream. `ic_dp` should point to an `a_allocbw_cbr_t` structure, which is defined as:

```
typedef struct {
    int bw;
} a_allocbw_cbr_t;
```

In this `ioctl` the bandwidth amount is expressed as an integer number of 64 kilobit per second (Kbps) units. See the table below for the amount of bandwidth available to be allocated by the user. All unallocated bandwidth is given to IP and `dlpi` mode traffic.

A_ALLOCBW_VBR Allocate variable bit rate bandwidth for this

CODE EXAMPLE 4-1 ba(7) Man Page (Continued)

stream. `ic_dp` should point to an `a_allocbw_vbr_t` structure, which is defined as:

```
typedef struct {
    int peak_bw;
    int avg_bw;
    int max_burst;
    int priority;
} a_allocbw_vbr_t;
```

`A_ALLOCBW_VBR` implements the GCRA (Generic Cell Rate Algorithm) as defined by the ATM Forum UNI 3.0 specification. `peak_bw` specifies (in 64 Kbps units) the Peak Cell Rate. `avg_bw` specifies (in 64 Kbps units) the Sustainable Cell Rate. `max_burst` specifies the number of cells which can be sent back to back on the media, the Maximum Burst Size from the UNI spec. `priority` can be `AVBR_HIGH_PRI` or `AVBR_LO_PRI`. `AVBR_HIGH_PRI` will always get their requested bandwidth, `AVBR_LO_PRI` can starve if other users request all available bandwidth.

Note that the `peak_bw`, `avg_bw`, and `max_burst` parameters are enforced by the hardware device. Since the hardware is not infinitely programmable the driver may have to modify the requested B/W before programming the device. The driver will program the hardware `avg_bw` as close to the requested value as possible. `peak_bw` may be rounded down as necessary to meet the hardware granularity; the received `peak_bw` will always be less than or equal to the requested `peak_bw`, never greater. `max_burst` will be truncated at the maximum supported by the hardware; the received `max_burst` will always be less than or equal to the requested `max_burst`, never greater.

See the table below for the amount of (sustained) bandwidth available to be allocated by the user. All unallocated bandwidth is given to IP and `dlpi` mode traffic.

CODE EXAMPLE 4-1 ba(7) Man Page (Continued)

Available Bandwidth

Product	SunATM-155		SunATM-622	
Unit of Measure	Mbps	64 Kbps	Mbps	64 Kbps
Total Bandwidth	155	2480	622	9952
Cell Header/Phy Layer Overhead	20	320	88	1408
Reserved by Software	0.64	1	0.64	1
Available to User	134.875	2158	533.875	8542

A_RELSEBW Release bandwidth that was previously allocated for this stream. `ic_dp` should point to an `a_allocbw_t` structure.

On successful completion, the ALLOCBW/RELSEBW ioctls return 0. Otherwise, -1 is returned and `errno` is set to one of the following values:

- EUNATCH The user has not attached to a ppa.
- EINVAL The requested bandwidth is negative or otherwise invalid.
- ENOSPC All useable bandwidth has already been allocated, or no bandwidth group is available.
- EDEADLK (VBR only) The requested peak rate is less than the requested average rate. The traffic parameters are impossible to

satisfy.

A_ADDVC Add a vpci to those serviced by this stream, and specify the encapsulation type. The encapsulation type defines the format in which data will be sent to the driver: raw mode, indicated by `NULL_ENCAP`, implies a single mblock with only the four-byte vpci followed immediately by the data. `dlpi` mode, indicated by `LLC_ENCAP`, implies a two-mblock message, consisting of a `M_PROTO` mblock followed by a `M_DATA` mblock containing the data. The `M_PROTO` mblock will contain a `dlpi` message type (`dl_unitdata_req` or `dl_unitdata_ind`) and the vpci; the format may be found in `<sys/dlpi.h>`. For the `A_ADDVC` ioctl call, `ic_dp` points to an `a_addVC_t` structure, which is defined as:

```
typedef struct {
    vci_t vp_vc; /* vpci to be added */
    int aal_type; /* null -> 0,          */
                    /* AAL5 -> 5          */
    int encap; /* encapsulation; see */
                    /* <atm/atmiocntl.h> for */
                    /* possible values */
    int buf_type; /* if AAL5:          */
                    /* 0 -> small buf (9 k) */
                    /* 1 -> big buf (9 k) */
                    /* 2 -> huge buf (64 k) */
                    /* if null AAL          */
                    /* -> # of cells          */
} a_addVC_t;
```

A_DELVC Remove a vpci from those serviced by this stream. `ic_dp` points to an `a_delVC_t` structure:

```
typedef struct {
    vci_t vp_vc;
} a_delVC_t;
```

CODE EXAMPLE 4-1 ba(7) Man Page (Continued)

On successful completion, the ADDVC/DELVC ioctls return 0 . Otherwise, - 1 is returned and errno is set to one of the following values:

EUNATCH	The user has not attached to a ppa.
EINVAL	The encap argument is not valid, the aal_type is not valid, or the size is too large. The hardware controlled by the ba driver supports frames up to 64 KBytes.
E2BIG	The VCI is outside the range supported by the hardware. The hardware controlled by the ba driver supports VCIs 0-1023.
EBUSY	The requested VCI is in use by another process.
ENOMEM	Memory allocation failed. Resources for the HUGE_BUF_TYPE buffer ring are not allocated by the driver until a user requests them.

EXAMPLES

The following code fragment demonstrates opening a ba device and allocating 128 Kbits/sec of bandwidth for that stream. The example shows the actual ioctl to set the bandwidth. There is a utility function in libatm, atm_allocate_cbr_bw, to make this task easier.

```
#include <sys/types.h>
#include <stropts.h>
#include <sys/conf.h>
#include <atm/atm.h>
#include <atm/atmioctl.h>

int
main (int argc, char **argv)
{
    char                dev[0x20] = "/dev/ba0";
    int                 fd;
```

CODE EXAMPLE 4-1 ba(7) Man Page (Continued)

```
int                ppa = 0;
a_allocbw_cbr_t   ap;
struct strioctl   strioctl;

if ((fd = atm_open(dev)) < 0) {
    exit(-1);
}

if (atm_attach(fd, ppa, -1) < 0) {
    exit(-1);
}

ap.bw = 2;

strioctl.ic_cmd = A_ALLOCBW_CBR;
strioctl.ic_timeout = -1;
strioctl.ic_len = sizeof (ap);
strioctl.ic_dp = (caddr_t) &ap;

if (ioctl(fd, I_STR, &strioctl) < 0) {
    exit(-1);
}
}
```

SEE ALSO

atm_util(3), dlpi(7), streamio(7)

q93b(7)

CODE EXAMPLE 4-2 q93b(7) Man Page

q93b(7) Device and Network Interfaces q93b(7)

NAME

q93b - Multiplexing Driver supporting Q.2931 signalling

SYNOPSIS

CODE EXAMPLE 4-2 q93b(7) Man Page (Continued)

```
#include <atm/qcc.h>
#include <atm/qccioctl.h>
```

DESCRIPTION

The q93b driver supports Q.2931 call control signalling as defined by the ATM Forum's User Network Interface, V3.0, V3.1, and V4.0. It is a multi-threaded, loadable, clonable, M-to-N multiplexing STREAMS driver. Its interface is defined by the Q.2931 message set, with some additions for synchronization between the driver and user process. A Q.2931 Call Control library is provided with the SUNWatma software package which provides a set of functions that may be used to build and parse q93b messages. See the qcc_* man pages for further information.

The following table lists the messages types that are supported. For sample message exchanges, see Appendix E in the SunATM Manual.


TYPE	DIRECTION
setup	both
setup_ack*	to user
call_proceeding	both
alerting	both**
connect	both
connect_ack	to user
release	to q93b
release_complete	both
status_enquiry	to q93b
status	to user
notify	both**
restart	both
restart_ack	both
add_party	to q93b
add_party_ack	to user
add_party_alerting	to user**
add_party_reject	to user
drop_party	both
drop_party_ack	to q93b
leaf_setup_fail	both**
leaf_setup_req	both**

*private to the user/q93b interface

**only supported in UNI 4.0

CODE EXAMPLE 4-2 q93b(7) Man Page (Continued)

Messages to the q93b driver should consist of two mblks, as shown below:



The 9 byte header on the M_DATA block consists of the Q.2931 header information; the 16 byte trailer is allocated for use by the lower layers to enhance performance. This additional 25 bytes is added to the variable length Information Element (IE) section when the `qcc_len` functions calculate the required buffer sizes for the message types. The Q.2931 header is also filled in by the `qcc_bld` functions.

IOCTLS

The q93b driver supports a q93b-specific STREAMS `ioctl`, `Q93B_IOC`. Several commands may be specified using this `ioctl`. The data structure used varies depending on the command; see the `<atm/qccioctl.h>` header file for a definition of these structures. Functional interfaces for these `ioctl` commands are provided in the `qcc` library; see the `qcc_util` man page for descriptions of these functions.

The following commands are supported:

Q93B_IOC_BIND Binds a stream to the q93b driver to a specified service access point (sap). The q93b driver uses the sap, which must be specified in the BHLI Information Element of a setup message, to determine to which of its user streams it will send an incoming setup message.

Q93B_IOC_BIND_LIJID Binds a stream to a specified Leaf-Initiated Join ID. Leaf-initiated join is a new feature in UNI 4.0 signalling, which allows an endpoint to request to be added to a point-to-multipoint connection. The leaf-initiated join id is used by the endpoint to

CODE EXAMPLE 4-2 q93b(7) Man Page (*Continued*)

identify the connection which it wishes to join. In order to be the root of a point-to-multipoint call which will support leaf-initiated join, a user application must associate its q93b stream with the leaf-initiated join id in one of two ways: by setting up a call in which the leaf-initiated join id is specified, or by sending this ioctl to the q93b driver.

Q93B_IOC_UNBIND_LIJID

Unbinds a Leaf-Initiated Join ID from a stream.

SEE ALSO

qcc_bld(3), qcc_create(3), qcc_len(3), qcc_pack(3),
qcc_parse(3), qcc_unpack(3), qcc_util(3), atm_util(3),
qcc_bld(9F), qcc_create(9F), qcc_pack(9F), qcc_parse(9F),
qcc_unpack(9F), ba(7)

"ATM User-Network Interface Specification, V3.0," ATM Forum.

"ATM User-Network Interface Specification, V3.1," ATM Forum.

"ATM User-Network Interface Specification, V4.0," ATM Forum.

"Data Link Provider Interface Specification, Rev. 2.0.0," 20
Aug 1991, UNIX International.

SunATM Manual

DDI and DKI Kernel Functions

The man pages in this chapter describe the kernel functions available for use by the SunATM device drivers.

TABLE 5-1 DDI and DKI Kernel Function Man Pages

Man Page	Description	Page Number
qcc_bld(9F)	Build Q.2931 messages, with these commands: qcc_bld_setup(9F), qcc_bld_alerting(9F), qcc_bld_call_proceeding(9F), qcc_bld_connect(9F), qcc_bld_release(9F), qcc_bld_release_complete(9F), qcc_bld_status(9F), qcc_bld_status_enquiry(9F), qcc_bld_notify(9F), qcc_bld_restart(9F), qcc_bld_restart_ack(9F), qcc_bld_add_party(9F), qcc_bld_add_party_ack(9F), qcc_bld_party_alerting(9F), qcc_bld_add_party_reject(9F), qcc_bld_drop_party(9F), qcc_bld_drop_party_ack(9F),	page 127

TABLE 5-1 DDI and DKI Kernel Function Man Pages (Continued)

Man Page	Description	Page Number
qcc_create(9F)	<p>qcc_bld_leaf_setup_fail(9F), qcc_bld_leaf_setup_req(9F)</p> <p>Build Q.2931 messages, including:</p> <p>qcc_create_setup(9F), qcc_create_alerting(9F), qcc_create_call_proceeding(9F), qcc_create_connect(9F), qcc_create_connect_ack(9F), qcc_create_release(9F), qcc_create_release_complete(9F), qcc_create_status(9F), qcc_create_status_enq(9F), qcc_create_notify(9F), qcc_create_restart(9F), qcc_create_restart_ack(9F), qcc_create_add_party(9F), qcc_create_add_party_ack(9F), qcc_create_party_alerting(9F), qcc_create_add_party_reject(9F), qcc_create_drop_party(9F), qcc_create_drop_party_ack(9F), qcc_create_leaf_setup_fail(9F), qcc_create_leaf_setup_req(9F)</p>	page 135
qcc_pack(9F)	<p>Encode Q.2931 message structure information and pack into streams buffers, with these commands:</p> <p>qcc_pack_setup(9F), qcc_pack_alerting(9F), qcc_pack_call_proceeding(9F), qcc_pack_connect(9F), qcc_pack_connect_ack(9F), qcc_pack_release(9F),</p>	page 144

TABLE 5-1 DDI and DKI Kernel Function Man Pages (Continued)

Man Page	Description	Page Number
qcc_parse(9F)	<p>qcc_pack_release_complete(9F), qcc_pack_status(9F), qcc_pack_status_enq(9F), qcc_pack_notify(9F), qcc_pack_restart(9F), qcc_pack_restart_ack(9F), qcc_pack_add_party(9F), qcc_pack_add_party_ack(9F), qcc_pack_party_alerting(9F), qcc_pack_add_party_reject(9F), qcc_pack_drop_party(9F), qcc_pack_drop_party_ack(9F), qcc_pack_leaf_setup_fail(9F), qcc_pack_leaf_setup_req(9F)</p> <p>Parse Q.2931 messages, with these commands:</p> <p>qcc_parse_setup(9F), qcc_parse_alerting(9F), qcc_parse_call_proceeding(9F), qcc_parse_connect(9F), qcc_parse_release(9F), qcc_parse_release_complete(9F), qcc_parse_status_enquiry(9F), qcc_parse_notify(9F), qcc_parse_status(9F), qcc_parse_restar(9F), qcc_parse_restart_ack(9F), qcc_parse_add_party(9F), qcc_parse_add_party_ack(9F), qcc_parse_party_alerting(9F), qcc_parse_add_party_reject(9F),</p>	page 148

TABLE 5-1 DDI and DKI Kernel Function Man Pages (Continued)

Man Page	Description	Page Number
	<pre>qcc_parse_drop_party(9F), qcc_parse_drop_party_ack(9F), qcc_parse_leaf_setup_fail(9F), qcc_parse_leaf_setup_req(9F)</pre>	
qcc_set_ie(9F)	Add or update Information Elements in a Q.2931 message structure	page 156
qcc_unpack(9F)	Decode Q.2931 messages and unpack into message structures with these commands: <pre>qcc_unpack_setup(9F), qcc_unpack_alerting(9F), qcc_unpack_call_proceeding(9F), qcc_unpack_connect(9F), qcc_unpack_connect_ack(9F), qcc_unpack_release(9F), qcc_unpack_release_complete(9F), qcc_unpack_status(9F), qcc_unpack_status_enq(9F), qcc_unpack_notify(9F), qcc_unpack_restart(9F), qcc_unpack_restart_ack(9F), qcc_unpack_add_party(9F), qcc_unpack_add_party_ack(9F), qcc_unpack_party_alerting(9F), qcc_unpack_add_party_reject(9F), qcc_unpack_drop_party(9F), qcc_unpack_drop_party_ack(9F), qcc_unpack_leaf_setup_fail(9F), qcc_unpack_leaf_setup_req(9F)</pre>	page 162

qcc_bld(9F)

CODE EXAMPLE 5-1 qcc_bld(9F) Man Page

```
qcc_bld(9F)           Kernel Functions for Drivers           qcc_bld(9F)
```

NAME

```
qcc_bld,           qcc_bld_setup,           qcc_bld_alerting,
qcc_bld_call_proceeding, qcc_bld_connect, qcc_bld_release,
qcc_bld_release_complete,           qcc_bld_status,
qcc_bld_status_enquiry, qcc_bld_notify, qcc_bld_restart,
qcc_bld_restart_ack,           qcc_bld_add_party,
qcc_bld_add_party_ack,           qcc_bld_party_alerting,
qcc_bld_add_party_reject,           qcc_bld_drop_party,
qcc_bld_drop_party_ack,           qcc_bld_leaf_setup_fail,
qcc_bld_leaf_setup_req - build Q.2931 messages
```

SYNOPSIS

```
cc -DKERNEL -D_KERNEL [ flag ... ] file ...
```

```
#include <atm/types.h>
#include <atm/qcc.h>
```

```
char _depends_on[] = "drv/qcc";
```

```
mblk_t *qcc_bld_setup(char *ifname, int calltag, int vci,
                    int forward_sdusize, int backward_sdusize,
                    atm_addr_t *src_addrp, atm_addr_t *dst_addrp,
                    int sap, int endpt_ref);
```

```
mblk_t *qcc_bld_alerting(char *ifname, int callid, int vci,
                        int endpt_ref);
```

```
mblk_t *qcc_bld_call_proceeding(char *ifname, int callid,
                                int vci, int endpt_ref);
```

```
mblk_t *qcc_bld_connect(char *ifname, int callid, int vci,
                        int forward_sdusize, int backward_sdusize,
                        int endpt_ref);
```

```
mblk_t *qcc_bld_release(char *ifname, int callid,
                        int cause);
```

CODE EXAMPLE 5-1 qcc_bld(9F) Man Page (Continued)

```
mblk_t *qcc_bld_release_complete(char *ifname, int callid,
    int cause);

mblk_t *qcc_bld_status_enquiry(char *ifname, int callid,
    int endpt_ref);

mblk_t *qcc_bld_status(char *ifname, int callid,
    int callstate, int cause, int endpt_ref,
    int endpt_state);

mblk_t *qcc_bld_notify(char *ifname, int callid,
    int contentlen, u_char *contentp, int endpt_ref);

mblk_t *qcc_bld_restart(char *ifname, int callid, int vci,
    int rstall);

mblk_t *qcc_bld_restart_ack(char *ifname, int callid,
    int vci, int rstall);

mblk_t *qcc_bld_add_party(char *ifname, int callid,
    int forward_sdu_size, int backward_sdu_size,
    atm_address_t *src_addrp,
    atm_address_t *dst_addrp, int sap, int endpt_ref);

mblk_t *qcc_bld_add_party_ack(char *ifname, int callid,
    int endpt_ref);

mblk_t *qcc_bld_party_alerting(char *ifname, int callid,
    int endpt_ref);

mblk_t *qcc_bld_add_party_reject(char *ifname, int callid,
    int cause, int endpt_ref);

mblk_t *qcc_bld_drop_party(char *ifname, int callid,
    int cause, int endpt_ref);

mblk_t *qcc_bld_drop_party_ack(char *ifname, int callid,
    int cause, int endpt_ref);

mblk_t *qcc_bld_leaf_setup_fail(char *ifname, int callid,
    int cause, atm_address_t *dst_addrp,
    int leaf_num);

mblk_t *qcc_bld_leaf_setup_req(char *ifname, int leaftag,
    atm_address_t *src_addrp,
```


CODE EXAMPLE 5-1 qcc_bld(9F) Man Page (Continued)

```
atm_address_t *dst_addrp, int lij_callid);
```

MT-LEVEL

Safe.

AVAILABILITY


The functionality described in this man page is available in the SUNWatma package included with the SunATM adapter board. The `-DKERNEL` and `-D_KERNEL` flags must be included to indicate that the application should run in kernel space, and the qcc driver must be loaded (this requirement is expressed in the code using the "depends_on" line shown in the synopsis).

DESCRIPTION

These functions build the various messages that make up the Q.2931 protocol which is used for ATM signalling. A full description of the message format and use can be found in the ATM Forum's User Network Interface Specification, V3.0, V3.1, or V4.0. The messages built will conform to the version of the UNI Specification which is configured on the indicated interface. The functions may be used by processes which are running in kernel space.

In general, no error checking is performed on the data that is passed in. Whatever data is passed in will be placed in the message that is built without examination. The only exceptions to this are mentioned in the function descriptions.

Two `mblk_t` structures are allocated and linked by each of the functions (their format is shown in the following diagram). The pointer that is returned points to the `M_PROTO` block, and may then be passed downstream with the `putq(9F)` command.



The parameters passed in to each function are used to fill in the data portions of these two mblks.

Each function requires a minimum of 2 parameters: `ifname`, which is a string containing the physical interface (such as `ba0`); and an integer, either `calltag` or `callid`, depending on the message type. `calltag` is used in the setup message only; it is a reference number that is assigned by the calling application. `callid` is used in all other messages; it is assigned by the lower layer and will be sent up to the user, with the `calltag`, in the `setup_ack` message.

Other parameters for each function depend on the type of information required for each message type, and are defined in the paragraphs describing each function call.

`qcc_bld_setup()` constructs a setup message containing the following Information Elements: AAL parameters, ATM user cell rate, broadband bearer capability, called party number, calling party number, quality of service parameter, and endpoint reference. The user must pass in the forward and backward sdu sizes for the AAL parameter IE, an ATM address for the destination for the called party number IE, and one for itself for the calling party number IE (`atm_address_t` format is defined in the `<atm/qcc.h>` header file). The value passed in the `sap` parameter is placed in a broadband higher layer IE. The higher layer IE indicates the `sap` to which received messages should be directed. If the user passes in a positive `vci`, a connection identifier IE will be included; if the user passes in a non-negative `endpt_ref` (0 is valid), an endpoint reference IE will be included. The endpoint reference IE indicates that this is a point-to-multipoint call.

`qcc_bld_alerting()` is specific to UNI 4.0. It builds an alerting message containing a connection identifier IE if a positive `vci` is passed in, and an endpoint reference IE if a non-negative `endpt_ref` is passed in. An endpoint reference IE should only appear if the call is a point-to-multipoint call. The alerting message is only supported under UNI 4.0.

`qcc_bld_call_proceeding()` includes a connection identifier IE if a positive `vci` is passed in, and an endpoint reference IE if a non-negative `endpt_ref` is passed in. An endpoint reference IE should only appear if the call is a point-to-multipoint call.

`qcc_bld_connect()` includes an AAL parameters IE, requiring the `forward_` and `backward_sdu` values, a connection identifier IE if a positive `vci` value is passed in, and an endpoint reference IE if a non-negative `endpt_ref` value is passed in. An endpoint reference IE should only appear if the call is a point-to-multipoint call.

`qcc_bld_release()` includes a cause IE for which the user must pass in a cause value. The possible values can be found in the `<atm/qcc.h>` header file. The same is true for `qcc_bld_release_complete()`.

`qcc_bld_status_enquiry()` includes only an endpoint reference IE if a non-negative `endpt_ref` value is passed in. An endpoint reference IE should only appear if the call is a point-to-multipoint call.

`qcc_bld_status()` includes a call state IE, requiring the user pass in the `callstate` parameter; possible values can be found in the `<atm/qcc.h>` header file. It also includes a cause IE; the cause value must also be passed in. Its possible values may also be found in the `<atm/qcc.h>` header file. Finally, if the call is a point-to-multipoint call, endpoint reference and endpoint state IEs may also be included; they are included if a non-negative `endpt_ref` value is passed in. The `endpt_state` parameter is used in the endpoint state IE; possible party state values may be found in `<atm/qcc.h>`.

`qcc_bld_notify()` is specific to UNI 4.0. It builds a notify message, including a notification indicator IE, which contains a buffer of user-defined information up to a maximum length of 16 bytes (defined by `contentlen` and `contentp`), and an endpoint reference IE if a non-negative `endpt_ref` value is passed in. An endpoint reference IE should only appear

if the call is a point-to-multipoint call. The notify message is only valid under UNI 4.0.

`qcc_bld_restart()` includes a restart indicator IE, which is used to determine whether an individual call or all calls on an interface should be restarted. If `rstall` is 0, only the call identified by `vci` should be restarted; in this case, a connection identifier IE will also be included. If `rstall` is non-zero, all calls will be restarted. The same format

applies to the `qcc_bld_restart_ack()` function.

`qcc_bld_add_party()` constructs an add party message for a point-to-multipoint call. The message constructed will contain an AAL parameters IE, which includes the `forward_` and `backward_sdu_size` parameters, a calling party number IE, which includes the value pointed to by `src_addrp`, a called party number IE, which includes the value pointed to by `dst_addrp`, a broadband higher layer interface IE, which includes the `sap` parameter, and an endpoint reference IE, which includes the `endpt_ref` parameter. The `sap` value in the broadband higher layer information IE is used to indicate the `sap` to which the message should be passed by the receiving host.

`qcc_bld_add_party_ack()` constructs an add party ack message which includes an endpoint reference IE, for which the `endpt_ref` parameter is required.

`qcc_bld_party_alerting()` is specific to UNI 4.0. It builds a party alerting message, containing an endpoint reference IE, for which the `endpt_ref` parameter is required.

`qcc_bld_add_party_reject()` includes a cause IE, containing the cause value passed in. The possible cause values may be found in the `<atm/qcc.h>` header file. An endpoint reference IE is also included, which requires the `endpt_ref` parameter.

`qcc_bld_drop_party()` constructs a drop party message. The message constructed will contain two IEs: a cause IE, which requires the cause parameter, and an endpoint reference IE, which requires the `endpt_ref` parameter. Possible cause values may be found in the header file `<atm/qcc.h>`.

`qcc_bld_drop_party_ack()` contains an endpoint reference IE, requiring the `endpt_ref` parameter, and optionally, a cause IE. The cause IE will be included if a positive value is passed in in the cause parameter. Possible cause values may be found in the `<atm/qcc.h>` header file.

`qcc_bld_leaf_setup_fail()` is specific to UNI 4.0. It contains a cause IE if a non-negative cause value is passed in; a called number IE if a non-null `dst_addrp` is passed in; and a leaf number IE, for which the `leaf_num` parameter is required. This message type is only valid under UNI 4.0.

CODE EXAMPLE 5-1 qcc_bld(9F) Man Page (Continued)

`qcc_bld_leaf_setup_req()` is specific to UNI 4.0. It contains Calling Number and Called Number IEs if non-null `src_addrp` and `dst_addrp` are passed in, respectively; it also contains a leaf initiated join call identifier IE for which `lij_callid` is required, and a leaf number IE. The leaf number is assigned by the q93b driver. Because the leaf number is assigned by the q93b driver, a mechanism similar to that used in the `setup` and `setup_ack` messages is used with the leaf number: the user must provide a 'leaftag' parameter in the call to `qcc_bld_leaf_setup_req()`; this tag is inserted in the `calltag` field of the qcc header. When the message is received and accepted by the q93b driver, a `leaf_setup_ack` message is returned, containing both the `leaftag`, in the `calltag` field of the qcc header, and the driver-assigned leaf number, in the `callref` field. The `leaf_setup_req` and `leaf_setup_ack` messages are the only messages which will not contain a call reference value in the `callref` field; this is because the messages are not tied to a specific call. This message, and the leaf-initiated join functionality, are only supported under UNI 4.0.

RETURN VALUES

All functions return a pointer to an `mblk_t`. If the function is not successful, the pointer will be `NULL`.

EXAMPLES

The following code fragment builds a setup message and sends it downstream.

```
#include <sys/stream.h>
#include <atm/qcc.h>
#include <atm/limits.h>

char    _depends_on[] = "drv/qcc";

void
send_setup(queue_t *q);
{
    mblk_t    *mp;
    char      ifname[QCC_MAX_IFNAME_LEN] = "ba0";
    int       calltag = 0x1234;
    int       vci = 0x100;
    int       forward_sdusize = 0x2378;
    int       backward_sdusize = 0x2378;
    int       sap = 0x100;
```

CODE EXAMPLE 5-1 qcc_bld(9F) Man Page (Continued)

```
    atm_addr_t    src_addr = {
        0x45, 0x00, 0x00, 0x00, 0x00, 0x00, 0x00,
        0x00, 0x0f, 0x00, 0x00, 0x00, 0x00,
        0x08, 0x00, 0x20, 0x1a, 0xe1, 0x53, 0x00
    };

    atm_addr_t    dst_addr = {
        0x45, 0x00, 0x00, 0x00, 0x00, 0x00, 0x00,
        0x00, 0x0f, 0x00, 0x00, 0x00, 0x00,
        0x08, 0x00, 0x20, 0x1a, 0xb6, 0xb9, 0x00
    };

    mp = qcc_bld_setup(iframe, calltag, vci,
        forward_sdu_size, backward_sdu_size,
        &src_addr, &dst_addr, sap, -1);

    if (putq(q, mp) < 0) {
        perror("putq");
        exit (-1);
    }
}
```

SEE ALSO

qcc_util(3), qcc_parse(9F), q93b(7)

"ATM User-Network Interface Specification, V3.0," ATM Forum.

"ATM User-Network Interface Specification, V3.1," ATM Forum.

"ATM User-Network Interface Specification, V4.0," ATM Forum.

NOTES

This API is an interim solution until the ATM Forum has standardized an API. At that time, Sun will implement that API, and support for the Q.2931 Call Control library may not be continued.

The additional support of the UNI 4.0 signalling specification includes the addition of several new message types which are not supported in the earlier versions of the UNI specification. These message types, if sent on an interface configured for UNI 3.0 or 3.1, will be discarded by the q93b driver and will not be sent out to the network. The UNI 4.0-specific messages are Alerting, Notify, Party Alerting, Leaf Setup Fail, and Leaf Setup Request, and are identified in the applicable function descriptions.

qcc_create(9F)

CODE EXAMPLE 5-2 qcc_create(9F) Man Page

qcc_create(9F) Kernel Functions for Drivers qcc_create(9F)

NAME

```
qcc_create,            qcc_create_setup,            qcc_create_alerting,
qcc_create_call_proceeding,            qcc_create_connect,
qcc_create_connect_ack,            qcc_create_release,
qcc_create_release_complete,            qcc_create_status,
qcc_create_status_enq,            qcc_create_notify,
qcc_create_restart,            qcc_create_restart_ack,
qcc_create_add_party,            qcc_create_add_party_ack,
qcc_create_party_alerting,            qcc_create_add_party_reject,
qcc_create_drop_party,            qcc_create_drop_party_ack,
qcc_create_leaf_setup_fail,            qcc_create_leaf_setup_req    -
create Q.2931 message structures
```

SYNOPSIS

```
cc -DKERNEL -D_KERNEL [ flag ... ] file ...

#include <atm/qcc.h>
#include <atm/qcctypes.h>

char _depends_on[] = "drv/qcc";

int qcc_create_setup(qcc_setup_t *msgp, char *ifname,
                    int calltag, atm_address_t *dst_addrp);

int qcc_create_alerting(qcc_alerting_t *msgp, char *ifname,
                       int callid);

int qcc_create_call_proceeding(qcc_call_proc_t *msgp,
                               char *ifname, int callid);

int qcc_create_connect(qcc_connect_t *msgp, char *ifname,
                      int callid);

int qcc_create_connect_ack(qcc_connect_ack_t *msgp,
                          char *ifname, int callid);
```

CODE EXAMPLE 5-2 qcc_create(9F) Man Page (Continued)

```
int qcc_create_release(qcc_release_t *msgp, char *ifname,
    int callid, int cause);

int qcc_create_release_complete(qcc_release_complete_t *
    msgp, char *ifname, int callid);

int qcc_create_status_enq(qcc_status_enq_t *msgp,
    char *ifname, int callid);

int qcc_create_status(qcc_status_t *msgp, char *ifname,
    int callid, int callstate, int cause);

int qcc_create_notify(qcc_notify_t *msgp, char *ifname,
    int callid, int contentlen, u_char *contentp);

int qcc_create_restart(qcc_restart_t *msgp, char *ifname,
    int callid, int indicator, int vci);

int qcc_create_restart_ack(qcc_restart_ack_t *msgp,
    char *ifname, int callid, int indicator, int vci);

int qcc_create_add_party(qcc_add_party_t *msgp,
    char *ifname, int callid, atm_address_t *dst_addrp,
    int endpt_ref);

int qcc_create_add_party_ack(qcc_add_party_ack_t *msgp,
    char *ifname, int callid, int endpt_ref);

int qcc_create_party_alerting(qcc_party_alerting_t *msgp,
    char *ifname, int callid, int endpt_ref);

int qcc_create_add_party_reject(qcc_add_party_reject_t *
    msgp, char *ifname, int callid, int cause,
    int endpt_ref);

int qcc_create_drop_party(qcc_drop_party_t *msgp,
    char *ifname, int callid, int cause, int endpt_ref);

int qcc_create_drop_party_ack(qcc_drop_party_ack_t *msgp,
    char *ifname, int callid, int endpt_ref);

int qcc_create_leaf_setup_fail(qcc_leaf_setup_fail_t *msgp,
    char *ifname, int callid, int cause,
    atm_address_t *dst_addrp, int leaf_num);

int qcc_create_leaf_setup_req(qcc_leaf_setup_req_t *msgp,
```


CODE EXAMPLE 5-2 qcc_create(9F) Man Page (Continued)

```
char *ifname, int leaftag, atm_address_t *src_addrp,  
atm_address_t *dst_addrp, int lij_callid);
```

MT-LEVEL

Safe.

AVAILABILITY

The functionality described in this man page is available in the SUNWatma package included with the SunATM adapter board. The `-DKERNEL` and `-D_KERNEL` flags must be included to indicate that the application should run in kernel space, and the `qcc` driver must be loaded (this requirement is expressed in the code using the "depends_on" line shown in the synopsis).

DESCRIPTION

These functions create message structures representing the various messages that make up the Q.2931 protocol, which is used for ATM signalling. A full description of the message format and use can be found in the ATM Forum's User Network Interface Specification, V3.0, V3.1, or V4.0. The content of the created message structures will conform to the version of the UNI Specification which is configured on the indicated interface. The functions may be used by processes which are running in kernel space.

After a message structure has been created, non-default Information Elements (IEs) may be added or existing IEs may be changed using the `qcc_set_ie(9F)` function. When the message structure has been completely specified, the corresponding `qcc_pack(9F)` function should be called to translate the message structure into the correct encoded format, contained in message blocks which may be passed downstream using the `putq(9F)` function.

In general, no error checking is performed on the data that is passed in. Whatever data is passed in will be placed in the message that is built without examination. The only exceptions to this are mentioned in the function descriptions.

Each function requires a minimum of 3 parameters: `msgp`, which is a pointer to the appropriate message structure type; `ifname`, which is a string containing the physical interface (such as `ba0`); and an integer, either `calltag` or `callid`, depending on the message type. `calltag` is used in

CODE EXAMPLE 5-2 qcc_create(9F) Man Page (Continued)

the setup message only; it is a reference number that is assigned by the calling application. callid is used in all other messages; it is assigned by the lower layer and will be sent up to the user, with the calltag, in the setup_ack message.

The structure to which msgp points must be allocated by the calling user. There is a unique structure for each message type; the message structures are defined in <atm/qcctypes.h>.

Only the mandatory IEs for each message type are added to the message structure by the qcc_create call. The additional parameters to the qcc_create functions allow the user to define most of the information contained in those mandatory IEs; however, in some cases default values are assumed. Those values, as well as the additional parameters for each function, are indicated in the following paragraphs describing each function call.

qcc_create_setup() creates a setup message structure containing the following Information Elements: ATM traffic descriptor (called ATM cell rate in UNI 3.0), broadband bearer capability, called party number, and quality of service parameter. The user must pass in the destination ATM address for the called party number IE (atm_address_t format is defined in the <atm/types.h> header file). The following default values are used for the remaining Information Elements:

ATM Traffic Descriptor:

best effort; line rate is used for the forward and backward peak rates

Broadband Bearer Capability:

Bearer Class X, no indication for traffic type and timing requirements, not susceptible to clipping, and point-to-point user plane

Called Party Number:

ATM Endsystem (NSAP) address type

Quality of Service:

Forward and backward class unspecified

qcc_create_alerting() creates the structure for an alerting

CODE EXAMPLE 5-2 `qcc_create(9F)` Man Page (Continued)

message, which is supported only under UNI 4.0. The alerting message contains no mandatory IEs; only the message header is filled in.

`qcc_create_call_proceeding()` creates the structure for a call proceeding message, which contains no mandatory IEs. Only the message header is filled in.

`qcc_create_connect()` creates the structure for a connect message, which also contains no mandatory IEs. Again, only the required header is filled in. The same is true for `qcc_create_connect_ack`.

`qcc_create_release()` creates a release message structure containing a cause IE, for which the user must pass in a cause value. The possible values can be found in the `<atm/qccdefs.h>` header file. By default, no diagnostic is included and the user location is assigned.

`qcc_create_release_complete()` creates the structure for a release complete message, which contains no mandatory IEs. Only the message header is filled in.

`qcc_create_status_enquiry()` creates a status enquiry message structure, which contains no mandatory IEs. Only the message header is filled in.

`qcc_create_status()` builds a status message structure, containing two mandatory IEs: call state and cause. The user should pass in value for both the callstate and the cause; possible values may be found in the `<atm/qccdefs.h>` header file. In the cause IE, no diagnostic is included and the user location is assigned.

`qcc_create_notify()` builds a notify message structure, which is only supported under UNI 4.0. The message contains a single mandatory IE, the notification indicator, which contains a buffer of user-specified data. The maximum size of the buffer is 16 bytes, defined as `QCC_MAX_NOTIFICATION_LEN` in `<atm/qcc.h>`. The user should allocate a buffer and pass in the buffer length, `contentlen`, and a pointer to the buffer, `contentp`.

`qcc_create_restart()` creates a restart message structure, containing the mandatory restart indicator IE, and optionally the connection identifier IE. The user should pass in

CODE EXAMPLE 5-2 `qcc_create(9F)` Man Page (Continued)

a value for the restart indicator, either `RESTART_INDICATED_VC` or `RESTART_ALL_VCS`. If a non-zero `vci` parameter is passed in, the connection identifier IE is also included in the message, using a default `vpci` of 0 and the `vci` parameter value.

`qcc_create_add_party()` constructs an add party message structure. It includes the mandatory called party number and endpoint reference IEs. The user should pass in a pointer to the called number and an endpoint reference value; for the called party number, ATM Endsystem (NSAP) address type is assumed.

`qcc_create_add_party_ack()` fills in an add party ack message structure with the endpoint reference IE. The `endpt_ref` parameter value is used.

`qcc_create_party_alerting()` creates a party alerting message structure with the endpoint reference IE, which uses the `endpt_ref` parameter. This message type is only supported under UNI 4.0.

`qcc_create_add_party_reject()` fills the cause and endpoint reference IEs into an add party reject structure. The user should provide the cause and endpoint reference value; possible cause values are defined in the `<atm/qccdefs.h>` header file. By default, no diagnostic is included and the user location is assigned in the cause IE.

`qcc_create_drop_party()` fills the cause and endpoint reference IEs into a drop party structure. The user should pass in the cause and endpoint reference values; possible cause values are defined in the `<atm/qccdefs.h>` header file. By default, no diagnostic is included and the user location is assigned in the cause IE.

`qcc_create_drop_party_ack()` fills in only the mandatory endpoint reference IE, requiring the `endpt_ref` parameter.

`qcc_create_leaf_setup_fail()` creates a leaf setup fail message structure, with three mandatory IEs. The cause IE requires the cause parameter, which should be one of the cause values defined in `<atm/qccdefs.h>`; the called number IE requires the destination ATM address, `dst_addrp`; and the leaf number IE requires the `leaf_num` parameter. This message is only supported under UNI 4.0.

CODE EXAMPLE 5-2 qcc_create(9F) Man Page (Continued)

qcc_create_leaf_setup_req() creates a leaf setup request message structure, with four mandatory IEs. Both the calling party and called party number IEs are required, using the source and destination ATM addresses, passed in in the src_addrp and dst_addrp parameters, respectively. The leaf initiated join call identifier IE requires the lij_callid parameter. The final required IE, the leaf number IE, is inserted as a placeholder; the actual leaf number will be assigned and filled in by the q93b driver. It will be returned in the callref field of the qcc header of a leaf_setup_ack message, much as the call reference is returned in a setup_ack message in the setup case. Refer to the description of the qcc_bld_leaf_setup_req() function for more details on this process. This message is only supported under UNI 4.0.

RETURN VALUES

All functions return 0 on success and -1 on error.

EXAMPLES

The following code fragment creates a setup message, adds an optional AAL Parameters IE, packs the message into m_blks, and sends it downstream.

```
#include <sys/stream.h>
#include <atm/limits.h>
#include <atm/qcc.h>
#include <atm/qcctypes.h>

char    _depends_on[] = "drv/qcc";

void
send_setup(queue_t *q);
{
    mblk_t    *mp;
    char      ifname[QCC_MAX_IFNAME_LEN] = "ba0";
    int       calltag = 0x1234;
    int       forward_sdu_size = 0x2378;
    int       backward_sdu_size = 0x2378;
    qcc_msg_t    msgstruct;
    qcc_setup_t    setup;
    qcc_ie_t      iestruct;
    qcc_aal_params_t    aal;

    atm_addr_t    dst_addr = {
```

CODE EXAMPLE 5-2 qcc_create(9F) Man Page (Continued)

```
        0x45, 0x00, 0x00, 0x00, 0x00, 0x00, 0x00,
        0x00, 0x0f, 0x00, 0x00, 0x00, 0x00,
        0x08, 0x00, 0x20, 0x1a, 0xb6, 0xb9, 0x00
    };

    if ((qcc_create_setup(&setup, ifname,
                        calltag, dst_addr)) < 0) {
        printf("qcc_create_setup failed\n");
        exit (-1);
    }

    msgstruct.type = QCC_SETUP;
    msgstruct.msg.setup = &setup;

    aal.type = AAL_TYPE_5;
    aal.info.aal5.forward_max = forward_sdusize;
    aal.info.aal5.backward_max = backward_sdusize;
    aal.info.aal5.mode = MESSAGE_MODE;
    aal.info.aal5.sscs_type = SSCS_TYPE_NULL;

    iestruct.type = QCC_AAL_PARAMETERS;
    iestruct.ie.aal_params = &aal;

    if ((qcc_set_ie(&msgstruct, &iestruct)) < 0) {
        printf("qcc_set_ie failed\n");
        exit (-1);
    }

    if ((mp = qcc_pack_setup(&setup)) == NULL) {
        printf("qcc_pack_setup failed\n");
        exit (-1);
    }

    if (putq(q, mp) < 0) {
        perror("putq");
        exit (-1);
    }
}
```

SEE ALSO

qcc_util(3), qcc_set_ie(9F), qcc_pack(9F), qcc_unpack(9F),
qcc_parse(9F), q93b(7)

"ATM User-Network Interface Specification, V3.0," ATM Forum.

"ATM User-Network Interface Specification, V3.1," ATM Forum.

"ATM User-Network Interface Specification, V4.0," ATM Forum.

CODE EXAMPLE 5-2 `qcc_create(9F)` Man Page (Continued)

NOTES

This API is an interim solution until the ATM Forum has standardized an API. At that time, Sun will implement that API, and support for the Q.2931 Call Control library may not be continued.

The additional support of the UNI 4.0 signalling specification includes the addition of several new message types which are not supported in the earlier versions of the UNI specification. These message types, if sent on an interface configured for UNI 3.0 or 3.1, will be discarded by the `q93b` driver and will not be sent out to the network. The UNI 4.0-specific messages are Alerting, Notify, Party Alerting, Leaf Setup Fail, and Leaf Setup Request, and are identified in the applicable function descriptions.

qcc_pack(9F)

CODE EXAMPLE 5-3 qcc_pack(9F) Man Page

qcc_pack(9F) Kernel Functions for Drivers qcc_pack(9F)

NAME

qcc_pack, qcc_pack_setup, qcc_pack_alerting,
qcc_pack_call_proceeding, qcc_pack_connect,
qcc_pack_connect_ack, qcc_pack_release,
qcc_pack_release_complete, qcc_pack_status,
qcc_pack_status_enq, qcc_pack_notify, qcc_pack_restart,
qcc_pack_restart_ack, qcc_pack_add_party,
qcc_pack_add_party_ack, qcc_pack_party_alerting,
qcc_pack_add_party_reject, qcc_pack_drop_party,
qcc_pack_drop_party_ack, qcc_pack_leaf_setup_fail,
qcc_pack_leaf_setup_req - encode Q.2931 message structure
information and pack into streams buffers

SYNOPSIS

```
cc -DKERNEL -D_KERNEL [ flag ... ] file ...
```

```
#include <atm/types.h>
```

```
#include <atm/qcc.h>
```

```
char _depends_on[] = "drv/qcc";
```

```
mblk_t *qcc_pack_setup(qcc_setup_t *msgp);
```

```
mblk_t *qcc_pack_alerting(qcc_alerting_t *msgp);
```

```
mblk_t *qcc_pack_call_proceeding(qcc_call_proc_t *msgp);
```

```
mblk_t *qcc_pack_connect(qcc_connect_t *msgp);
```

```
mblk_t *qcc_pack_connect_ack(qcc_connect_ack_t *msgp);
```

```
mblk_t *qcc_pack_release(qcc_release_t *msgp);
```

```
mblk_t *qcc_pack_release_complete(  
    qcc_release_complete_t *msgp);
```


CODE EXAMPLE 5-3 qcc_pack(9F) Man Page (Continued)

```
mblk_t *qcc_pack_status_enq(qcc_status_enq_t *msgp);  
mblk_t *qcc_pack_status(qcc_status_t *msgp);  
mblk_t *qcc_pack_notify(qcc_notify_t *msgp);  
mblk_t *qcc_pack_restart(qcc_restart_t *msgp);  
mblk_t *qcc_pack_restart_ack(qcc_restart_ack_t *msgp);  
mblk_t *qcc_pack_add_party(qcc_add_party_t *msgp);  
mblk_t *qcc_pack_add_party_ack(qcc_add_party_ack_t *msgp);  
mblk_t *qcc_pack_party_alerting(qcc_party_alerting_t *msgp);  
mblk_t *qcc_pack_add_party_reject(  
    qcc_add_party_reject_t *msgp);  
mblk_t *qcc_pack_drop_party(qcc_drop_party_t *msgp);  
mblk_t *qcc_pack_drop_party_ack(qcc_drop_party_ack_t *msgp);  
mblk_t *qcc_pack_leaf_setup_fail(  
    qcc_leaf_setup_fail_t *msgp);  
mblk_t *qcc_pack_leaf_setup_req(qcc_leaf_setup_req_t *msgp);
```

MT-LEVEL

Safe.

AVAILABILITY

The functionality described in this man page is available in the SUNWatma package included with the SunATM adapter board. The `-DKERNEL` and `-D_KERNEL` flags must be included to indicate that the application should run in kernel space, and the qcc driver must be loaded (this requirement is expressed in the code using the "depends_on" line shown in the synopsis).

DESCRIPTION

These functions take message structures as input and encode the information contained in the structure to create a Q.2931 message, which is then packed into `mblk_t` structures. The Q.2931 protocol is used for ATM signalling; a full description of the message format and use can be found in

CODE EXAMPLE 5-3 qcc_pack(9F) Man Page (Continued)


the ATM Forum's User Network Interface Specification, V3.0, V3.1, or V4.0. The encoded messages will conform to the version of the UNI Specification which is configured on the indicated interface. The functions may be used by processes which are running in kernel space.

Message structures should be filled using the qcc_create(9F) and qcc_set_ie(9F) functions before calling qcc_pack functions.

In general, no error checking is performed on the data that is passed in. Whatever data is contained in the message structure will be placed in the encoded message without examination.

Each function requires 1 parameter: msgp, which is a pointer to the appropriate message structure.

Two mblk_t structures are allocated and linked by each of the functions (their format is shown in the following diagram). The pointer that is returned points to the M_PROTO block, and may then be passed downstream with the putq(9F) command.



The information in the message structure passed in to each function is used to fill in the data portions of these two mblks.

RETURN VALUES

All functions return a pointer to an mblk_t. If the function is not successful, the pointer will be NULL.

EXAMPLES

For an example using qcc_pack_setup, see the example in the qcc_create(9F) man page.

CODE EXAMPLE 5-3 `qcc_pack(9F)` Man Page (Continued)

SEE ALSO

`qcc_util(3)`, `qcc_create(9F)`, `qcc_set_ie(9F)`, `q93b(7)`

"ATM User-Network Interface Specification, V3.0," ATM Forum.

"ATM User-Network Interface Specification, V3.1," ATM Forum.

"ATM User-Network Interface Specification, V4.0," ATM Forum.

NOTES

This API is an interim solution until the ATM Forum has standardized an API. At that time, Sun will implement that API, and support for the Q.2931 Call Control library may not be continued.

The additional support of the UNI 4.0 signalling specification includes the addition of several new message types which are not supported in the earlier versions of the UNI specification. These message types will be ignored by the `q93b` driver if used on an interface which is configured for UNI 3.0 or 3.1. The UNI 4.0-specific messages are Alerting, Notify, Party Alerting, Leaf Setup Fail, and Leaf Setup Request.

qcc_parse(9F)

CODE EXAMPLE 5-4 qcc_parse(9F) Man Page

qcc_parse(9F) Kernel Functions for Drivers qcc_parse(9F)

NAME

qcc_parse, qcc_parse_setup, qcc_parse_alerting,
qcc_parse_call_proceeding, qcc_parse_connect,
qcc_parse_release, qcc_parse_release_complete,
qcc_parse_status_enquiry, qcc_parse_notify,
qcc_parse_status, qcc_parse_restart, qcc_parse_restart_ack,
qcc_parse_add_party, qcc_parse_add_party_ack,
qcc_parse_party_alerting, qcc_parse_add_party_reject,
qcc_parse_drop_party, qcc_parse_drop_party_ack,
qcc_parse_leaf_setup_fail, qcc_parse_leaf_setup_req - parse
Q.2931 messages

SYNOPSIS

```
cc -DKERNEL -D_KERNEL [ flag ... ] file ...
```

```
#include <atm/types.h>  
#include <atm/qcc.h>
```

```
char _depends_on[] = "drv/qcc";
```

```
int qcc_parse_setup(mblk_t *mp, int *vcip,  
                  int *forward_sdusizep, int *backward_sdusizep,  
                  atm_addr_t *src_addrp, atm_addr_t *dst_addrp,  
                  int *sapp, int *endpt_refp);
```

```
int qcc_parse_alerting(mblk_t *mp, int *vcip,  
                      int *endpt_refp);
```

```
int qcc_parse_call_proceeding(mblk_t *mp, int *vcip,  
                              int *endpt_refp);
```

```
int qcc_parse_connect(mblk_t *mp, int *vcip,  
                      int *forward_sdusizep, int *backward_sdusizep,  
                      int *endpt_refp);
```

```
int qcc_parse_release(mblk_t *mp, int *causep);
```

CODE EXAMPLE 5-4 qcc_parse(9F) Man Page (Continued)

```
int qcc_parse_release_complete(mblk_t *mp,
    int *causep);

int qcc_parse_status_enquiry(mblk_t *mp,
    int *endpt_refp);

int qcc_parse_status(mblk_t *mp, int *callstatep,
    int *causep, int *endpt_refp, int *endpt_statep);

int qcc_parse_notify(mblk_t *mp, int *contentlenp,
    u_char *contentp, int *endpt_refp);

int qcc_parse_restart(mblk_t *mp, int *vcip,
    int *rstallp);

int qcc_parse_restart_ack(mblk_t *mp, int *vcip,
    int *rstallp);

int qcc_parse_add_party(mblk_t *mp, int *forward_sdu_sizep,
    int *backward_sdu_sizep, atm_address_t *src_addrp,
    atm_address_t *dst_addrp, int *sapp, int *endpt_refp);

int qcc_parse_add_party_ack(mblk_t *mp, int *endpt_refp);

int qcc_parse_party_alerting(mblk_t *mp, int *endpt_refp);

int qcc_parse_add_party_reject(mblk_t *mp, int *causep,
    int *endpt_refp);

int qcc_parse_drop_party(mblk_t *mp, int *causep,
    int *endpt_refp);

int qcc_parse_drop_party_ack(mblk_t *mp, int *causep,
    int *endpt_refp);

int qcc_parse_leaf_setup_fail(mblk_t *mp, int *causep,
    atm_address_t *dst_addrp, int *leaf_nump);

int qcc_parse_leaf_setup_req(mblk_t *mp,
    atm_address_t *src_addrp, atm_address_t *dst_addrp,
    int *lij_callidp, int *leaf_nump);
```

MT-LEVEL
Safe.


AVAILABILITY

The functionality described in this man page is available in the SUNwATMA package included with the SunATM adapter board. The `-DKERNEL` and `-D_KERNEL` flags must be included to indicate that the application should run in kernel space, and the `qcc` driver must be loaded (this requirement is expressed in the code using the "depends_on" line shown in the synopsis).

DESCRIPTION

These functions parse the various messages that make up the Q.2931 protocol which is used for ATM signalling. A full description of the message format and use can be found in the ATM Forum's User Network Interface Specification, V3.0, V3.1, or V4.0. Messages conforming to both versions will be parsed. The functions may be used by processes which are running in kernel space.

Each function requires a minimum of 1 parameter: `mp`, which is a pointer to a `mblk_t` structure, and is extracted from the following structure:



When a message is received from the `q93b` driver using the `getq(9F)` function, a pointer to the `M_PROTO` block shown above is returned. However, the `q93b` message which is parsed is contained in the `M_DATA` block, so the first parameter passed to a `qcc_parse` function must be `mp->b_cont`, where `mp` is the pointer received by `getq()`. The `M_PROTO` block data may be examined to determine the message type, which indicates the parsing function that should be called.

Other parameters for each function depend on the type of information that is available in each message type. In all cases, certain IEs are examined in each message, as indicated below. If those IEs exist, the data that is expected from them is retrieved, but no error message is sent if they

CODE EXAMPLE 5-4 qcc_parse(9F) Man Page (Continued)

do not exist; the value of the parameter is set to -1 for any data that was expected from that particular IE. Also, IEs that are not expected are ignored. If the user wishes to ignore any of the parameters of a parse function, passing in a NULL pointer for that parameter is allowed so that space need not be allocated for the unnecessary parameter.

qcc_parse_setup() parses a setup message containing the following Information Elements: AAL parameters, ATM user cell rate, broadband bearer capability, called party number, calling party number, quality of service parameter, connection identifier, broadband higher layer information, and endpoint reference. The endpoint reference IE is only included in setup messages for point-to-multipoint calls. The following table matches the data that is retrieved from the message with the IE from which it is parsed.

DATA RETRIEVED	INFORMATION ELEMENT
vci	connection identifier
forward sdu size	AAL parameters
backward sdu size	AAL parameters
source address	calling party number
destination address	called party number
sap	broadband higher layer
endpoint reference id	endpoint reference

qcc_parse_alerting() parses an alerting message. The alerting message is new in UNI 4.0; if received on an interface configured for uni 3.0 or 3.1, it will be dropped by the q93b driver. The IEs examined by this function are the connection identifier IE, from which the vci is parsed, and the endpoint reference IE, from which the endpt_ref parameter is parsed. The endpoint reference IE is only included in alerting messages for point-to-multipoint calls.

qcc_parse_call_proceeding() parses a call proceeding message containing a connection identifier IE, which is used to set the value of vci, and an endpoint reference IE, setting the value of endpt_ref. The endpoint reference IE is only included in call proceeding messages for point-to-multipoint calls.

qcc_parse_connect() parses a connect message containing an AAL parameters IE, setting the forward and backward sdu size values, a connection identifier IE, setting the value of vci, and an endpoint reference IE, setting the value of

endpt_ref. The endpoint reference IE is only included in connect messages for point-to-multipoint calls.

qcc_parse_release() parses a cause IE, setting the cause value. A listing of the possible values can be found in the <atm/qcc.h> header file. The same is true for qcc_parse_release_complete.

qcc_parse_status_enquiry() parses a status enquiry message containing an endpoint reference IE, setting the value of endpt_ref. The endpoint reference IE is only included when enquiring about a party state in a point-to-multipoint call.

qcc_parse_status() parses a status message. The IEs that are parsed are call state, cause, endpoint reference, and endpoint state. The call state and cause IEs are used to set the values of the parameters callstate and cause; possible values for both parameters may be found in the <atm/qcc.h> header file. The endpoint reference and endpoint state IEs will be used to set the values of the endpt_ref and endpt_state parameters; they are included if an enquiry is made about a party state in a point-to-multipoint call or to report an error condition in a point-to-multipoint call.

qcc_parse_notify() parses a notify message, which is only supported under UNI 4.0. The notification indicator and endpoint reference IEs are parsed; from the notification indicator, the contentlenp and contentp parameters are filled in, with the maximum buffer size copied being 16 bytes. If the size contained in the message is greater than 16 bytes (QCC_MAX_NOTIFICATION_LEN, defined in <atm/qcc.h>), the first 16 bytes are copied, contentlenp is set to contain the copied length of 16 bytes, and the overflow flag is set. From the endpoint reference IE, endpt_refp is filled in. The endpoint reference IE is only present on point-to-multipoint calls.

qcc_parse_restart() parses a restart message containing two possible IEs: connection identifier and restart indicator. The restart indicator IE is used to set the value of rstall; this parameter indicates whether a particular vci or all vcis are to be restarted (rstall = 1 implies all vcis, rstall = 0 implies a particular vci). The connection identifier identifies the particular vci. In this case, the value of the parameter vci is set to 0 if there is no connection identifier IE in the message. The same format

CODE EXAMPLE 5-4 qcc_parse(9F) Man Page (Continued)

applies to the `qcc_parse_restart_ack()` function.

`qcc_parse_add_party()` parses an add party message containing several possible IEs. They include AAL parameters, calling party number, called party number, broadband higher layer information, and endpoint reference. The following table matches the data that is retrieved from the message with the IE from which it is parsed.

DATA RETRIEVED	INFORMATION ELEMENT
forward sdu size	AAL parameters
backward sdu size	AAL parameters
source address	calling party number
destination address	called party number
sap	broadband higher layer
endpoint reference id	endpoint reference

`qcc_parse_add_party_ack()` extracts an endpoint reference value from the endpoint reference IE in an add party ack message.

`qcc_parse_party_alerting()` extracts an endpoint reference value from the endpoint reference IE in a party alerting message. This message is specific to UNI 4.0.

`qcc_parse_add_party_reject()` parses an add party reject message possibly containing a cause IE, from which it extracts the cause value, and an endpoint reference IE, from which it extracts the endpoint reference value. Possible cause values may be found in the header file `<atm/qcc.h>`.

`qcc_parse_drop_party()` extracts an endpoint reference value and a cause value from those respective IEs in a drop party message. Possible cause values may be found in the header file `<atm/qcc.h>`. The same parsing applies to `qcc_parse_drop_party_ack()`.

`qcc_parse_leaf_setup_fail()` extracts a cause value (defined in `<atm/qcc.h>`) from the cause IE; a destination address from the called number IE; and a leaf number from the leaf number IE. The leaf setup fail message is specific to UNI 4.0.

`qcc_parse_leaf_setup_req()` parses a leaf setup request message, which is specific to UNI 4.0. The calling number and called number IEs are parsed, yielding the source and desti-

CODE EXAMPLE 5-4 qcc_parse(9F) Man Page (Continued)

nation ATM addresses, respectively; in addition, the leaf initiated join call identifier IE is parsed to obtain the leaf initiated join callid, and the leaf number IE is parsed for the leaf number.

RETURN VALUES

All functions return 0 on success and -1 on error.

EXAMPLES

The following code fragment receives and parses a setup message.

```
#include <sys/stream.h>
#include <atm/qcc.h>
#include <atm/limits.h>

char    _depends_on[] = "drv/qcc";

void
wait_for_setup(queue_t *q);
{
    int            vci;
    int            forward_sdusize;
    int            backward_sdusize;
    int            sap;
    atm_addr_t     src_addr;
    atm_addr_t     dst_addr;
    mblk_t         *mp;
    qcc_hdr_t      *hdrp;

    do {
        if !(mp = getq(q)) {
            perror("getq");
            exit (-1);
        }
        hdrp = (qcc_hdr_t *)mp;
    } while (hdrp->type != QCC_SETUP);

    qcc_parse_setup(mp->b_cont, &vci, &forward_sdusize,
                   &backward_sdusize, &src_addr,
                   &dst_addr, &sap, NULL);
    printf("parse_setup: vci = 0x%x, sap = 0x%x0, vci, sap);
}

```

SEE ALSO

qcc_util(3), qcc_bld(9F), q93b(7)

CODE EXAMPLE 5-4 qcc_parse(9F) Man Page (Continued)

```
"ATM User-Network Interface Specification, V3.0," ATM Forum.  
"ATM User-Network Interface Specification, V3.1," ATM Forum.  
"ATM User-Network Interface Specification, V4.0," ATM Forum.
```

NOTES

This API is an interim solution until the ATM Forum has standardized an API. At that time, Sun will implement that API, and support for the Q.2931 Call Control library may not be continued.

The additional support of the UNI 4.0 signalling specification includes the addition of several new message types which are not supported in the earlier versions of the UNI specification. These message types, if received on an interface configured for UNI 3.0 or 3.1, will be discarded by the q93b driver and will not be sent up to the user applications. The UNI 4.0-specific messages are Alerting, Notify, Party Alerting, Leaf Setup Fail, and Leaf Setup Req, and are identified in the applicable function descriptions.

qcc_set_ie(9F)

CODE EXAMPLE 5-5 qcc_set_ie(9F) Man Page

qcc_set_ie(9F) Kernel Functions for Drivers qcc_set_ie(9F)

NAME

qcc_set_ie - add or update Information Elements in a Q.2931 message structure

SYNOPSIS

```
cc -DKERNEL -D_KERNEL [ flag ... ] file ...
```

```
#include <atm/qcc.h>
#include <atm/qcctypes.h>
```

```
char _depends_on[] = "drv/qcc";
```

```
int qcc_set_ie(qcc_msg_t *msgp, qcc_ie_t *iep);
```

MT-LEVEL

Safe.

AVAILABILITY

The functionality described in this man page is available in the SUNWatma package included with the SunATM adapter board. The `-DKERNEL` and `-D_KERNEL` flags must be included to indicate that the application should run in kernel space, and the qcc driver must be loaded (this requirement is expressed in the code using the "depends_on" line shown in the synopsis).

DESCRIPTION

This function adds a new or changes an existing Information Element in Q.2931 messages. The Q.2931 protocol is used for ATM signalling. A full description of the message format and use can be found in the ATM Forum's User Network Interface Specification, V3.0 or V3.1. The function may be used by processes which are running in kernel space.

A message structure should first be created using the appropriate `qcc_create(9F)` function call. IEs may then be

CODE EXAMPLE 5-5 qcc_set_ie(9F) Man Page (Continued)

added or changed using `qcc_set_ie`. When the message structure has been completely specified, the corresponding `qcc_pack(9F)` function should be called to translate the message structure into the correct encoded format, contained in `mblk_t` structures which may be passed to the `putq(9F)` function.

In general, no error checking is performed on the data that is passed in. Whatever data is passed in will be placed in the message that is built without examination. The user should insure that the values passed in in the IE structure conform with the UNI version (3.0 or 3.1) that is running.

The function requires 2 parameters: `msgp`, which is a pointer to the appropriate message structure; and `iep`, which is a pointer to the new IE structure. The message and IE structure types are defined in the `<atm/qcctypes.h>` header file.

The structure to which `msgp` points must be allocated by the calling user. The structure pointed to by `iep` should have the desired values filled in to its fields, and the "valid" field should be set to 1. A value of 0 in the "valid" field indicates that the IE should not be included in the message.

The fields of each Information Element structure and their interpretations are described in the following paragraphs. Possible values for IE fields are defined in the `<atm/qccdefs.h>` header file.

`qcc_aal_params_t`

Currently, the only ATM Adaptation Layer supported on SunATM products is AAL 5. However, to allow for future changes, the aal parameters ie type consists of a field identifying the aal and a union of structures for each aal, called "info." The aal 5 structure contains 4 fields: `forward_max` and `backward_max` for the SDU sizes, `mode`, and `sscs_type`. The `sscs_type` is only valid in UNI 3.0; therefore, a value of 0 for `sscs_type` indicates that that field should not be included.

`qcc_traffic_desc_t`

The ATM Traffic Descriptor IE (called User Cell Rate in UNI 3.0) contains a large set of traffic parameter values. Two parameters do not have numeric values associated; they are either included or not. The are

CODE EXAMPLE 5-5 qcc_set_ie(9F) Man Page (Continued)

represented by two fields, `best_effort` and `tagging`, that are either set to 1 if the parameter is to be included or set to 0 if it is not. The remaining parameters all have numeric values associated with them. Since 0 is a valid value for these parameters, an additional field, `params`, is included in the IE structure which indicates which of these should be included in the message. Each parameter has a corresponding bit in the `params` field, which, when set, indicates that the parameter should be included. Flags are defined for this field in the `<atm/qcdefs.h>` header file.

`qcc_bbc_t`

The Broadband Bearer Capability IE fields correspond directly to the options for this IE. The fields are:

<code>class</code>	Bearer Class
<code>type</code>	Traffic Type
<code>timing</code>	Timing Requirements
<code>clipping</code>	Susceptibility to Clipping
<code>userplane</code>	User plane connection configuration

`qcc_bhli_t`

The Broadband High Layer Information IE structure contains 3 fields which specify the IE contents. They are `type`, which identifies the High Layer Information Type; `infolen`, which indicates the number of octets of high layer information is to be included in the message (the maximum is 8 octets), and finally an array of bytes called `info` which contains the information octets, called `info`. The octets should be placed in the first `infolen` elements of the array.

`qcc_blli_t`

The Broadband Low Layer Information IE contains 2 fields to specify the IE contents. The first, `layer`, is an integer which specifies which layer protocol is being specified, layer 1, 2, or 3. The second is a union, with unique structures for layer 2 and layer 3. For both layer 2 and layer 3 IEs, the protocol value will be examined and the correct coding format will be used for that protocol. Therefore, only the applicable fields from the layer structure will be used for the specified protocol type.

CODE EXAMPLE 5-5 qcc_set_ie(9F) Man Page (Continued)

Layer 2 fields:

protocol	User information layer 2 protocol
mode	Mode of operation
window size	Window size (k)
userspec	User specified layer 2 protocol information

Layer 3 fields:

protocol	User information layer 3 protocol
mode	Mode of operation
pktsize	Default packet size
window size	Packet window size
userspec	User specified layer 3 protocol information
ipi	8-bit Initial Protocol Identifier for ISO/IEC TR 9577
oui	24-bit organization unique identifier for ISO/IEC TR 9577 and IEEE 802.1 SNAP
pid	16-bit protocol identifier for ISO/IEC TR 9577 and IEEE 802.1 SNAP

qcc_call_state_t

There is only one informational field in the Call State IE structure: state, specifying the call state.

qcc_called_num_t

The Called Party Number IE structure contains a planid field, which specifies the Addressing/Numbering Plan Identification. The Type of Number is based on this value as well. There is also an address field, to specify a 20-byte address.

qcc_called_subaddr_t

The Called Party Subaddress IE structure contains a type field, which specifies the Type of Subaddress, and a 20-byte address field.

qcc_calling_num_t

In addition to the 20-byte address field, the Calling Party Number IE structure contains several fields to describe the intended interpretation of the address. They are:

planid	Addressing/Numbering Plan
--------	---------------------------

CODE EXAMPLE 5-5 qcc_set_ie(9F) Man Page (Continued)

	Identification
presentation	Presentation indicator
screening	Screening indicator

qcc_calling_subaddr_t

The structure for the Calling Party Subaddress IE is identical to that of the Called Party Subaddress IE.

qcc_cause_t

The Cause IE structure contains a location field and a cause field. In addition, it contains an array of 28 octets, *diag*, for diagnostic information. The number of diagnostic octets included in the array should be specified in the *diaglen* field.

qcc_conn_id_t

The Connection Identifier IE structure contains a *vpci* and a *vci* field. Note that currently, the SunATM software only supports *vpci* 0, although any value may be placed in the *vpci* field and will be encoded into the message.

qcc_qos_t

The Quality of Service IE has 3 informational fields: *codingstd*, specifying the Coding Standard value; and *forward_class* and *backward_class*, specifying the Forward and Backward QoS Class.

qcc_restart_ind_t

There is only one informational field in the Restart Indicator IE structure: *class*, which specifies the class of the facility to be restarted.

qcc_transit_t

The Transit Network Selection IE structure contains an array of up to four octets to specify the Carrier Identification Code value.

qcc_endpt_ref_t

The Endpoint Reference IE structure contains an *endptref* field, which specifies the endpoint reference value.

qcc_endpt_state_t

The Endpoint State IE structure contains a *state* field, which identifies the endpoint state value.

CODE EXAMPLE 5-5 `qcc_set_ie(9F)` Man Page (Continued)

RETURN VALUES

The function returns 0 on success and -1 on error.

EXAMPLES

See the Example section of the `qcc_create(9F)` man page for an example using `qcc_set_ie`.

SEE ALSO

`qcc_util(3)`, `qcc_create(9F)`, `qcc_pack(9F)`, `qcc_unpack(9F)`,
`qcc_parse(9F)`, `q93b(7)`

"ATM User-Network Interface Specification, V3.0," ATM Forum.

NOTES

This API is an interim solution until the ATM Forum has standardized an API. At that time, Sun will implement that API, and support for the Q.2931 Call Control library may not be continued.

qcc_unpack(9F)

CODE EXAMPLE 5-6 qcc_unpack(9F) Man Page

qcc_unpack(9F) Kernel Functions for Drivers qcc_unpack(9F)

NAME

qcc_unpack, qcc_unpack_setup, qcc_unpack_alerting,
qcc_unpack_call_proceeding, qcc_unpack_connect,
qcc_unpack_connect_ack, qcc_unpack_release,
qcc_unpack_release_complete, qcc_unpack_status,
qcc_unpack_status_enq, qcc_unpack_notify,
qcc_unpack_restart, qcc_unpack_restart_ack,
qcc_unpack_add_party, qcc_unpack_add_party_ack,
qcc_unpack_party_alerting, qcc_unpack_add_party_reject,
qcc_unpack_drop_party, qcc_unpack_drop_party_ack,
qcc_unpack_leaf_setup_fail, qcc_unpack_leaf_setup_req -
decode Q.2931 messages and unpack into message structures

SYNOPSIS

```
cc -DKERNEL -D_KERNEL [ flag ... ] file ...
```

```
#include <atm/types.h>
```

```
#include <atm/qcc.h>
```

```
char _depends_on[] = "drv/qcc";
```

```
int qcc_unpack_setup(qcc_setup_t *msgp, mblk_t *ctlp,  
                    mblk_t *datap);
```

```
int qcc_unpack_alerting(qcc_alerting *msgp, mblk_t *ctlp,  
                        mblk_t *datap);
```

```
int qcc_unpack_call_proceeding(qcc_call_proc_t *msgp,  
                                mblk_t *ctlp, mblk_t *datap);
```

```
int qcc_unpack_connect(qcc_connect_t *msgp, mblk_t *ctlp,  
                        mblk_t *datap);
```

```
int qcc_unpack_connect_ack(qcc_connect_ack_t *msgp,  
                            mblk_t *ctlp, mblk_t *datap);
```

CODE EXAMPLE 5-6 qcc_unpack(9F) Man Page (Continued)

```
int qcc_unpack_release(qcc_release_t *msgp, mblk_t *ctlp,
    mblk_t *datap);

int qcc_unpack_release_complete(qcc_release_complete_t *
    msgp, mblk_t *ctlp, mblk_t *datap);

int qcc_unpack_status_enq(qcc_status_enq_t *msgp,
    mblk_t *ctlp, mblk_t *datap);

int qcc_unpack_status(qcc_status_t *msgp, mblk_t *ctlp,
    mblk_t *datap);

int qcc_unpack_notify(qcc_notify_t *msgp, mblk_t *ctlp,
    mblk_t *datap);

int qcc_unpack_restart(qcc_restart_t *msgp, mblk_t *ctlp,
    mblk_t *datap);

int qcc_unpack_restart_ack(qcc_restart_ack_t *msgp,
    mblk_t *ctlp, mblk_t *datap);

int qcc_unpack_add_party(qcc_add_party_t *msgp,
    mblk_t *ctlp, mblk_t *datap);

int qcc_unpack_add_party_ack(qcc_add_party_ack_t *msgp,
    mblk_t *ctlp, mblk_t *datap);

int qcc_unpack_party_alerting(qcc_party_alerting_t *msgp,
    mblk_t *ctlp, mblk_t *datap);

int qcc_unpack_add_party_reject(qcc_add_party_reject_t *
    msgp, mblk_t *ctlp, mblk_t *datap);

int qcc_unpack_drop_party(qcc_drop_party_t *msgp,
    mblk_t *ctlp, mblk_t *datap);

int qcc_unpack_drop_party_ack(qcc_drop_party_ack_t *msgp,
    mblk_t *ctlp, mblk_t *datap);

int qcc_unpack_leaf_setup_fail(qcc_leaf_setup_fail_t *msgp,
    mblk_t *ctlp, mblk_t *datap);

int qcc_unpack_leaf_setup_req(qcc_leaf_setup_req_t *msgp,
    mblk_t *ctlp, mblk_t *datap);
```

MT-LEVEL

Safe.

AVAILABILITY

The functionality described in this man page is available in the SUNWatma package included with the SunATM adapter board.

DESCRIPTION


These functions take streams buffers containing encoded Q.2931 messages as input and decode the information, placing the extracted values into the appropriate message structure. The Q.2931 protocol is used for ATM signalling; a full description of the message format and use can be found in the ATM Forum's User Network Interface Specification, V3.0, V3.1, or V4.0. Messages conforming to both versions of the UNI standard will be decoded. The functions may be used by processes which are running in kernel space.

In general, no error checking is performed on the data that is extracted from the message. Whatever data is found will be placed in the message structure without examination.

Each function requires 3 parameters: msgp, which is a pointer to the appropriate message structure; and ctlp and datap, which are pointers to mblk_t structures.

Information extracted from the message is filled into the message structure pointed to by msgp. The user should allocate this structure before calling the qcc_unpack function.

The ctlp and datap mblk_t pointers should be extracted from the following structure:



Header information is contained in the M_PROTO mblk, and the q93b message which is parsed is contained in the M_DATA block. When a message is received from the q93b driver using the getq(9F) function, a pointer to the M_PROTO block shown

CODE EXAMPLE 5-6 qcc_unpack(9F) Man Page (Continued)

above is returned. If that pointer is called `mp`, the pointer to the `M_DATA` `mblk` will be `mp->b_cont`. The `M_PROTO` block data may be examined to determine the message type, which indicates the parsing function that should be called.

RETURN VALUES

All functions return 0 on success and -1 on error. The returned message structure contains an entry for each possible Information Element for that message type; if an Information Element is found in the received message, the "valid" field for that IE will be set to 1. If the IE was not found, the "valid" field will be 0.

EXAMPLES

The following code fragment receives a setup message and prints elements in the message structure.

```
#include <sys/stream.h>
#include <atm/types.h>
#include <atm/qcc.h>
#include <atm/limits.h>

char    _depends_on[] = "drv/qcc";

void
wait_for_setup(queue_t *q);
{
    int            vci = -1;
    int            sap = -1;
    mblk_t         *mp;
    qcc_hdr_t      *hdrp;
    qcc_setup_t    setup;

    do {
        if ((mp = getq(q)) == NULL) {
            perror("getq");
            exit (-1);
        }
        hdrp = (qcc_hdr_t *)mp;
    } while (hdrp->type != QCC_SETUP);

    if ((qcc_unpack_setup(&setup, mp, mp->b_cont)) < 0) {
        printf("unpack_setup failed\n");
        exit (-1);
    }
    if (setup.conn_id.valid)
```

CODE EXAMPLE 5-6 qcc_unpack(9F) Man Page (Continued)

```
        vci = setup.conn_id.vci;
    if (setup.bhli.valid)
        memcpy((caddr_t) &sap,
            (caddr_t) setup.bhli.info, 4);

    printf("parse_setup: vci=0x%x, sap=0x%x\n",
        vci, sap);
}
```

SEE ALSO

qcc_util(3), qcc_create(9F), qcc_set_ie(9F), qcc_pack(9F),
q93b(7)

"ATM User-Network Interface Specification, V3.0," ATM Forum.
"ATM User-Network Interface Specification, V3.1," ATM Forum.
"ATM User-Network Interface Specification, V4.0," ATM Forum.

NOTES

This API is an interim solution until the ATM Forum has standardized an API. At that time, Sun will implement that API, and support for the Q.2931 Call Control library may not be continued.

The additional support of the UNI 4.0 signalling specification includes the addition of several new message types which are not supported in the earlier versions of the UNI specification. These message types will be ignored by the q93b driver if used on an interface which is configured for UNI 3.0 or 3.1. The UNI 4.0-specific messages are Alerting, Notify, Party Alerting, Leaf Setup Fail, and Leaf Setup Request.

Maintenance Commands

The man pages in this section describe the SunATM commands that are used chiefly for system maintenance and administration purposes.

TABLE 6-1 Maintenance Command Man Pages

Man Page	Description	Page Number
<code>aarsetup(1M)</code>	ATM Address Resolution Table setup program	page 168
<code>aarstat(1M)</code>	Display Classical IP ATM address resolver status	page 171
<code>atmadmin(1M)</code>	ATM configuration program	page 173
<code>atmarp(1M)</code>	ATM to IP address resolution	page 178
<code>atmgetmac(1M)</code>	Get the MAC address assigned to an ATM interface	page 180
<code>atmreg(1M)</code>	ATM address registration	page 181
<code>atmsetup(1M)</code>	Configure an ATM device	page 183
<code>atmsnmpd(1M)</code>	ATM SNMP agent daemon	page 185
<code>atmsnoop(1M)</code>	Capture and inspect ATM network packets	page 188
<code>atmspeed(1M)</code>	Get and set the total link bandwidth of an ATM device	page 192
<code>atmstat(1M)</code>	Display ATM network interface information	page 194
<code>ilmid(1M)</code>	ATM Address Registration daemon	page 202
<code>lanearp(1M)</code>	MAC to ATM address resolution	page 205
<code>lanesetup(1M)</code>	LAN Emulation setup program	page 208
<code>lanestat(1M)</code>	Display status of LAN Emulation over ATM	page 210
<code>qccstat(1M)</code>	Display Q.2931 call control information	page 214

aarsetup(1M)

CODE EXAMPLE 6-1 aarsetup(1M) Man Page

aarsetup(1M) Maintenance Commands aarsetup(1M)

NAME

aarsetup - ATM Address Resolution Table setup program

SYNOPSIS

```
/etc/opt/SUNWatm/bin/aarsetup [ -nkpV ] [ filename ]
```

AVAILABILITY

SUNWatm

DESCRIPTION

The aarsetup program reads a local ATM to IP address resolution table from the /etc/aarconfig file and loads the information into the kernel. In addition, aarsetup will determine whether it is executing on the client or the server and will configure the Classical IP kernel modules appropriately.

If an ATM ARP server exists on a subnet, the configuration file on clients need only contain the system's local information and the server information. If an ATM ARP server is not being used, each system's configuration file must contain IP/ATM address resolution information for every host which it needs to contact. See the aarconfig(4) man page for details on the format of the configuration file.

By default, the /etc/aarconfig file is read and downloaded into the local kernel table on startup. If the configuration file is modified later, aarsetup must be rerun to load the new information into the kernel.

OPTIONS

-n Only parse the configuration table. Using this option, the syntax and information in the table can be checked to verify that it is acceptable to the aarsetup program without actually attempting to download any data. Physical interface informa-

CODE EXAMPLE 6-1 aarsetup(1M) Man Page (Continued)

tion entered in the table is compared with known configured interfaces; IP addresses must be on the correct subnet for the corresponding physical interface in an entry. In order to do this checking, the physical interface must be configured. The -k option will omit the network checks. Error messages will be printed if any problems are encountered.

- k Only parse the configuration table, but do not check configured interfaces. Using this option, only the syntax of the configuration is checked; no verification of IP address information is performed. This enables a check of the configuration file before the physical interfaces have been configured.
 - p Prints to the standard output the table entries from the configuration file, with all variable expressions expanded. Does not download any information into the kernel.
 - v Verbose mode. Additional information is printed.
- filename A filename may be specified to download a configuration file other than /etc/aarconfig. Standard input, indicated with a hyphen '-', is a legal value for filename if the -n option is being used.

FILES

/etc/aarconfig ATM to IP address registration configuration file. Contains entries which specify ATM and IP address pairs for systems.

SEE ALSO

aarconfig(4)

M. Laubach, RFC 1577: Classical IP and ARP over ATM, Network Working Group.

NOTES

In this context, "server" and "client" refer to an ATM ARP server and nodes on the subnet which it serves, respectively.

CODE EXAMPLE 6-1 aarsetup(1M) Man Page (*Continued*)

```
aarsetup SHOULD NOT be put into the background (i.e. run
with the command 'aarsetup &'). When executed, aarsetup will
first perform some essential first steps, then put itself
into the background without user intervention.
```

aarstat(1M)

CODE EXAMPLE 6-2 aarstat(1M) Man Page

```
aarstat(1M)           Maintenance Commands           aarstat(1M)
```

NAME

aarstat - display Classical IP ATM address resolver status

SYNOPSIS

```
/etc/opt/SUNWatm/bin/aarstat interface
```

```
/etc/opt/SUNWatm/bin/aarstat -a
```

AVAILABILITY

SUNWatm

DESCRIPTION

aarstat displays information about the state of the Classical IP protocol on an ATM interface. The information provided may be used to debug configuration problems, or to verify successful bring-up of a Classical IP interface.

The only parameter is the physical interface, which will be of the form baN, where N is the instance number. Optionally, the -a flag may be used to request information for all interfaces.

The following fields will be displayed for all Classical IP interfaces:

setup_state	The state of the Classical IP setup program, aarsetup. The possible values are setup-not-run, which means that aarsetup has not been run successfully for this interface; setup-started, which means that aarsetup is currently running; setup-finished, which means that aarsetup has successfully completed; and interface-defunct, which means that the interface has been partially unconfigured by removing its entries from the configuration files and re-running aarconfig.
-------------	---

CODE EXAMPLE 6-2 aarstat(1M) Man Page (Continued)

Interfaces whose state is interface-defunct will be removed from the kernel on reboot, assuming that the configuration files are not changed.

arpcsmode The mode in which the Classical IP software is running. The possible values are stand-alone, server-being-modified, server, client-being-modified, and client. The first, stand-alone, indicates that the system is running as an ATM ARP client with no ATM ARP server configured. server-being-modified and client-being-modified indicate that aarsetup is currently running on the system; the configuration is not complete. Finally, server and client indicate that the system is an ATM ARP server or client, respectively.

interface_state The state of the interface. The possible values are up and down.

The following additional fields will be printed on systems running as ATM ARP clients:

server_state The state of the connection to the ATM ARP server. The possible values for this field are no-connection, connecting, connected, and closing-connection, referring to phases of Q.2931 call control. When an interface is up and running Classical IP, the server state should be connected.

server_vci This field will indicate the vci for the outgoing connection to the ATM ARP server.

configured_server_addr The atm address of the ATM ARP server.

SEE ALSO

aarsetup(1M), aarconfig(4)

atmadmin(1M)

CODE EXAMPLE 6-3 atmadmin(1M) Man Page

atmadmin(1M) Maintenance Commands atmadmin(1M)

NAME

atmadmin - ATM configuration program

SYNOPSIS

/etc/opt/SUNWatm/bin/atmadmin [basedir]

AVAILABILITY

SUNWatm

DESCRIPTION

The ATM configuration program, atmadmin, is an interactive command-line interface. The program contains a hierarchy of menus, which divide the configuration into six main parameter groups: System, Physical Layer, Signalling, ILMI, Classical IP and LAN Emulation. All but the System parameter group are specific to individual SunATM interfaces, so you must configure the parameters in that group separately for each interface. If you prefer, you may enter and change the SunATM configuration information by editing the SunATM configuration files directly.

By default, atmadmin looks for configuration files in the /etc directory. If they are not there, the alternate path may be specified as basedir. This may be desirable if you wish to create test files, but do not want to overwrite the existing files in /etc.

COMMON NAVIGATION COMMANDS

Some basic commands are recognized throughout the menu hierarchy, and they may be used to navigate through the various menus. These commands are:

m Return to the atmadmin main menu.

p Return to the previous menu.

CODE EXAMPLE 6-3 atmadmin(1M) Man Page (Continued)

- x Exit atmadmin.

- ? Provide more information about the options on this menu.

PARAMETER GROUPS

The atmadmin configuration program contains a series of menus where you can input or alter the configuration of specific SunATM software parameters. These menus, or parameter groups, are:

System Parameter Group

The system parameter group contains parameters that are not interface-specific, but apply to the entire system. This group contains only the SNMP Agent Status parameter.

Parameters	Possible Values	Default Values	Required?
SNMP Agent Status	agent/not_agent	not_agent	Yes
SNMP Agent UDP port	0 <= n <= 6535	161 or 1000	For SNMP Agent

Physical Layer Parameter Group

The physical layer parameter group contains only the framing interface parameter.

Parameters	Possible Values	Default Values	Required?
Framing Interface	SONET/SDH	SONET	Yes

Signalling Parameters

The signalling parameter group contains only the UNI version parameter.

Parameters	Possible Values	Default Values	Required?
UNI Version	3.0/3.1/4.0/none	No default	Yes

ILMI Parameters

CODE EXAMPLE 6-3 atmadmin(1M) Man Page (Continued)

If your ATM switch does not support Interim Local Management Interface (ILMI), you can turn off the ILMI registration on your SunATM interface from the ILMI configuration menu.

Parameters	Possible Values	Default Values	Required?
Use ILMI	Yes/No	Yes	Yes

Classical IP Parameter Group

Several parameters define the Classical IP (CIP) configuration of a SunATM interface, and all of these parameters can be configured through the Classical IP parameter group menu.

Parameters	Possible Values	Default Values	Required?
IP hostname/ address	Valid IP hostname and address	No default	For CIP
Interface Type	Client/Server/ Standalone	No default	For CIP
Local ATM address	Valid ATM address	\$myaddress	For CIP
ARP Server	ATM address	\$localswitch_ server	For CIP clients
PVC	32 <= n < 1024	32	For CIP standalones
Destination IP hostname/address	Valid IP hostname and address	No default	For CIP standalones

LAN Emulation Parameter Group

After choosing to configure LAN Emulation (LANE) parameters, you will be asked to choose an existing (previously configured) LAN Emulation instance, or to create a new one in the LAN Emulation Instance menu.

CODE EXAMPLE 6-3 atmadmin(1M) Man Page (Continued)

Parameters	Possible Values	Default Values	Required?
Instance Number	0 <= n <= 999	No default	For LANE

Per-Instance LAN Emulation Parameters

This menu allows you to configure the per-instance LAN Emulation parameters.

Parameters	Possible Values	Default Values	Required?
IP hostname/ address	Valid IP hostname and address	No default	For IP over LANE
Local ATM address	Valid ATM address	\$myaddress	For LANE
LECS Indicator	no_lecs/ lecs_present	lecs_present	For LANE
LECS ATM address	Valid ATM address	A well-known address	For LANE, lecs_present
LES ATM address	Valid ATM address	No default	For LANE, no_lecs
Emulated LAN Name	Character string	No default	For additional instance on a physical interface
Additional IP addresses	Yes/No	No	For LANE

Per-Additional IP address

With this menu you can configure logical interfaces in the SunATM LAN Emulation environment. Logical interfaces allow you to assign multiple IP addresses to a single LAN Emulation interface. The SunATM software will associate each logical interface with a unique IP hostname and address. All logical interfaces on a given physical interface will be associated with the same ATM and MAC addresses.

CODE EXAMPLE 6-3 atmadmin(1M) Man Page (Continued)

Parameters	Possible Values	Default Values	Required?
Minor Instance Number	0 <= n <= 255	None	For LANE, additional IP
IP hostname/ address	Valid IP hostname and address	No default	For LANE, additional IP

SEE ALSO

aarconfig(4), aarsetup(1M), atmconfig(4), atmsetup(1M),
laneconfig(4), lanesetup(1M),

atmarp(1M)

CODE EXAMPLE 6-4 atmarp(1M) Man Page

atmarp(1M) Maintenance Commands atmarp(1M)

NAME

atmarp - ATM to IP address resolution

SYNOPSIS

```
/etc/opt/SUNWatm/bin/atmarp interface
```

```
/etc/opt/SUNWatm/bin/atmarp interface [ IP hostname | IP  
address ]
```

```
/etc/opt/SUNWatm/bin/atmarp interface - [ ATM address ]  
/etc/opt/SUNWatm/bin/atmarp -a
```

AVAILABILITY

SUNWatm

DESCRIPTION

The atmarp program may be used to display ATM and IP address pairs for a given ATM interface. The required parameter interface is a string of the form name unit, such as ba0.

If only the interface is provided, as in the first form of the command, atmarp will print the ATM address and IP address for that physical interface, and an entry for each resolved IP address for that interface.

If additional information is provided, it will be used to identify a device on the subnet to which interface is connected, and the corresponding address information will be printed. In the second form, when an IP address (in the standard dot notation) or IP hostname is provided, the ATM address for that node will be printed. In the third form, when an ATM address (in the colon-separated octet format used in /etc/aarconfig) is provided, the corresponding IP address will be printed. Note: in this third form of the command, a hyphen (-) must be included to indicate that an IP hostname/address is not being provided.

CODE EXAMPLE 6-4 atmarp(1M) Man Page (Continued)

The -a option dumps the complete ATM ARP table, listing the ATM and IP address for each physical interface and a listing of the ATM address for each resolved IP address on that interface.

EXAMPLES

```
muskogee# ./atmarp ba0
Local IP addr = 192.168.144.108
ATM addr = 47:00:00:00:00:00:00:00:00:00:00:00:00:CC:BA::08:00:20:82:BD:E1::00
```

ARP Table for interface ba0:

```
-----
IP addr = 192.168.144.108
ATM addr = 47:00:00:00:00:00:00:00:00:00:00:00:00:CC:BA::08:00:20:82:BD:E1::00
-----
```

```
IP addr = 192.168.144.109
ATM addr = 47:00:00:00:00:00:00:00:00:00:00:00:00:CC:BA::08:00:20:84:E3:21::00
-----
```

SEE ALSO

ifconfig(1M), aarconfig(4), ba(7)

atmgetmac(1M)

CODE EXAMPLE 6-5 atmgetmac(1M) Man Page

atmgetmac(1M) Maintenance Commands atmgetmac(1M)

NAME

atmgetmac - get the MAC address assigned to an ATM interface

SYNOPSIS

/etc/opt/SUNWatm/bin/atmgetmac interface [count]

AVAILABILITY

SUNWatm

DESCRIPTION

atmgetmac retrieves MAC addresses of the specified ATM interface (specified in the form "device unit;" an example is ba0). If the board has multiple MAC addresses, only the first one will be returned. The remaining addresses follow sequentially after the first.

OPTIONS

count This flag requests the number of MAC addresses assigned to the interface board. SunATM 2.0 boards have one assigned MAC address, while SunATM 2.1 and 3.0 boards have sixteen assigned MAC addresses.

SEE ALSO

aarconfig(4), laneconfig(4)

atmreg(1M)

CODE EXAMPLE 6-6 atmreg(1M) Man Page

```
atmreg(1M)           Maintenance Commands           atmreg(1M)
```

NAME

atmreg - ATM address registration

SYNOPSIS

```
/etc/opt/SUNWatm/bin/atmreg interface [ -r | -d ]  
atm_address
```

AVAILABILITY

SUNWatm

DESCRIPTION

atmreg communicates with the ILMI daemon, ilmid, which controls notifications to the switch of local address changes. The user may register new addresses, check the status of addresses, or de-register addresses. A list of all registered addresses for an interface is printed in the output of qccstat(1M).

The first parameter is the physical interface name. This should be specified in the form "device unit;" an example is ba0. If neither of the optional flags is specified, the status of atm_address is printed. atm_address may be either 20 or 7 colon-separated hexadecimal octets (2 characters), providing an entire ATM address or simply the local ESI and selector bytes. If only 7 bytes are provided, the default 13-byte prefix assigned by the switch is assumed.

OPTIONS

-r This flag specifies that the given address should be registered on this interface. As soon as the registration request has been sent to the switch, the program will return; therefore, the output of qccstat(1M) or atmreg with no flag should be checked to verify that the address has been successfully registered. The switch will fail an address registration request if the same address has already been registered by a different

CODE EXAMPLE 6-6 atmreg(1M) Man Page (Continued)

host.

- d This flag specifies that the given address should be de-registered on this interface. As is the case with the -r flag, the atmreg program will exit as soon as the request has been sent to the switch, and successful de-registration should be verified with either qccstat(1M) or atmreg.

EXAMPLES

The following example shows three operations: first, the status of an address is checked on an interface, which indicates that the address is not registered. Next, registration of the address is requested. Finally, another status request is sent to verify that the address was successfully registered.

```
muskogee# atmreg ba0 08:00:20:aa:bb:cc:00
ATM address
45:00:00:00:00:00:00:00:0f:00:00:00:00:08:00:20:aa:bb:cc:00
is unknown on ba0.
```

```
muskogee# atmreg ba0 -r 08:00:20:aa:bb:cc:00
Requested registration of ATM address on ba0:
45:00:00:00:00:00:00:00:0f:00:00:00:00:08:00:20:aa:bb:cc:00
```

```
muskogee# atmreg ba0 08:00:20:aa:bb:cc:00
ATM address
45:00:00:00:00:00:00:00:0f:00:00:00:00:08:00:20:aa:bb:cc:00
is registered on ba0.
```

SEE ALSO

ilmid(1M), qccstat(1M)

atmsetup(1M)

CODE EXAMPLE 6-7 atmsetup(1M) Man Page

atmsetup(1M) Maintenance Commands atmsetup(1M)

NAME

atmsetup - configure an ATM device

SYNOPSIS

/etc/opt/SUNWatm/bin/atmsetup config_file

AVAILABILITY

SUNWatm

DESCRIPTION

atmsetup performs ATM configuration, based on the information found in the specified configuration file. In general, the configuration file should be /etc/atmconfig; the specified configuration file must have the same format as /etc/atmconfig.

Configuration of a SunATM device is divided into two phases. The first consists of plumbing all devices, and IP setup (using ifconfig(1M)) for Classical IP interfaces. The second consists of IP setup for LAN Emulation interfaces, and is performed by lanesetup(1M).

atmsetup is called with the appropriate options during the execution of the SunATM startup script, S00sunatm, which runs during system boot. Users should not call it from the command prompt.

RETURN VALUES

On success, atmsetup returns a value indicating the presence of configured Classical IP interfaces: 0 indicates none, 1 indicates Classical IP interfaces are present.

-1 is returned on failure.

SEE ALSO

ifconfig(1M), aarsetup(1M), lanesetup(1M), atmconfig(4)

CODE EXAMPLE 6-7 atmsetup(1M) Man Page (*Continued*)

NOTES

Normally, this command is executed from /etc/rc2.d/S00sunatm. It should not be used from the command prompt.

atmsnmpd(1M)

CODE EXAMPLE 6-8 atmsnmpd(1M) Man Page

```
atmsnmpd(1M)           Maintenance Commands           atmsnmpd(1M)
```

NAME

atmsnmpd - ATM SNMP agent daemon

SYNOPSIS

```
/etc/opt/SUNWatm/bin/atmsnmpd [ -n ] [ -p port ] [ -f port ]  
[ -t port ] [ -c config-file ] [ -T trace-level ]
```

AVAILABILITY

SUNWatm

DESCRIPTION

The ATM SNMP agent daemon, `atmsnmpd`, provides a SNMP (Simple Network Management Protocol) agent which supports the ATM UNI and LAN Emulation Management Information Bases (MIBs) defined in the User Network Interface and LAN Emulation Specifications. This agent provides information to a Network Management System, such as SunNet Manager.

Unless otherwise specified, all SNMP agents use the same port number, so a system can only support a single SNMP agent on a port. If other SNMP agents are installed on your system, `atmsnmpd` must be started with the `-p` and/or `-f` options. Alternatively the other agent may be configured to listen on a UDP port other than the default one. If this is not done, `atmsnmpd` will exit with an error or cause the other agent to fail.

If you choose to configure your system as an ATM SNMP agent when installing the `SUNWatm` package, the software will be configured to automatically start `atmsnmpd` at boot time. Depending on the release of Solaris that you're using, the port on which the `atmsnmpd` will be started differs. Solaris 2.6 and above will include a bundled version of an SNMP agent that will be started by default on port 161. This means that any other agent running on the system will have to listen to another UDP port acting as a subagent. This

CODE EXAMPLE 6-8 atmsnmpd(1M) Man Page (Continued)

port can be configured by using the atmadmin program, and will use a default value of 1000 for a 2.6 release of Solaris and above, and a value of 161 otherwise.

If you choose not to configure your system as an ATM SNMP agent, the software will still start atmsnmpd, but with the -n option (see below). This means that atmsnmpd will not listen for incoming requests on any UDP port, but will respond to requests coming from ilmid(1M).

The default configuration information for the SunATM SNMP agent may be found in the daemon's configuration file, /etc/opt/SUNWatm/snmp/agent.cnf. Any changes to the defaults may be made in this file; atmsnmpd must be restarted for any changes to take effect. In particular, the default community values are public for read and private for write.

OPTIONS

- p port Defines an alternative UDP port on which atmsnmpd listens for incoming requests. The default is UDP port 161 for releases of Solaris prior to 2.6, or 1000 otherwise.

- t port Defines an alternative UDP port on which atmsnmpd sends traps. The default is UDP port 162.

- f port Defines a UDP port on which atmsnmpd forwards unknown incoming requests. If atmsnmpd gets a response back, it will forward it to the requesting SNMP manager. The default action is no forwarding.

- n atmsnmpd will not listen for incoming requests on any UDP port (either the default 161 or the one specified with -p). This option takes precedence over -p and is the option with which atmsnmpd is started if, during installation, it is not started as an SNMP agent. With this option, atmsnmpd is used for SNMP requests coming from ilmid(1M).

- c config-file Defines a configuration file that is read when the agent starts up. If a configuration file is not specified the file /etc/opt/SUNWatm/snmp/agent.cnf is used.

CODE EXAMPLE 6-8 atmsnmpd(1M) Man Page (Continued)

-T trace-level

Sets trace levels. A value of 0 disables all tracing and is the default. Levels 1 through 3 represent increasing levels of trace output. Trace output is sent to the standard output in effect at the time atmsnmpd is started.

FILES

/etc/opt/SUNWatm/snmp/agent.cnf(4)
Contains SunATM SNMP agent configuration information

/etc/opt/SUNWatm/snmp/acl.cfg(4)
Contains entries for the access list control table

/etc/opt/SUNWatm/snmp/context.cfg(4)
Contains entries for the context table

/etc/opt/SUNWatm/snmp/party.cfg(4)
Contains entries for the party table

/etc/opt/SUNWatm/snmp/view.cfg(4)
Contains entries for the view table

SEE ALSO

"ATM User-Network Interface Specification, V3.0, V3.1 or V4.0," ATM Forum.

"LAN Emulation over ATM Specification, V1.0," ATM Forum.

NOTES

atmsnmpd SHOULD NOT be put into the background (i.e. run with the command 'atmsnmpd &'). When executed, atmsnmpd will first perform some essential first steps, then put itself into the background without user intervention.

atmsnoop(1M)

CODE EXAMPLE 6-9 atmsnoop(1M) Man Page

atmsnoop(1M) Maintenance Commands atmsnoop(1M)

NAME

atmsnoop - capture and inspect ATM network packets

SYNOPSIS

```
/etc/opt/SUNWatm/bin/atmsnoop [ -aPDSvVNC ] [ -d device ]
[ -s snaplen ] [ -c maxcount ] [ -i filename ]
[ -o filename ] [ -n filename ] [ -t [ r | a | d ] ]
[ -p first [ , last ] ] [ -I vc [ , vc ] [ - vc ] ]
[ -X vc [ , vc ] [ - vc ] ] [ -x offset [ , length ] ]
[ -q ] [ expression ]
```

AVAILABILITY

SUNWatm

DESCRIPTION

atmsnoop captures packets from an ATM interface and displays their contents. The options and functionality are the same as the generic snoop command, with a few ATM-specific additions. The options that are different from those described in the snoop(1M) man page are described here. For a full description of the basic options, see the snoop(1M) man page.

OPTIONS

-d device Receive packets from the network using the interface specified by device. If no device is specified using the -d flag, atmsnoop will use ba0 by default.

-I vc[,vc][-vc] Only display frames from the specified VC(s). A single VC, a list of VCs (vc,vc,vc), or a range of VCs (vc-vc) may be specified. Note that -I 5 directly contradicts the expression nosig; if both of these options appear in the command line, an error will be printed and

CODE EXAMPLE 6-9 atmsnoop(1M) Man Page (Continued)

atmsnoop exits. The same is true for the combination of `-I 16` and the expression `noilmi`. However, the combination of `-I 5` and the expression `noqsaal` is allowed; this will result in the printing of VC 5 signaling messages only.

`-X vc[,vc][-vc]`

Do not display frames from the specified VC(s). A single VC, a list of VCs (`vc,vc,vc`), or a range of VCs (`vc-vc`) may be specified.

`-q`

When capturing to a file (`-o` option) do not print a running count of the number of packets captured. At high packet rates continuously printing the packet count uses significant CPU time, the `-q` option can improve atmsnoop's capture performance.

`expression`

Select packets either from the network or from a capture file. Only packets for which the expression is true will be selected. If no expression is provided it is assumed to be true.

atmsnoop supports the boolean primitives and operators that are discussed in the `snoop(1M)` man page. In addition, it supports some atm-specific primitives that may also be used in filter expressions. They are:

`nosig`

When used as an argument to atmsnoop, `nosig` filters out of the output all packets sent or received on the signalling VC, VC 5, which is used for signalling and QSAAL packets.

`noqsaal`

QSAAL packets are a subset of those seen on the signalling VC. When `noqsaal` is used as an argument to atmsnoop, it filters out only the QSAAL packets.

`noilmi`

ILMI packets (all VC 16 traffic) will be

CODE EXAMPLE 6-9 atmsnoop(1M) Man Page (Continued)

filtered out if noilmi appears as an argument to atmsnoop.

nolmc

The LLC protocol is used to encapsulate IP packets into ATM; if the primitive nolmc appears as an argument to atmsnoop, all LLC packets will be filtered out of the output. LAN Emulation data frames will be filtered, since they are LLC encapsulated.

nolane

All LAN Emulation frames are filtered out. This includes both LAN Emulation control frames and data sent over LAN Emulation connections.

EXAMPLES

Capture all non-ILMI packets on ba0 and display them as they are received:

```
muskogee# atmsnoop -d ba0 noilmi
Using device ba0 (promiscuous mode)
TX: VC=5
QSAAL: PDU_BGN N(MR)=40 N(UU)=0
```

```
TX: VC=5
QSAAL: PDU_BGN N(MR)=40 N(UU)=0
```

```
TX: VC=5
QSAAL: PDU_BGN N(MR)=40 N(UU)=0
```

```
^Cmuskogee#
```

Capture all non-QSAAL packets on ba0 and save them to a file:

```
muskogee# atmsnoop -d ba0 -o save noqsaal
Using device ba0 (promiscuous mode)
^Cmuskogee#
```

Capture all packets and show the verbose summary output:

```
muskogee# atmsnoop -d ba0 -V
Using device ba0 (promiscuous mode)
TX: VC=5
```

CODE EXAMPLE 6-9 atmsnoop(1M) Man Page (Continued)

```
QSAAL: PDU_POLL N(S)=7 N(PS)=271
```

```
RX: VC=5
```

```
QSAAL: PDU_STAT N(R)=7 N(MR)=22 N(PS)=271
```

```
RX: VC=1005
```

```
LLC Type=0x0800 (IP), size = 160 bytes
```

```
IP D=192.1.1.5 S=192.1.1.8 LEN=148, ID=23478
```

```
UDP D=2049 S=836 LEN=128
```

```
RPC C XID=797246949 PROG=100003 (NFS) VERS=2 PROC=4
```

```
NFS C LOOKUP FH=B609 dir_entry055
```

```
RX: VC=5
```

```
QSAAL: PDU_POLL N(S)=7 N(PS)=270
```

```
TX: VC=5
```

```
QSAAL: PDU_STAT N(R)=7 N(MR)=47 N(PS)=270
```

```
RX: VC=1007
```

```
LLC Type=0x0800 (IP), size = 152 bytes
```

```
IP D=192.1.1.5 S=192.1.1.12 LEN=140, ID=51245
```

```
UDP D=2049 S=946 LEN=120
```

```
RPC C XID=797034130 PROG=100003 (NFS) VERS=2 PROC=6
```

```
NFS C READ FH=79DA at 0 for 8192
```

```
^Cmuskoguee#
```

SEE ALSO

snoop(1M), ilmid(1M), q93b(7)

atmspeed(1M)

CODE EXAMPLE 6-10 atmspeed(1M) Man Page

```
atmspeed(1M)           Maintenance Commands           atmspeed(1M)
```

NAME

atmspeed - get and set the total link bandwidth of an ATM device

SYNOPSIS

```
/etc/opt/SUNWatm/bin/atmspeed interface [ bandwidth ]
```

AVAILABILITY

SUNWatm

DESCRIPTION

atmspeed gets and sets the link bandwidth (wire speed) of an ATM device, providing a mechanism to limit the total bandwidth of the ATM device. If no bandwidth is specified, the current link bandwidth is displayed in Megabits per second. If a bandwidth is specified, the link bandwidth is set to that amount; the total throughput of the link will be limited to the value specified. The specified bandwidth should be an integer number of Megabits per second, and should be less than the maximum bandwidth that may be allocated, which is 135 Mbits/sec in the SunATM-155 products and 534 Mbits/sec in the SunATM-622 products. See the ATM device man pages (ba(7)) for information on the maximum device bandwidth.

EXAMPLES

The following example shows how the bandwidth of an ATM device may be limited for a switch that can only handle 100 Mbits/sec of traffic. After being set, the bandwidth is checked to verify the correct setting.

```
muskogee# atmspeed ba0 100
muskogee# atmspeed ba0
100
muskogee#
```


CODE EXAMPLE 6-10 `atmspeed(1M)` Man Page *(Continued)*

SEE ALSO
ba(7)

atmstat(1M)

CODE EXAMPLE 6-11 atmstat(1M) Man Page

atmstat(1M) Maintenance Commands atmstat(1M)

NAME

atmstat - display ATM network interface information

SYNOPSIS

```
/etc/opt/SUNWatm/bin/atmstat interface [ -d [ -T ] ] [ -t ]  
[ interval ]
```

AVAILABILITY

SUNWatm

DESCRIPTION

atmstat displays statistics for an ATM interface. If only the interface is provided, as shown in the first form of the command, a one-line summary for each VC on the ATM interface is displayed. Information is given regarding the mode which is being used on each VC, the bandwidth group to which each VC is assigned, and the number of incoming and outgoing packets for each VC. The interface parameter should be a string of the form baN, where N is the unit number.

Different output information is provided if one of the flags in the second or third forms is used. These optional flags can be used to display debugging information or bandwidth group information.

OPTIONS

-d Display debugging information. The output consists of error and activity counters from the hardware device.

-T Display timestamp information in addition to the debugging information provided with the -d option. Timestamps are generated by the driver at the time the statistics are copied from its internal data structures. This option is useful to correlate atmstat output with atmsnoop data.

CODE EXAMPLE 6-11 atmstat(1M) Man Page (Continued)

-t Display the bandwidth group table for the interface. The bandwidth group table controls the multiplexing of packets from multiple VCs into the transmit path.

interval Display updated information every interval seconds. The display will continue until interrupted by the user.

EXAMPLES

The following command displays a summary of VC information for ba0 every 5 seconds. Initially, there are three active VCs, the Q.2931 signalling VC 5, the ILMI address registration VC 16, and the Classical IP connection to the arp server VC 32; during the display, a fourth VC is set up for IP traffic, using Classical IP.

```
muskogee# atmstat ba0 5
ba0 VC  sap  aal  bufsize  ipkts  opkts  encap  BWG  BW(Mb/s)
-----
      5  sig  5    9264    492   1233  null   0     0.06
     16  ilmi  5    9264     22     23  null   0     0.06
     32  atmip  5    9264     2     3   llc   4    135.00
```

```
ba0 VC  sap  aal  bufsize  ipkts  opkts  encap  BWG  BW(Mb/s)
-----
      5  sig  5    9264    502   1243  null   0     0.06
     16  ilmi  5    9264     23     24  null   0     0.06
     32  atmip  5    9264     2     3   llc   4    135.00
```

```
ba0 VC  sap  aal  bufsize  ipkts  opkts  encap  BWG  BW(Mb/s)
-----
      5  sig  5    9264    514   1254  null   0     0.06
     16  ilmi  5    9264     23     24  null   0     0.06
     32  atmip  5    9264     4     6   llc   4    135.00
     33  atmip  5    9264     1     1   llc   4    135.00
```

```
^C
muskogee#
```

The fields of atmstat's display are:

VC The Virtual Circuit to which this line of statistics applies. The VC is displayed as a decimal number.

CODE EXAMPLE 6-11 atmstat(1M) Man Page (Continued)

sap The service access point, if any, associated with this VC. If the value is for a non-IP data connection, it is displayed as a hexadecimal number. For IP connections, either atmip or lane is displayed, for Classical IP and LAN Emulation connections, respectively. Utility VCs used by the ATM software are also identified by name, rather than a numerical service access point.

aal The ATM Adaptation Layer used on this VC.

bufsize The buffer size, in bytes, being used.

ipkts The number of incoming packets received on this VC since the VC was established.

opkts The number of outgoing packets sent since the VC was established.

encap The type of encapsulation being used.

BWG Bandwidth group with which this VC is associated.

BW(Mb/s) The total bandwidth (in Mbits per second) which is allocated for the BWG associated with this VC.

The following command displays error and activity counters for the port ba0:

```
muskogee# atmstat ba0 -dT
timestamp 18:27:28.93043
intrs           1697143           inits                    2
ipackets        1817576           opackets                47017
ierrors           107            oerrors                   0
out of rbufs        0            out of tbufs             0
canput fails       107            flow ctls                0
copy receives     1817576           allocb fails             0
too many bytes     0            rx overflows             0
out of txds        0            bad crcs                 0
no receivers       0            err encaps               0
err acks           0            txc overflows            0
rx memnotav       0            rx statenotav            0
rx badcells        0            rx flush count           65
rx dirty count     0            rx targ kicks            0
sbufnum           192            bbufnum                 0
IP disabled VCs    0            rx bogus len             0
```

CODE EXAMPLE 6-11 atmstat(1M) Man Page (Continued)

```
RX PFIFO full          0
```

The fields of the atmstat -d display are:

intrs The number of interrupts generated by the device.

inits The number of times the hardware has been initialized.

ipackets The number of packets which have arrived on any VCI.

opackets The number of packets which have been sent on any VCI.

ierrors The number of input errors.

oerrors The number of output errors.

out of rbufs

The number of times the hardware signalled it had to drop a received packet due to no host memory buffer. This indicates that packets are arriving from the network faster than the driver can process them.

out of tbufs

The number of transmitted packets which were dropped because memory allocation failed. This indicates that the system is running low on memory.

canput fails

The number of received packets which were dropped by the driver because canput() failed. This indicates that packets are arriving from the network faster than software above the driver can process them.

flow ctls The number of transmit packets which were discarded because there was no transmit descriptor available and the software queue was full.

copy receives

CODE EXAMPLE 6-11 atmstat(1M) Man Page (Continued)

The number of received packets which were small enough that the driver copied them into a new mblk rather than sending up the hardware's buffer. It is faster to copy a small packet than allocate a new buffer for the hardware to DVMA to. This is not an error, the counter is for informational purposes.

allocb fails

The number of received packets which were dropped because allocb() failed. This indicates the system is running low on memory.

too many bytes

The number of times the driver started queueing transmit packets because there were already too many bytes given to the hardware. "too many" is defined as 4 Kbytes for every 64 Kbps of requested bandwidth for a particular VCI, and implements a flow control mechanism to keep low bandwidth connections from using too much system memory. This is not an error, the counter is for informational purposes.

rx overflows

The number of times a received packet was dropped because it overflowed the hardware buffer allocated for its reception. This generally indicates that cells are being dropped in the ATM network due to congestion, causing cells from different packets to become concatenated together into a giant packet.

out of txds

The number of times the driver started queueing transmit packets because there were no descriptors available on the hardware ring. This is not an error, the counter is for informational purposes.

bad crcs

The number of times a received packet was dropped because its AAL5 CRC was incorrect. This indicates a problem in the ATM network.

no receivers

The number of times a packet arrived on a VCI for which there was no user. Generally this is a race

CODE EXAMPLE 6-11 atmstat(1M) Man Page (Continued)

condition, the user which allocated that VCI having exited while packets were still in flight through the network.

err encaps

The number of received LLC packets which were dropped because the indicated SAP had no listener.

err acks The number of bus errors which have occurred. The hardware must be reinitialized when this happens. Bus errors can result from excessive electrical noise, and indicate a hardware fault.

txc overflows

The number of times the hardware indicated its transmit completion ring was full. The hardware must be reinitialized when this happens. This indicates that packets are being transmitted way faster than the driver can clean up after them, or that the driver was unable to run for an extended period of time due to higher priority interrupts hogging the CPU.

rx memnotav

The number of times the hardware indicated its receive buffer memory was full. This indicates that packets are arriving from the network faster than the hardware can DMA them to host memory. This can happen sporadically if other devices on the bus consume too much bandwidth for a short period of time.

rx statenotav

The number of times the hardware indicated its receive control memory was full. This indicates that packets are arriving from the network faster than the hardware can process them.

rx badcells

The number of cells which arrived to the hardware destined for a VCI which was not turned on. This often happens with switches configured to use SPANS signalling, which sends cells to VCI 15 looking for a SPANS-capable device.

rx flush count

CODE EXAMPLE 6-11 atmstat(1M) Man Page (Continued)

The number of DMA states loaded into the RX control memory. This is not an error, the counter is for informational purposes.

rx dirty count

The number of DMA states loaded into the RX control memory when there was no clean state available. The hardware has to flush one of the existing states to external RAM. This indicates that the hardware is approaching its limits for the number of simultaneously active VCIs, but is still able to keep up. This is not an error, the counter is for informational purposes.

rx targ kicks

The number of times the driver had to instruct the hardware to move its targeted channels back to their private buffer rings. This indicates that either the incoming traffic load is truly monumental, or that the driver was unable to run for an extended period due to a higher priority interrupt hogging the CPU. This is not an error, the counter is for informational purposes.

sbufnum

The number of buffers available to the hardware on the non-targeted buffer ring. This ring is used for VCIs requesting the small or big buffer size. This is not an error, the counter is for informational purposes.

bbufnum

The number of buffers available to the hardware on the non-IP buffer ring. This ring is used for VCIs requesting the huge buffer size. Buffers for this ring are not allocated by the driver until a user requests the huge buffer ring. This is not an error, the counter is for informational purposes.

IP disabled VCs

The number of packets sent from the IP stream to VCIs the driver thinks are turned off. If the q93b link has recently gone down this is normal (a simple race condition between IP and the driver). A large number of these errors would indicate a signalling problem.

rx bogus len

CODE EXAMPLE 6-11 atmstat(1M) Man Page (Continued)

The number of times a received packet was dropped because its claimed AAL5 length did not match the number of cells received by the hardware. This indicates a problem with some piece of ATM equipment sending cells to the adaptor; in particular misconfigured ATM analyzers can do this.

rx PFIFO full

The number of times a received packet was dropped because the queue used by the software to send them up to higher protocol layers was full. This indicates that there are so many hardware interrupts generated by devices in the system that the software interrupt is never able to run.

SEE ALSO

ifconfig(1M), netstat(1M), ba(7)

ilmid(1M)

CODE EXAMPLE 6-12 ilmid(1M) Man Page

ilmid(1M) Maintenance Commands ilmid(1M)

NAME

ilmid - ATM Address Registration daemon

SYNOPSIS

```
/etc/opt/SUNWatm/bin/ilmid [ -c ] [ -n ] [ -v ] [ -x ]
```

AVAILABILITY

SUNWatm

DESCRIPTION

The ATM Address Registration daemon communicates with the switch to establish the 20-byte ATM address for the end system. It implements ILMI, which is the Interim Local Management Interface specified in the ATM User Network Specification. It uses the Simple Network Management Protocol (SNMP) for communication between an ATM switch and host.

An ATM address is made up of a 13-byte network prefix, a 6-byte end system identifier (esi), and a 1-byte selector. Currently, the selector byte is not used in the SunATM implementation; it will be 00 in most cases. The network prefix is assigned by the switch and will be used by the switch for routing. The esi is the unique identification of the end system. A good choice for this is often the default MAC address for the interface. For all Sun products, the MAC address will begin with the octets 08:00:20.

When the ilmi daemon is executed, it first registers the local MAC address for each interface, obtained from the ATM driver, with the switch. Part of the initial registration process involves obtaining the switch prefix, which ilmid reports to the ATM software. It then waits to receive messages from user programs or the switch, and responds to those accordingly.

Additional addresses may be registered in two different

CODE EXAMPLE 6-12 ilmid(1M) Man Page (Continued)

ways. `aarsetup(1M)` and `lanesetup(1M)` register additional addresses that may appear in `aarconfig(4)` and `laneconfig(4)`, respectively. There is also a user program, `atmreg(1M)`, that may be used to register and de-register addresses, and also check the status of any address.

OPTIONS

- c Clear address table. Normally, when `ilmid` is started, it obtains a list of all addresses that were previously registered from the ATM software, and re-registers all of them. Using the `-c` option instructs `ilmid` instead to only register the default address for each interface, and clear all other addresses from the ATM software address table.
- n No auto registration. By default, `ilmid` automatically registers a local address with the switch, which is made up of the switch prefix, the MAC address assigned to the board (or system if the board does not have its own), and a 0 selector. This option turns off that feature, so that the only addresses registered are those that appear in 'l' entries in `/etc/aarconfig` and/or `/etc/laneconfig`.
- v Verbose mode. Print additional information regarding the communication with the switch.
- x Print (to the console) the messages exchanged between the switch and end system in hexadecimal notation.

SEE ALSO

`atmreg(1M)`, `aarsetup(1M)`, `lanesetup(1M)`, `aarconfig(4)`, `laneconfig(4)`

"ATM User-Network Interface Specification, V3.0," ATM Forum.

"ATM User-Network Interface Specification, V3.1," ATM Forum.

NOTES

`ilmid` SHOULD NOT be put into the background (i.e. run with the command '`ilmid &`'). When executed, `ilmid` will first perform some essential first steps, then put itself into the background without user intervention. An exception is made if `ilmid` is run with debug flags (`-x` and/or `-v`); since those

CODE EXAMPLE 6-12 `ilmid(1M)` Man Page *(Continued)*

```
modes result in continuous output, ilmid will not put itself  
into the background if running with the -x or -v option.
```

lanearp(1M)

CODE EXAMPLE 6-13 lanearp(1M) Man Page

```
lanearp(1M)           Maintenance Commands           lanearp(1M)
```

NAME

lanearp - MAC to ATM address resolution

SYNOPSIS

```
/etc/opt/SUNWatm/bin/lanearp laneN  
  
/etc/opt/SUNWatm/bin/lanearp laneN [ MAC address ]  
  
/etc/opt/SUNWatm/bin/lanearp laneN - [ ATM address ]  
  
/etc/opt/SUNWatm/bin/lanearp -a
```

AVAILABILITY

SUNWatm

DESCRIPTION

The lanearp program may be used to display ATM and MAC address pairs for a given LAN Emulation interface. The required parameter laneN is a LAN Emulation interface name, where N is the LAN Emulation instance number (specified in /etc/atmconfig). An example is lane0.

If only the interface is provided, as in the first form of the command, lanearp will print the ATM address and MAC address for that LAN Emulation interface, and an entry for each resolved IP address for that interface.

If additional information is provided, it will be used to identify a device on the subnet to which the LAN Emulation interface is connected, and the corresponding address information will be printed. In the second form, when a MAC address (in the colon-separated form used in the output of arp) is provided, the ATM address for that node will be printed. In the third form, when an ATM address (in the colon-separated octet format used in /etc/laneconfig) is provided, the corresponding MAC address will be printed.

CODE EXAMPLE 6-13 lanearp(1M) Man Page (Continued)

Note: in this third form of the command, a hyphen (-) must be included to indicate that a MAC address is not being provided.

The -a option dumps the complete LANE ARP table, listing the ATM and IP address for each LAN Emulation interface and a listing of the ATM address for each resolved IP address on that interface.

EXAMPLES

```
sunatml# lanearp -a
LANE Interface lane2:
Local MAC addr = 8:0:20:82:4f:f6
ATM addr = 47:00:00:00:00:00:00:00:00:00:00:c0:01::08:00:20:82:4F:F6::00

LE_ARP table:
-----
MAC addr = 0:e0:f9:c5:58:0
ATM addr = 47:00:00:00:00:00:00:00:00:00:00:cc:00::00:E0:F9:C5:58:00::36
-----
MAC addr = 8:0:20:7e:58:6
ATM addr = 47:00:00:00:00:00:00:00:00:00:00:c0:01::08:00:20:7E:58:06::00
-----
MAC addr = 8:0:20:82:4f:f6
ATM addr = 47:00:00:00:00:00:00:00:00:00:00:c0:01::08:00:20:82:4F:F6::00
-----
MAC addr = ff:ff:ff:ff:ff:ff
ATM addr = 47:00:00:00:00:00:00:00:00:00:00:c0:01::00:60:47:2C:3E:04::36
-----

LANE Interface lane1:
Local MAC addr = 8:0:20:82:4f:f5
ATM addr = 47:00:00:00:00:00:00:00:00:00:00:c0:01::08:00:20:82:4F:F5::00

LE_ARP table:
-----
MAC addr = 0:e0:f9:c5:58:0
ATM addr = 47:00:00:00:00:00:00:00:00:00:00:cc:00::00:E0:F9:C5:58:00::35
-----
MAC addr = 8:0:20:7e:58:5
ATM addr = 47:00:00:00:00:00:00:00:00:00:00:c0:01::08:00:20:7E:58:05::00
-----
MAC addr = 8:0:20:82:4f:f5
ATM addr = 47:00:00:00:00:00:00:00:00:00:00:c0:01::08:00:20:82:4F:F5::00
```

CODE EXAMPLE 6-13 lanearp(1M) Man Page (Continued)

```
-----  
MAC addr = ff:ff:ff:ff:ff:ff  
ATM addr = 47:00:00:00:00:00:00:00:00:00:00:c0:01::00:60:47:2c:3e:04::35  
-----
```

SEE ALSO

```
arp(1M), ifconfig(1M), laneconfig(4),
```

lanesetup(1M)

CODE EXAMPLE 6-14 lanesetup(1M) Man Page

lanesetup(1M) Maintenance Commands lanesetup(1M)

NAME

lanesetup - LAN Emulation setup program

SYNOPSIS

```
/etc/opt/SUNWatm/bin/lanesetup [ -pnvf ] [ -a filename ] [
filename ]
```

AVAILABILITY

SUNWatm

DESCRIPTION

The lanesetup program reads local LAN Emulation configuration information from the /etc/laneconfig file and loads the information into the kernel.

By default, the /etc/laneconfig file is read and downloaded into the local kernel table on startup. If the configuration file is modified later, lanesetup must be rerun to load the new information into the kernel.

OPTIONS

-p Prints to the standard output the table entries from the configuration file, with all variable expressions expanded. Does not download any information into the kernel.

-n Only parse the configuration table. Using this option, the syntax and information in the table can be checked to verify that it is acceptable to the lanesetup program without actually attempting to download any data. Physical interface information entered in the table is compared with known configured interfaces. Error messages will be printed if any problems are encountered.

-v Verbose mode. Additional information is printed.

CODE EXAMPLE 6-14 lanesetup(1M) Man Page (Continued)

`-f` Also do the LAN Emulation interface plumbing. This is only done once, at boot time. The only time this option should be used is when lanesetup is called in the /etc/rc2.d/S00sunatm startup script.

`-a filename` Used in conjunction with the `-f` option, this flag specifies the file from which plumbing information should be read (typically /etc/atmconfig).

`filename` A filename may be specified to download a configuration file other than /etc/laneconfig. Standard input, indicated with a hyphen '-', is a legal value for filename if the `-n` option is being used.

FILES

/etc/laneconfig File that contains configuration information specific to the LAN Emulation interfaces. Read by lanesetup, which downloads the configuration information to the LAN Emulation kernel software.

SEE ALSO

laneconfig(4)

ATM Forum, LAN Emulation Over ATM Specification Version 1.0,
LAN Emulation SWG Drafting Group

NOTES

lanesetup SHOULD NOT be put into the background (i.e. run with the command 'lanesetup &'). When executed, lanesetup will first perform some essential first steps, then put itself into the background without user intervention.

lanestat(1M)

CODE EXAMPLE 6-15 lanestat(1M) Man Page

lanestat(1M) Maintenance Commands lanestat(1M)

NAME

lanestat - display status of LAN Emulation over ATM

SYNOPSIS

/etc/opt/SUNWatm/bin/lanestat lane_interface

/etc/opt/SUNWatm/bin/lanestat -a

AVAILABILITY

SUNWatm

DESCRIPTION

lanestat displays information about the state of the LAN Emulation protocol on an ATM interface. The information provided may be used to debug configuration problems, or to verify successful bring-up of a LAN Emulation interface.

The only parameter is the LAN Emulation interface name, which will be of the form laneN, where N is the instance number. Optionally, the -a flag may be used to request information for all LAN Emulation interfaces.

The following fields will be displayed:

setup_state The state of the LAN Emulation setup program, lanesetup. The possible values are setup-not-run, which means that lanesetup has not been run successfully for this interface; setup-started, which means that lanesetup is currently running; setup-requested-join, which means that a join request has been sent to the LES, but a response has not yet been received; setup-finished, which means that lanesetup has successfully completed; and interface-defunct, which means that the interface has been partially unconfigured by

CODE EXAMPLE 6-15 lanestat(1M) Man Page (Continued)

removing its entries from the configuration files and re-running laneconfig. Interfaces whose state is interface-defunct will be removed from the kernel on reboot, assuming that the configuration files are not changed.

arpcsmode The mode in which the LAN Emulation software is running. The possible values are client-being-modified and client. client-being-modified indicates that lanesetup is currently running on the system; the configuration is not complete; client indicates that the system is a LAN Emulation client.

proto_address The protocol address of this lane instance.

atm_address The ATM address of this lane instance.

lanestate The state of the LAN Emulation client. When a LAN Emulation client interface comes up, it must go through a process called "joining the LAN." The value in this field reflects the current stage in that process. For a description of the steps a client goes through to join a LAN, see section 5.3.1, LAN Emulation Services, in the SunATM 2.1 Manual. For a client that is up and running, the value of this field should be active.

lecConfigSource The source of the LECS address used to configure this lane instance. The possible values are LocalInformation, which means the address is provided in the laneconfig file using the 'c' flag; getAddressViaIlmi, which means the address was provided by the switch via the ILMI daemon; usedWellKnownAddress, which means the well-known LECS address from the ATM Forum UNI standard was used; usedLecsPvc, which means the LECS VCI was provided in /etc/laneconfig using the 'c' flag; and didNotUseLecs, which means the LECS address was provided in /etc/laneconfig using the 's' flag.

driver name The ATM hardware device this lane instance

CODE EXAMPLE 6-15 lanestat(1M) Man Page (Continued)

runs over.

lan_type The type of Emulated LAN. Possible values are unspecified, ethernet(802.3), tokenring(802.5), and <unknown>. Currently, SunATM supports only emulated LANs of type ethernet(802.3).

elan_name The name of the Emulated LAN. Most LAN Emulation Servers will provide this information to the client when the client joins the LAN, but in some cases, such as in the case of multiple Emulated LANs, the user must provide this name in its requests to join. If this is the case in your configuration, see the description of the `n' flag in laneconfig(4).

lecid A number assigned by the LES to uniquely identify this LAN Emulation client.

max_frame_size_code
size A code identifying the maximum SDU size of an Emulated LAN data frame; the actual size corresponding to the code is provided as well. This value is generally determined by the LAN Emulation Configuration Server.

LECS_atm_address The atm address of the LECS for this lane instance.

LES_atm_address The atm address of the LES for this lane instance.

BUS_atm_address The atm address of the BUS for this lane instance.

lecs_vci

les_vci

les_distribute_vci

bus_vci

CODE EXAMPLE 6-15 lanestat(1M) Man Page (Continued)

bus_forward_vci

The VCIs identifying the connections to the three servers providing LAN Emulation services for the emulated LAN. A VCI of 0 indicates that no connection exists. It is normal for the LECS connection to be torn down during the process of joining the emulated LAN.

SEE ALSO

lanesetup(1M), laneconfig(4)

qccstat(1M)

CODE EXAMPLE 6-16 qccstat(1M) Man Page

qccstat(1M) Maintenance Commands qccstat(1M)

NAME

qccstat - display Q.2931 call control information

SYNOPSIS

/etc/opt/SUNWatm/bin/qccstat interface [interval]

AVAILABILITY

SUNWatm

DESCRIPTION

qccstat displays signalling and link layer information for an ATM interface. The information includes the current link state, ATM addresses registered for the interface, and the state of all Q.2931 calls present on the interface.

Without options, qccstat displays several lines of information for the specified interface. The interface parameter is a string of the form baN, where N is the unit number. If interval is given, the information will be updated and printed every interval seconds, repeating until interrupted by the user.

If there are no calls present on the interface, several summary lines are displayed. They include the following information:

linkstate	The DLPI link state, usually either DL_ACTIVE or DL_IDLE.
outcalls	The total number of outgoing calls on this interface.
incalls	The total number of incoming calls.
sig	The signalling version that is plumbed on this interface. Possible values are UNI3.0,

CODE EXAMPLE 6-16 qccstat(1M) Man Page (Continued)

UNI3.1, and UNI4.0.

registered addresses

A list of the addresses that have been registered for this interface with the switch.

If calls are present, three additional lines of information are provided for each call. These lines include the following information:

callref	The call reference for this call.
vci	The virtual circuit identifier, displayed in decimal.
state	The Q.2931 call state.
dir	The direction of the call. If this system initiated the call, the direction is OUTGOING; otherwise, the direction is INCOMING.
sap	The service access point (sap) associated with this call, displayed as a hexadecimal number.
src	The 20-byte source ATM address for the call, in the colon-separated octet format used in the aarconfig(4) file.
dst	The destination ATM address for the call.

EXAMPLES

The following command displays Q.2931 call information for ba0 every 2 seconds. Initially, there are no active calls; during the display, a call is connected. The display is then terminated by the user.

```
muskogee# qccstat ba0 2
ba0: linkstate=DL_ACTIVE outcalls=0 incalls=0 sig=UNI3.0
    registered addresses:
        45:00:00:00:00:00:00:00:0f:00:00:00:00:00:08:00:20:75:a2:77:00

ba0: linkstate=DL_ACTIVE outcalls=0 incalls=0 sig=UNI3.0
    registered addresses:
        45:00:00:00:00:00:00:00:0f:00:00:00:00:00:08:00:20:75:a2:77:00
```

CODE EXAMPLE 6-16 qccstat(1M) Man Page (Continued)

```
ba0: linkstate=DL_ACTIVE outcalls=0 incalls=1 sig=UNI3.0
    registered addresses:
        45:00:00:00:00:00:00:00:0f:00:00:00:00::08:00:20:75:a2:77:00

    incoming calls:
        callref=1 vci=0x20 state=ACTIVE dir=INCOMING sap=0x800
        src=47:00:05:80:ff:e1:00:00:00:f1:24:0e:e8::08:00:20:10:0a:2d:00
        dst=47:00:05:80:ff:e1:00:00:00:f1:24:0e:e8::08:00:20:22:21:b1:00

^Cmuskogee#
```

SEE ALSO

q93b(7), ba(7)

Index

A

allocating bandwidth, 10

API, 1

 allocating bandwidth, 10

 ATM signalling, 2

 atm_util functions, 9

 CBR allocation, 9

 device driver

 connecting, 9

 receiving data, 9

 sending data, 9

 DLPI encapsulated connections, 10

 message formats, 5

 q93b and device drivers, 2

 qcc functions, 6

 raw mode connections, 10

 VBR allocation, 10

Application Programmers Interface

See API

ATM

 M_PROTO mblock fields, 5

 q93b driver, 3

 signalling, 2

 switched virtual circuit, 3

atm_util functions, 9

C

Call_ID message, 5

Call_Tag message, 5

CBR, 9

constant bit rate, 9

D

DLPI encapsulated connections, 10

E

Error_Code message, 5

I

Ifname message, 5

P

permanent virtual circuits, 1

PVC, 1

Q

Q.2931, 1

Q.93B, 1

qcc functions, 6

S

SVC, 1

switched virtual circuits, 1

T

Type message, 5

V

variable bit rate bandwidth, 9

VBR, 10