

Enabling Capacity on Demand (COD) CPU/Memory Boards on Sun Fire™ 15K/12K/6800/4810/4800/3800 Systems

This card describes how the `enablecodboard` system controller command converts a non-COD CPU/Memory board (Uniboard) to a COD CPU/Memory board. This command is for the Sun Fire™ mid-range and high-end systems and is for **Sun™ internal use only**.

TABLE 1 `enablecodboard` Command User, Usage, and Minimum Firmware/Software Versions

User	Shell, Mode, and Minimum Firmware/Software Versions
Sun service engineers	Sun Fire 6800/4810/4800/3800 systems <ul style="list-style-type: none"> Platform shell (password-protected service or manufacturing modes) 5.14.0 firmware release
Sun service engineers	Sun Fire 15K/12K systems <ul style="list-style-type: none"> Superuser/platform service privilege System Management Services (SMS) 1.3 software release

TABLE 2 describes this command and lists the step you must complete before executing this command.

TABLE 2 `enablecodboard` Command Prerequisite and Description

Before Executing This Command	Command Description
<ul style="list-style-type: none"> Power off CPU/Memory board (Uniboard) 	<ul style="list-style-type: none"> Converts a non-COD CPU/Memory board to a COD CPU/Memory board.



Caution – To use the COD CPU board, a COD license is required.

A COD CPU/Memory board cannot be reversed to a non-CPU/Memory board at a customer site. Return the board to the Sun repair depot to reconvert it to non-COD CPU/Memory board.

Syntax

```
enablecodboard [ -y|-n ] board_name [ board_name ... ]
```

```
enablecodboard -h
```

Options/Parameters

TABLE 3 lists and describes the options and parameters.

TABLE 3 Options/Parameters for the enablecodboard Command

Options/Parameters	Description
-h	Displays help for this command. Use the -h option alone. Any option specified in addition to the -h option is ignored.
-y	Automatically answers <i>Yes</i> to all prompts.*
-n	Automatically answers <i>No</i> to all prompts.*
<i>board_name</i>	SB0, SB1, ..., SB17

* This option is accepted in manufacturing mode but *not* in service mode for the Sun Fire 6800/4810/4800/3800 systems. This option is accepted on the Sun Fire 15K/12K system.

Examples

CODE EXAMPLE 1 and CODE EXAMPLE 2 display the enablecodboard syntax and the results returned in converting SB0 and SB1 to COD CPU/Memory boards.

CODE EXAMPLE 1 Converting SB0 to a COD CPU/Memory Board

```
schostname:SC> enablecodboard SB0
WARNING: After conversion, a COD Board requires licenses to be used.
This conversion cannot be reversed.
Do you want to convert SB0 to COD [no]? yes
SB0: converted
```

CODE EXAMPLE 2 Converting SB0 and SB1 to COD CPU/Memory Boards

```
schostname:SC> enablecodboard SB0 SB1
WARNING: After conversion, a COD Board requires licenses to be used.
This conversion cannot be reversed.
Do you want to convert SB0 to COD [no]? yes
SB0: converted
Do you want to convert SB1 to COD [no]? yes
SB1: board is powered on, please turn it off
```

See Also

showboards

Placing the COD Label on the COD CPU/Memory Board

- ◆ Affix the supplied COD label on the ASIC cover in back of the cover for the CPUs (FIGURE 1).

CAPACITY ON DEMAND
RTU License required to enable the
COD CPU resources




FIGURE 1 Sun Fire CPU/Memory Board

Accessing Sun Documentation Online

A broad selection of Sun system documentation and Solaris documentation is located at:

<http://www.sun.com/documentation>

Sun Welcomes Your Comments

Sun is interested in improving its documentation and welcomes your comments and suggestions. You can email your comments to Sun at:

docfeedback@sun.com

Please include the part number 816-6062-10 of the document in the subject line of your email.

Copyright 2002 Sun Microsystems, Inc. All rights reserved. Use is subject to license terms. Third-party software, including font technology, is copyrighted and licensed from Sun suppliers. Portions may be derived from Berkeley BSD systems, licensed from U. of CA. Sun, Sun Microsystems, the Sun logo, Sun Fire, and Solaris are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and in other countries. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. in the U.S. and in other countries. Federal Acquisitions: Commercial Software—Government Users Subject to Standard License Terms and Conditions.

Copyright 2002 Sun Microsystems, Inc. Tous droits réservés. Distribué par des licences qui en restreignent l'utilisation. Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun. Des parties de ce produit pourront être dérivées des systèmes Berkeley BSD licenciés par l'Université de Californie. Sun, Sun Microsystems, le logo Sun, Sun Fire, et Solaris sont des marques de fabrique ou des marques déposées de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays. Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays.



Please
Recycle

Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, CA 95054 U.S.A.
650-960-1300, Fax 650-969-9131

