

CUSTOMER	TITLE	PART NUMBER	DATE
210QF	SYSTEMS, 400 SERIES ENCLOSURES IPB'S	EK-210QF-IP-002	May-92
210QS	SYSTEMS, 400 SERIES ENCLOSURES IPB'S	EK-210QS-IP-002	May-92
220QF	SYSTEMS, 400 SERIES ENCLOSURES IPB'S	EK-220QF-IP-001	May-92
220QH	SYSTEMS, 400 SERIES ENCLOSURES IPB'S	EK-220QH-IP-001	May-92
220QS	SYSTEMS, 400 SERIES ENCLOSURES IPB'S	EK-220QS-IP-001	May-92
670QJ	SYSTEMS IPB'S	EK-438AC-IP-003	May-92
660QH	SYSTEMS IPB'S	EK-439AB-IP-002	May-92
680QJ	SYSTEMS IPB'S	EK-455AA-IP-001	May-92
230ZM	SYSTEMS, 400 SERIES ENCLOSURES IPB'S	EK-5100X-IP-001	May-92
6200	SYSTEMS IPB'S	EK-6200X-IP-001	Jan-91
630QS	SYSTEMS IPB'S	EK-630QS-IP-001	Jan-91
640QR	SYSTEMS IPB'S	EK-640QR-IP-002	Apr-91
640QS	SYSTEMS IPB'S	EK-640QS-IP-002	Apr-91
640QT	SYSTEMS IPB'S	EK-640QT-IP-001	Apr-91
6000-500	SYSTEMS IPB'S	EK-6500X-IP-001	Jan-91
650QF	SYSTEMS IPB'S	EK-650QF-IP-003	Apr-91
650QS	SYSTEMS IPB'S	EK-650QS-IP-003	Apr-91
655QF	SYSTEMS IPB'S	EK-655QF-IP-002	May-92
655QR	SYSTEMS IPB'S	EK-655QR-IP-001	May-92
655QS	SYSTEMS IPB'S	EK-655QS-IP-001	May-92
660QF	SYSTEMS IPB'S	EK-660QF-IP-001	May-92
660QR	SYSTEMS IPB'S	EK-660QR-IP-003	May-92
660QS	SYSTEMS IPB'S	EK-660QS-IP-001	May-92

CUSTOMER	TITLE	PART NUMBER	DATE
8500/30/50	VAX 8500/30/50 IPB	EK-8500X-IP-002	Jul-89
8700/8800	VAX 8700/8800 SYSTEM IPB	EK-8800X-IP-002	Jan-90
8820/30/40	VAX 8820/30/40 IPB	EK-8840A-IP-002	Aug-89
H9644	CABINETS, HA3000 UPS, HSC50 CONTROLLER IPB'S	EK-9644-IP-003	Oct-91
MVAX 3100/VASSERVER 3100	MICROVAX SYSTEMS, PERSONAL COMPUTERS IPB'S	EK-A0372-IP-003	Feb-97
BA213A	EXPANDERS, SYSTEM BOXES AND ENCLOSURES, IPB'S	EK-B213A-IP-003	Jun-95
BA213F	EXPANDERS, SYSTEM BOXES AND ENCLOSURES, IPB'S	EK-B213F-IP-003	Jun-95
BA213	SYSTEM ENCLOSURES, EXPANDERS IPB'S	EK-BA213-IP-004	Jan-93
BA214	SYSTEM ENCLOSURES, EXPANDERS IPB'S	EK-BA214-IP-002	Jan-93
BA215	SYSTEM ENCLOSURES, EXPANDERS IPB'S	EK-BA215-IP-002	Jan-93
BA23-A	SYSTEM ENCLOSURES, EXPANDERS IPB'S	EK-BA23A-IP-001	Jan-93
DECIMAGE 1200	SYSTEM BOX, LASER PRINTERS IPB'S	EK-D1200-IP-001	Jan-93
DECLASER 2100/2200	SYSTEM BOX, LASER PRINTERS IPB'S	EK-D2122-IP-001	Jan-93
DECSYSTEM 5900	LASER PRINTER,DECSYSTEM 5900,NETWORK DEVICES,MODEMS IPB'S	EK-D590A-IP-001	Apr-94
DECCONNECT SYS	DECCONNECT SYSTEM IPB	EK-DECON-IP-003	Nov-93
DEFNCN	LASER PRINTER,DECSYSTEM 5900,NETWORK DEVICES,MODEMS IPB'S	EK-DEFNCN-IP-001	Apr-94
DEFEB	LASER PRINTER,DECSYSTEM 5900,NETWORK DEVICES,MODEMS IPB'S	EK-DEFEB-IP-002	Apr-94
DECLASER 3200/3250	LASER PRINTER,DECSYSTEM 5900,NETWORK DEVICES,MODEMS IPB'S	EK-DL300-IP-001	Apr-94
VAXFT 310 & 410	VAX FAULT TOLERANT SYSTEMS IPB'S	EK-FTV34-IP-001	Nov-93
HA300	CABINETS, HA3000 UPS, HSC50 CONTROLLER IPB'S	EK-HA300-IP-001	Oct-91
LA324	HARDCOPY TERMINALS, PRINTERS IPB'S	EK-LA324-IP-002	Jun-91
TK50-D/R	TAPE DEVICES IPB'S	EK-LEP05-IP-001	Aug-91
LG31	PRINTERS AND KEYBOARDS IPB'S	EK-LG31A-IP-002	Apr-89

CUSTOMER	TITLE	PART NUMBER	DATE
LA75/LA75P	HARDCOPY TERMINALS, PRINTERS IPB'S	EK-OLA75-IP-003	Apr-89
RA90	DISK DRIVES IPB'S	EK-ORA90-IP-001	Feb-89
RV64	DISK DRIVES, RV64 OPTICAL LIBRARY IPB'S	EK-ORV64-IP-001	May-90
RX33	DISK DRIVES, RV64 OPTICAL LIBRARY IPB'S	EK-ORX33-IP-001	May-90
TK50	TAPE DEVICES IPB'S	EK-OTK50-IP-002	Aug-91
R215F	MODULE TESTER, PAPER TAPE, EXPANDER, DISK DRIVES IPB'S	EK-R215F-IP-002	Nov-90
RV20,RV20-P/C,RV60	DISK DRIVES, RV64 OPTICAL LIBRARY IPB'S	EK-RV20P-IP-002	May-90
RX23	DISK DRIVES, RV64 OPTICAL LIBRARY IPB'S	EK-RX23A-IP-001	May-90
RZ22/RZ23	DISK DRIVES, EXP BOX, STORAGE ARRAYS, ET AL IPB'S	EK-RZ223-IP-001	Jan-91
RZ55	DISK DRIVES, EXP BOX, STORAGE ARRAYS, ET AL IPB'S	EK-RZ55E-IP-001	Jan-91
RZ56	DISK DRIVES, EXP BOX, STORAGE ARRAYS, ET AL IPB'S	EK-RZ56X-IP-001	Jan-91
RZ5X	DISK DRIVES, EXP BOX, STORAGE ARRAYS, ET AL IPB'S	EK-RZ5XX-IP-001	Jan-91
RZXX	DISK DRIVES, EXP BOX, STORAGE ARRAYS, ET AL IPB'S	EK-RZXXS-IP-001	Jan-91
SA600	DISK DRIVES, EXP BOX, STORAGE ARRAYS, ET AL IPB'S	EK-SA600-IP-001	Jan-91
SF72	DISK DRIVES, EXP BOX, STORAGE ARRAYS, ET AL IPB'S	EK-SF72X-IP-001	Jan-91
TK70	TAPE DEVICES IPB'S	EK-TK70A-IP-001	Aug-91
TKXXZ	TAPE DEVICES IPB'S	EK-TKXXZ-IP-001	Aug-91
TK50Z	TAPE DEVICES IPB'S	EK-TZ50Z-IP-001	Aug-91
VT1000	VIDEO TERMINALS, VT1000 SYSTEM BOX IPB'S	EK-V1000-IP-001	Mar-90
VXT2000	VIDEO TERMINALS IPB'S	EK-V2000-IP-001	Nov-92
VR201	SYSTEMS, GIGI TERM, MONITORS IPB'S	EK-VR201-IP-004	Feb-92
VR241	SYSTEMS, GIGI TERM, MONITORS IPB'S	EK-VR241-IP-002	Feb-92
VR295	MONITORS, SYSTEMS IPB'S	EK-VR29X-IP-001	Aug-91

CUSTOMER	TITLE	PART NUMBER	DATE
VR315	MONITORS, SYSTEMS IPB'S	EK-VR315-IP-001	Aug-91
VR319/VR320	MONITORS, SYSTEMS IPB'S	EK-VR319-IP-002	Aug-91
VR326	MONITORS, SYSTEMS IPB'S	EK-VR326-IP-001	Aug-91
VT330	VIDEO TERMINALS IPB'S	EK-VT330-IP-003	Nov-92
VT340	VIDEO TERMINALS IPB'S	EK-VT340-IP-003	Nov-92
HA3000 11KVA	UNINTERRUPTIBLE POWER SYSTEM USER'S GUIDE	EP-11KVA-UG-001	Jan-91
VAXSTATION 3	OWNER'S MANUAL BA123 ENCLOSURE	EP-155AA-OW-001	Jan-92
KA650	CPU SYSTEM MAINTENANCE	EP-180AB-MG-002	Jul-90
BA23	ENCLOSURE MAINTENANCE	EP-186AB-MG-002	Oct-90
MICROVAX & MICROPDP-11	MICROSYSTEMS OPTIONS	EP-192AF-MG-F01	Dec-93
DECSTATION 2100/3100	MAINTENANCE GUIDE	EP-291AB-MG-003	Aug-91
DECSTATION 2100/3100	DOCUMENTATION KIT	EP-308AB-DK-003	Aug-91
MICROVAX 3100	MODEL 30 INSTALLATION,OPERATION,TROUBLESHOOTING & DIAGNOSTICS CUSTOMER TECH INFO	EP-31030-KT-001	Apr-92
MICROVAX 3100	MODEL 40 & 80 INSTALLATION OPERATION,TROUBLESHOOTING & DIAGNOSTICS,CUSTOMER TECH INFO	EP-31040-KT-001	May-92
KN210	MODULE SET SYSTEM MAINTENANCE	EP-329AB-MG-002	May-91
VAXSTATION 3520/3540	DWFQA (Q-BUS ADAPTER) MODULE ADDENDUM	EP-333AA-AD-001	Jan-92
KA670	CPU SYSTEM MAINTENANCE	EP-347AB-MG-002	Aug-91
BA430/BA440	ENCLOSURE MAINTENANCE	EP-348AD-MG-004	Oct-92
DECSTATION 5000	MODEL 200 DOCUMENTATION KIT	EP-364AA-DK-003	May-92
DECSTATION 5000 SYS 5000	MODEL 200 MAINTENANCE GUIDE	EP-370AA-MG-003	Aug-91
RTVAX 300	HARDWARE USER'S GUIDE	EP-382AB-UG-002	Aug-91
VAX 4000	SITE PREPARATION AND DUAL-HOST SYSTEMS	EP-4000S-KT-001	Apr-91
B400X	EXPANDER INSTALLATION	EP-400AA-MG-001	Feb-91

CUSTOMER	TITLE	PART NUMBER	DATE
433MP	MASS STORAGE DEVICES IPB	EP-433MP-IP-001	Feb-95
VAX 4000	RACK-MOUNTABLE VAX 4000 MODEL 400/500/600 INSTALL/OPERATOR'S MANUAL	EP-4410M-IN-003	Oct-92
VAX 4000	RACK-MOUNTABLE VAX 4000 MODEL 500A/600A/700A INSTALLATION/OPERATOR'S MANUAL	EP-4513M-IN-A01	Dec-93
DSSI	DSSI WARM SWAPPING GUIDE FOR BA400-SERIES ENCLOSURES AND KFQSA ADAPTERS	EP-457AA-SG-001	Apr-92
DECSYSTEM 5800	SYSTEM TECHNICAL USER'S GUIDE	EP-580AA-TM-001	Sep-90
VAX 6000 SERIES	UPGRADE MANUAL	EP-600EB-UP-002	Aug-90
VAX 6000	MODEL 200/300/400 PROCESSOR CONSOLE AND DIAG ROM UPGRADE INSTR	EP-60ROM-UP-001	Dec-90
VAX 6000	INSTALLING THE FA64A VECTOR OPTION	EP-60VEA-IN-001	Mar-91
VAX 6000-400	OPTIONS AND MAINTENANCE	EP-640EB-MG-002	Aug-90
VAX 6000-400	SYSTEM TECHNICAL USER'S GUIDE	EP-640EB-TM-002	Sep-90
VAX 6000	MODEL 500 SYSTEM TECHNICAL USER'S GUIDE	EP-650EA-TM-001	Aug-91
VAX 6000	INSTALLING MODEL 600 PROCESSORS	EP-660EA-UP-001	Nov-91
881	POWER CONTROLLER USER GUIDE	EP-881PC-UG-003	Jul-90
DECSERVER 300	HARDWARE INSTALLATION	EP-A0366-IN-002	Aug-90
DECSERVER 300	TERMINAL SERVER TECHNICAL DESCRIPTION	EP-A0367-TM-001	Mar-90
MICROVAX 3100 VAXSRV 3100	MAINTENANCE GUIDE	EP-A0372-MG-B01	May-92
R23RF	REMOVABLE STORAGE ELEMENT/SYSTEM INSTALLATION/USER GUIDE	EP-A0375-IN-004	May-92
DECROUTER 250	HARDWARE INSTALLATION	EP-A0424-IN-001	Sep-91
BA42-A	ENCLOSURE MAINTENANCE	EP-A0510-MG-001	Apr-92
KA45	CPU SYSTEM MAINTENANCE	EP-A0513-MG-001	Apr-92
KA47	CPU SYSTEM MAINTENANCE	EP-A0514-MG-001	Apr-92
MICROVAX 3100 PLATFORM	OPTIONS ADDENDUM: RZ26/RZ35,RZ24L & TLZ06 DRIVES	EP-A0519-AD-B01	Oct-92
MICROVAX 3100 PLATFORM	OPTIONS	EP-A0519-MG-001	Apr-92

CUSTOMER	TITLE	PART NUMBER	DATE
MICROVAX 3100	PLATFORM CPU REFERENCE INFORMATION	EP-A0574-HR-001	Feb-93
BA211	RACKMOUNT SYSTEM DOCUMENT KIT	EP-BA211-DK-001	Mar-91
VAX 4000	MODEL 200 (BA215) INSTALLATION AND OPERATION	EP-BA215-KT-002	Aug-91
BA400 SERIES	CHASSIS RACKMOUNT INSTALLATION	EP-BA400-IN-001	Nov-92
BA42	STORAGE EXPANSION BOX INSTALLATION GUIDE	EP-BA42A-IN-004	Mar-92
BA42	STORAGE EXPANSION BOX MAINTENANCE GUIDE	EP-BA42A-MG-003	Jun-91
VAX 4000	RACK-MOUNTABLE VAX 4000 MODEL 300 INST/OWNER'S MANUAL	EP-BA441-IN-003	Dec-91
CXA16/CXB16	ASYNCHRONOUS MULTIPLEXER TECHNICAL MANUAL	EP-CAB16-TM-002	Jan-90
CI780	USER'S GUIDE	EP-CI780-UG-001	Feb-93
CIXCD	INTERFACE USER GUIDE	EP-CIXCD-UG-003	Dec-90
CXY08-AF	8-LINE ASYNCHRONOUS MULTIPLEXER OPTION INSTALLATION GUIDE	EP-CXY08-IN-001	Jan-90
DECLASER 3500	PRINTERS USER'S GUIDE	EP-D350P-UG-A01	Jan-95
DECSYSTEM 5400/5500	UPGRADE KIT	EP-D5455-KT-001	Feb-91
DECSYSTEM 5500	INSTALLATION,OPERATION,TROUBLESHOOTING & DIAG, TECHNICAL INFORMATION	EP-D5500-KT-001	Oct-90
DECSYSTEM 5500	TECHNICAL MANUAL	EP-D5500-TM-001	Feb-91
DECSYSTEM 5900	ENCLOSURE MAINTENANCE MANUAL	EP-D590A-EN-B01	May-93
DECSYSTEM 5900	CPU SYSTEM MANUAL	EP-D590A-SM-A01	Sep-92
DECSYSTEM 5900	STORAGESERVER 100 INSTALLATION GUIDE	EP-D59SS-IN-A01	Sep-92
DEC CHANNELSERVER II	INSTALLATION	EP-DCSII-IN-001	Aug-90
ETHERWORKS	TURBO PCI USER INFORMATION	EP-DE435-OM-B01	Nov-94
ETHERWORKS	TURBO ETHERNET ADAPTER CUSTOMER TECHNICAL INFORMATION	EP-DE435-TM-A01	Nov-94
DEC LANCONTROLLER 200	DEBNI CONTROLLER INSTALLATION GUIDE	EP-DEBNI-IN-002	Aug-90
DECSYSTEM 5900	DUAL CPU DRAWER INSTALLATION MANUAL	EP-DECDU-IN-A01	Sep-92

CUSTOMER	TITLE	PART NUMBER	DATE
DECLASER 2100 PLUS	INSTALLATION GUIDE, OPERATOR'S GUIDE	EP-DECLA-DK-001	Sep-91
DECLASER 2200 PLUS	INSTALLATION GUIDE, OPERATOR'S GUIDE	EP-DECLB-DK-001	Sep-91