



# Sun Fire™ B10p SSL Proxy Blade Product Notes

---

Sun Microsystems, Inc.  
[www.sun.com](http://www.sun.com)

Part No. 817-0827-11  
October 2003, Revision A

Submit comments about this document at: <http://www.sun.com/hwdocs/feedback>

Copyright 2003 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, U.S.A. All rights reserved.

Sun Microsystems, Inc. has intellectual property rights relating to technology embodied in the product that is described in this document. In particular, and without limitation, these intellectual property rights may include one or more of the U.S. patents listed at <http://www.sun.com/patents> and one or more additional patents or pending patent applications in the U.S. and in other countries.

This document and the product to which it pertains are distributed under licenses restricting their use, copying, distribution, and decompilation. No part of the product or of this document may be reproduced in any form by any means without prior written authorization of Sun and its licensors, if any.

Third-party software, including font technology, is copyrighted and licensed from Sun suppliers.

Parts of the product may be derived from Berkeley BSD systems, licensed from the University of California. UNIX is a registered trademark in the U.S. and in other countries, exclusively licensed through X/Open Company, Ltd.

Sun, Sun Microsystems, the Sun logo, AnswerBook2, docs.sun.com, Sun Fire, and Solaris are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and in other countries.

All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. in the U.S. and in other countries. Products bearing SPARC trademarks are based upon an architecture developed by Sun Microsystems, Inc.

The OPEN LOOK and Sun™ Graphical User Interface was developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

Use, duplication, or disclosure by the U.S. Government is subject to restrictions set forth in the Sun Microsystems, Inc. license agreements and as provided in DFARS 227.7202-1(a) and 227.7202-3(a) (1995), DFARS 252.227-7013(c)(1)(ii) (Oct. 1998), FAR 12.212(a) (1995), FAR 52.227-19, or FAR 52.227-14 (ALT III), as applicable.

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

---

Copyright 2003 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, Etats-Unis. Tous droits réservés.

Sun Microsystems, Inc. a les droits de propriété intellectuelle relatant à la technologie incorporée dans le produit qui est décrit dans ce document. En particulier, et sans la limitation, ces droits de propriété intellectuelle peuvent inclure un ou plus des brevets américains énumérés à <http://www.sun.com/patents> et un ou les brevets plus supplémentaires ou les applications de brevet en attente dans les Etats-Unis et dans les autres pays.

Ce produit ou document est protégé par un copyright et distribué avec des licences qui en restreignent l'utilisation, la copie, la distribution, et la décompilation. Aucune partie de ce produit ou document ne peut être reproduite sous aucune forme, par quelque moyen que ce soit, sans l'autorisation préalable et écrite de Sun et de ses bailleurs de licence, s'il y en a.

Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun.

Des parties de ce produit pourront être dérivées des systèmes Berkeley BSD licenciés par l'Université de Californie. UNIX est une marque déposée aux Etats-Unis et dans d'autres pays et licenciée exclusivement par X/Open Company, Ltd.

Sun, Sun Microsystems, le logo Sun, AnswerBook2, docs.sun.com, Sun Fire, et Solaris sont des marques de fabrique ou des marques déposées de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays.

Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays. Les produits portant les marques SPARC sont basés sur une architecture développée par Sun Microsystems, Inc.

L'interface d'utilisation graphique OPEN LOOK et Sun™ a été développée par Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox pour la recherche et le développement du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une licence non exclusive de Xerox sur l'interface d'utilisation graphique Xerox, cette licence couvrant également les licenciés de Sun qui mettent en place l'interface d'utilisation graphique OPEN LOOK et qui en outre se conforment aux licences écrites de Sun.

LA DOCUMENTATION EST FOURNIE "EN L'ÉTAT" ET TOUTES AUTRES CONDITIONS, DECLARATIONS ET GARANTIES EXPRESSES OU TACITES SONT FORMELLEMENT EXCLUES, DANS LA MESURE AUTORISEE PAR LA LOI APPLICABLE, Y COMPRIS NOTAMMENT TOUTE GARANTIE IMPLICITE RELATIVE A LA QUALITE MARCHANDE, A L'APTITUDE A UNE UTILISATION PARTICULIERE OU A L'ABSENCE DE CONTREFAÇON.



# Sun Fire™ B10p SSL Proxy Blade Product Notes

---

This document contains important information about the Sun Fire™ B10p software. This document also covers the Sun Fire™ B10n content load balancing blade application software update P1.2.

---

## Viewing the Latest Documentation

Additional issues may arise after the publication of this version of the product notes. For the latest information, refer to the latest version of this document currently available at the following web site:

[http://www.sun.com/products-n-solutions/hardware/docs/Servers/Workgroup\\_Servers/Sun\\_Fire\\_Blade\\_Platform/Sun\\_Fire\\_b100s/index.html](http://www.sun.com/products-n-solutions/hardware/docs/Servers/Workgroup_Servers/Sun_Fire_Blade_Platform/Sun_Fire_b100s/index.html)

---

## Open Issues

Please refer to the most recent version of this document located at the above URL for the latest known bugs. The following bugs were open at the release of this version of the product notes.

## Problem: HTTPS File is not Downloading Completely (Bug ID 4906357)

The HTTPS file might not download completely. If this problem occurs, the connection resets.

### Workaround:

If this occurs retry the download.

---

## VLANs Required for the SSL Proxy Blade

When using the Sun Fire B10p SSL proxy blade, VLANs must be used within the Sun Fire B1600 blade system. These VLANs are configured at the SSC switches to create logical groups of endpoints that can communicate as if they were on the same LAN. VLANs also prevent or restrict traffic between endpoints on separate VLANs. For details, refer to the “Why VLANs are Required for the SSL Proxy Blade” section of the *Sun Fire B10p SSL Proxy Blade Administration Guide*.

---

## Updating the Software and Firmware

Before you setup and configure the Sun Fire B10p SSL proxy blade you need to ensure you have the latest software and firmware for the SSL proxy blade, the B10n content load balancing blade, and the Sun Fire™ B1600 blade system chassis. The minimum versions are listed in TABLE 1.

The latest software and firmware versions can be downloaded from:

<http://www.sun.com/software/download/network.html>

---

# Hardware and Software Requirements

Before using the Sun Fire B10p blade, make sure your system meets the following hardware and software requirements.

**TABLE 1** Hardware and Software Requirements

Hardware and Software	Requirements
Hardware	<ul style="list-style-type: none"><li>• Sun Fire B10n content load balancing blade (at least one Sun Fire B10n blade for every four SSL proxy blades)</li><li>• Sun Fire B1600 blade system chassis and other horizontally scaled Sun platforms</li><li>• Sun Fire™ B100s blade server</li></ul>
Software	<ul style="list-style-type: none"><li>• Sun Fire B10p application software version 1.865 or subsequent equivalent version</li><li>• Sun Fire B10p BSC Firmware version v5.1.0-SUNW*</li><li>• Sun Fire B100s blade server Solaris 8 HW 3/03 or HW 7/03 operating system or subsequent compatible version</li><li>• Sun Fire B1600 SC (system controller) 1.2 or subsequent compatible system controller firmware</li><li>• Sun GigaSwift Ethernet Adapter Patch ID 111883-18 or subsequent compatible patch for supported versions of the Solaris 8 operating environment. Sun GigaSwift Ethernet Adapter Patch ID 112817-10 or subsequent compatible patch for supported versions of the Solaris 9 operating environment.**</li><li>• Sun Ethernet VLAN Patch ID 112119-04 or subsequent compatible patch for supported versions of the Solaris 8 operating environment.. Sun Ethernet VLAN Patch ID 114600-02 or subsequent compatible patch supported versions of the Solaris 9 operating environment.**</li></ul>

\* The version number displayed from the `showsc -v` command from the Sun Fire B1600 SC CLI printout refers to the BSC firmware version. The application software version is observed using the console `show version` command.

\*\* The patch currently installed can be displayed by entering `showrev -p | grep <patch-id without the rev>` for example: `showrev -p | grep 111883`. You can download patches from [sunsolve.sun.com](http://sunsolve.sun.com)

# Checking the Software Versions

## ▼ To Check the Sun Fire B1600 Software Version

- Type the `showsc -v` command:

```
sc> showsc -v
Sun Advanced Lights Out Manager for Blade Servers 1.2
Copyright 2003 Sun Microsystems, Inc. All Rights Reserved.
ALOM-B 1.2

Release: 1.2.6
```

## ▼ To Check the Sun Fire B10n Content Load Balancing Blade Application Software

- Type the console `s1` and `show system` commands:

```
sc> console s1
puma{admin}# show system
Boot Options:
=====
Config Type   Config File   Boot Image           Diag Level   Verbose Mode
-----
running              1   1 (1.1.9)             0             0
next                 1   1 (1.1.9)             0             0
=====

Image Information Table:
=====
Image   Blade   Image Type           Version       Build Date:Time     Size
-----
1       B10n   Load Balancer       1.1.9        10/14/03 : 23:16   4035122
2       B10n   Load Balancer       1.1.8        09/29/03 : 14:30   4022705
diag    B10n   Diagnostics         1.1.9        10/20/03 : 16:55   2410797
=====

Flash FS /RFA0 free space = 17,600,512 bytes
```

## ▼ To Check the Sun Fire B10p SSL Proxy Blade Application Software Version

- Type the console `s2` and `show version` commands:

```
sc> console s2
CLI# show version
software version: 1.863
```

## ▼ To Check any Sun Fire Blade BSC Firmware Version

- Type the `showsc -v` command:

```
sc> showsc -v
FRU      Software Version                               Software Release Date
-----
S0       v5.1.0-SUNW,B10p,SecureBlade1                 Jun 16 2003 16:41:38
S6       v5.1.3-SUNW,B10n,NetBlade1                    Aug  6 2003 15:43:56
```

---

# Software Architecture

The Sun Fire B10p SSL proxy blade delivers high performance by utilizing optimized hardware engines and a tightly coupled embedded processor running a real time operating system. The code that runs on this processor is called the application software and can be updated using an FTP process.

In addition to the embedded processor, there is a micro controller called the blade support controller (BSC). The BSC is the primary interface to the Sun Fire B1600 service controllers (SCs) and performs the advanced lights out management (ALOM) functions for a given blade. These functions include powering on and off, and the resetting and monitoring functions. The code that runs on this device is called the BSC firmware and can be updated using the `flashupdate` command which involves using TFTP.

The Sun Fire B10p software components are as follows:

- Application software
- BSC firmware

Check the following web site to ensure you have the latest software:

<http://www.sun.com/software/download/network.html>

## Command-Line and Console Interfaces

There are two types of command-line interfaces when working with blades in a Sun Fire B1600 system. The first type is the system controller or `sc>` interface. The commands for this interface are detailed in the *Sun Fire B1600 Blade System Chassis Software Setup Guide*. You will recognize this interface by the `sc>` prompt.

The second type is the switch interface and is accessed with the `console` command. The individual blades in the chassis are accessed through the `console` command that is entered at the `sc>` prompt, for example:

```
sc> console sn
```

Where *n* is the blade slot you wish to access, for example:

```
sc> console s0
```

Once the blade has been powered on and you are at the blade `console` prompt and have logged into the desired blade, you can administer the commands as outlined, in the *Sun Fire B10p SSL Proxy Blade Administration Guide*. You will recognize this interface by the `CLI#` prompt.

You can return to the `sc>` interface by using the `#.` key sequence. (that is, the hash (#) character followed by the dot (.) character.

## Application Software

The Sun Fire B10p SSL proxy blade has the ability to hold three versions of the application software: an active image, a backup image, and a factory image. This capability ensures that you can revert to a safe image of the application software if a problem occurs with the current version or a problem occurs when updating the software. The software images are stored and loaded as follows:

- Active image – Primary image stored in Flash and loaded into RAM on bootup
- Backup image – Secondary image stored in Flash and can be moved to the Active image. This image is over written when a new image is uploaded
- Factory image – Loaded into Flash at time of manufacture. Used in case both Active and Backup images are corrupted.

The typical operations associated with images are:

- Booting – loading the permanent active image into RAM and starting the system (automatic on power up)



- Upgrading – loading a new image as permanent. The backup image and the factory image are protection mechanisms to ensure recovery from failed or undesired upgrades.

There is also a configuration file that holds the configuration data (see the “Configuration Storage” section of the *Sun Fire B10p SSL Proxy Blade Administration Guide*). The operator will be prompted to overwrite the permanent configuration. It is important to backup the configuration of the system prior to the time when new software is uploaded.

FIGURE 1 shows the various images and how various CLI commands alter or copy them.




FIGURE 1 SSL Proxy Blade Images and CLI Commands

## BSC Firmware

The BSC is the primary interface to the Sun Fire B1600 SCs. There is a single image stored in the micro controller that can be overwritten through the `flashupdate` process. If there is a problem during the BSC `flashupdate` process the recovery is just a matter of repeating the update as the SC software is managing the process.

---

# Updating the Sun Fire B1600 System Controller

Before you install the Sun Fire B10p SSL proxy blade in your Sun Fire B1600 chassis, you must first update the system controller (*sc*) firmware version SC1.2. You can download the latest version of the *sc* firmware from Sun's download site:

<http://www.sun.com/software/download/network.html>

You need to set up a TFTP boot server to update the *sc* firmware. See the "Setting Up a TFTP Server" section of the *Sun Fire B10p SSL Proxy Blade Administration Guide*.

You can access all the Sun Fire B1600 documentation from the following web site:

[http://www.sun.com/products-n-solutions/hardware/docs/Servers/Workgroup\\_Servers/Sun\\_Fire\\_b100s/index.html](http://www.sun.com/products-n-solutions/hardware/docs/Servers/Workgroup_Servers/Sun_Fire_b100s/index.html)

## ▼ To Update the System Controller Firmware

1. At the *sc*> prompt, type the following command:

```
sc> flashupdate -s install server -f path SSCn/SC.
```

In the following example, 10.4.128.25 is the IP address for your TFTP boot server and *stiletto.1.1/c8/SunFireB1600-sc-v1.1.6.flash* is the path to the file:

```
sc> flashupdate -s 10.4.128.25 -f stiletto.1.1/c8/SunFireB1600-sc-v1.1.6.flash
SSC0/SC
Warning: Are you sure you want to flashupdate the SSC0/SC flash image (y/n)? y
SSC0/SC: Preparing to flashupdate.
flashupdate: erasing segment 36 programming address ffedffff
SSC0/SC: flashupdate complete.
```

2. Reset the system using *resetsc* to load the new image.

---

# Updating the Sun Fire B10n Application Software and BSC Firmware

It is important to verify that you have the latest software for the Sun Fire B10n content load balancing blade. Check the following web site for the latest software and documentation:

<http://www.sun.com/software/download/network.html>

You need to set up a TFTP boot server to update the BSC firmware. See the “Setting Up a TFTP Server” section of the *Sun Fire B10p SSL Proxy Blade Administration Guide*.

You also need to configure the management IP address and default gateway address. Refer to the “Configuring the Networking” section of the *Sun Fire B10n Content Load Balancing Blade Administration Guide*.

---

**Note** – If you are updating both the B10n application software and BSC firmware, be sure to update the B10n application software *first*.

---

## ▼ To Update the Sun Fire B10p Application Software

The SSL proxy blade supports the ability to perform network based software upgrades to the device. The software upgrades to the SSL proxy blade are encrypted and authenticated in order to preserve their security. Normal operation of the SSL proxy blade must be stopped during the upgrade process because a reboot is required after activating an upgrade.

---

**Note** – Read this section completely before proceeding to perform a software upgrade.

---

Download the application software to a local FTP/TFTP server before performing the upgrade.

Upgrades are a two step process. First, verify and copy the upgrade package as the backup image of the software. Then activate the new software using the `boot activate` command. This command swaps the active software with the backup, thus making the upgrade active on the next boot.

The upgrade sequence is as follows. You need to login as `so` (security officer) to perform upgrades.

## ▼ Executing Boot Upload Commands

### 1. Use FTP or TFTP to copy the package from the specified FTP or TFTP server.

The upgrade package is automatically decrypted and verified for authenticity. The successfully verified package is placed in the backup image location within the SSL proxy blade. An upgrade package can be up to three Megabytes in size and may take up to one minute to copy from a local FTP server. A spinning cursor shows activity during the process.

---

**Note – The FTP/TFTP server IP address must be on the same subnet as the management (admin) IP address of the SSL proxy blade.**

---

#### ■ Executing `boot upload` commands using an FTP server:

```
CLI# boot upload
Enter remote file name (520-3440-02.pkcs ): package_name
Enter remote path (releases): directory
Enter remote IP Address: (192.168.0.28): ip-addr
Enter remote user name (labuser): username
Enter remote user password (:): password
starting to load image
Verification Successful.
image loaded.
Type boot activate to install.
```

#### ■ Executing `boot upload` commands using a TFTP server:

```
CLI# boot upload-tftp
Enter remote file name (520-3440-02.pkcs ): package_name
Enter remote IP Address: (192.168.0.28): ip-addr
starting to load image
Verification Successful.
image loaded.
Type boot activate to install.
```

If the upgrade package is not successfully verified, then contact the Sun Microsystems support service to report the problem.

---

**Note** – A particular upgrade package may require some additional installation steps. For example, you may need to import a new key. Please read the release notes carefully before performing any upgrade.

---

**2. Once the upgrade is in the backup location, activate it:**

```
CLI# boot activate
Do you want to overwrite your existing flash.cfg file (Yes/No)? No
*** Warning. Do not turn off the power! ***
activating boot.
image updated.
reboot to run new image.
```

**3. After the upgrade is activated, reboot the SSL proxy blade:**

```
CLI# reboot
```

## Verifying the Upgrade

As soon as the upgrade is finished:

- Verify that the SSL proxy blade boots properly
- Perform some basic tests to make sure the SSL proxy blade operates correctly

### *Reverting to Previous Versions of Software*

You can always revert to the previous version of software by upgrading to a previous version. Also, the `boot activate` command will swap the current and backup versions, but this does not swap the boot images. If the upgrade documentation indicates that a new version of the boot image is part of the upgrade, then do not use `boot activate` to revert to the previous version.

## Factory Image

The SSL proxy blade has a built in Factory image that guarantees the SSL proxy blade platform is recoverable even if an unbootable image is loaded on it. Because SSL proxy blade software is authenticated, image corruption is extremely unlikely.

Although the Factory image can be used to process SSL traffic, it is intended to provide a safe mode to load the latest available software version for the SSL proxy blade.

The Factory image should be used only if the SSL proxy blade is not booting to a point where new software can be loaded. Before booting from the factory image, connect a serial terminal and reboot to inspect the boot up messages. The boot problem could be associated with some internal hardware malfunction. If this is the case, call support.

To boot from the Factory image, power on the SSL proxy blade and hold the `Esc` key down until prompted for input. When the boot menu is displayed, press `r` to revert to the Factory image. Under normal system operation, the command `boot revert` also reboots from the Factory image.

If the SSL proxy blade loses power during the upgrade process, the Backup image might be corrupted. In this case, it is best to ignore the Backup image and perform the upgrade process again.

## Image Commands

The description of each CLI command relevant to software image and booting is given below.

```
show version
```

Use the `show version` command to display the current version of the software.

- **As any user, enter the `show version` command:**

```
CLI# show version
software version: 1.863
```

```
reboot
```

Use the `reboot` command to restart the blade. You will be prompted to save the configuration, if needed. This command resets all connections and reboots the system.

- **As `so`, reboot the device:**

```
CLI# reboot
```

show boot

Use the show boot command to display version information for all system software components.

- **As so or admin, enter the show boot command:**

```
CLI# show boot
versions:
BBID: 66 CPLD version: 65
preboot 1855 Jul 16 2003
boot 1863 Oct 1 2003
app 1863 Oct 1 2003
Buff: BUFF3108.GZ
Mash: MASH1005.GZ

Active:   BAPP: 1863, BOOT: 1863, MASH: 1005, BUFF: 3108
Backup:   BAPP: 1863, BOOT: 1863, MASH: 1005, BUFF: 3108
Required: BAPP: 1863, MASH: 1005, BUFF: 3108, CPLD: 65.22D
```

boot activate

Use the boot activate command to activate the backup software version. The current active version is saved as the backup. This command is used after uploading a new software version. There may be a prompt to confirm overwriting the flash configuration (which should have been previously exported). You can also use this command to revert to a backup version.

- **As so, enter the boot activate command:**

```
CLI# boot activate
Do you want to overwrite your existing flash.cfg file (Yes/No)? Yes
*** Warning. Do not turn off power! ***
activating boot.
image updated.
reboot to run new image.
```

boot revert

Use the boot revert command to restore the factory installed software version. This command also clears the flash memory, removing *all* information including configuration, log files, and other information. This command reboots the SSL proxy blade and performs the operation.

- **As so, enter the boot revert command:**

```
CLI# boot revert  
This will reformat the system and erase all system files  
Are you sure you want to do this (Yes/No)?
```

`boot upload`

Use the `boot upload` command to load new images of the software using FTP.

- **As so, enter the boot upload command:**

```
CLI# boot upload  
Enter remote file name (520-3440-02.pkcs ): filename  
Enter remote path (releases): directory  
Enter remote IP Address: (192.168.0.28): ip-addr  
Enter remote user name (labuser): username  
Enter remote user password (:): password  
Connecting to 192.168.0.28  
starting to load image  
Verification Successful.  
image loaded.  
Type boot activate to install.
```

`boot upload-tftp`

Use the `boot upload-tftp` command to load new images of the software using TFTP.

- **As so, enter the boot upload-tftp command:**

```
CLI# boot upload-tftp  
Enter remote file name (520-3440-02.pkcs ): image_filename  
Enter remote IP Address: (192.168.0.28): ip-addr  
Connecting to 192.168.0.28  
starting to load image  
Verification Successful.  
image loaded.  
Type boot activate to install.
```



## ▼ To Update the BSC Firmware

### 1. Escape to the system controller console:

```
puma{admin}# #.
```

### 2. At the `sc` prompt, check the current version of the BSC firmware:

```
sc> showsc -v
FRU      Software Version                Software Release Date
-----
S0       v5.1.4-SUNW,B10n,NetBlade1     Aug 12 2003 15:31:48
```

### 3. At the `sc` prompt, enter the following command:

```
sc> flashupdate -s TFTP_ip-addr -f filename sn
```

---

## Known Problems With the Documentation

The Declaration of Conformity is incorrect and is missing the Compliance Model Number in the *Sun Fire B10p SSL Proxy Blade Administration Guide*. The following Declaration of Conformity document contains all of the correct information for the Sun Fire B10p SSL Proxy Blade.

### Declaration of Conformity

Compliance Model Number: BP-5  
Product Family Name: Sun Fire B10p SSL proxy blade

### EMC

USA - FCC Class A

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This equipment may not cause harmful interference.
- 2) This equipment must accept any interference that may cause undesired operation.

## European Union

This equipment complies with the following requirements of the EMC Directive 89/336/EEC:

*As Telecommunication Network Equipment (TNE) in both Telecom Centers and Other Than Telecom Centers per (as applicable):*

EN300-386 V.1.3.1 (09-2001) Required Limits:

EN55022/CISPR22	Class A
EN61000-3-2	Pass
EN61000-3-3	Pass
EN61000-4-2	6 kV (Direct), 8 kV (Air)
EN61000-4-3	3 V/m 80-1000MHz, 10 V/m 800-960 MHz and 1400-2000 MHz
EN61000-4-4	1kV AC and DC Power Lines, 0.5 kV Signal Lines.
EN61000-4-5	2 kV AC Line-Gnd, 1 kV AC Line-Line and Outdoor Signal Lines, 0.5 kV Indoor Signal Lines > 10m.
EN61000-4-6	3 V
EN61000-4-11	Pass

*As information Technology Equipment (ITE) Class A per (as applicable):*

EN55022:1998/CISPR22:1997 Class A

EN55024:1998 Required Limits:

EN61000-4-2	4 kV (Direct), 8 kV (Air)
EN61000-4-3	3 V/m
EN61000-4-4	1kV AC Power Lines, 0.5 kV Signal and DC Power Lines.
EN61000-4-5	1 kV AC Line-Line and Outdoor Signal Lines, 2 kV AC Line-Gnd, 0.5 kV DC Power Lines
EN61000-4-6	3 V
EN61000-4-8	1 A/m
EN61000-4-11	Pass
EN61000-3-2:1995 + A1, A2, A14	Pass
EN61000-3-3:1995	Pass

## Safety

This equipment complies with the following requirements of the Low Voltage Directive 73/23/EEC:

EC Type Examination Certificates:

EN60950:2000, 3rd Edition	TÜV Rheinland Certificate No. Not Required
IEC 60950:1999, 3rd Edition, Evaluated to all CB Countries	CB Scheme Certificate No. US/6982/UL
UL 60950, 3rd Edition, CSA C22.2 No. 60950-00	File:E138989-A10-UL-1

## Supplementary Information

This product was tested and complies with all the requirements for the CE Mark.

/S/

20 APR 03

---

Dennis P. Symanski  
Manager, Compliance Engineering  
Sun Microsystems, Inc.  
901 San Antonio Road, MPK15-102  
Palo Alto, CA 94303-4900 U.S.A.  
Tel: 650-786-3255  
Fax: 650-786-3723

DATE

/S/

1st MAY 03

---

Donald Cameron  
Program Manager  
Sun Microsystems Scotland, Limited  
Blackness Road, Phase I, Main Bldg  
Springfield, EH49 7LR  
Scotland, United Kingdom  
Tel: +44 1 506 672 539  
Fax: +44 1 506 670 011

DATE

